

## **Scanner control API manual**

FileName: BojayScanerClassAPI.py

Version : V1.0

Date: 2019.9.9

Company:Bojay

### **1. OpenDevice()**

Parameters: None

Function:

Connect to Scanner device

Returns: None

### **2. CloseDevice()**

Parameters: None

Function:

Disconnect to Scanner device

Returns: None

### 3. PullTriggerAndGetData(Timeout=10)

Parameters:

Timeout:Maximum scanning time(unit: second)

Function:

Pull the trigger button to Scanner device, and get the scan data.

Returns:

-1:fail

Scan data:success

### 4. ReleaseTrigger()

Parameters: None

Function:

Release the trigger button to Scanner device

Returns:

-1:fail

0:success