


## Slicer parameters description



**LayerHeight** : set the layer height in millimeters between 0.5 and 2.

**PPL** : set the numbers of points per layers.

**Angle** : change the angle for the zigzag and crossed zigzag.

**Scale** : multiply the length of each line of the zigzag.

**Rotation angle** : twist the object, every layer rotates that angle in degrees.

**ZigZag** : enable zigzag.

**Cross** : enable crossed zigzag (only if zigzag is enabled).

**Zoffset** : shift the object in the z axis in millimeters.

**AddHoles** : removes certain points to create the hole effect.

**Vertical** : add a vertical zigzag.

**Feedrate** : set the speed printing, 60 = 1mm/s