

Jetbot factory firmware opening opportunity to run through the system service self-starting APP program:

①If you want to temporarily turn off the app from the startup, execute the following command:

```
sudo systemctl stop jetbot_ start
```

②If you need to temporarily open the APP program that starts up and start, execute the following command:

```
sudo systemctl start jetbot_ start
```

③Or use the following command to manually run the APP program after closing the APP large program service process.

(This method can view the debugging information of the relevant output)

```
cd yahboom-jetbot/
```

```
sudo python3 yahboom- jetbot . pyc
```

④To permanently disable the function of the APP program that is turned on, execute the following command:

```
sudo systemctl disable jetbot_ start
```

⑤To permanently disable the function of the APP program that is turned on, execute the following command:

```
sudo systemctl enable jetbot start
```

⑥If you do not restart the APP program by restarting Jetbot, execute the following command:

```
sudo systemctl stop jetbot_ start
```

```
sudo systemctl start jetbot_ start
```