

# DVD MODS

## DVD-S550, DVS-5750, DVD-S657

- Eject the tray by pressing the "open / close" button on the DVD player
- Enter the following numbers slowly on the remote control "9 9 9 9 0"
- Confirmation will appear on the top left hand side of the TV for two seconds
- Close the tray by pressing "open / close" on the DVD player

The DVD player will return to normal operation.

## DVD-S1500 and DVDS-2500

- Using the units remote control and without any disc in the disc tray
- Enter the following PLAY,2,7,4,2,2,2,2,2,2,0,0,5,2,5,5,PLAY

## DVX-S120& DVX-S200

- Using the units remote control and without any disc in the disc tray
- Enter the following PLAY,2,7,4,2,2,2,2,2,2,0,0,5,2,5,5,PLAY

## DVR-S150

We will introduce how to setting region "0"

Key function

PLAY: Enter key

STOP: Escape key

Skip+/-: Select root menu

1. Turn off the system
2. Push the "A/B/C/D/E" key with "STANDBY/ON" key pushed simultaneously.
3. Then push "PROGRESSIVE" (Memory) key within 3sec.
4. Front display show "DVD DiagMode and few seconds after display [Ver.Disp]  
If push Skip key display show [Ver.Disp] or [TV Setup]
5. Remote control push DVD/CD key
6. Push "shift" + "8"(A-B) keys simultaneously.  
If push Skip key display show [Ver.Disp] or [TV Setup] or [Ver. Matrix]
7. Select [Ver. Matrix] menu and push PLAY key display shows VerMatx>Init  
If push Skip key display show VerMatx>Init,  
VerMatx>U(1),>G(2),>J(2),>K(3),>L(3),>R(3),>A(4),>T(6),back >Init
8. Select [Ver. Matrix] menu, Push "shift" + "7"(REPEAT) keys simultaneously.  
Now appear VerMatx>Init,  
VerMatx>U(1),>G(2),>J(2),>K(3),>L(3),>R(3),>A(4),>T(6),F(0)
9. VerMatx>F(0) display and push PLAY key.
10. Asking "Are you sure?" displayed and push PLAY. Then change region "0"

### DVD-S540 & DVS-5650

- Eject the tray by pressing the “open / close” button on the DVD player
- Enter the following numbers on the remote control “9 9 9 9 0”
- Confirmation will appear on the top left hand side of the TV for two seconds
- Close the tray by pressing “open / close” on the DVD player  
The DVD player will return to normal operation.

### DVD-C740

- Same process as DVDS510/20/30
- Macro code

### DVD-CX1

- Same process as DVXS100
- Modification disc 2

### DVD-S830

- Same as DVD-S80

### DRX-1& DRX-2

- Turn on the DRX-2
- On the Learning capable remote-control select the V-AUX input button (confirm V-AUX is displayed in the LCD window of the remote control)
- Press the PAUSE button while aiming the remote at the DRX-2
- After inputting the access command, the LCD window on the DRX-2 will display “ \_ \_ \_ \_ \_ \_ \_ \_ ”
- Using the numeric keypad (1, 2, 3, etc) on the DRX-2 remote control, enter the following number:

**121212005255**

The LCD window on the DRX-2 will display all numerals except the last “2,5,5”

- Press the “PLAY” key on the DRX-2 remote control.
- The LCD window will display “NO DISC”. The unit is now region free.

### DVD-S2300

- Same process as DVXS100

## DVD-S510, DVD-S520 & DVD-S530

- Turn on the DVD-S510.  
Do not load any type of disc into the player ('NO DISC' is displayed in the LCD window)
- On the Learning capable remote-control select the V-AUX input button (confirm V-AUX is displayed in the LCD window of the remote control)
- Press the STOP button while aiming the remote at the DVD-S510
- After inputting the access command, the LCD window on the DVD-S510 will display " \_ \_ \_ \_ \_ \_ \_ \_ \_ \_ "
- Using the numeric keypad (1, 2, 3, etc) on the DVD-S510 remote control, enter the following number:

**222222005255**

The LCD window on the DVD-S510 will display all numerals except the last "5". The extra "5" numeral shows as a small "dot" in front of the first "2", ie. – ".22222200525"

- Press the PLAY key on the DVD-S510 remote control.
- The LCD window will display "NO DISC".  
The unit is now region free.

## DVDS80

- With no disc in unit, in stop mode.
- Please use a small credit card remote.
- Point at the unit press the one button on the remote for 5 seconds, then lift your finger and keep the remote pointing at the unit for another five seconds.

## DVDC750

- Same as DVDS540.