



Ntablet-870A  
First Edition  
May 2019

Thank you for purchasing Ntablet !

Ntablet is not just a tablet. It is a gateway for new ideas.

#### Warranty Card

User information					_____Day_____Month_____Year
Name		Gender		Age	
Address					
Phone Number				Zip Code	
Place Of Purchase					
Serial No					

#### Warranty

- The product is guaranteed for one year from the date of sale, but accessories are not covered by warranty.
- Warranty service is valid only for normal use.
- Damaged, disassembled, remove seals or all appearance damage because use improperly, are not covered by warranty. This card must be provided during the warranty period.

For more support, please visit:

<http://yeacreate.com/support>

#### Package contents:

Check your Ntablet package for the following items:

Ntablet x 1	Charging dock x 1
GPIO connector x1	Instruction manual x 1


#### Product Label

#### Ntablet specification summary


##### Specification

Operating System:	Linux/Android;	CPU:	RK3288, Quad-core, 1.8GHz;
GPU:	Mali-T760 Quad-core GPU;	RAM:	2GB LPDDR3;
NAND FLASH:	16GB EMMC;	Camera:	OV5648 5M front camera ;
Display:	7" 1200*1920 IPS;	Touch screen :	5 point glass+glass;
Battery :	3.8V/4800mAh high capacity high voltage battery;	Wireless :	AP6255 802.11 a/b/g/n/ac + BT4.0
Micro USB2.0 Interface:	OTG features included; 5V-2A for charging supported;	Full-size USB :	Full size USB2.0 interface;
HDMI Interface:	Micro HDMI,		
Headphone Seat:	Φ3.5 Headphone jack; CTIA supported;	TF Card Slot:	Max. 32GB;
Serial Port:	Wireless Serial Port included in the charging dock(option); RS232 wire Serial Port included in the GPIO connector;		
GPIO :	5V-500ma port x 2; 3.3V-500ma port x 1; I2C x 1; UART x 2; SPI x 1; PWMx1; ADC_IN x 1;		
Power supply:	Charging dock supports wide voltage 90V-230V;  Wireless debug port connected to UART2(option);		


#### Forward split plane of tablet computer





#### Back view of tablet 1



#### Back view of tablet 2



#### Charging dock




#### Notice:

The STA LED would be turned on if wireless serial connected to router

The AP LED would be turned on if using the AP mode for the wireless serial.

#### GPIO Connector



1	VCC 5V	2	VCC 5V
3	3.3V	4	GND
5	I2C1_SDA/SC_RST/ GPIO8_A4	6	I2C1_SCL/I2C1_SCL/ SC_CLK/GPIO8_A5
7	UART1_RX/TS0_D0/ GPIO5_B0	8	UART1_TX/TS0_D1/ GPIO5_B1
9	GND	10	GND
11	SPI2_CSN1/SC_IO/ GPIO8_A3	12	SPI2_CSN0/SC_DE T_T1/GPIO8_A7
13	SPI2_CLK/SC_IO_T 1/GPIO8_A6	14	SPI2_RXD/SC_RST_ T1/GPIO8_B0
15	SPI2_TXD/SC_CLK _T1/GPIO8_B1	16	UART3_RTSn/GPIO7 _B2_u
17	PWM1/GPIO7_A1	18	ADC_IN0/SARADC_ AIN0
19	UART2_TXD	20	UART2_RXD

#### Notice:

All GPIO pins only support 500ma current.