

## 1. modify code with PWM function

refer readme.txt

### (1) open PWM

path:

git/som1\_ek/buildroot-at91/output/build/linux-linux4sam-2020.10/arch/arm/boot/dts

file: sama5d2.dtsi

//orig

```
pwm0: pwm@f802c000 {
    compatible = "atmel,sama5d2-pwm";
    reg = <0xf802c000 0x4000>;
    interrupts = <38 IRQ_TYPE_LEVEL_HIGH 7>;
    #pwm-cells = <3>;
    clocks = <&pmc PMC_TYPE_PERIPHERAL 38>;
    status = "disabled";
};
```

//改 status = "okay";

```
pwm0: pwm@f802c000 {
    compatible = "atmel,sama5d2-pwm";
    reg = <0xf802c000 0x4000>;
    interrupts = <38 IRQ_TYPE_LEVEL_HIGH 7>;
    #pwm-cells = <3>;
    clocks = <&pmc PMC_TYPE_PERIPHERAL 38>;
    status = "okay";
};
```

### (2) configure and open pin in PWM

path:

git/som1\_ek/buildroot-at91/output/build/linux-linux4sam-2020.10/arch/arm/boot/dts

file: at91-sama5d27\_som1\_ek.dts

//orig

```
pwm0: pwm@f802c000 {
    pinctrl-names = "default";
    pinctrl-0 = <&pinctrl_mikrobus1_pwm &pinctrl_mikrobus2_pwm>;
    status = "disabled"; /* Conflict with leds. */
};
```

//改 status = "okay";

```
pwm0: pwm@f802c000 {
    pinctrl-names = "default";
    pinctrl-0 = <&pinctrl_mikrobus1_pwm &pinctrl_mikrobus2_pwm>;
};
```

```
status = "okay"; /* Conflict with leds. */  
// PWM和LED可以使用相同的針腳, 可能存在配置衝突
```

```
};
```

### (3) LEDS off

```
path:
```

```
git/som1_ek/buildroot-at91/output/build/linux-linux4sam-2020.10/arch/arm/boot/dts
```

```
file: at91-sama5d27_som1_ek.dts
```

```
//orig
```

```
leds {
```

```
    compatible = "gpio-leds";
```

```
    pinctrl-names = "default";
```

```
    pinctrl-0 = <&pinctrl_led_gpio_default>;
```

```
    status = "okay"; /* Conflict with pwm0. */
```

```
//改 status = "disabled"
```

```
leds {
```

```
    compatible = "gpio-leds";
```

```
    pinctrl-names = "default";
```

```
    pinctrl-0 = <&pinctrl_led_gpio_default>;
```

```
    status = "disabled"; /* Conflict with pwm0. */
```

### (4) recompile and effective process of dts

```
buildroot-at91/output/build/linux-linux4sam-2020.10
```

```
# rm .stamp_built
```

```
# rm .stamp_target_installed
```

```
buildroot-at91/output/build/dt-overlay-at91-linux4sam-2020.10
```

```
# rm .stamp_built
```

```
# rm .stamp_target_installed
```

## **2. observe how the PWM functionality was configured in the Linux kernel**

refer to <https://microchipdeveloper.com/32mpu:apps-pwm>

```
cd /git/som1_ek/buildroot-at91$ make linux-menuconfig
```

## **3. compile**

```
cd /git/som1_ek/buildroot-at91$ make
```

## **4. SD1 burning via Etcher tool**

## 5. change SD1 to Microchip and try to boot it

the following will setup a 10 kHz 90% duty cycle PWM output:

```
welcome to the Microchip Demo
sama5 login: root
#
#
# cd /sys/class/pwm/
# ls
pwmchip0
#
# cd pwmchip0/
# echo 1 > export
# ls
device      npwm      pwm1      uevent
export      power     subsystem unexport
# cd pwm1
# ls
capture      enable      polarity    uevent
duty_cycle   period     power
# echo 100000 > period
# echo 90000 > duty_cycle
# echo 1 > enable
#
```