

ActiveX Control "LNComm.OCX" for LN Communications

External Specifications

First edition: June 2, 2003

Second edition: September 5, 2003

Third edition: September 8, 2003

Fourth edition: October 9, 2003

Fifth edition: October 10, 2003

Sixth edition: July 8, 2005

Seventh edition: July 28 2006

Eighth edition: January 26 2007

Revisions

Revision	Date	Version	Contents
First edition	June 2, 2003		Based on the Mk30LQ.OCX specifications, seventh edition, LN power supply (EDM/EDW/MC) integration OCX (LNComm.OCX) specifications created
Second edition	September 5, 2003		To keep compatibility with Mk30Comm.OCX, event and method return values modified Explanations on the HTTP connection deleted A sequence example added Supplementary information A added Specifications of "GetMacroParm" modified (to enable handling of null data) "GetDrSodickDatabase" deleted "GetCondSchDatabase" deleted
Third edition	September 8, 2003		Errors in the method return values that are newly added for LNCOMM corrected Description added to indicate that the file being edited cannot be overwritten with "Sendfile" Description about the difference in "ExecuteComplete" between LN1X and LN2X added
Fourth edition	October 9, 2003		The default value for "Poweron" property modified Description about the use of the status property and event added Explanations on "Username" and "Password" properties added Precautions on the use of "GetMacroParm" during NC execution added Description about the file extension modified
Fifth edition	October 10, 2003		Description about the setup modified Errors corrected
Sixth edition	July 8, 2005	V2.20	Add a postscript about parameter of "SendEmKey" Modify specifications about "LogStart" Add remarks about timeout in "Execute" and "SendFile" Modify errata
Seventh edition	July 28 2006	V2.21	Add a postscript about behavior that connection aborted
Eighth edition	January 26 2007	V2.22	Change a period until abort
		V2.23	Add a method "SetMacroParm" Modify errata


Table of Contents

1. Overview	4
2. File Configuration	5
3. Setup	6
3.1. Setup Procedure of LNCOMM.OCX	6
3.2. Possible Reasons for Setup Failure	6
3.3. Version Update	6
3.4. OLE Support DLL Files and Precautions	6
4. Property, Method, Event	7
4.1. List of Properties, Methods, Events	7
4.2. Property	9
4.3. Method	13
4.4. Event	28
4.5. Relations between Methods and Events	31
4.6. List of GetLastError Method Error	33
4.7. Relations between "nCoordSys" and Coordinate Systems	33
5. Sequence Example	34
6. Remarks	35
7. Supplementary Information A	36
7.1. Setting the Shared Folder	36
7.2. Setting Properties	36

1. Overview

ActiveX Control "LNComm.OCX" enables communications between Sodick LN series and WindowsNT4.0 compatibles. The LN series can be remote-controlled from a computer.

Program Name	LNComm.OCX
Applicable NC machines	Die sinking electrical discharge machine Sodick LN-EDM ("EDM") Wire-cut electrical discharge machine Sodick LN-WIRE ("EDW") Machining center Sodick Engineering LN2X ("MC2") Machining center Sodick Engineering LN1X version 7 or later ("MC1")
Applicable OS	Microsoft Windows NT4.0 (SP3 or above) Microsoft Windows 2000 Microsoft Windows XP Microsoft Windows 7 (The OCX corresponds only to the 32-bit version.)
Applicable computers	Computers operating on the above OS
Available language	Microsoft Visual Basic 5.0/6.0 Microsoft Visual C++ 5.0/6.0
Ethernet	Ethernet used as an interface between the computer and the NC machine
Protocol	Winsock 2.0
Functions	File transfer File deletion Program execution command Acquisition of machining history file Acquisition of offset term file



2. File Configuration

- LNCOMM.OCX ActiveX OCX
- LNCOMM.EXP Export (.EXP) file
 Contains information related to the functions and data items to be exported.

3. Setup

3.1. Setup Procedure of LNCOMM.OCX

- ① Copy "LNCOMM.OCX" and "LNCOMM.EXP" into a folder.

These two files must be copied into the same folder.

- ② Start Command Prompt.

- ③ Execute "REGSVR32.EXE".

When these two files are copied into "C:\TEMP";

execute "REGSVR32 C:\TEMP\LNCOMM.OCX".

With the above procedure, OCX can be used on the client computer.

3.2. Possible Reasons for Setup Failure

There are a number of possibilities of setup failure; however, the following two points are the major reasons for most cases.

- "REGSVR32.EXE" cannot confirm the control.
- Some OLE support DLL files are missing.

If you have failed in setup, check the above points.

3.3. Version Update

When updating the version, follow the same steps as described in "3.1 Setup Procedure of LNCOMM.OCX". However, be sure to copy the files to the same folder where the previous version files are contained. Otherwise, the browse setting from the application software may not be performed correctly.

This is also the case with a downgrading to an earlier version.

If you have failed in updating, cancel the previous OCX registration and then try again.

To cancel registration of the previous OCX file that is located at "C:\TEMP", execute;

```
REGSVR32 C:\TEMP\LNCOMM.OCX /u
```

3.4. OLE Support DLL Files and Precautions

When using ActiveX (OCX) control, OLE support DLL files are required in addition to the control.

The following OLE support DLL files are required for operation of LNCOMM.OCX.

MFC42.DLL, MSVCRT.DLL, OLEPRO32.DLL

OLE support DLL files are available in multiple versions. Check to see which versions are used as well as where the files are installed. For more information, refer to the documents about MFC, such as MSDN.

4. Property, Method, Event

4.1. List of Properties, Methods, Events

Property	
Name	Function
MachineStatus	Checks the LN machine state.
MyComputer	Refers to the computer name of the client computer.
Password	Sets a user password to enable access to the shared folder on the client computer.
PowerOn	Checks the LN power state.
RasPassword	Sets a user password to enable access to the shared folder on the LN.
RasUserName	Sets a user name to enable access to the shared folder on the LN.
UserName	Sets a user name to enable access to the shared folder on the client computer.
Version	Acquires the OCX version number.
Method	
Name	Function
Connect	Establishes a connection with the LN.
DeleteFile	Deletes a file from the LN.
Disconnect	Cuts the connection from the LN.
Execute	Issues program execution command to the LN.
GetHistory	Acquires the latest machining history file from the LN (EDM/EDW).
GetLastError	Acquires the number of the error that has occurred most recently (for debugging).
GetOffset	Acquires the offset term file from the LN (EDM/EDW).
LogEnd	Ends communication logging (for debugging).
LogStart	Starts communication logging (for debugging).
Pause	Temporarily cuts and restarts the connection with the LN.
SendEmKey	Sends the [OFF]/[HALT]/[ACK] /[ENT]key data to the LN.
SendFile	Transfers a file to the LN.
GetToolNum	Acquires the tool number.
GetCoordSys	Acquires the current coordinate system.
GetCoordOrg	Acquires the origin of the coordinate system.
GetMachCoord	Acquires the machine coordinate value.
GetCoord	Acquires the coordinate value.
GetUpperGuideDistance	Acquires the distance between the table and the upper wire guide (EDW).
GetLowerGuideDistance	Acquires the distance between the table and the lower wire guide (EDW).
GetZAxisLimit	Acquires the Z-axis limit value (EDM/EDW).
GetInchUnit	Acquires the "Inch on/off" state (EDM/EDW/MC2).
GetDigit	Acquires the "Digit" state (EDM/EDW/MC2).
GetOffsetD	Acquires cutter compensation in a batch from the LN (MC2/MC1).
GetOffsetH	Acquires tool length compensation in a batch from the LN (MC2/MC1).
GetMacroParm	Acquires a system variable for a macro from the LN (MC2/MC1).
GetFeedrate	Acquires the machining speed from the LN (MC2/MC1).
GetSpindle	Acquires the spindle speed from the LN (MC2/MC1).
GetlineNumber	Acquires the number of the line that is currently being machined in the execution file (MC1).
SetMacroParm	Changes a system variable for a macro in the LN (MC2).

Event	
Name	Function
DeleteFileComplete	Occurs on completion of file deletion from the LN.
DenyRemoteAccess	Occurs when the LN does not allow remote operation.
ExecuteComplete	Occurs on completion of program execution on the LN.
NcError	Occurs when an error or a halt arises on the LN.
NetworkError	Occurs when a network error arises.
SendFileComplete	Occurs on completion of file transfer to the LN.
VersionError	Occurs when the server version is not consistent with the client version at the time of connection with the LN.
MachineStatusChanged	Occurs when the LN machine state is changed.

* Properties, methods and events may be changed or added due to future extensions.

4.2. Property

MachineStatus

EDM/EDW/MC2/MC1

Function	Checks the LN machine state.	
Format	<i>intMachineStatus</i> = <i>mLNComm</i> . MachineStatus	
Setting Value	Integer type	
	0	READY(execution possible state)
	1	In executing
	2	In a halt or feed hold
	3	Waiting for ACK/RESET
	(Default value)	-1
Usage	Referencing	
Explanation	<p>This property is updated at regular cycles.</p> <p>If the machine state on the LN changes quickly, it may not be reflected correctly.</p> <p>If it is necessary to know every change of the machine state precisely, use the MachineStatusChange event.</p>	

MyComputer

EDM/EDW/MC2/MC1

Function	Refers to the computer name of the client computer.	
Format	<i>mLNComm</i> . MyComputer = <i>strMyComputer</i>	
Setting Value	String type	
	Client computer name (Default value)	Client computer name (host name)
Usage	Setting and referencing	
Explanation	<p>This property is used when the LN has access to a client computer.</p> <p>The client computer name (host name) is automatically acquired at the startup of OCX.</p>	

Password

EDM/EDW/MC2/MC1

Function	Sets a user password to enable access to the shared folder on the client computer.		
Format	<i>mLNComm. Password</i> = <i>strPasswd</i>		
Setting Value	String type User password (Default value)	" "	
Usage	Setting and referencing		
Explanation	<p>This property is used when the LN has access to a client computer. It must be the password for the account that can be logged on from the LN to the client computer. For example, when transferring a file using the SendFile method, the LN logs in the client computer to read the file. In such a case, this password is used as the access password.</p>		

PowerOn

EDM/EDW/MC2/MC1

Function	Checks the LN power state.		
Format	<i>BlnPowerOn</i> = <i>mLNComm. PowerOn</i>		
Setting Value	Bool type TRUE FALSE (Default value)	Power ON Power OFF FALSE	
Usage	Referencing		
Explanation	<p>This property is updated at regular cycles. If the power state on the LN changes quickly, it may not be reflected correctly.</p>		

RasPassword

EDM/EDW/MC2/MC1

Function	Sets a user password to enable access to the shared folder on the LN.		
Format	<i>mLNComm. RasPassword = strPasswd</i>		
Setting Value	String type User password (Default value)		"enkaku"
Usage	Setting and referencing		
Explanation	This property is used when having access to the shared folder on the LN.		

RasUserName

EDM/EDW/MC2/MC1

Function	Sets a user name to enable access to the shared folder on the LN.		
Format	<i>mLNComm. RasUserName = strUserName</i>		
Setting Value	String type User name (Default value)		"rasperson"
Usage	Setting and referencing		
Explanation	This property is used when having access to the shared folder on the LN.		

UserName

EDM/EDW/MC2/MC1

Function	Sets a user name to enable access to the shared folder on the client computer.	
Format	<i>mLNComm.UserName</i> = <i>strUserName</i>	
Setting Value	String type User name (Default value)	User name to be used when the LN logs on
Usage	Setting and referencing	
Explanation	<p>This property is used when the LN has access to a client computer. It must be the account that can be logged on from the LN to the client computer. For example, when transferring a file using the SendFile method, the LN logs in the client computer to read the file. In such a case, this password is used as the access account.</p>	

Version

EDM/EDW/MC2/MC1

Function	Acquires the OCX version number.
Format	<i>strVer</i> = <i>mLNComm. Version</i>
Setting Value	String type Version number
Usage	Referencing
Explanation	

4.3. Method

Connect

EDM/EDW/MC2/MC1

Function	Establishes a connection with the LN.	
Format	<i>intError</i> = <i>mLNComm</i> . Connect (<i>strMachineName</i>)	
Argument	<i>strMachineName</i> \$	Character string of the machine name (computer name) to be connected
Return value	Integer type -1 0	Connection successful Connection failure
Explanation	If connection has failed, the error number can be acquired by executing the GetLastError method.	

DeleteFile

EDM/EDW/MC2/MC1

Function	Deletes a file from the LN.	
Format	<i>intError</i> = <i>mLNComm</i> . DeleteFile (<i>strFileName</i>)	
Argument	<i>strFileName</i> \$	Character string of the file name (including file extension) to be deleted
Return value	Integer type -1 0	Deletion successful Deletion failure
Explanation	When this method has been completed, the DeleteFileComplete event occurs. If an invalid character string is used for the argument, etc., the return value is given for the error that has occurred before deleting the file. For the error that has occurred during file deletion, the error number is transferred as an argument in the DeleteFileComplete event.	

Disconnect

EDM/EDW/MC2/MC1

Function	Cuts the connection with the LN.
Format	<i>mLNComm. Disconnect()</i>
Argument	None
Return value	None
Explanation	If failed, the error number can be acquired by executing the GetLastError method.

Execute

EDM/EDW/MC2/MC1

Function	Gives program execution command to the LN.
Format	<i>intError = mLNComm. Execute(strCommand)</i>
Argument	strCommand\$ Character string for execution command ("ENKAKU.NC")
Return value	Integer type -1 Execution successful 0 Execution failure
Explanation	<p>Before executing this method, the "ENKAKU.NC" file must be transferred to the LN. When this method has been completed, the ExecuteComplete event occurs. (With MC1, however, the ExecuteComplete event does not occur if an error arises.)</p> <p>If an invalid character string is used for the argument, etc., the return value "0" is given for the error that has occurred before issuing the program execution command. In this case, the error number can be acquired by executing the GetLastError method.</p> <p>For the error that has occurred when the program execution command is issued, the error number is transferred as an argument in the ExecuteComplete event.</p> <p>EDM/EDW: The contents of the "ENKAKU.NC" file describes the real file in the RAM of the LN in the Q command format. (Example) QTEST(0.000,10.000);</p> <p>MC: The contents of the "ENKAKU.NC" file describe the real file in the RAM of the LN using a macro call. (Example) G65P1000 A0 B10.000;</p>

GetHistory

EDM/EDW

Function	Acquires the latest machining history file from the LN.	
Format	<i>nRet</i> = <i>mLNComm</i> . GetHistory (BSTR *pHistDat)	
Argument	strHistory\$	Character string of the data in the acquired machining history file (output)
Return value	Bool type TRUE FALSE	Successful Failure
Explanation	<p>Before executing this method, the RasUserName and RasPassword properties must be set.</p> <p>File reading must not be attempted during NC execution.</p> <p>The maximum size in file acquisition is not limited.</p> <p>To read a file, use "FILE_SHARE_READ FILE_SHARE_WRITE".</p> <p>When acquiring a file, only the one recently used is acquired.</p> <p>If failed in acquisition, the error number can be acquired by executing the GetLastError method.</p>	

GetLastError

EDM/EDW/MC2/MC1

Function	Acquires the number of the error that has occurred most recently (for debugging).	
Format	<i>ret</i> = <i>mLNComm</i> . GetLastError	
Argument	None	
Return value	Integer type	Error number
Explanation	For more information on return values, refer to "4.6 GetLastError Method Error List".	

LogEnd

EDM/EDW/MC2/MC1

Function	Ends communication logging (for debugging).
Format	<i>mLNComm. LogEnd</i>
Argument	None
Return value	None
Explanation	When LogStart is executed, be sure to execute this method.

LogStart

EDM/EDW/MC2/MC1

Function	Starts communication logging (for debugging).						
Format	<i>mLNComm. LogStart</i>						
Argument	None						
Return value	<table> <tr> <td>Bool type</td><td></td></tr> <tr> <td>TRUE</td><td>Start successful</td></tr> <tr> <td>FALSE</td><td>Start failure</td></tr> </table>	Bool type		TRUE	Start successful	FALSE	Start failure
Bool type							
TRUE	Start successful						
FALSE	Start failure						
Explanation	<p>The log file is created in the "TEMP" or "TMP" folder.</p> <p>The log file is named "LOGyyymmdd.log". (<i>yy</i>: year, <i>mm</i>: month, <i>dd</i>: date)</p> <p>The log file is recorded time, method name, argument and return value.</p>						

GetOffset

EDM/EDW

Function	Acquires the offset term file from the LN.	
Format	<i>Ret = mLNComm. GetOffset(strOffset)</i>	
Argument	strOffset\$	Character string of the data in the acquired offset term file (output)
Return value	Bool type TRUE FALSE	Acquisition successful Acquisition failure
Explanation	<p>Before executing this method, the RasUserName and RasPassword properties must be set.</p> <p>File reading must not be attempted during NC execution on the client computer.</p> <p>The maximum size in file acquisition is not limited.</p> <p>To read a file, use "FILE_SHARE_READ FILE_SHARE_WRITE".</p> <p>If failed in acquisition, the error number can be acquired by executing the GetLastError method.</p>	

Pause

EDM/EDW

Function	Temporarily cuts and restarts the connection with the LN.	
Format	<i>mLNComm. Pause(blnPause)</i>	
Argument	blnPause	Temporary cut and restart of the connection with the LN TRUE (connection canceled) FALSE (connection resumed)
Return value	None	
Explanation	<p>Use this method when manual intervention is required on the LN during communications between the LN and a computer.</p> <p>This method ignores all the notices from the LN.</p> <p>This method may not be supported in future.</p>	

SendEmKey

EDM/EDW/MC2/MC1

Function	Sends the [OFF]/[HALT]/[ACK]/[ENT] key data to the LN.	
Format	<i>intError</i> = <i>mLNComm</i> . SendEmKey (<i>strKey</i> \$)	
Argument	<i>strKey</i> \$	Character string of the key data to be sent to the LN EDM/EDW/MC2/MC1 "OFF" Execution stop "HALT" Temporary stop of execution "ACK" Error reset "ENT" Restart after temporary stop
Return value	Integer type -1 0	Sending successful Sending failure
Explanation	If an invalid character string is used for the argument, etc., the return value "0" is given for the error that has occurred before issuing the program execution command. In this case, the error number can be acquired by executing the GetLastError method. Depending on the key character string that is sent, the NcError event may occur.	

SendFile

EDM/EDW/MC2/MC1

Function	Transfers a file to the LN.	
Format	<i>intError</i> = <i>mLNComm</i> . SendFile (<i>strFileName</i>)	
Argument	<i>strFileName</i> \$	Character string of the file name (including file extension) to be sent
Return value	Integer type -1 0	Sending successful Sending failure
Explanation	Before executing this method, the UserName and Password properties must be set. Only the files in the folder that can be shared with "PCSHARE" on the client computer can be transferred. If the file specified for "strFileName" exists on the LN, the existing file on the LN will be overwritten. However, if the file is opened on the [Edit] screen, it is locked and cannot be overwritten. In this case, an error arises. When this method has been completed, the SendFileComplete event occurs. If an invalid character string is used for the argument, if the file to be sent does not exist, etc, the return value is given for the error that has occurred before transferring the file. In this case, the error number can be acquired by executing the GetLastError method. For the error that has occurred during file transfer, the error number is transferred as an argument in the SendFileComplete event.	

GetToolNum

EDM/MC1/MC2

Function	Acquires the tool number.	
Format	<i>LongNum</i> = <i>mLNComm</i> . GetToolNum()	
Argument	None	
Return value	Long integer type	The number of the currently selected tool
Explanation		

GetCoordSys

EDM/EDW/MC2/MC1

Function	Acquires the current coordinate system.	
Format	<i>LongCoord</i> = <i>mLNComm</i> . GetCoordSys()	
Argument	None	
Return value	Long integer type	Current coordinate system
Explanation	For more information on the coordinate system, refer to "Relations between 'nCoordSys' and Coordinate Systems".	

GetCoordOrg

EDM/EDW/MC2/MC1

Function	Acquires the origin of the coordinate system (nCoordSys).	
Format	<i>LongRet = mLNCComm. GetCoordOrg (long nCoordSys, double *pdblCoord)</i>	
Argument	Long integer type for input	Coordinate system: For more information on "nCoordSys", refer to "Relations between 'nCoordSys' and Coordinate Systems".
	Double precision type [8] for output	Coordinate origin: Array index: 0: X, 1: Y, 2: Z, 3: A, 4: B, 5: C, 6: U, 7: V
Return value	Long integer type	
	-1 0	Successful Failure
Explanation	If failed (return value "0"), the error number can be acquired by executing the GetLastError method.	

GetMachCoord

EDM/EDW/MC2/MC1

Function	Acquires the machine coordinate value.	
Format	<i>LongRet = mLNCComm. GetMachCoord(double *pdblCoord)</i>	
Argument	Double precision type [8] for output	Array index: 0: X, 1: Y, 2: Z, 3: A, 4: B, 5: C, 6: U, 7: V
Return value	Long integer type	
	-1 0	Successful Failure
Explanation	If failed (return value "-1"), the error number can be acquired by executing the GetLastError method.	

GetCoord

EDM/EDW/MC2/MC1

Function	Acquires the coordinate value of the specified coordinate system.	
Format	<i>LongRet = mLNComm. GetCoord(long CoordSys, double *pdblCoord)</i>	
Argument	Long integer type for input CoordSys	Coordinate system:
	Double precision type [8] for output	Coordinate value: Array index: 0: X, 1: Y, 2: Z, 3: A, 4: B, 5: C, 6: U, 7: V
Return value	Long integer type	
	-1 0	Successful Failure
Explanation	If failed (return value "-1"), the error number can be acquired by executing the GetLastError method.	

GetUpperGuideDistance

EDW

Function	Acquires the distance between the table and the upper wire guide. (Varies along the X-axis travel during machining)	
Format	<i>mLNComm. GetUpperGuideDistance(long &pnUpperGuideDistance)</i>	
Argument	Output pnUpperGuideDistance	Pointer for the distance between the table and the upper wire guide Unit: "10000" is indicated for pnUpperGuideDistance when the distance is 1 mm.
Return value	None	
Explanation		

GetLowerGuideDistance			EDW
Function	Acquires the distance between the table and the lower wire guide. (Varies as "TL" in the NC code or when the setting has been changed)		
Format	<i>mLNComm. GetLowerGuideDistance(long &pnLowerGuideDistance)</i>		
Argument	Output pnLowerGuideDistance	Pointer of the distance between the table and the lower wire guide Unit: "10000" is indicated for pnLowerGuideDistance when the distance is 1 mm.	
Return value	None		
Explanation			

GetZAxisLimit			EDM/EDW
Function	Acquires the Z-axis limit value.		
Format	<i>LongLimit = mLNComm. GetZAxisLimit()</i>		
Argument	None		
Return value	Long integer type	Z-axis limit value Unit: "10000" is indicated for "1 mm" as the return value.	
Explanation			

GetInchUnit			EDM/EDW/MC2
Function	Acquires the "Inch on/off" state of the machine.		
Format	<i>bIsInch</i> = <i>mLNComm</i> . GetInchUnit ()		
Argument	None		
Return value	Bool type		
	TRUE	inch	
	FALSE	mm	
Explanation			

GetDigit			EDM/EDW/MC2
Function	Acquires the "Digit" state of the machine.		
Format	<i>nDigit</i> = <i>mLNComm</i> . GetDigit ()		
Argument	None		
Return value	Long integer type		
	For mm: 0, 1, 2	The coordinate value is indicated to three, four or five decimal places.	
	For inch: 0, 1, 2	The coordinate value is indicated to four, five or six decimal places.	
Explanation	The number of decimal places for coordinate display is acquired as an integer from 0 to 2.		

GetOffsetD

MC2/MC1

Function	Acquires cutter compensation data (1 - 99) in a batch from the LN.	
Format	<i>LongRet</i> = <i>mLNComm</i> . GetOffsetD (<i>strOffsetD_data</i>)	
Argument	<i>strOffsetD_data</i> for output	Character string of acquired cutter compensation data (1 - 99)
Return value	Long integer type	
	-1	Acquisition successful
	0	Acquisition failure
Explanation	If failed in acquisition, the error number can be acquired by executing the GetLastError method.	

GetOffsetH

MC2/MC1

Function	Acquires tool length compensation data (1 - 99) in a batch from the LN.	
Format	<i>LongRet</i> = <i>mLNComm</i> . GetOffsetH (<i>strOffsetH_data</i>)	
Argument	<i>strOffsetH_data</i> for output	Character string of acquired tool length compensation data (1 - 99)
Return value	Long integer type	
	-1	Acquisition successful
	0	Acquisition failure
Explanation	If failed in acquisition, the error number can be acquired by executing the GetLastError method.	

GetLineNumber			MC1
Function	Acquires the number of the line that is currently being machined in the execution file.		
Format	<i>LongRet = mLNCmm. GetLineNumber(long LineNum)</i>		
Argument	Long integer type for output	Line number	
Return value	Long integer type		
	-1	Successful	
	0	Failure	
Explanation	If failed (return value "0"), the error number can be acquired by executing the GetLastError method. Acquisition is possible only with MC1.		

GetFeedrate			MC2/MC1
Function	Acquires the machining speed.		
Format	<i>LongRet = mLNCmm. GetFeedrate(long cmdFeedrate, long actFeedrate)</i>		
Argument	Long integer type for output	Specified machining speed	
	Long integer type for output	Actual machining speed	
Return value	Long integer type		
	-1	Successful	
	0	Failure	
Explanation	If failed (return value "0"), the error number can be acquired by executing the GetLastError method.		

GetSpindle

MC2/MC1

Function	Acquires the spindle speed.	
Format	<i>LongRet = mLNCmm. GetSpindle(long cmdSpindle)</i>	
Argument	Long integer type for output	Specified spindle speed
Return value	Long integer type -1 0	Successful Failure
Explanation	If failed (return value "0"), the error number can be acquired by executing the GetLastError method.	

GetMacroParm

MC2/MC1

Function	Acquires a system variable for a macro from the LN.	
Format	<i>LongRet = mLNCmm. GetMacroParm(int_no, long_type, strMacro_data)</i>	
Argument	int_no for input Long integer type for output strMacro_data for output	Macro variable number to be acquired Macro variable type to be acquired Character string of macro variable data acquired
Return value	Long integer type -1 0	Acquisition successful Acquisition failure
Explanation	If failed in acquisition, the error number can be acquired by executing the GetLastError method. Depending on the data type, strMacro_Data will be in the following format. 0: Double precision type data, 1: null data (NULL: data_type = 0 with LN1X, IsNull = 1 with LN2X)	

SetMacroParm

MC2

Function	Changes a system variable for a macro in the LN	
Format	<i>LongRet = mLNComm. SetMacroParm(int_no, strMacro_data)</i>	
Argument	int_no for input	Macro variable number to be changed
	strMacro_data for input	Character string of macro variable data changed
Return value	Long integer type	
	-1	Change successful
	0	Change failure
Explanation	<p>If failed in change, the error number can be acquired by executing the GetLastError method.</p> <p>Depending on the data type, strMacro_Data will be in the following format. 0: Double precision type data, 1: null data</p> <p>The number of the maximums which can be specified with strMacro_Data is 15.</p>	

4.4. Event

DeleteFileComplete

EDM/EDW/MC2/MC1

Function	Occurs on completion of file deletion from the LN.		
Format	<i>mLNComm_DeleteFileComplete(intError,Cstring strError)</i>		
Argument	IntError	Error number	If an error arises during file deletion, the error number is passed; if no error arises, "19" is passed.
Argument	Cstring strError	Error message	If an error arises during file deletion, the error message is passed; if no error arises, the message "The file on LN machine RAM is deleted." is passed.
Explanation	This event occurs when the DeleteFile method has been executed.		

DenyRemoteAccess

EDM/EDW/MC2/MC1

Function	Occurs when the LN does not allow remote operation.		
Format	<i>mLNComm DenyRemoteAccess()</i>		
Argument	None		
Explanation	This event occurs when the LN does not allow remote operation on completion of execution of each method. This event occurs when remote operation is not permitted on the setting of the LN.		

ExecuteComplete

EDM/EDW/MC2/MC1

Function	Occurs on completion of program execution on the LN.		
Format	<i>mLNComm ExecuteComplete(intError,Cstring strError)</i>		
Argument	IntError	Error number	If an error arises during program execution command, the error number is passed; if no error arises, "166" is passed.
Argument	Cstring strError	Error message	If an error arises during program execution command, the error message is passed; if no error arises, "Program end." is passed.
Explanation	This event occurs when the Execute method has been executed. This event does not occur with MC1 when an error arises. This event occurs with EDM, EDW or MC2 when an error arises.		

NetworkError

EDM/EDW/MC2/MC1

Function	Occurs when a network error arises.		
Format	<i>MLNComm</i> NetworkError (<i>intError</i>)		
Argument	IntError	Network error number	
Explanation	This event occurs when the Connect method has been executed.		

NcError

EDM/EDW/MC2/MC1

Function	Occurs when an error or a halt arises on the LN.		
Format	<i>mLNComm</i> NcError (<i>strError</i>)		
Argument	strError\$	Character string of the error or halt	
Explanation	This event does not occur with E00166 (program end). This event occurs when NcError arises.		

SendFileComplete

EDM/EDW/MC2/MC1

Function	Occurs on completion of file transfer to the LN.		
Format	<i>mLNComm</i> SendFileComplete (<i>intError</i> , <i>Cstring strError</i>)		
Argument	IntError	Error number	If an error arises during file transfer, the error number is passed; if no error arises, "17" is passed.
Argument	Cstring strError	Error message	If an error arises during file transfer, the error message is passed; if no error arises, the message "Writing is normally over on LN machine./" is passed.
Explanation	This event occurs when the SendFile method has been executed. "17" is transferred at normal termination. "16" is transferred when the LN cannot have access to the specified file.		

VersionError

EDM/EDW/MC2/MC1

Function	Occurs when the LN server version is not consistent with the client version at the time of connection with the server and indicates the message box of "Version Error".		
Format	<i>mLNComm</i> VersionError (<i>Int wServerVersionMajor, Int wServerVersionMinor, Int wClientVersionMajor, Int wClientVersionMinor</i>)		
Argument	Int wServerVersionMajor	Server's major version	Major version of the server (MDComServer.exe on the LN)
Argument	Int wServerVersionMinor	Server's minor version	Minor version of the server (MDComServer.exe on the LN)
Argument	Int wClientVersionMajor	OCX's major version	Major version of the LNComm.ocx
Argument	Int wClientVersionMinor	OCX's minor version	Minor version of the LNComm.ocx
Explanation	<p>The LN server version and the client version are determined when a connection with the server has been established.</p> <p>This event does not occur when the server and client versions are consistent.</p> <p>When the server and client versions are consistent, this event occurs, and the message box of "Version Error" is displayed.</p>		

MachineStatusChanged

EDM/EDW/MC2/MC1

Function	Occurs when the LN machine state is changed.		
Format	<i>LNComm</i> . MachineStatusChanged (<i>long oldValue, long newValue</i>)		
Argument	Output: oldValue: State before change newValue: Current state		
Explanation	<p>Values for "newValue" and "oldValue":</p> <ul style="list-style-type: none"> 0: READY 1: In executing 2: In a halt or feed hold 3: Waiting for ACK (RESET) -1: Default value <p>This event occurs each time the machine state changes.</p> <p>If a program syntax error, etc. occurs with MC1, pressing the [RESET] key triggers the error again; events of "3" → "0" and "0" → "3" occur continuously.</p>		

4.5. Relations between Methods and Events

Depending on the method that has been executed, the occurring event varies. Relations between methods and events are shown below.

Method	Error	Event
Connect	⇒ Error occurs before connection.	⇒ No event occurs. If connection has failed, the error number can be acquired by executing the GetLastError method.
	⇒ Error occurs at the time of connection.	⇒ The NetworkError event occurs.
	⇒ Connection successful	⇒ No event occurs.
DeleteFile	⇒ Error occurs before file deletion.	⇒ No event occurs.
	⇒ Error occurs at the time of file deletion.	⇒ The DeleteFileComplete event occurs.
	⇒ File deletion successful	⇒ The DeleteFileComplete event occurs.
Disconnect	⇒ Error occurs at the time of disconnection.	⇒ The NetworkError event occurs.
	⇒ Disconnection successful	⇒ No event occurs.
Execute	⇒ Error occurs before issuing program execution command.	⇒ No event occurs. If execution has failed, the error number can be acquired by executing the GetLastError method.
	⇒ Error occurs when the program execution command is issued.	⇒ The ExecuteComplete event occurs. (EDM/EDW/MC2)
	⇒ Program execution command successful	⇒ The ExecuteComplete event occurs.

GetHistory	⇒ Error occurs.	⇒ No event occurs. "False" is returned as the method return value.
	⇒ Successful.	⇒ No event occurs. "TRUE" is returned as the method return value.

GetOffset	⇒ Error occurs.	⇒ No event occurs. "False" is returned as the method return value.
	⇒ Successful.	⇒ No event occurs. "TRUE" is returned as the method return value.

Pause	⇒ Temporarily disconnected.	⇒ All events are invalid.
	⇒ Connection resumed.	⇒ All events are valid.

SendEmKey	⇒ Error occurs before sending key data.	⇒ No event occurs. If execution has failed, the error number can be acquired by executing the GetLastError method.
	⇒ Error occurs when key data is sent.	⇒ No event occurs. Depending on the key character string that is sent, the NcError event may occur.
	⇒ Sending key data successful.	⇒ No event occurs. Depending on the key character string that is sent, the NcError event may occur.

SendFile	⇒ Error occurs before file transfer.	⇒ No event occurs. If execution has failed, the error number can be acquired by executing the GetLastError method.
	⇒ Error occurs during file transfer.	⇒ The SendFileComplete event occurs.
	⇒ File transfer successful.	⇒ The SendFileComplete event occurs.

4.6. List of GetLastError Method Error

The following errors may occur when the **GetLastError** method is executed.

Return value	Explanation
0	No error is occurring.
1	Could not create the socket.
2	Could not connect to the socket.
3	Could not send the message to the LN.
4	Could not receive the message from the LN.
5	The parameter specified with the method is not correct.
6	Could not open the file.
7	Could not open the file in the shared holder on the LN.
8	Could not acquire the computer name of the client computer.
9	The user name that enables access to the shared folder on the client computer is not specified.
10	The password that enables access to the shared folder on the client computer is not specified.
11	Timeout occurs.
12	Connected with the LN already.
13	Cannot disconnect because connection with LN is not established.
14	Cannot read data because the LN is preparing data.
15	There is no response from the LN.
16	The macro variable cannot be found or the variable specification is not correct.
17	Cannot find the specified file.
18	The system variable cannot be changed. The LN's status is not READY.
19	You are going to set inaccurate data for the system variable.
20	You are forbidden change to the system variable, has been trying to remote access.

* Be careful not to confuse the return values with the following event values.

Value for the **SendFileComplete** event: 16 (file access failure), 17 (sending successful)

Value for the **DeleteFileComplete** event: 18 (deletion failure), 19 (deletion successful)

4.7. Relations between "nCoordSys" and Coordinate Systems

nCoordSys	0	1	2	3	4	5	6	7	8	9
Coordinate system:	54	55	56	57	58	59	154	155	156	157
nCoordSys	10	11	12	13	14	15	16	17	18	19
Coordinate system:	158	159	254	255	256	257	258	259	354	355
nCoordSys	20	21	22	23	24	25	26	27	28	29
Coordinate system:	356	357	358	359	454	455	456	457	458	459
nCoordSys	30	31	32	33	34	35	36	37	38	39
Coordinate system:	554	555	556	557	558	559	654	655	656	657
nCoordSys	40	41	42	43	44	45	46	47	48	49
Coordinate system:	658	659	754	755	756	757	758	759	854	855
nCoordSys	50	51	52	53	54	55	56	57	58	59
Coordinate system:	856	857	858	859	954	955	956	957	958	959


* With MC-LN1X, only coordinate systems 54 to 59 are usable.

5. Sequence Example

A sequence example using LNComm.OCX is given below.

This is an example of transferring "1234.NC" from the client computer to the LN2X, executing the file and then deleting the file.

It is assumed that the settings for connection (the OCX property setting and the setting on the LN) have been finished.



* Before step ②, "ENKAKU.NC" file must be created.

This file should describe the file (real file) to be transferred in step ④ using a macro call or in the Q Assist format.

(Example) G65P1234 A0 B10.000;

6. Remarks

- Do not execute the **GetOffset**, **GetOffsetD** or **GetOffsetH** method during NC execution.
- Do not execute the **DeleteFile** method during NC execution. If a failure occurs with this method, add a wait (2 sec or longer) immediately before processing.
- If the **GetMacroParm** method is used during NC execution, the response may be delayed and a timeout (for 4 sec) may occur. Use this method for cases except for NC execution. If it is absolutely necessary to use this method during NC execution, take appropriate action such as adding retrial processing on the calling side, etc.
- If **Execute** or **SendFile** method times out, you should be cope with it. (Timeout – **Execute**: 10 sec, **SendFile**: 20 sec) When LNComm.ocx detects timeout, retry the method.
- When communication is aborted, the system displays a dialog -"The connection was aborted due to timeout or other failure."- for both LN and client PC. And **MachineStatus** property changes to default value. Client PC needs to run reconnection process.

7. Supplementary Information A

7.1. Setting the Shared Folder

With the LN series, the following shared folders are predetermined.

Shared name:	RAM	This is the folder to be used for file transfer and execution.
Shared name:	NCPROHD	This is the general NC program storage area. (This is not used with LNComm.ocx.)
Shared name:	HISTORY	This folder contains log files, etc.

Create the following shared folder and set the access account on the client computer.

Shared name:	PCSHARE	This is the area for file transfer.
--------------	---------	-------------------------------------

- * File transfer and execution of LNComm.ocx are performed between the PCSHARE folder on the client PC and the RAM folder on the LN (EDM, EDW or MC2) or the REMOTE folder on the LN (MC1).

7.2. Setting Properties

Set the above folders and the access account for the properties of LNComm.ocx.

The LN uses these property settings when having access to the client PC.

MyComputer	=	Computer name of the client PC (automatically acquired when the OCX starts up)
UserName	=	Access account to the shared folder (PCSHARE) on the client PC
Password	=	Access password to the shared folder (PCSHARE) on the client PC

The client PC uses the information when having access to the LN.

RasUserName	=	Access account to the shared folder on the LN series NC control unit
RasPassword	=	Access password to the shared folder on the LN series NC control unit

