


## CREDIT SALE – FROM MAIN MENU


### 1. Terminal Idle Display

Press **MC/VISA/ICB/UPI/AMEX** button to go to Credit MENU




### 2. Credit MENU

Press **STRAIGHT SALE** for Credit straight transaction




### 3. Amount Entry

Enter amount then press **ENTER** button to continue, **CLEAR** button to erase, and **CANCEL** to go back to Idle Menu



### 3.2. FOR RESTAURANT SETUP ONLY


Enter tip amount then press **[ENTER]** to continue or just press **[ENTER]** button if none.



### FOR ECR TRANSACTIONS ONLY


### 4. ECR MENU

Once POS Cash register charged the transaction, our terminal will display transaction type selection. Press **MC/VISA/ICB/UPI/AMEX** button to proceed




### 5. Card Entry

Tap/Insert/Swipe/Key-in customer card or Press **[X]** to cancel  
**Note: Contactless/Tap applicable for Credit Sale Only**



### 6.1. For Manual Entry Only

Input the Card number once Manual Entry is pressed




### 6.2. For Manual Entry Only

Input the Card's expiry date



### 6.3. For Manual Entry Only

Input Manual Entry password (100824) and then press **[ENTER]** to continue




### 7. FOR DCC TRANSACTIONS

(VISA and MASTERCARD only)


#### Currency Selection

Terminal will display exchange rate and the currency you will select. Press the Flag of the currency that you will choose for the transaction to proceed.



### 8. Card Details


Terminal will display card and amount details. Press **PROCEED** button to continue



### 9. PIN Entry

**FOR EMV PIN BASED CARD only**

If card has pin, hand the terminal to customer to input pin, then press **[Enter]** button to confirm. If not, press **[Enter]** button for pin bypass or **[Cancel]** to abort the transaction




### 10. Connecting to Bank Host

Terminal will connect to BANK HOST and receive approval data from host



### 11. Customer Copy Printing

Terminal will print customer copy once approval




### 12. Merchant Copy Print Prompt

Press **[PRINT]** Button to print MERCHANT COPY, **[CANCEL]** button if not



**FOR CHIP/EMV TRANSACTIONS ONLY:**  
Wait for terminal to display "PLEASE REMOVE CARD" before pulling out the chip/EMV card from the terminal



## VOID – FROM MAIN MENU


### 1. Terminal Idle Display

Press **MC/VISA/ICB/UPI/AMEX** button to go to Credit MENU




### 2. Credit MENU

Navigate to find VOID in menu and press the button




### 3. Void Password

Input Void password (0000) and then press **[ENTER]** to continue



### 4. Trace Number


Input trace number of transaction needed to void then press **[ENTER]** to continue  
**NOTE: BANCNET AND QRPH CANNOT BE VOIDED**



### FOR ECR TRANSACTION

#### 5.1. Void Confirmation

Terminal will display the Void confirmation, press **[OK]** to continue



#### 5.2. ECR Triggered

Once POS Cash register charged the transaction, our terminal will display void confirmation

### 6. Connecting to Bank Host


Terminal will connect to BANK HOST and receive approval data from host



### 7. Transaction Approval and Printing of Receipt

Once approved, terminal will print Customer Copy follow by Merchant Copy


Press **[PRINT]** Button to print, **[CANCEL]** button if not



## PREAUTH – FROM MAIN MENU


### 1. Terminal Idle Display

Press **MC/VISA/ICB/UI/AMEX** button to go to Credit MENU




### 2. Credit MENU

Press **PREAUTHORIZATION** for Pre Auth transaction




### 3. Card Entry

Insert/Swipe/Key-in customer card or Press **[X]** to cancel  
**Note: Contactless/Tap applicable for Credit Sale Only**




### 4.1. For Manual Entry Only

Input the Card number once Manual Entry is pressed




### 4.2. For Manual Entry Only

Input the Card's expiry date




### 4.3. For Manual Entry Only

Input Manual Entry password (100824) and then press **[ENTER]** to continue



### 5. Amount Entry


Enter amount then press **ENTER** button to continue, **CLEAR** button to erase, and **CANCEL** to go back to Idle Menu



### 6. FOR DCC TRANSACTIONS (VISA and MASTERCARD only)


#### Currency Selection

Terminal will display exchange rate and the currency you will select. Press the Flag of the currency that you will choose for the transaction to proceed.



#### 7. Card Details


Terminal will display card and amount details. Press **PROCEED** button to continue



#### 8. PIN Entry

##### FOR EMV PIN BASED CARD only

If card has pin, hand the terminal to customer to input pin, then press **[Enter]** button to confirm. If not, press **[Enter]** button for pin bypass or **[Cancel]** to abort the transaction



#### 9. Connecting to Bank Host


Terminal will connect to BANK HOST and receive approval data from host



#### 10. Transaction Approval and Printing of Receipt


Once approved, terminal will print Customer Copy follow by Merchant Copy

Press **[PRINT]** Button to print, **[CANCEL]** button if not



#### FOR CHIP/EMV TRANSACTIONS ONLY:

Wait for terminal to display "PLEASE REMOVE CARD" before pulling out the chip/EMV card from the terminal



#### SAMPLE RECEIPT:


QR Printed in Preauthorization receipts are for Preauth Completion Function only



## PREAUTH VOID – FROM MAIN MENU


### 1. Terminal Idle Display

Press **MC/VISA/ICB/UI/AMEX** button to go to Credit MENU




### 2. Credit MENU

Press **PREAUTH VOID** for Pre Auth Void transaction




### 3. Card Entry

Insert/Swipe/Key-in customer card or Press **[X]** to cancel  
**Note: Contactless/Tap applicable for Credit Sale Only**




#### 4.1. For Manual Entry Only

Input the Card number once Manual Entry is pressed



#### 4.2. For Manual Entry Only

Input the Card's expiry date



#### 4.3. For Manual Entry Only

Input Manual Entry password (100824) and then press **[ENTER]** to continue




### 5. Reference Number

Enter the 12 digit REF NUM from the preauthorization receipt then press **ENTER** button to continue




### 6. Approval Code

Enter the approval code from the preauthorization receipt then press **ENTER** button to continue.



### 7. Amount Entry


Enter amount then press **ENTER** button to continue, **CLEAR** button to erase, and **CANCEL** to go back to Idle Menu



### 8. FOR DCC TRANSACTIONS (VISA and MASTERCARD only)

#### Currency Selection

Terminal will display exchange rate and the currency you will select. Press the Flag of the currency that you will choose for the transaction to proceed.



#### 9. Card Details


Terminal will display card and amount details. Press **PROCEED** button to continue



#### 10. PIN Entry

##### FOR EMV PIN BASED CARD only

If card has pin, hand the terminal to customer to input pin, then press **[Enter]** button to confirm. If not, press **[Enter]** button for pin bypass or **[Cancel]** to abort the transaction



#### 11. Connecting to Bank Host

Terminal will connect to BANK HOST and receive approval data from host



#### 12. Transaction Approval and Printing of Receipt

Once approved, terminal will print Customer Copy follow by Merchant Copy

Press **[PRINT]** Button to print, **[CANCEL]** button if not




#### FOR CHIP/EMV TRANSACTIONS ONLY:

Wait for terminal to display "PLEASE REMOVE CARD" before pulling out the chip/EMV card from the terminal




## OFFLINE SALE – FROM MAIN MENU


**1. Terminal Idle Display**  
Press **MC/VISA/JCB/UP/AMEX** button to go to Credit MENU




**2. Credit MENU**  
Press **OFFLINE SALE** for Offline sale transaction




**3. Offline Password**  
Input Offline password (0000) and then press **[ENTER]** to continue




**4. Card Entry**  
Insert/Swipe/Key-in customer card or Press **[X]** to cancel  
**Note: Contactless/Tap applicable for Credit Sale Only**




**5.1. For Manual Entry Only**  
Input the Card number once Manual Entry is pressed




**5.2. For Manual Entry Only**  
Input the Card's expiry date




**5.3. For Manual Entry Only**  
Input Manual Entry password (100824) and then press **[ENTER]** to continue




**6. Approval Code**  
Enter the approval code from the preauthorization receipt then press **ENTER** button to continue.



**7.1. Amount Entry**  
Enter amount then press **ENTER** button to continue, **CLEAR** button to erase, and **CANCEL** to go back to Idle Menu




**7.2. FOR RESTAURANT SETUP ONLY**  
Enter tip amount then press **[ENTER]** to continue or just press **[ENTER]** button if none.




### 8. FOR DCC TRANSACTIONS (VISA and MASTERCARD only)

**Currency Selection**  
Terminal will display exchange rate and the currency you will select. Press the Flag of the currency that you will choose for the transaction to proceed.




**9. Card Details**  
Terminal will display card and amount details. Press **PROCEED** button to continue



**10. Transaction Approval and Printing of Receipt**  
Once approved, terminal will print Customer Copy follow by Merchant Copy  
Press **[PRINT]** Button to print, **[CANCEL]** button if not




**FOR CHIP/EMV TRANSACTIONS ONLY:**  
Wait for terminal to display "PLEASE REMOVE CARD" before pulling out the chip/EMV card from the terminal




## PREAUTH COMPLETION – FROM MAIN MENU


**1. Terminal Idle Display**  
Press **MC/VISA/JCB/UP/AMEX** button to go to Credit MENU




**2. Credit MENU**  
Press **PREAUTH COMPLETION** for Preauth Completion transaction




**3. Amount Entry**  
Enter amount then press **ENTER** button to continue, **CLEAR** button to erase, and **CANCEL** to go back to Idle Menu




**4. Card Entry**  
Insert/Swipe/Key-in customer card or Press **[X]** to cancel  
**Note: Contactless/Tap applicable for Credit Sale Only**



**4.1. For Manual Entry Only**  
Input the Card Number then press **ENTER** button, then enter Card's expiry date and then press **ENTER** button to continue



**4.2. For Manual Entry Only**  
Input Manual Entry password (100824) and then press **[ENTER]** to continue




**5.1. SCAN QR INSTRUCTIONS**  
Terminal will display how to scan the QR, press **SCAN NOW** to continue




**5.2. SCAN QR**  
Terminal will turn on the camera and proceed to scan the QR printed from the Preauthorization Receipt. If QR cannot be scan, you may press the button below scan box to manual input approval code and reference number



**FOR MANUAL INPUT ONLY**  
Enter the approval code from the preauthorization receipt then press **ENTER** button to continue.




**FOR MANUAL INPUT ONLY**  
Enter the 12 digit REF NUM from the preauthorization receipt then press **ENTER** button to continue



### 6. FOR DCC TRANSACTIONS (VISA and MASTERCARD only)

**Currency Selection**  
Terminal will display exchange rate and the currency you will select. Press the Flag of the currency that you will choose for the transaction to proceed.




**7. Card Details**  
Terminal will display card and amount details. Press **PROCEED** button to continue



**8. Connecting to Bank Host**  
Terminal will connect to BANK HOST and receive approval data from host



**9. Transaction Approval and Printing of Receipt**  
Once approved, terminal will print Customer Copy follow by Merchant Copy  
Press **[PRINT]** Button to print, **[CANCEL]** button if not




**FOR CHIP/EMV TRANSACTIONS ONLY:**  
Wait for terminal to display "PLEASE REMOVE CARD" before pulling out the chip/EMV card from the terminal



## BANCNET – FROM MAIN MENU


### 1. Terminal Idle Display

Press **Bancnet** button to go to Bancnet MENU



### 2. BANCNET MENU


Press the desired transaction to start SALE, BALANCE INQUIRY, LOG ON



## LOGON

### 1. BANCNET MENU

Press LOG ON button in menu




### 2. Connecting to Host

Terminal will connect to BANK HOST and receive approval data from host



### 3. Logon Successful/Failed


Terminal will process and receive Data to/from host, and will prompt a message if successful or not then will go back to idle menu



## BALANCE INQUIRY


### 1. BANCNET MENU

Press **BALANCE INQUIRY** button in menu




### 2. Card Entry

Insert/Swipe customer card to continue or Press **[BACK]** for cancel (will back to idle menu)




### 3. Selection of Account

Terminal will ask for debit account selection, press the corresponding buttons for **Savings** Account and **Current** Account




### 4. Card Details

Terminal will display card details. Press **PROCEED** button to continue



### 5. PIN Entry

If card has pin, hand the terminal to customer to input pin, then press **[Enter]** button to confirm. If not, press **[Enter]** button for pin bypass or **[Cancel]** to abort the transaction




### 6. Connecting to Bank Host

Terminal will connect to BANK HOST and receive approval data from host



### 7. Card Balance Display

Terminal will display account balance of customer once success.




## BANCNET – FROM MAIN MENU

## SALE

### 1. BANCNET MENU


Press **SALE** button in menu



## FOR ECR TRANSACTIONS ONLY


### 2. ECR MENU

Once POS Cash register charged the transaction, our terminal will display transaction type selection. Press **Bancnet** button to proceed




### 3. Card Entry

Insert/Swipe customer card to continue or Press **[BACK]** for cancel (will back to idle menu)




### 4. Selection of Account

Terminal will ask for debit account selection, press the corresponding buttons for **Savings** Account and **Current** Account




### 5. Amount Entry

Enter amount then press **ENTER** button to continue, **CLEAR** button to erase, and **CANCEL** to go back to Idle Menu




### 6. Card Details

Terminal will display card details. Press **PROCEED** button to continue



### 7. PIN Entry

If card has pin, hand the terminal to customer to input pin, then press **[Enter]** button to confirm. If not, press **[Enter]** button for pin bypass or **[Cancel]** to abort the transaction



### 8. Connecting to Bank Host

Terminal will connect to BANK HOST and receive approval data from host




### 10. Customer Copy Printing

Terminal will print customer copy once approval




### 11. Merchant Copy Print Prompt

Press **[PRINT]** Button to print MERCHANT COPY, **[CANCEL]** button if not



## FOR CHIP/EMV TRANSACTIONS ONLY:

Wait for terminal to display "PLEASE REMOVE CARD" before pulling out the chip/EMV card from the terminal






## QRPAY – FROM MAIN MENU

### SALE

- 1. Terminal Idle Display**  
Press **QRPAY** button to go to QRPAY MENU



- 6.2. SCAN QR**  
Terminal will turn on the camera and proceed to scan the customer's QR




#### FOR ECR TRANSACTIONS ONLY


- 2. ECR MENU**  
Once POS Cash register charged the transaction, our terminal will display transaction type selection. Press **QRPAY** button to proceed



- 3. QRPAY Menu**  
Press **SALE** button to proceed with sale transaction




- 4. QRPAY Sale Menu**  
Choose the QRPAY wallet you wish to do a transaction



- 5. Amount Entry**  
Enter amount then press **ENTER** button to continue, **CLEAR** button to erase, and **CANCEL** to go back to Idle Menu



- 5. SELECT QR CODE PRESENTED**  
Select **SCAN QR CODE** if you wish to scan customers QR



- Select **GENERATE QR CODE** if you wish the customer will scan the QR generated by the terminal

#### FOR SCAN QR CODE

- 6.1. SCAN QR INSTRUCTIONS**  
Terminal will display how to scan the QR, press **SCAN NOW** to continue



#### FOR GENERATE QR CODE

- 7. GENERATE QR CODE**  
Terminal will connect to BANK HOST for generation of QR. Once QR is display, present it to customer for scanning. Once customer confirm payment, press **CONFIRM** to continue



- 8. Connecting to Bank Host**  
Terminal will connect to BANK HOST and receive approval data from host



- 9. Transaction Approval and Printing of Receipt**  
Once approved, terminal will print Customer Copy follow by Merchant Copy




- Press **[PRINT]** Button to print, **[CANCEL]** button if not


## QRPAY – FROM MAIN MENU

### RETRIEVE


- 1. Terminal Idle Display**  
Press **QRPAY** button to go to QRPAY MENU




- 2. QRPAY Menu**  
Press **RETRIEVE** button to proceed with retrieve transaction



- 4. QRPAY Retrieve Menu**  
Choose the QRPAY wallet you wish to do a retrieve



- 4. Retrieve List**  
Terminal will display retrieve list. Press the transaction you wish to retrieve then press **CONFIRM**



- 5. Connecting to Bank Host**  
Terminal will connect to BANK HOST and receive approval data from host




- 6. Transaction Approval and Printing of Receipt**  
Once approved, terminal will print Customer Copy follow by Merchant Copy




- Press **[PRINT]** Button to print, **[CANCEL]** button if not

### VOID


- 1. Terminal Idle Display**  
Press **QRPAY** button to go to QRPAY MENU




- 2. QRPAY Menu**  
Press **VOID** button to proceed with void transaction



- 3. Void Password**  
Input Void password (0000) and then press **[ENTER]** to continue




- 4. Trace Number**  
Input trace number of transaction needed to void then press **[ENTER]** to continue  
**NOTE: BANCNET AND QRPH CANNOT BE VOIDED**



#### FOR ECR TRANSACTION

- 5.1. Void Confirmation**  
Terminal will display the Void confirmation, press **[OK]** to continue




- 5.2. ECR Triggered**  
Once POS Cash register charged the transaction, our terminal will display void confirmation

- 6. Connecting to Bank Host**  
Terminal will connect to BANK HOST and receive approval data from host



- 7. Transaction Approval and Printing of Receipt**  
Once approved, terminal will print Customer Copy follow by Merchant Copy



- Press **[PRINT]** Button to print, **[CANCEL]** button if not


## QRPH SALE – FROM MAIN MENU

### LOG IN

- Terminal Idle Display**  
Press **QRPH** button to go to QRPH MENU




- QRPH Menu**  
Press **LOGIN** button to proceed with host login



- Connecting to Bank Host**  
Terminal will connect to BANK HOST and receive approval data from host




- Login Successful/Failed**  
Terminal will process and receive Data to/from host, and will prompt a message if successful or not then will go back to idle menu



### SALE

- Terminal Idle Display**  
Press **QRPH** button to go to QRPH MENU




### FOR ECR TRANSACTIONS ONLY


- ECR MENU**  
Once POS Cash register charged the transaction, our terminal will display transaction type selection. Press **QRPH** button to proceed




- QRPH Menu**  
Press **SALE** button to proceed with QRPH Sale transaction



- Amount Entry**  
Enter amount then press **ENTER** button to continue, **CLEAR** button to erase, and **CANCEL** to go back to Idle Menu



- GENERATE QR CODE**  
Terminal will connect to BANK HOST for generation of QR. Once QR is display, present it to customer for scanning. Once customer confirm payment, press **CONFIRM** to continue




- Connecting to Bank Host**  
Terminal will connect to BANK HOST and receive approval data from host




- Transaction Approval and Printing of Receipt**  
Once approved, terminal will print Customer Copy follow by Merchant Copy

Press [PRINT] Button to print, [CANCEL] button if not




### RETRIEVE

- Terminal Idle Display**  
Press **QRPH** button to go to QRPH MENU



- QRPH Menu**  
Press **LOGIN** button to proceed with host login




- Retrieve List**  
Terminal will display retrieve list. Press the transaction you wish to retrieve then press **CONFIRM**



- Connecting to Bank Host**  
Terminal will connect to BANK HOST and receive approval data from host




- Transaction Approval and Printing of Receipt**  
Once approved, terminal will print Customer Copy follow by Merchant Copy  
  
Press [PRINT] Button to print, [CANCEL] button if not



## INSTALLMENT SALE – FROM MAIN MENU


**1. Terminal Idle Display**  
Press **MC/VISA/ICB/UPI/AMEX** buttonto go to Credit MENU



**8. Connecting to Bank Host**  
Terminal will connect to BANK HOST and receive approval data from host




**2. Credit MENU**  
Press **INSTALLMENT** for Credit installment transaction




**9. Transaction Approval and Printing of Receipt**  
Once approved, terminal will print Customer Copy follow by Merchant Copy


Press [PRINT] Button to print, [CANCEL] button if not



**3. Card Entry**  
Insert/Swipe/Key-in customer card or Press [X] to cancel  
**Note: Contactless/Tap applicable for Credit Sale Only**




**4. Select Promo**  
Press the promo the customer wish to avail




**5. Amount Entry**  
Enter amount then press **ENTER** button to continue, **CLEAR** button to erase, and **CANCEL** to go back to Idle Menu



**7. SELECT TERMS**  
Navigate and press the button the terms that the customer will avail.




**8. Card Details**  
Terminal will display card and amount details. Press **PROCEED** button to continue



## TIP ADJUST – FROM MAIN MENU (FOR RESTAURANTS SETUP ONLY)


**1. Terminal Idle Display**  
Press **MC/VISA/ICB/UPI/AMEX** buttonto go to Credit MENU




**7. Tip Adjust Confirmation**  
Terminal will display confirmation of new tip  
Press [PROCEED] Button to continue




**2. Credit MENU**  
Press **TIP ADJUST** for tip adjustment




**8. Tip Adjust Approval**  
Once approved, terminal will print Customer Copy follow by Merchant Copy  
Press [PRINT] Button to print, [CANCEL] button if not




**3. Tip Adjust Password**  
Input Tip Adjust password (0000) and then press [ENTER] to continue




**4. Trace Number**  
Input trace number of transaction needed to adjust the tip then press [ENTER] to continue



**5. Confirmation**  
Terminal will display the Card details and amount for confirmation, press [OK] to continue




**6. TIP ADJUST**  
Input the new amount of tip for this transaction.  
**NOTE: INPUT THE NEW TIP AMOUNT, DO NOT ADD FROM THE ORIGINAL TIP AMOUNT**




## SETTLEMENT – FROM MAIN MENU

### SETTLE ONE


**1. Terminal Idle Display**  
Press **SETTLEMENT** button from terminal idle screen




**1. Settle Password**  
Input Settle password (0000) and then press **[ENTER]** to continue



**2. SETTLE MENU**  
Press the desired settle procedure to start




**2. SELECT HOST**  
Choose host you wish to settle




### SETTLE ALL


**1. Settle Password**  
Input Settle password (0000) and then press **[ENTER]** to continue



**2. Settle Confirmation**  
Terminal will display batch totals for confirmation. Press **OK** button to continue. Press **CANCEL** button to not push through the settlement



**2. Settle Confirmation**  
Terminal will go through all batches and will display batch totals for confirmation. Press **OK** button to continue. Press **CANCEL** button to not push through that batch's settlement




**3. Connecting to Bank Host**  
Terminal will connect to BANK HOST and receive approval data from host



**3. Connecting to Bank Host**  
Terminal will connect to BANK HOST and receive approval data from host



**4. Settlement Approval**  
Terminal will print settlement report once approved




**4. Settlement Approval**  
Terminal will print settlement report once approved




## WIFI FUNCTIONS (FOR WIFI SETUP ONLY)

### WIFI SCAN

**1. Terminal Idle Display**  
Press **REPORTS** button from terminal idle screen




**2. WIFI SCAN**  
Swipe up to navigate Menu and press SET WIFI




### WIFI ON/OFF


**1. Terminal Idle Display**  
Press **REPORTS** button from terminal idle screen



**2. WIFI ON/OFF**  
Swipe up to navigate Menu and press WIFI ON/OFF




**3. NETWORKS**  
Choose the network you wish to connect




**3. WIFI ON/OFF**  
Choose to DISABLE or ENABLE the WIFI connection




**4. INPUT WIFI PASSWORD**  
Input the wifi password then press OK to proceed



**WIFI SETUP – GPRS BACKUP CONNECTION**  
If merchant's WIFI has no internet connection, you may disable the WIFI to proceed with GPRS connection as long as there's a GPRS signal available in the terminal. You may set to enable again the WIFI once internet connection is back.

 - If wifi password is correct, it will display a white wifi logo on the upper right

 - If wifi password is incorrect, it will display a black wifi logo with question mark on the upper left



### CUSTOMER CARE



Tel. No.: +63 2 8870-0999  
PLDT Toll Free: 1-800-10-8870 0999  
Email: [merchanthelpdesk@metrobancard.com](mailto:merchanthelpdesk@metrobancard.com)



Smart: +63 929-346-3452  
Globe: +63 966-345-8040  
Office No.: +63 2 8584-3540 / +632 8728 0672  
Email: [CITAS\\_Customercare@castech.asia](mailto:CITAS_Customercare@castech.asia)