



zCFDguide Documentation

Release v2023.06.5001-107-g47425

Zenotech Ltd

Aug 31, 2023

CONTENTS

1	Version: v2023.06.5001-107-g47425	1
1.1	Overview	1
1.2	Installation	2
1.3	Running zCFD	4
1.4	Reference Guide	8
1.5	zCFD Functions	68
1.6	Mesh Conversion	74
1.7	Visualisation	76
1.8	Utilities	77

VERSION: V2023.06.5001-107-G47425

1.1 Overview

zCFD is a GPU-accelerated high-performance computational fluid dynamics (CFD) solver.

zCFD is designed to make highly effective use of modern computer architectures. It is structured as a high performance core, executed via a flexible Python based wrapper. zCFD will run on unstructured meshes from a variety of sources, and will export data in many common formats. zCFD offers an easier route to coupling multi-disciplinary capabilities and integrating third-party data sources.

Features include both finite-volume and finite-element, (high order Discontinuous Galerkin) formulations, overset capability and fluid-structure interaction (FSI) running on both CPUs and GPUs. zCFD is capable of performing both steady-state and time accurate simulations, with a range of time marching schemes. The numerical schemes available have been selected for accuracy and robustness. The code provides automatic scaling of turbulent wall functions; automatic determination of inflow / outflow conditions and pre-conditioning to allow for low and high Mach number flow.

zCFD makes use of the MPI protocol to manage execution over a set of compute nodes. The execution process is completely parallel from the start to finish including all the input/output functionality. To support this scalable implementation the mesh input is provided in hdf5 format which is portable and self describing. Filters are provided to convert the most frequently used formats to this internal format.

zCFD uses a single control dictionary to specify all the parameters. This is a Python file containing a python dictionary with certain mandatory keys. The use of Python for the control dictionary enables the user to add custom functions that populate the dictionary at runtime.

The zCFD distribution includes a GPU-accelerated high performance Computational Aero-Acoustics solver (CAA), primarily aimed at broadband, aerodynamically generated noise. This is based on the high order Discontinuous Galerkin (DG) method which solves the Acoustic Perturbation Equations (APE) to predict noise based on aerodynamic sources. zCFD is a time domain solver therefore noise signals can be post-processed to provide narrowband and broadband spectra.

In order to generate aeroacoustic noise predictions, acoustic sources can be specified using a stochastic noise generation technique based on the Fast Random Particle Mesh (FRPM) method, alternatively, acoustic sources from high fidelity CFD simulations can be used.

To improve ease of use, the included zMesh mesh generator will generate appropriate acoustics meshes, permitting optimum time steps, using the CFD surface mesh, thus eliminating further CAD clean up and meshing effort by the user.

1.2 Installation

1.2.1 System Requirements

zCFD is supported on the following Linux distributions:

- RHEL 7+
- CentOS 7+
- Ubuntu 20.04+
- Windows 10/11 via [WSL2](#)

By default zCFD is compiled for x86_64 but is available for ARM and IBM Power on request.

GPU support

zCFD supports running on NVidia GPUs with a compute capability of 6.1 and above (See [Compute Capability](#)).

An AMD GPU (HIP) based version is available on request.

1.2.2 Linux / Unix

If you are running Linux/Unix zCFD is provided as a stand-alone installer containing all the packages required to get started. The installer is available for download from the [zCFD website](#). Once the zCFD installer has been downloaded run the install script and follow the prompts.

```
$ bash zCFD-icx-sse-mpi-<INSTALL_VERSION>-Linux-64bit.sh
```

Then copy the license file provided over email into the lic folder in the install directory.

```
$ cp zcfd.lic /<path to zCFD install>/lic/
```

Once zCFD has been installed the zCFD environment can be activated from a bash shell:

```
$ source /<path to zCFD install>/bin/activate
(zCFD)$
```

1.2.3 Windows

zCFD can be run locally on windows machines if Windows Subsystem for Linux 2 (WSL2) is installed. To install WSL2 simply follow the Microsoft instructions which can be found [here](#).

The chosen Linux distribution shouldn't have an effect on how the code runs, but the Linux distributions listed above are supported.

In order to access your Linux filesystem on Windows it can be useful to add a quick access link in file explorer. To do this, in the address in file explorer enter

```
\\wsl$\\
```

This will show you the root folders for your installed Linux distributions.

The installer is available for download from the [zCFD website](#). For WSL, download the standard Linux distribution. Once the zCFD installer has been downloaded run the install script from within the WSL2 environment and follow the prompts.

```
$ bash zCFD-icc-sse-mpi-<INSTALL_VERSION>-Linux-64bit.sh
```

Then copy the license file provided over email into the lic folder in the install directory.

```
$ cp zcfd.lic /<path to zCFD install>/lic/
```

Once zCFD has been installed the zCFD environment can be activated:

```
$ source /<path to zCFD install>/bin/activate
(zCFD)$
```

1.2.4 Licence

zCFD requires a license. If you do not already have a license, please contact zcfd@zenotech.com to obtain one. When zCFD starts it will look in the following locations for a licence file:

1. 'zcfd.lic' in the directory alongside the input files
2. 'zcfd.lic' in the lic directory of the zCFD installation. i.e. /<path to zCFD install>/lic/
3. RLM_LICENSE environment variable

The RLM_LICENSE environment variable can be defined as below.

```
export RLM_LICENSE=/path/to/license/file
```

or, where port is the port number in the license file, and host is the hostname in the license file

```
export RLM_LICENSE=port@server
```

In the case that the system running the simulation cannot access the internet a local license server will be required. See <http://www.reprisesoftware.com/admin/software-licensing.php> for details.

Licence Error codes

Below is a list of some of the error codes that you may encounter due to licensing errors. If the error code you receive is not listed, please contact us.

Error Code	Description	Possible Remedy
-3	License has expired	Contact us to renew your license
-6	Requested version is not supported	Your license is for an older product version; contact us to upgrade
-8	checkout request for too many licenses	Reduce the number of ranks that you are running the solver on or stop any existing running processes.
-21	No heartbeat	The license heartbeat was not received; check that the license server is still running and that have connectivity to it
-22	All licenses in use	All licenses are currently in use; stop any running processes to free up a license.
-37	License start date has not been reached	Your license has not yet become valid. Contact us if you believe this to be in error
-102	Can't read license data	Check the permissions on the license file on the server
-103	Network error	Check that you have connectivity to the license server; this may involve opening a port on your firewall or connecting to the internet

continues on next page

Table 1 – continued from previous page

Error Code	Description	Possible Remedy
-104	Error writing to network	Check your connectivity to the license server; check firewall settings and any endpoint security software you may be running
-105	Error reading from network	Check your connectivity to the license server; check firewall settings and any endpoint security software you may be running
-106	Unexpected response from license server	Check that your license configuration is pointing to the correct server
-107	HELLO message for wrong server	Check that your license configuration is pointing to the correct server
-108	Error in private key	There is an issue with your server side license file - contact us to resolve this issue
-109	Error signing authorization	There is an issue with your server side license file - contact us to resolve this issue
-110	Internal error	An error occurred in the license server - contact us if this error repeats itself
-111	Connection refused at server	Check your firewall settings and that you are pointing at the correct license server
-112	No server to connect to	Check that the server is running and that you are pointing at the correct license server
-113	Bad Communication handshake	Check that the server is running and that you are pointing at the correct license server
-114	Can't get ethernet address	Check that the user that you are running as has correct permissions to query the network card

1.3 Running zCFD

zCFD is designed to exploit parallelism in the target computing hardware, making use of multiple processes (MPI), multiple threads per CPU process (OpenMP) and / or many threads per GPU. zCFD will handle most parallel functions automatically, so the user just needs to specify how much, and what type, of resource to use for a given run.

1.3.1 Command Line Execution

zCFD includes an in-built command-line environment, which should be activated either when run directly or via a cluster management and job scheduling system, such as Slurm.

```
>source /INSTALL_LOCATION/zCFD-version/bin/activate
```

This sets up the environment to enable execution of the specific version. When within the command-line environment, the command prompt will show a zCFD prefix:

```
(zCFD) >
```

To deactivate the command line environment, returning the environment to the previous state use:

```
(zCFD) >zdeactivate
```

Your command prompt should return to its normal appearance.

To run zCFD on the command-line:

```
(zCFD) > run_zcfd -n <num_tasks> -d <device_type> -p <mesh_name> -c <case_name>
```


where:

Parameter	Value	Description
num_tasks	Integer	The number of partitions (one per device socket - CPU or GPU)
device_type	CPU or GPU	Specifies whether or not to use GPU(s) if present
mesh_name	String	The name of the mesh file (<mesh>.h5)
case_name	String	The name of the control dictionary (<control_dict>.py)

For example, to run zCFD from the command-line environment on a desktop computer with a single 12-core CPU processor and no GPU:

```
(zCFD) >run_zcfd -n 1 -d cpu -p <mesh_name> -c <case_name>
```

By default, zCFD will use all 12 cores via OpenMP unless a specific number is required. To run the above case using only 6 cores (there will be one thread per CPU core):

```
(zCFD) >export OMP_NUM_THREADS=6; run_zcfd -n 1 -d cpu -p <mesh_name> -c <case_name>
```

To run zCFD on a desktop computer with a single CPU and two GPUs:

```
(zCFD) >run_zcfd -n 2 -d gpu -p <mesh_name> -c <case_name>
```

1.3.2 Input Validation

zCFD provides an input validation script which can be used to check the solver control dictionary before run time reducing the likelihood of a job spending a long time queuing only to fail at start up.

The script can be executed from the zCFD environment as follows:

```
(zCFD) >validate_input <case_name> [-m <mesh_name>]
```

```
Validating parameters dictionary...
Parameters dictionary is valid
Checking BC_, FR_, FZ_, IC_ and TR_ numbering...
IC_ numbering is correct
FR_ numbering is correct
BC_ numbering is correct
zCFD input file <case_name> is valid
```

If the -m option is given with a mesh file the script will check whether any zones specified as lists to boundary conditions, transforms or reports in the input exist in the mesh.

1.3.3 Overriding Mesh and Case Names

For more advanced simulations with overset meshes (see *overset*) an override dictionary can be supplied as an additional argument to the command-line, in interactive mode or within a batch submission script, to specify multiple meshes and associated control dictionaries:

```
(zCFD) >run_zcfd -n 2 -d gpu -f <override_file>
```

An example override.py file for a background domain with a single rotating turbine would be:

```
override = {'problem_case_pair': [('background.h5', 'background.py'),
                                ('turbine.h5', 'turbine.py')]}
```

1.3.4 Batch Queue Submission

To run zCFD on a compute cluster with a queuing system (such as Slurm), the command-line environment activation is included within the submission script:

Example Slurm submission script “run_zcfd.sub”:

```
#!/bin/bash
#SBATCH -J account_name
#SBATCH --output zcfd.out
#SBATCH --nodes 2
#SBATCH --ntasks 4
#SBATCH --exclusive
#SBATCH --no-requeue
#SBATCH --time=10:00:00
#SBATCH --gres=gpu:2
#SBATCH --cpus-per-task=16
source /INSTALL_LOCATION/zCFD-version/bin/activate
run_zcfd -n 4 -d gpu -p <mesh_name> -c <case_name>
```

In this system we have 2 nodes, each with 2 GPUs. We allocate one task per GPU, giving a total of 4 tasks. Note that num_tasks, in this case 4, on the last line should match Slurm “ntasks” on line 5. The case is, optionally, run in “exclusive” mode which means that zCFD has uncontested use of the devices. In this case we have a 64-core CPU, giving 16 CPU cores for each of the 4 tasks. The “gres” line tells zCFD that there are 2 GPUs available on each node.

The submission script would be submitted from the command-line:

```
sbatch run_zcfd.sub
```

The job can then be managed using the standard Slurm commands.

Note: Users unfamiliar with the batch submission parameters in a specific system should consult the system administrator.

1.3.5 EPIC

For larger jobs or where resource availability is limited, [EPIC](#) allows users to submit zCFD jobs to a range of on-demand computing resources in an intuitive and secure way. EPIC also provides access to interactive post-processing environments without the need to download large data files.



1.3.6 Using Jupyter

We also recommend the use of [Jupyter Notebooks](#) for post-processing zCFD runs. This is one of the easiest ways to use Python, via an interactive notebook on your local computer. The notebook is a locally hosted server that you can access via a web-browser. Jupyter is included in the zCFD distribution and notebooks for visualising the residual data will automatically be created when you run a zCFD case.

To automatically start up notebook server on your computer within the zCFD environment run:

```
(zCFD) >start_notebook
```

1.3.7 zCFD Environment Variables

The following table gives some of the environment variables that can be set before running zCFD. These are generally for advanced users who can impact the way zCFD runs on your system.

Variable	Default	Description
ZCFD_GPUDIREC	unset	Set if you are using NVIDIA GPU direct (custom builds only) with a CUDA aware mpi implementation.
ZCFD_PRE_LAUN	unset	This option allows a script to be run just before the code is launched so that the user can override any environment that has been automatically setup.
CUDA_VISIBLE_D	unset	This option restricts the list of GPU devices that zCFD will be able to use. Typically this can be used to remove an incompatible GPU or the display GPU from the list of candidate GPUs.
ZCFD_DISABLE_P	unset	When set this causes the GPU memory allocated to be page-able and not pinned memory. This should always be used on Windows in WSL as CUDA inside WSL has a fixed low threshold for the maximum amount of allowed pinned memory.
ZCFD_NCCL	unset	Set to 1 to make use of the NVIDIA NCCL library during parallel exchanges.
PMPI_CUDA	unset	Set if you are running with platform MPI (custom builds only) to enable GPU aware MPI memory allocations
MPICH_GPU_SUF	unset	Set to 1 if you are running with Cray MPI (custom builds only) to enable GPU aware MPI memory allocations
ZCFD_DISPATCH_	unset	Makes all kernel launches synchronous.

1.4 Reference Guide

The zCFD control file is a python file that is executed at runtime. This provides a flexible way of specifying key parameters, enabling user defined functions and leveraging the rich array of python libraries available.

A python dictionary called 'parameters' provides the main interface to controlling zCFD

```
parameters = {...}
```

zCFD will validate the parameters dictionary specified at run time against a set of expected values for each key. In general, values that should be integers and floats will be coerced to the correct type. Values which should be strings, booleans, lists or dictionaries will cause an error if they are the incorrect type. The time marching scheme and solver/equation set chosen defines which dictionary keys are valid. A simple script is provided to allow the user to check the validity of their input parameters before submitting their job. See [Input Validation](#).

This reference guide documents the parameters available in a zCFD control dictionary and the valid values for those keywords.

```
parameters = {
    'reference': IC_1,
    'initial': { Initial State },
    'restart': False,
    'partitioner': 'metis',
    'scale': [1,1,1],
    'time marching': { Time Marching },
    'equations': { Equations },
    'material': { Material Specification },
    'IC_1': {Initial Conditions}
    'BC_1': {Boundary Conditions}
    'TR_1': {Mesh Transformation}
    'mapping': {Overset}
    'write output': {Write Output}
    'report': {Reporting}
}
```

1.4.1 Reference Settings

Reference state

Keyword	Re-quired	Default	Valid values
'reference'	No	'IC_1'	"IC_?" where ? is an integer.

```
# set reference state to IC_1
'reference' : 'IC_1',
```

Sets the *Initial Condition* which provides the reference quantities when non-dimensionalisation is applied to *force reporting*. "IC_?" must be a valid *initial conditions* dictionary defined in the parameters file

Initial State

Keyword	Re-quired	Default	Valid values
'name'	No	'IC_1'	"IC_?" where ? is an integer.
'func'	No	–	An (optional) <i>initial conditions function</i> .

```
# set initital state to IC_1
"initial": {
  "name": "IC_1"
}
```

Sets which block *Initial Condition* block will be used to provide initial flow field conditions for the simulation. If **'func'** is provided it will be used to provide the initial flow field variables on a cell-by-cell basis.

Note: If the **'initial'** entry is missing then the conditions default to the *reference* state.

Scale mesh

Keyword	Re-quired	Default	Valid values
'scale'	No	[1,1,1]	[scaleX,scaleY,scaleZ] : Any list of positive floats with length 3

Before being loaded in to the solver, the mesh's [x,y,z] location data is multiplied by this vector.

Example usage:

```
# Scale from mm to metres
'scale' : [0.001,0.001,0.001]
```

```
# Scale from inches to metres
'scale' : [0.0254,0.0254,0.0254]
```

```
# Scale the mesh to be 10 times larger in y axis
'scale' : [1,10,1]
```

Note: The 'scale' parameter applies to the mesh only - not interpolated surface outputs etc. (see *Tab x*)

Scale Function

As an alternative to passing a fixed scaling factor the 'scale' parameter will also accept a function. See the *Scale Function* for details.

Partitioner

Keyword	Re-quired	Default	Valid values
'partitioner'	No	'metis'	['metis']. The name of the partitioner to use.

The 'metis' partitioner is used to split the computational mesh up so that the job can be run in parallel. Other partitioners will be added in future code releases

Restart

Keyword	Re-quired	Default	Valid values
'restart'	No	False	True/False
'restart casename'	No		Optionally supply the name of a case to restart from that case, if not supplied then the current casename will be used..
'interpolate restart'	No	False	True/False: True to interpolate restart results from a different mesh.
'restart meshname'	No	False	The name of the mesh to interpolate the restart from.
'solution smooth cycles'	No	0	Number of Laplace smoothing cycles to smooth initial mapped solution

Restart allows you to load a solution from a previous run and continue the solver from that point. By default the solver will look for a <casename>_results.h5 file to load the restart, this can be overridden with the 'restart casename' parameter.

The default restart assumes that the same mesh is used. Alternatively, a solution from another mesh can be mapped on to a new mesh using the 'interpolate restart' parameter.

Example usage:

```
# Restart from previous solution
'restart' : True,
# Load solution from case name 'my_case'
'restart casename' : 'my_case',
```

```
# Restart from previous solution on a different mesh
"interpolate restart": True,
# Interpolate restart from "different_mesh.h5"
"restart meshname": "different_mesh",
# Do not smooth initial solution
"solution smooth cycles": 0,
```

Advanced Restart

It is possible to restart the SA-neg solver from results generated using the Menter SST solver and vice versa, however by default the turbulence field(s) are reset to zero. An approximate initial solution for the SA-neg model can be generated from Menter-SST results by adding the key

```
# Generate approximate initial field for SA-neg
'approximate sa from sst results' : True,
```

Safe Mode

Keyword	Re-quired	Default	Valid values
'safe'	No	False	True/False

Safe mode turns on extra checks and provides diagnosis in the case of solver stability issues

Example usage:

```
# Enable safe mode
'safe' : True,
```

1.4.2 Boundary Conditions

Boundary condition properties are defined using consecutively numbered blocks

```
'BC_1' : {...},
'BC_2' : {...},
```

zCFD will automatically detect zone types and numbers in a number of mesh formats, and assign appropriate boundary conditions. The type tags follow the Fluent convention (wall = 3, etc), and if present no further information is required. Alternatively, the mesh format may contain explicitly numbered zones (which can be determined by inspecting the mesh). In this case, the user can specify the list of zone numbers for each boundary condition 'type' and 'kind' (see below).

Wall

Wall boundaries in zCFD can be either slip walls, no-slip walls, or use automatic wall functions. No-slip walls are appropriate when the mesh is able to fully resolve the boundary layer (i.e $y^+ \leq 1$) otherwise automatic wall functions should be used. This behaviour is chosen by setting 'kind' in the wall specification below. Optionally it is possible to set wall velocity, roughness and temperature.

```
'BC_1' : {  
    # Zone type tag  
    'ref' : 3,  
    # Optional: Specific zone boundary condition override  
    'zone' : [0,1,2,3],  
    # Required: Boundary condition type  
    'type' : 'wall',  
    # Type of wall, one of 'slip', 'noslip', 'wallfunction'  
    'kind' : 'slip',  
    # Optional: Roughness specification  
    'roughness' : {  
        # Type of roughness specification (option: height or length)  
        'type' : 'height',  
        # Constant roughness  
        'scalar' : 0.001,  
        # Roughness field specified as a VTK file  
        'field' : 'roughness.vtp',  
    },  
    # Optional: Wall velocity specification either 'linear' or 'rotating'  
    'V' : {  
        'linear' : {  
            # Velocity vector  
            'vector' : [1.0,0.0,0.0],  
            # Optional: specifies velocity magnitude  
            'Mach' : 0.20,  
        },  
        'rotating' : {  
            # Rotational velocity in rad/s  
            'omega' : 2.0,  
            # Rotation axis  
            'axis' : [1.0,0.0,0.0],  
            # Rotation origin  
            'origin' : [0.0,0.0,0.0],  
        },  
    },  
    # Optional: Wall temperature specification either a constant 'scalar' value  
    'temperature' : {  
        # Temperature in Kelvin  
        'scalar' : 280.0,  
        # Temperature field specified as a VTK file  
        'field' : 'temperate.vtp',  
    },  
}
```

Note: The roughness at each boundary face is set by finding the nearest point to the face centre on the supplied VTK file with the roughness value looked up in a node based scalar array called 'Roughness'

Note: The temperature at each boundary face is set by finding the nearest point to the face centre on the supplied VTK file with the temperature value looked up in a node based scalar array called 'Temperature'

Farfield

The farfield boundary condition can automatically determine whether the flow is locally an inflow or an outflow by solving a Riemann equation. The conditions on the farfield boundary are set by referring to an 'IC_' block. In addition to this an atmospheric boundary layer profile or a turbulence profile may be set.

```
'BC_2' : {
    # Zone type tag
    'ref' : 9,
    # Optional: Specific zone boundary condition override
    'zone' : [0,1,2,3],
    # Required: Boundary condition type
    'type' : 'farfield',
    # Required: Kind of farfield options (riemann, pressure or supersonic)
    'kind' : 'riemann',
    # Required: Farfield conditions
    'condition' : 'IC_1',
    # Optional: Atmospheric Boundary Layer
    'profile' : {
        'ABL' : {
            # Roughness length
            'roughness length' : 0.05,
            # Fiction velocity
            'friction velocity' : 2.0,
            # Surface Layer Height
            'surface layer height' : 1000,
            'Monin-Obukhov length' : 2.0,
            # Turbulent kinetic energy
            'TKE' : 1.0,
            # Ground Level
            'z0' : 0.0,
        },
    },
    # Optional: Specify a turbulence profile
    'turbulence' : {
        'length scale' : 'filename.vtp',
        'reynolds tensor' : 'filename.vtp',
    },
},
```

Inflow

zCFD can specify two kinds of inflow boundary condition: pressure or massflow, selected using the 'kind' key. When using the pressure inflow the boundary condition is specified by a total pressure ratio and a total temperature ratio that needs to be defined by the condition this refers to. When using the massflow condition a total temperature ratio and mass flow ratio or a mass flow rate is required. Note the mass flow ratio is defined relative to the condition set in the 'reference' key. By default the flow direction is normal to the boundary but either a single vector or a python function can be used to specify the inflow normal vector of each face on the surface.

```
'BC_3' : {  
    # Zone type tag  
    'ref' : 4,  
    # Optional: Specific zone boundary condition override  
    'zone' : [0,1,2,3],  
    # Required: Boundary condition type  
    'type' : 'inflow',  
    # Required: Kind of inflow, either 'default' for pressure or 'massflow'  
    'kind' : 'default',  
    # Required: Reference inflow conditions  
    'condition' : 'IC_2',  
},
```

Example Pressure Inflow

An example setup for a pressure inflow is given below:

```
'IC_1' : {  
    'temperature' : 293.0,  
    'pressure' : 101325.0,  
    'V' : {  
        'vector' : [1.0,0.0,0.0],  
        'Mach' : 0.20,  
    },  
    'Reynolds No' : 1.0e6,  
    'Reference Length' : 1.0,  
    'turbulence intensity' : 0.1,  
    'eddy viscosity ratio' : 1.0,  
},  
'IC_2' : {  
    'reference' : 'IC_1',  
    'total temperature ratio' : 1.0,  
    'total pressure ratio' : 1.0,  
    # Optional - specify mach number to set  
    # static pressure at inflow from total pressure  
    'mach' : 0.1,  
},  
'BC_3' : {  
    'ref' : 4,  
    'zone' : [0,1,2,3],  
    'type' : 'inflow',  
    'kind' : 'default',  
    'condition' : 'IC_2',  
},
```

Example Massflow Inflow

An example setup for a massflow inflow is given below:

```
def inflow_direction(x, y, z):
    # x, y, and z are the coordinates of the face centre
    cen = [1.0, 0.0, 0.0]
    y1 = y - cen[1]
    z1 = z - cen[2]
    rad = math.sqrt(z1*z1 + y1*y1)
    phi = math.atan2(y1,z1)
    angle = -0.24
    x2 = math.cos(angle)
    y2 = math.sin(phi) * math.sin(angle)
    z2 = math.cos(phi) * math.sin(angle)
    return {'v1': x2, 'v2': y2, 'v3': z2}

'IC_1' : {
    'temperature' : 293.0,
    'pressure' : 101325.0,
    'V': {
        'vector' : [1.0,0.0,0.0],
        'Mach' : 0.20,
    },
    'Reynolds No' : 1.0e6,
    'Reference Length' : 1.0,
    'turbulence intensity' : 0.1,
    'eddy viscosity ratio' : 1.0,
},
'IC_2' : {
    'reference' : 'IC_1',
    'total temperature ratio' : 1.0,
    'mass flow rate' : 10.0,
    'vector' : inflow_direction
},
'BC_3' : {
    'ref' : 4,
    'zone' : [0,1,2,3],
    'type' : 'inflow',
    'kind' : 'massflow',
    'condition' : 'IC_2',
},
```

Outflow

Pressure or massflow outflow boundaries are specified in a similar manner to the *Inflow* boundary. They can be of:code`'kind` 'pressure', 'radial pressure gradient' or 'massflow'. When either pressure boundary is set the 'IC_' conditions it refers to must set a static temperature ratio, when 'massflow' is specified a mass flow ratio or mass flow rate must be set. Note the mass flow ratio is defined relative to the condition set in the 'reference' key.

```
'BC_4' : {
    # Zone type tag
    'ref' : 5,
    # Optional: Specific zone boundary condition override
    'zone' : [0,1,2,3],
```

(continues on next page)

(continued from previous page)

```
# Boundary condition type
'type' : 'outflow',
# Kind of outflow 'pressure', 'massflow' or 'radial pressure gradient'
'kind' : 'pressure',
# Required only when using 'radial pressure gradient'
# Radius at which the static pressure ratio is defined
'reference radius' : 1.0,
# Outflow conditions
'condition' : 'IC_2',
},
```

Symmetry

```
'BC_5' : {
    # Zone type tag
    'ref' : 7,
    # Optional: Specific zone boundary condition override
    'zone' : [0,1,2,3],
    # Required: Boundary condition type
    'type' : 'symmetry',
},
```

Periodic

This boundary condition needs to be specified in pairs with opposing transformations. The transforms specified should map each zone onto each other.

```
'BC_6' : {
    # Required: Specific zone index
    'zone' : [1],
    # Required: Type of boundary condition
    'type' : 'periodic',
    # Required: Either 'rotated' or 'linear' periodicity
    'kind' : {
        # Rotated periodic settings
        'rotated' : {
            'theta' : math.radians(120.0),
            'axis' : [1.0,0.0,0.0],
            'origin' : [-1.0,0.0,0.0],
        },
        # Linear periodic settings
        'linear' : {
            'vector' : [1.0,0.0,0.0],
        },
    },
},
```

1.4.3 Time Marching

zCFD is capable of performing both steady-state and time dependent simulations. Steady-state solutions are marched in pseudo time towards convergence. Time dependent simulations can be either globally time-stepped or use local pseudo time-stepping within a dual time-stepping iteration in physical time. The ‘time marching’ dictionary controls the selection of these schemes. Major options are what CFL number to use, whether explicit or implicit time-stepping is used and whether the simulation is time dependent.

```
parameters = {
    ...
    "time marching": {
        "cycles": 5000,
        "unsteady": {...},
        "scheme": {...},
        'cfl': 30.0,
        "multigrid": 3,
        "multigrid cycles": 20000,
        "multipoly": False,
        "moving mesh": False,
    },
    ...
}
```

Cycles

The total number of pseudo time-steps to use in a *steady-state* simulation, or the number of pseudo time-steps to use in each real time-step of an *unsteady* time-dependent simulation

Example usage:

```
# A good starting value for most explicit, steady state cases. Implicit simulations
- can use a higher CFL and therefore require fewer cycles - around 100 - 500 cycles
- is a good starting point for an implicit steady state case.
'cycles' : 5000,
```

CFL Control

The Courant-Friedrichs-Lewy (CFL) number controls the local pseudo time-step that the solver uses to reach a converged solution. The larger the CFL number, the faster the solver will run but the less stable it will be. The CFL dictionary keys are only valid when using dual time-stepping.

Keyword	Re-quired	Default	Valid values
'cfl'	Yes	0	Any positive floating point number.
'cfl transport'	No	–	Any positive floating point number.
'cfl ramp'	No	–	Dictionary containing 'initial' and 'growth' - respectively the starting CFL number and the growth rate applied as a multiplier each successive time step until the CFL number is reached.
'ramp func'	No	–	Instead of the 'cfl ramp' parameter the user can specify a <i>ramp function</i> .
'cfl coarse'	No	Current CFL number	Any positive floating point number.
'cfl viscous factor'	Yes	1	Any positive floating point number.
'cfl for pmg levels'	No	–	List of 2 floating point numbers.

cfl

Sets the CFL number used in the mass, momentum and energy equations. When using dgcaa this applies to the the 'rho', 'rho_i' and 'rhoE' equations.

Example usage:

```
# Typical value used for a RANS simulation using explicit time marching
'cfl' : 1
```

```
# Typical value used for a RANS simulations using implicit time marching
'cfl' : 30
```

Note: Besides mesh quality, CFL is the most important parameter affecting simulation stability. If you find your simulation does not converge, consider reducing CFL

cfl transport

Sets the maximum CFL number used to update the turbulent transport equations (for example k and ω).

```
# Use cfl transport to promote solver stability
'cfl' : 30,
'cfl transport': 20
```

Note: If you find your simulation does not converge and reports high turbulence equation residuals which increase with successive cycles, consider setting this to a value lower than 'cfl'

cfl ramp

This allows a relatively large target CFL number to be specified, but start the simulation using a smaller one to provide stability as large non-physical transients are eliminated from the solution.

Starting a simulation with a large CFL number can cause instability to crash the solver. A more gentle start will reduce the impact of non-physical transients.

```
# Start cfl at 0.1 and grow at a rate 1.1, reaching the target cfl of 30 in 26 steps
'cfl' : 30,
'cfl ramp': {
  'initial': 0.1,
  'growth': 1.1
}
```

cfl coarse

For simulations with multigrid acceleration, the **'cfl coarse'** number is used as a CFL condition on the coarse meshes. For such cases the **'cfl'** number is still applied to the finest mesh.

This only applies to explicit finite volume solutions.

```
# The quality of agglomerated (multigrid) coarse meshes is typically less than the
→quality of the primary (fine) mesh and so a lower CFL number may be required for
→numerical stability.
'cfl' : 1.0,
'cfl coarse': 0.5
```

cfl viscous factor

Factor applied to the diffusive (viscous) time step when applying the CFL condition. As viscous effects are rarely the cause of solver instability, the contribution of the viscous terms to the time step evaluation may be reduced by setting **'cfl viscous factor'** to a number less than 1.

```
# For the low Reynolds number cylinder case, viscous effects are dominant but do not
→contribute to instability.
# The value of 1e-6 effectively discounts viscosity in the determination of the time
→step when applying the CFL condition.
"cfl": 200,
"cfl viscous factor": 1.0E-6,
"cfl ramp factor": {"initial": 0.1, "growth": 1.05},
```

cfl for pmg levels

'cfl for pmg levels' sets the cfl number for each polynomial level during a polynomial multigrid cycle. Two values are required in the Python list, the CFL number for the highest polynomial order, and the CFL number for a P0 polynomial. The CFL number varies with polynomial order in accordance with the linear formula $1.0/(2 * P + 1)$. Note that the order of spatial accuracy of a P0 polynomial is $P + 1$ and for a P2 polynomial the order is $P + 3$.

```
# For the high order (DG) cylinder case, the CFL for the P2 polynomial is 0.55, while
→the CFL for the P0 polynomial can be larger at 1.5.
"cfl": 0.55,
"cfl for pmg levels": [0.55, 1.5],
"cfl viscous factor": 0.5,
"cfl ramp factor": {"initial": 0.1, "growth": 1.05},
```

Solver scheme

There are two different time marching schemes available in zCFD: multistage explicit and euler implicit scheme. These can be used for both steady and unsteady (using global or dual time-stepping) simulations. Global time-stepping requires no preconditioning and excludes some of the multistage RK schemes.

Keyword	Required	Default	Valid values	Description
'name'	Yes	"runge kutta"	"euler" "runge kutta" "implicit euler"	Name of scheme
'stage'	No	"rk third order tvd"	1 4 5 'rk third order tvd'	("runge kutta" only) Number of RK stages
'kind'	No	–	'local timestepping' 'global timestepping'	Timestepping mode

Note: The Euler scheme has a single stage and is the safest option for new or problematic cases.

name

The solution is integrated in time (solved) using an integration scheme that can be either explicit (variables driving the change are evaluated at the previous step) or implicit (some or all of the variables driving the change are evaluated at the current step). **'euler'** or **'runge kutta'** are the explicit schemes and **'implicit euler'** is the implicit option.

A larger time step can be taken using the implicit scheme, as the method is more stable than an explicit scheme.

Note: The trade off in using implicit time integration is the increase in memory requirement, typically 3-5 times more than for an explicit scheme.

stage

The number of Runge-Kutta stages in each step of the integration scheme affects the order of temporal convergence, and affects the maximum CFL that can be used.

Note: For most of the test cases where Runge-Kutta integration is used, 5 stages are applied. This is a typical industry standard and has been shown to be robust for most test cases.

kind

Global time stepping uses the same time step in each cell for the integration, whereas local time stepping calculates and uses the time step in each cell as determined by the local flow conditions and the prescribed CFL number. In cases where there are very small cells. it would be impractical to use global timestepping as all the cells would have to march at the pace of the slowest.

Note: While global timestepping restricts all cells to the smallest timestep and should only be used for unsteady simulations.

Unsteady

The Unsteady dictionary controls the simulation time and can be used to set up both Steady and Unsteady cases.

Keyword	Required	Default	Valid values	Description
'total time'	Yes	–	Positive float	Total time to simulate
'time step'	Yes	–	Positive float	Physical time step for the simulation
'order'	Yes	"second"	"first" "second" 1 2	(Unsteady only) Order of time integration.
'start'	No	–	Positive integer	(Unsteady only) For unsteady simulations, how many steady-state timesteps to run to initialise solution.

Running steady state

For steady-state simulations, **'total time'** should be set equal to the **'time step'** value. The solver will then automatically run a steady-state simulation.

Example usage:

```
# Run an unsteady simulation for 1.7 seconds with a time step of 0.002 seconds
'time marching' : {
    ...
    "unsteady": {
        "total time": 1.0,
        "time step": 1.0,
    },
    ...
}
```

Running unsteady

If the **'time step'** value is less than the **'total time'** value, then an unsteady simulation is created.

Time integration for unsteady simulations is based on the solution at the current time step and the contribution of the solution in previous time steps, represented by a Backward Difference Formula. Dual time-stepping is used to update the current solution with data from previous time steps. **'order'** controls the order of the Dual time-stepping.

'start' provides the option of initialising an unsteady simulation with a number of steady-state pseudo timesteps.

Example usage:

The unsteady laminar cylinder test case sheds a vortex street with a specific Strouhal number. We want to run the simulation for 1.7 seconds to allow the oscillation to begin and establish a well-formed pattern. We set the time step to a small enough value to capture the unsteady shedding phenomenon.

```
# Run an unsteady simulation for 1.7 seconds with a time step of 0.002 seconds
'time marching' : {
    ...
    "unsteady": {
```

(continues on next page)

(continued from previous page)

```

        "total time": 1.7,
        "time step": 0.002,
        "order": "second",
        "start": 0
    },
    ...
}

```

The example below uses a relatively large time step and maintains accuracy with a second order integration scheme. The case starts with 2000 pseudo-timesteps before starting the unsteady simulation.

```

# Run an unsteady simulation for 1.7 seconds with a time step of 0.002 seconds
'time marching' : {
    ...
    "unsteady": {
        "total time": 0.06,
        "time step": 2.0e-5,
        "order": "second",
        "start": 2000
    },
    ...
}

```

Multigrid

Keyword	Re-quired	Default	Valid values
'multigrid'	No	–	Any positive integer.
'multigrid cycles'	No	–	Any positive integer.
'multipoly'	No	False	True False

To accelerate an explicit finite volume solution, coarse meshes are generated from the original (fine) mesh by agglomerating or combining cells together to create larger cells. The **'multigrid'** value sets the number of successive times to apply this operation, each iteration resulting in a coarser mesh with fewer cells. By solving on the hierarchy of coarser meshes as well as the fine mesh, information is moved faster in the flow domain and a converged solution is reached more efficiently. The multigrid scheme is designed so that the acceleration does not (in theory) change the result that would be obtained just by solving on the finest mesh alone, though in practice the use of multigrid does ultimately stall convergence on most meshes.

Use multigrid acceleration for a specified number of **'multigrid cycles'** and then revert to the finest mesh only. This is to make use of the more efficient scheme at the start, and avoid convergence stall due to multigrid at the end of a solution process.

For high order (Discontinuous Galerkin) simulations, **'multipoly'** may be used to accelerate convergence by using lower order polynomials in a manner analogous to finite volume multigrid acceleration. The time step limitation on the lower order polynomials is less restrictive than for the higher order polynomials and hence information corresponding to longer wavelengths may be more efficiently propagated in the fluid domain. The use of **'multipoly'** automatically uses the highest one specified and P0.

Example usage:

```

# 3 levels of multigrid is sufficient in most cases to reduce the number of cycles
→ required by an order of magnitude.
# If this causes instability, a reduction to 2 may solve the problem.
'time marching' : {

```

(continues on next page)

(continued from previous page)

```

...
'multigrid': 3,
...
}

```

```

# After 20000 explicit cycles, multigrid stall prevents convergence to the correct
→drag value.
# By turning it off, the correct value is obtained on the finest mesh.
'time marching' : {
    ...
    'multigrid': 3,
    'multigrid cycles' 20000,
    ...
}

```

Note: Multigrid only applies to explicit finite volume solutions. Multipoly only applies to High Order (DG) solutions.

Moving Mesh

Keyword	Re-quired	Default	Valid values
'moving mesh'	No	False	True False

In any case where the mesh (or a fluid zone within the mesh) is moving (translation or rotation) the simulation can be performed in either the frame of reference of the mesh or in a fixed coordinate system. For simulations where there is no relative movement of interest, **'moving mesh'** may be set to False. For simulations where there is relative movement, setting **'moving mesh'** to True will force a recalculation of the physical location of the mesh, including the recalculation of any overset mappings.

1.4.4 Equations

Keyword	Re-quired	Default	Valid values
'equations'	Yes	–	Any of equation sets detailed below.

The equations key selects the equation set to be solved as well as the finite volume solver or the high order strong form Discontinuous Galerkin/Flux Reconstruction solver.

The corresponding equation set options should also be defined in the control dictionary. The valid equation keys are shown in the table below.

Solver	Description	Com- press- ible	High order	Incom- press- ible
Euler	Use the Euler flow equations in the simulation. These are compressible, inviscid flow equations.	<i>“euler”</i>	–	–
RANS	Use the RANS (Reynolds-Averaged Navier-Stokes) equations in the simulation. These are compressible, viscid flow equations with additional terms included to account for the effect of turbulence on the flow without the expense of simulating the turbulent flow structures themselves.	<i>“rans”</i>	<i>“dgrans”</i>	Coming soon
Viscous	Use the viscous flow equations. These are compressible, viscid flow equations which do not model turbulence.	<i>“vis-cous”</i>	<i>“dgvis-cous”</i>	Coming soon
LES	Use the Large Eddy Simulation (LES) equations.	<i>“les”</i>	<i>“dgles”</i>	Coming soon

Example usage:

```
parameters = {
    ..
    # Use the euler equation set
    'equations' : 'euler',
    # Define the inputs for the 'euler' equation set
    'euler': {...}
    ..
}
```

Common Settings

The following parameters are common for all of the equation sets.

Keyword	Required	Default	Valid values
‘order’	Yes	–	‘first’ ‘second’ ‘euler_second’
‘first order cycles’	No	–	Positive integer
‘linear gradients’	No	False	True False
‘leastsq gradients’	No	False	True False
‘inviscid flux scheme’	Yes	“HLLC”	“HLLC” “Rusanov” “Roe” “Roe low diss”
‘roe low dissipation sensor’	No	–	“FD” “NTS” “DES” “NONE”
‘roe dissipation sensor minimum’	No	–	Float between 0.05 and 1.0
‘freeze limiter cycle’	No	–	Positive integer
‘relax’	Yes (for incompressible equation set)	0.5	Positive float
‘turbulence’	Yes (for ‘les’ or ‘rans’ equation set)	{}	See <i>“turbulence”</i>

order

Sets the order of the spatial discretisation. **'euler_second'** is second order for the flow variables and first order for the turbulence.

first order cycles

Specifies the number of cycles the solver will run with first order spatial discretisation. This can be used to improve stability at start up.

Example usage: Run 500 cycles first order.

```

parameters = {
  ..
  'equations' : 'euler',
  'euler': {
    ...
    'first order cycles': 500,
    ...
  }
  ..
}

```

linear gradients & leastsq gradients

By default zCFD uses a Weighted Green-Gauss gradient calculation. This can be switched to a standard Green-Gauss by setting **'linear gradients'** to True. Setting **'leastsq gradients'** to True will set the gradient calculation to Least Squares.

inviscid flux scheme

Picks the scheme to use for the inviscid flux. **HLLC** is good when running explicit, **Roe** is best for implicit and **Rusanov** is good for getting an implicit simulation going. The **Roe low diss** scheme can be used with LES or Hybrid RANS/LES

roe low dissipation sensor

The sensor used to decide whether to use (and by how much) the Roe low dissipation scheme.

Setting	Notes
'DES'	Uses the blending function from the selected DES model to turn on the Roe low dissipation scheme in LES regions
'NONE'	Uses the value set on 'roe dissipation sensor minimum' everywhere
'FD'	See Johnsen et al. JCP 229 (2010) pag. 1234
'NTS'	See Xiao et al. INT J HEAT FLUID FL 51 (2015) pag. 141 https://doi.org/10.1016/j.ijheatfluidflow.2014.10.007

roe dissipation sensor minimum

Sets the minimum value that the dissipation term in the Roe scheme is multiplied by when using the ‘**Row low diss**’ scheme. This allows you control the stability of the low diss scheme (smaller values reduce the dissipation and hence the stability of the scheme)

freeze limiter cycle

If set the values of the limiter used in the MUSCL reconstruction are frozen at the specified cycle. This can be useful in the latter stages of a simulation if noise from the limiter is causing the residual convergence to stall.

relax

The relaxation factor used on the flow equations in the incompressible solver. Increasing this will speed up convergence at the expense of stability and vice versa.

turbulence

The turbulence dictionary is required for the “*rans*” and “*les*” equations sets.

Euler

Compressible Euler flow is inviscid (no viscosity and hence no turbulence). The compressible Euler equations are appropriate when modelling flows where momentum significantly dominates viscosity - for example at very high speed. The computational mesh used for Euler flow does not need to resolve the flow detail in the boundary layer and hence will generally have far fewer cells than the corresponding viscous mesh would have.

As well as the “*common*” settings, the following settings are available:

Keyword	Required	Default	Valid values	Description
‘precondition’	Yes	False	True False	Use low speed mach preconditioner

Example usage:

```
parameters = {  
    ..  
    # Use the euler equation set  
    'equations' : 'euler',  
    'euler' : {  
        'order' : 'second',  
        'first order cycles': 100,  
        # Cycle on which to freeze the limiter values  
        'freeze limiter cycle': 500,  
        # Use low speed mach preconditioner  
        'precondition' : True,  
        'Inviscid Flux Scheme': 'HLLC',  
    },  
}
```

Viscous

The viscous (laminar) equations model flow that is viscous but not turbulent. The **Reynolds number** of a flow regime determines whether or not the flow will be turbulent.

The computational mesh for a viscous flow has to resolve the boundary layer so will generally be larger than that used for an Euler simulation. A viscous simulation will run faster than a RANS simulation using the same mesh since fewer equations are being modelled.

As well as the “*common*” settings, the following settings are available:

Keyword	Required	Default	Valid values	Description
'precondition'	Yes	False	True False	Use low speed mach preconditioner

Example usage:

```
parameters = {
    ..
    # Use the viscous equation set
    'equations' : 'viscous',
    'viscous' : {
        'order' : 'second',
        'first order cycles': 100,
        # Use low speed mach preconditioner
        'precondition' : True,
        'linear gradients' : False,
        'Inviscid Flux Scheme': 'HLLC',
    },
    ..
}
```

RANS

The fully turbulent (Reynolds Averaged Navier-Stokes Equations)

As well as the “*common*” settings, the ‘**RANS**’ equation set requires the additional ‘**turbulence**’ dictionary, which can have the following parameters:

Keyword	Required	Default	Valid values	Description
'les'	Yes	'none'	'none' 'DES' 'DDES' 'IDDES' 'SAS'	Selects the hybrid RANS/LES model.
'model'	Yes	–	'sst' 'sas' 'sa-neg' 'sst-transition'	Selects the RANS turbulence model
'approximate sa from sst results'	No		True False	Restart an SA-neg calculation from an SST solution
'rotation correction'	No	False	True False	Adds the rotation correction term to SST or SA-neg
'limit gradient k'	No		Float from 0.01 to 1	Activates the $\tilde{\nu}$ gradient limiter in the SA-neg model
'qcr'	No	False	True False	Activates the non-linear QCR correction to the turbulent stress. Applicable to both SST and SA-neg

les

Selects the hybrid RANS/LES model in the RANS solver which is applied to the base model selected with the “**model**” key word.

Setting	Notes
'none'	Solve the RANS equations with no hybrid RANS/LES model
'DES'	Detached Eddy Simulation
'DDES'	Delayed Detached Eddy Simulation
'IDDES'	Improved Delayed Detached Eddy Simulation
'SAS'	Scale Adaptive Simulation

model

Selects the RANS turbulence model.

Setting	Notes
'sst'	The Menter Shear Stress Transport Turbulence Model (https://turbmodels.larc.nasa.gov/sst.html)
'sa'	Spalart-Allmaras turbulence model (https://turbmodels.larc.nasa.gov/spalart.html)
'sa-neg'	Negative Spalart-Allmaras turbulence model (https://turbmodels.larc.nasa.gov/spalart.html)
'sst-transition'	The Langtry-Menter 4-equation Transitional SST Model (https://turbmodels.larc.nasa.gov/langtrymenter_4eqn.html)

limit gradient k

Activates the $\tilde{\nu}$ gradient limiter in the SA-neg model. This helps eliminate gradient under/over shoot in regions of poor mesh quality.

The value should be between 0 and 1. **0** is off and **1** is maximum limiting.

qcr

Activates the non-linear QCR correction to the turbulent stress. Applicable to both SST and SA-neg. QCR has been shown to improve the prediction of separated corner flows, particularly on highly loaded wings.

Example RANS usage:

```

parameters = {
    ..
    # Use the viscous equation set
    'equations' : 'RANS',
    'RANS': {
        'order' : 'second',
        'first order cycles': 100,
        'freeze limiter cycle': 500,
        'linear gradients' : False,
        'leastsq gradients' : False,
        'Inviscid Flux Scheme': 'HLLC',
        'roe low dissipation sensor': 'DES',
        'roe dissipation sensor minimum': 0.05,
        'turbulence' : {
            'model' : 'sst',
            # No Hybrid RANS/LES
            'les' : 'none',
            'rotation correction': False,
            'limit gradient k': 0.5
            'qcr': True
        },
    },
    ...
}

```

Advanced parameters for turbulence models

The following parameters can be used in the ‘turbulence’ dictionary to allow tuning of the turbulence models in zCFD. These are advanced parameters and shouldn’t normally need to be adjusted.

Keyword	Required	Default	Valid values	Description
‘betastar’	No	0.09	Positive number	Constant in the dissipation term on the k equation in the SST model
‘cdes_kw’	No	0.78	Positive number	The $k-\omega$ part of the blended C_{DES} in SST
‘cdes_keps’	No	0.21	Positive number	The $k-\epsilon$ part of the blended C_{DES} in SST
‘cd1’	No	20	Positive number	Constant in the f_{dt} blending function in IDDES
‘cd2’	No	3	Positive integer	Constant in the f_{dt} blending function in IDDES
‘production’	No	0	Positive integer	Selects the model for the production term in the SST model.
‘cdes’	No	0.65	Positive number	C_{DES} constant used for SA-neg based hybrid RANS/LES

‘production’ can have the following values:

Setting	Notes
0	Selects the vorticity based production term (SST-V) $P_m = \mu_t \Omega_v^2 - \frac{2}{3} \rho k \delta_{ij} \frac{\partial u_i}{\partial x_j}$
1	Selects the strain based production term for incompressible flows $P_m = \mu_t S^2$
2	Selects the strain based production term for compressible flows $P_m = \mu_t S^2 - \frac{2}{3} \rho k \delta_{ij} \frac{\partial u_i}{\partial x_j}$
3	Selects the Kato-Launder source term $P_m = \mu_t S \Omega_v - \frac{2}{3} \rho k \delta_{ij} \frac{\partial u_i}{\partial x_j}$

LES

As well as the “common” settings, the ‘LES’ equation set requires the additional ‘turbulence’ dictionary, which can have the following parameters:

Keyword	Required	Default	Valid values	Description
‘les’	Yes	‘none’	‘none’ ‘WALE’	Selects the hybrid RANS/LES model.

les

Selects the model for the subgrid eddy viscosity in the LES solver: either “**none**” for implicit LES or “**WALE**” to use the Wall Adapted Local Eddy Viscosity model.

Example usage:

```
parameters = {
    ..
    # Use the viscous equation set
    'equations' : 'LES',
    'LES': {
        'order' : 'second',
        'first order cycles': 100,
        'freeze limiter cycle': 500,
        'linear gradients' : False,
        'leastsq gradients' : False,
        'Inviscid Flux Scheme': 'HLLC',
        'roe low dissipation sensor': 'DES',
        'roe dissipation sensor minimum': 0.05,
        'turbulence' : {
            'les' : 'none',
        },
    },
    ..
}
```

High Order

When using the high order strong form Discontinuous Galerkin/Flux Reconstruction solver the keys in the “*common*” equations dictionary are the same for each equation set except that the ‘**linear gradients**’ and ‘**limiter**’ keys are not valid and additional keys are available in the equations dictionary. For example all the available keys for ‘**dgviscous**’ are a combination of the ‘**viscous**’ keys and the keys shows below. The same logic applies to the ‘**dgrans**’, and ‘**dgles**’ equation sets.

These additional DG keys are:

Keyword	Required	Default	Valid values	Description
'order'	Yes		0 1 2 3 4	This parameter sets the order of the polynomials within each element used to define the numerical solution
'freeze diffusion during rk stages'	Yes	True	True False	Fixes diffusion terms after first RK stage
'inviscid flow'	Yes	False	True False	Defines if only advective terms should be computed
'c11 stability parameter'	Yes	0	Number	
'ldg upwind parameter'	Yes	0.5	Number between 0 & 1	
'shock sensing'	Yes	False	True False	
'shock sensing variable'	Yes	density	"density" "temperature" "mach" "turbulence"	
'shock k'	No	1.0	Number	
'shock sensing viscosity scale'	No	1.0	Number	

DG Nodal locations

In addition to the equation set the location of the DG solution points must be specified in the parameters dictionary. The definitions first need to be imported by including this import statement at the start of the control dictionary. The nodal locations are used in the generation of Lagrange polynomials used to define the solution within an element.

There are various sets of nodal locations defined in literature for use with high order methods. Varying the nodal locations can minimise aliasing errors within the DG method. It is recommended to use the default values.

Key-word	Re-quired	Default	Valid values	Description
'line'	Yes	line_gaus	line_evenly_spaced line_gauss_lobatto line_gauss_legendre	Specifies 1D points defining nodal locations.
'tri'	Yes	tri_shunn	tri_shunn_ham tri_evenly_spaced,	Specifies 2D triangle points defining nodal locations.
'tetra-hedron'	Yes	tet_shunn	tet_shunn_ham tet_evenly_spaced	Specifies 3D tetra points defining nodal locations.
'pyra-mid'	Yes	pyra-mid_gaus	pyra-mid_evenly_spaced pyra-mid_gauss_legendre pyra-mid_gauss_legendre	Specifies 3D pyramid points defining nodal locations.

Before you use the nodal locations the dictionaries must be imported by adding the following to your control file:

```
from zcfd.solvers.utils.DGNodalLocations import *
```

To use the default values:

```
from zcfd.solvers.utils.DGNodalLocations import *

parameters = {
    ..
    'Nodal Locations' : nodal_locations_default['Nodal Locations']
    ..
}
```

Or select from the available types

```
from zcfd.solvers.utils.DGNodalLocations import *

parameters = {
    ..
    'Nodal Locations' : {
        'line': line_gauss_legendre_lobatto,
        'tetrahedron': tet_evenly_spaced,
        'tri' : tri_evenly_spaced,
        'pyramid': pyramid_evenly_spaced
    },
    ..
}
```

Example “dgviscous”

```
from zcfd.solvers.utils.DGNodalLocations import *

parameters = {
    ..
    'equation': "dgviscous",
    'dgviscous' : {
        # Keys for viscous
        'precondition' : True,
        'Inviscid Flux Scheme': 'HLLC',

        # Additional DG Keys
        'order' : 2,
        'inviscid flow': False,
        'freeze diffusion during rk stages': False
        'c11 stability parameter': 0.0,
        'LDG upwind parameter': 0.5,
        'Shock Sensing': False,
        'Shock Sensing k': 1.0,
        'Shock Sensing Viscosity Scale': 1.0,
        'Shock Sensing Variable': 'density',
    },
    'Nodal Locations' : nodal_locations_default['Nodal Locations']
    ..
}
```

1.4.5 Aero-Acoustics

Broadband aero-acoustic simulations can be performed by selecting the DGCAA solver. Aero-acoustic sources are currently limited to stochastic noise sources generated by the FRPM method. These sources are typically driven by a steady state RANS simulation.

The CAA conditions can be mapped from a CFD solution or specified as a set of initial conditions to give freestream density and sound speed.

The configuration can make use of multiple “FRPM” domains and also include a *sponge* layer.

DGCAA Solver

The DGCAA is configured in the same way as the other solvers via an equations set with the name “dgcaa”.

Keyword	Required	Default	Valid values
‘order’	Yes		0 1 2 3 4
‘map cfd to caa mesh’	Yes	True	True False
‘frpm solver only’	Yes	False	True False
‘microphone output frequency’	Yes	1	Positive integer
‘frpm sources’	Yes	True	True False
‘number of smallest timestep locations to display’	Yes	1	Positive integer
‘rans case name’	Yes		String; python case file name
‘rans mesh name’	No		String; mesh file name
‘frpm’	No	{}	See “frpm”

Example usage

```
parameters = {  
    ..  
    'equations' : 'DGCAA',  
    'DGCAA' : {  
        'order' : 2,  
        'map cfd to caa mesh' : True,  
        'frpm solver only' : False,  
        'rans mesh name' : "rans_mesh.h5",  
        'rans case name' : "rans_case.py",  
        'frpm sources' : True,  
        'microphone output frequency' : 10,  
        'frpm' : {...}  
    }  
    ..  
}
```

order

This parameter sets the order of the polynomials within each element used to define the numerical solution.

Map CFD to CAA mesh

If there are large variations in the freestream flow properties, it may be desirable to include refraction effects within the acoustic simulation. This can be done by supplying a CFD flow field where the variations in temperature and velocity are mapped onto the acoustic mesh and are used within the CAA propagation. If this is set to FALSE, the freestream properties supplied within the IC_1 dictionary are used.

frpm solver only

If this is set to TRUE, there will be no solution of the acoustic (APE-4) equations, only the FRPM solver will be run. This allows you to examine the nearfield FRPM predicted flow field, without the necessity of running a full CAA simulation.

microphone output frequency

This is after how many time steps the next solution at the microphone locations should be written to file.

Note: Note this is number of cycles rather than Hz.

frpm sources

If this is set to TRUE, the acoustic sources driving the acoustic simulation will come from the FRPM method. If this is set to FALSE, sources will be supplied by the user elsewhere, for example, velocity fluctuations on a surface.

number of smallest timestep locations to display

The solver will report this number of cells with the smallest time steps.

Note: The time step utilised by the solver is limited by the smallest (or poorest quality) cells in the mesh. This keyword allows the user to see the X,Y,Z location of the cells which are restricting the time step and so can be useful for mesh improvement purposes.

rans case name

Specifies the zCFD results file to provide turbulent mean flow data to both the FRPM and CAA solver if required.

rans mesh name

Specifies the zCFD mesh file to provide turbulent mean flow data to both the FRPM and CAA solver if required.

FRPM Domains

Several FRPM domains can be defined within the aero-acoustic simulation by adding additional 'FRPM_2', 'FRPM_3', etc., dictionaries. With a single FRPM domain, the dictionary must be labelled 'FRPM_1'. Each dictionary can contain the following parameters:

Keyword	Required	Default	Valid values
'map cfd to frpm mesh'	Yes	True	True False
'number of frpm mpi processes'	Yes	1	Positive integer
'frpm spacing'	Yes		Positive float
'frpm turbulence integral length scale'	Yes		Positive float
'frpm maximum variable turbulence integral length dx scale'	Yes	7	Positive float
'frpm turbulence integral length scale parameter'	Yes	1	Positive float
'frpm cart num mesh cells'	Yes		[x, y, z]: vector of integers or function
'frpm domain translate'	Yes		[x, y, z]: vector of integers or function
'frpm domain rotate (deg)'	Yes		[x, y, z]: vector of integers or function
'frpm blend sources from side'	Yes		[]: list of floats
'frpm monitor points'	No		[x1, y1, z1, x2, y2, z2...]: list of X, Y, Z coordinates
'frpm flush particles cycles'	Yes	0	Positive integer
'frpm mapped tke smoothing iterations'	Yes	0	Positive integer
'frpm mapped tke smoothing relaxation'	Yes	0.2	Float between 0 & 1
'frpm inverse distance source mapping'	Yes	True	True False
'frpm inverse distance source mapping'	Yes	True	True False
'minimum particle speed'	Yes	0.0000000001	Positive float
'use constant integral length scale'	Yes	True	True False
'wall distance blend over'	Yes	-1	Float
'frpm anisotropy'	Yes	-1	Float
'frpm inverse distance source mapping distance'	No		Float
'frpm inflow boundaries'	No	[True, True, True, True, True, True]	List of booleans
'frpm minimum turbulence integral length scale'	No		Float

Example usage

```
parameters = {
    ..
    'equations' : 'DGCAA',
    'DGCAA': {
        ..
        "FRPM_1": {
            "number of frpm mpi processes": 1,
            "map cfd to frpm mesh": True,
            "frpm Spacing": 0.1,
            "frpm turbulence integral length scale": 0.2,
            "frpm cart num mesh cells": [100, 100, 100],
            "frpm march frequency": [0, 0, 0],
            "frpm domain translate": [0, 0, 0],
            "frpm domain rotate (Deg)": [0, 0, 0],
            "frpm blend sources From side": [0.1, 0.1, 0.1, 0.1, 0.1, 0.1],
            "frpm monitor points": [0.0, 0.0, 0.0],
            "frpm flush particle cycles": 2500,
            "frpm mapped tke smoothing iterations": 5,
            "frpm mapped tke smoothing relaxation": 0.2,
            "frpm inverse distance source mapping": True,
            "use constant integral length scale": False,
            "frpm turbulence integral length scale parameter": 0.61,
            "frpm anisotropy": 3.0,
        },
        ..
    },
    ..
}
```

map cfd to frpm mesh

Load turbulence information from a CFD RANS solution (see '**Map CFD to CAA mesh**'), if this is set to FALSE, the freestream properties supplied within the IC_1 dictionary are used.

number of frpm mpi processes

Specifies the number of host CPUs to be used by the FRPM solver.

If the FRPM solver is slowing down the overall CAA computation, the user may wish to increase the parallelism by adding more host CPUs to the FRPM computation. Ideally this should be kept as low as possible as the FRPM method does not naturally scale well with increased CPUs.

frpm spacing

Specifies the cartesian cell dimensions for the FRPM mesh which is automatically generated by the FRPM solver.

This is required to specify the FRPM mesh used in the FRPM computations. This dimension will limit the resolved turbulence integral length scale to $l_{resolved} = \sqrt{l_t^2 + (0.75 * \Delta)^2}$ where Δ is the frpm spacing.

frpm turbulence integral length scale

If the user chooses to use a constant integral length scale for the FRPM source predictions, this value will be used.

This value currently requires being set, however is only used if **'use constant integral length scale'** is set to TRUE. A constant turbulence integral length scale permits the use of numerically efficient (fast) filtering operations and considerably reduces the FRPM run times. If a constant turbulence length scale provides a reasonable estimate of the sound producing length scales, this parameter should be used in conjunction with **'use constant integral length scale'** set to TRUE.

frpm maximum variable turbulence integral length dx scale

Limits the CFD predicted turbulence integral length scale to this value multiplied by the **'frpm spacing'**.

If the FRPM solver is to use the turbulence integral length scales provided by a CFD solution, it may be necessary to limit the maximum integral length scale within the FRPM solver. This is to prevent filtering operations which extend over the entire FRPM domain, for each FRPM node, which rapidly becomes expensive.

frpm turbulence integral length scale parameter

Specifies the constant of proportionality for the turbulence length scale calculation from the CFD simulation. The turbulence integral length scale is specified from turbulence kinetic energy and turbulence eddy frequency using the following expression $l_t = C_l * \sqrt{k} / (betaStar * omega)$. This value specifies C_l .

Note: 0.61 to 1 are the values specified within the literature

frpm cart num mesh cells

Specifies the number of Cartesian cells in each direction.

This vector of integers specifies how many cells are in each Cartesian direction, effectively specifying the extent of the FRPM domain.

frpm march frequency

Specifies after how many time steps the FRPM solver should be updated.

The CAA solver time step may be much smaller than that necessary for the FRPM solver, therefore to reduce the FRPM overhead, we can perform fewer FRPM updates and interpolate at time levels in between FRPM updates.

Note: If this is set to -1 the FRPM solver will compute this update frequency based on particles not traversing a cell.

frpm domain translate

Specifies the X, Y, Z translation to place the FRPM domain in the desired location.

The FRPM domain by default is cartesian aligned and placed at the origin. This parameter allows the user to place the FRPM domain anywhere in the domain. Note that translation happens AFTER rotation of the domain.

frpm domain rotate (deg)

Specifies the X, Y, Z rotations to place the FRPM domain in the desired location.

The FRPM domain by default is cartesian aligned and placed at the origin. This parameter allows the user to rotate the FRPM domain into the desired orientation PRIOR to translation of the domain.

frpm blend sources from side

Acoustic sources will be blended to zero strength across this distance from the interior of the FRPM domain, towards each of the cartesian boundaries.

It is undesirable to have acoustic sources appearing to vanish within the CAA solver, therefore it is necessary to blend sources smoothly to zero strength. This is done via a shifted Cosine function where the value is zero at the boundaries and 1 the specified distance into the FRPM domain (when considered in its original Cartesian alignment). The ordering is distance from [XMIN, XMAX, YMIN, YMAX, ZMIN, ZMAX]. If any of XMIN, XMAX, etc are set to 0, no blending is done.

frpm monitor points

Contiguous list of X,Y,Z locations specifying monitor points where data such as velocity and source fluctuations should be output from the FRPM solver.

It may be useful to the user to interrogate the data being produced by the FRPM solver to monitor statistics such as mean turbulence kinetic energy, turbulence spectra (using the frozen turbulence approximation), etc.

frpm flush particles cycles

Specifies number of FRPM cycles to run prior to starting an aero-acoustic calculation.

During initialisation, particles are placed randomly within active areas in the FRPM domain. The user can perform a specified number of particle marches to essentially flush particles through the domain such that the distribution of particles is as would be achieved after running for a period of time. No filtering operations are applied, simply particle tracking.

frpm mapped the smoothing iterations

Number of smoothing iterations for turbulence kinetic energy field.

When a CFD solution is mapped to the FRPM domain, there may be a considerable difference in local cell sizes. As such, the mapped solution may show mild discontinuities. In order to prevent this causing an issue with numerical differentiations during the FRPM computations, the mapped solution can be smoothed using a relaxed Lagrangian smoothing method. This parameter specifies the number of smoothing cycles.

It should be noted that peak turbulence levels may reduce and smear out as a result of the smoothing process so the user should take care to ensure the smoothed turbulence field is as representative of the actual CFD solution as possible.

frpm mapped tke smoothing relaxation

Relaxation during smoothing iterations for turbulence kinetic energy field. This parameter specifies the relaxation during the Lagrange smoothing steps specified by '**frpm mapped tke smoothing iterations**'

frpm inverse distance source mapping

Use inverse distance weighing mapping to map acoustic sources from the FRPM domain to the CAA mesh.

There are two options to map acoustic sources from the FRPM domain to the CAA mesh. The first is using a modified Shepard inverse distance weighted mapping (recommended) or simply locate the CAA mesh point in the FRPM domain and interpolate the solution to that point ('**frpm inverse distance source mapping**' set to FALSE). The inverse distance mapping has been observed to exhibit minimal spurious numerical noise at high frequencies.

minimum particle speed

The minimum local flow speed of a particle before it is deleted and reseeded at an inflow boundary.

It is possible, as a result of numerical integration, that a particle may enter an almost dead zone with very negligible flow velocity. It may be desirable to delete the particle and reseed the particle at an inflow boundary to prevent the build up of particles in stagnant areas (or areas which are inactive). This should only be used if issues with large numbers of stationary particles are encountered in regions of the FRPM domain.

use constant integral length scale

Defines whether or not a constant, user specified, turbulence integral length scale should be used in the FRPM computations.

A constant turbulence integral length scale permits the use of numerically efficient (fast) filtering operations and considerably reduces the FRPM run times. If a constant turbulence length scale provides a reasonable estimate of the sound producing length scales, this parameter should be set to True. If this parameter is set to False, the turbulence integral length scale varies throughout the domain and is calculated from the CFD solution.

wall distance blend over

Defines the distance from walls the acoustic sources should blend to zero.

It is undesirable to have acoustic sources appearing to vanish within the CAA solver, therefore it is necessary to blend sources smoothly to zero strength. This is done via a shifted Cosine function where the value is 1 at a distance of this value from a wall, then blends to zero over this value such that it is zero two times this value from the wall.

frpm anisotropy

Defines anisotropy factor for acoustic sources generated by the FRPM method.

If the turbulence field to be modelled is anisotropic, it is possible to specify anisotropy with this parameter. The streamwise integral length scale will be scaled by $\sqrt{anisotropy}$ and the length scale normal to the streamwise direction will be scaled by $1.0/anisotropy$.

frpm inverse distance source mapping distance

Specifies the radial distance from a target CAA mesh point that source data from the FRPM domain should be taken from.

This parameter defines a sphere around the CAA mesh point where we wish to map acoustic data to, where any FRPM point within will contribute to the inverse distance weighted mapping. By default this is set to 3 times to FRPM mesh spacing, however and be increased or decreased if necessary (due to memory limitations for example).

frpm inflow boundaries

List of booleans defining the Cartesian FRPM domain boundaries in which deleted particles can be reseeded into the domain.

If an FRPM particle exits the domain, it is reseeded at one of the FRPM domain boundaries. This list of booleans allows the user to set which boundaries particles can be reseeded. By default, reseeding can happen at all boundaries, however some can be turned off if desired. The booleans are ordered XMIN, XMAX, YMIN, YMAX, ZMIN, ZMAX.

For example, *[True, False, True, False, False, False]* will have particles reseeded at only the XMIN and YMIN boundaries.

frpm minimum turbulence integral length scale

Specifies the minimum turbulence integral length scale permitted when using the turbulence integral length scales predicted by a CFD simulation.

This parameter specifies the minimum turbulence integral length scale permitted, when the turbulence integral length scales being used are those from a CFD simulation. It is highly recommended to set this value to twice the FRPM spacing. Any value below this will likely result in the sources being poorly resolved in the FRPM domain and result in spurious high frequency noise.

Sponge Layers

This option can be used to permit non reflecting farfield boundaries. When set, damping terms will be linearly ramped from zero at this distance from farfield boundaries, to the highest value (defined by 'damping factor') at the farfield boundary.

Keyword	Required	Default	Valid values
'distance'	No	–	Number
'damping factor'	No	–	Number

'distance' specifies the distance from farfield boundaries in which the solution should be damped towards freestream values. **'damping factor'** specifies the amount of damping to be applied at cells close to farfield boundaries.

Example usage

```
parameters = {
    ..
    'equations' : 'DGCAA',
    'DGCAA': {...},
    "sponge layer damping": {
        "distance": 1.0,
        "damping factor": 1.0,
    },
    ..
}
```

1.4.6 Fluid-structure interaction

zCFD has the capability of simulating Fluid Structure Interaction (FSI) using both a modal model, as well as any generic full FEA program through the use of our generic coupling scheme.

Keyword	Re- quire	Default	Valid values	Description
'type'	Yes		'abaqus' 'generic'	FSI driver to be used when coupling to an FEA code
'zone'	Yes		List of zone ID integers	Which boundaries within the aerodynamic mesh are moving structural boundaries
'fixed zones'	Yes		List of zone ID integers	Which boundaries should not be moved by any mesh deformation
'transform type'	Yes		'rbf multiscale' 'rbf' 'IDW'	Interpolation method to be used.
'alpha'	Yes	1	Float	Support radius used by RBF
'basis'	Yes	'c2'	'c2' 'c4' 'c0' 'tps' 'gaussian'	Which basis function to use for RBF
'base point fraction'	Yes	0.1	Float	Number of points to use in the reduced base set for rbf multiscale interpolation
'tol'	Yes	0.01	Float	Set the target error tolerance for the rbf interpolation
'max error'	Yes	0.1	Float	Set the maximum initial error tolerance for rbf interpolation
'n nearest'	Yes	100	Positive integer	Number of points to be used in IDW interpolation
'deformation distance'	Yes	1	Float	Set the maximum support radius for IDW interpolation
'blending stiffness'	Yes	0.5	Float	Set the blending stiffness for the IDW interpolation
'power'	Yes	[3.0,5.0,10.0]	Set the IDW power for the nearfield and farfield boundaries, and the power between them.	List of Float
'user variables'	No	{}	Dict of variables to values	Custom parameters passed into the generic FSI code

type

Specifies which FSI driver should be used when coupling to an FEA code, **'abaqus'** or **'generic'**. This tells zCFD which FSI python file should be used to execute the FSI coupling:

'generic' will use the **genericFSI.py** interface that should be implemented to meet your requirements. Out the box **genericFSI.py** will not perform any changes.

'abaqus' is an extension of generic interface that allows the solver to run in tandem with the SIMULIA CSE engine.

Note: Abaqus requires the CSE engine to be built with zCFD

zone

zone should be a list of zone IDs, these specify which surface is the moving FSI surface. This provides methods to extract surface normals, pressure forces, and cell centres from the specified cells, as well as allowing these surface points to drive mesh deformations in the volume mesh.

For RBF, this must include any static zones, where the motion of a static zone is set to 0.

fixed zones

fixed zones should be a list of zone IDs, these specify surfaces which must remain fixed, such as an interface, periodic boundary, or symmetry plane, these surfaces will remain untouched by the IDW mesh motion interpolation.

Note: IDW only

transform type

In FSI simulations the active surface defined in the **'zone'** block, will move relative to the rest of the mesh. In order to maintain a conformal volume mesh, these displacements must be interpolated into the volume mesh. **transform type** defines which interpolation scheme should be used.

Setting	Notes
'rbf'	Radial Basis Functions require the solving of a linear system, where a continuous function is fitted between all points which defines the motion. This function can then be evaluated at other points within the domain to get the interpolated values.
'rbf multiscale'	RBF multiscale uses the a multiscale algorithm using a varying support radius to reduce the number of nodes in the linear system, where as RBF uses a Greedy algorithm.
'IDW'	Inverse Distance Weighting does not require the solving of a linear system, and instead represents a function using a weighted sum of nearby function values.

Note: **'rbf multiscale'** has generally superseded the greedy algorithm, used in **'rbf'**, in terms of both speed performance and accuracy, so is the preferred RBF option.

alpha

Only applies to **'rbf'** and **'rbf multiscale'** interpolation schemes.

'alpha' sets the support radius used by the RBF. The Radial Basis Function used in RBF interpolation will have a set support radius defining the 1D shape of the function as a function of r . This determines the region of influence for the function. Compact functions such as C0, C2, C4 have a maximum radius, outside of which the influence of the RBF is 0. For functions with global influence such as Gaussian and TPS, alpha becomes the normalisation factor - i.e. when $r = \alpha$, $e = 1$ if $\text{rbf} = f(e)$.

'alpha' should be larger than the maximum anticipated deformation.

basis

Only applies to **'rbf'** and **'rbf multiscale'** interpolation schemes.

When performing RBF interpolation a specific function needs to be defined to create the interpolant. Compact functions such as C0, C2, C4 have a maximum region of influence, Gaussian and TPS have global influence.

Note: For 99% of applications C2 works best

base point fraction

Only applies to **'rbf'** and **'rbf multiscale'** interpolation schemes.

Solving the RBF system requires solving an $N \times N$ sized linear system, where N is the number of moving nodes- i.e. nodes on the surface [4] defined earlier. For large meshes this quickly becomes prohibitively expensive, therefore it is desirable to solve a reduced set of points. The Multiscale method is a 'reduced base set method' where the linear system is only solved on the base set of nodes, with the remaining nodes solved iteratively. **'base point fraction'** dictates how many nodes of the full set should be included in the base set. Setting the base point fraction to 1.0 returns a standard full RBF.

tol

Only applies to **'rbf'** interpolation scheme.

At each point selection step during Greedy selection, the interpolation problem is solved on the current base set of data. From this the error between the exact solution and interpolated solution for all points in the mesh is identified, this value is used as the initial guess for the 'worst' error within the mesh. Once the total error is below this tolerance, the greedy point selection is complete.

max error

Only applies to **'rbf'** interpolation scheme.

At each point selection step during Greedy selection, the interpolation problem is solved on the current base set of data. From this the error between the exact solution and interpolated solution for all points in the mesh is identified. If this error is greater than the max error specified here, an error message is thrown.

n nearest

Only applies to 'IDW' interpolation scheme.

When using IDW mapping, the deformation of each surface point is mapped onto a set number of volume points, with the value determined by the weighted inverse distance between the donor and the recipient.

deformation distance

Only applies to 'IDW' interpolation scheme.

Sets the maximum region of influence for the inverse distance weighting mapping. If there are fewer than "n" neighbours within a distance "d", then only neighbours within that distance are used.

blending stiffness

Only applies to 'IDW' interpolation scheme.

Set the blending stiffness for the IDW interpolation.

power

Only applies to 'IDW' interpolation scheme.

Set the IDW power for the nearfield and farfield boundaries, and the power between them.

user variables

If you had additional variables for time marching scheme or FSI control (e.g. file names) you may want to pass as variables to the **genericFSI.py** script, these should be included in this dictionary.

1.4.7 Material Specification

This dictionary sets the material properties of the fluid being modelled. The default values are those of air, but the dictionary can be modified to model any ideal, compressible, perfect gas.

Keyword	Re-quired	Default	Valid values
'sutherlands const'	Yes	110.4	Float
'prandtl no'	Yes	0.72	Float
'gas constant'	Yes	287	Float
'gamma'	Yes	1.4	Float
'turbulent prandtl no'	Yes	0.9	Float
'gravity'	No		Vector

Example usage:

```
parameters = {
    ..
    'material' : 'air',
    'air' : {
        'gamma' : 1.4,
        'gas constant' : 287.0,
        'Sutherlands const': 110.4,
```

(continues on next page)

(continued from previous page)

```
'Prandtl No' : 0.72,  
'Turbulent Prandtl No' : 0.9,  
},  
..  
}
```

sutherlands const

This option controls the variation of the viscosity of the fluid with temperature.

Sutherland's law: $\mu = \mu_{ref} \left(\frac{T}{T_{ref}} \right)^{3/2} \frac{T_{ref} + S}{T + S}$, where S is Sutherland's constant.

In zCFD, T_{ref} and μ_{ref} are given by the *reference* initial condition dictionary, where T is specified directly and μ is specified either directly via '**viscosity**' or indirectly via '**reynolds no**'.

Typically for air $\mu_{ref} = 1.716e-5$ and $T_{ref} = 273.15$

For more information: https://www.cfd-online.com/Wiki/Sutherland%27s_law

prandtl no

This option sets the Prandtl number, a non-dimensional number which is the ratio of momentum and thermal diffusivities in a fluid. In zCFD, where μ and c_p are already set, setting the Prandtl number has the effect of setting the thermal conductivity, k , of the fluid.

$$\text{Pr} = \frac{\text{momentum diffusivity}}{\text{thermal diffusivity}} = \frac{c_p \mu}{k}$$

This can also be considered as $\text{Pr} = \frac{\text{Thickness of thermal boundary layer}}{\text{Thickness of fluid boundary layer}}$

gas constant

This changes R , the gas constant of the fluid. Different fluids have different molecular masses, and therefore different gas constants. 287.1 is appropriate for air.

Constant pressure and constant volume specific heats, c_p and c_v , are set by *gamma* and R according to the following relationships:

$$c_p = \frac{\gamma - 1}{\gamma} R$$

$$\gamma = \frac{c_p}{c_v}$$

gamma

This changes γ , the ratio of specific heats of the fluid. 1.4 is appropriate for air, but a value of 1.33 is often used for combustion exhaust gases.

turbulent prandtl no

This changes the turbulent Prandtl number of the fluid being modelled.

In simulations which model turbulence viscosity (RANS, LES and other scale resolving simulations), the eddy viscosity, μ_t accounts for the additional diffusivity of momentum due to turbulence relative to the equivalent laminar flow. There is likewise additional diffusivity of heat due to turbulence relative to the equivalent laminar flow, and the turbulent prandtl number accounts for this.

In an eddy viscosity based simulation, $Pr_t = \frac{c_p \mu_t}{k_t}$

gravity

This sets the direction in which gravity acts in your simulation. For most industrial and aerospace flows, bouyancy effects are not important and therefore bouyancy should not be set. However, certain flows (e.g. plumes) do require bouyancy effects for accurate modelling.

gravity is specified as x,y,z vector, for example “[0,0,-9.81]”

1.4.8 Initial Conditions

An initial condition dictionary defines a fluid state. They are used to provide a reference initial state for the solution as well as specific conditions that can be assigned to *boundary conditions*.

Initial condition properties are defined using consecutively numbered blocks

```
'IC_1' : {....},  
'IC_2' : {....},
```

By default zCFD will use the “IC_1” block to provide initial flow field conditions for the simulation but this can be changed with the *‘initial’* parameter.

In addition to fully describing a set of conditions, zCFD allows you to specify *‘reference conditions’* to be specified relative to a base set. This is typically used to set conditions for flow entering (inflow) or leaving (outflow) the domain.

Another way of prescribing an initial condition is by defining a dynamic *‘driving function’*, which on evaluation returns an initial condition dictionary.

Keyword	Re- quired	Default	Valid values	Description
'pressure'	Yes		Float	Static pressure in Pascals. Used to compute density and set Total Energy in the Compressible solver.
'temperature'	Yes		Float	Static temperature in Kelvin. Used to compute density and for dynamic viscosity scaling using Sutherlands law.
'V'	No		Dict	See <i>Velocity</i>
'reynolds no'	When 'viscosity' not set.		Float	Used to calculate viscosity at supplied temperature
'reference length'	No	1	Float	Reference length to be used to calculate viscosity from the Reynolds number
'viscosity'	When 'reynolds no' not set.		Float	Sets the dynamic viscosity at the temperature with scaling provided by Sutherlands law defined in <i>material</i> section.
<i>'turbulence intensity'</i>	No		Float	Turbulence intensity (%)
<i>'eddy viscosity ratio'</i>	No		Float	Ratio of dynamic viscosity to turbulent viscosity used to set the turbulence quantities
<i>'ambient turbulence intensity'</i>	No		Float	Value of background turbulence intensity (%) to maintain in fluid
<i>'ambient eddy viscosity ratio'</i>	No		Float	Value of background turbulence eddy viscosity ratio to maintain in fluid
'profile'	No		Dict	See <i>Velocity Profile</i>

Example usage:

```
parameters = {
  ..
  "IC_1": {
    "V": {"vector": [0.0, 2.5, 0.0] },
    "ambient eddy viscosity ratio": 1e-20,
    "ambient turbulence intensity": 1e-20,
    "eddy viscosity ratio": 0.1,
    "pressure": 101325.0,
    "temperature": 273.15,
    "turbulence intensity": 0.01,
    "viscosity": 1.79e-05,
    ..
  },
}
```

Velocity

Velocity can be specified in two ways, either a vector or a vector and a Mach number. When Mach number is specified the velocity direction is provided by the vector and the velocity magnitude is computed from the Mach number and speed of sound at the pressure and temperature provided.

For example to set a velocity of 50 mesh units/sec in the X direction:

```
..
"V" : {[50.0,0.0,0.0]},
..
```

Or to set a velocity of mach 0.2 in the X direction:

```
..
"V" : {[1.0,0.0,0.0], "mach": 0.2}
..
```

Viscosity

Dynamic (shear, absolute or molecular) viscosity should be defined at the static temperature previously specified. This can be specified either as a dimensional quantity or by a Reynolds number and reference length

```
# Dynamic viscosity in dimensional units
'viscosity' : 1.83e-5,
```

or

```
# Reynolds number
'reynolds No' : 5.0e6,
# Reference length
'reference length' : 1.0,
```

Note: Reynolds number is defined as: $Re = \frac{\text{density} * V * \text{referencelength}}{\text{viscosity}}$

Turbulence intensity & Eddy viscosity

Turbulence intensity is defined as the ratio of velocity fluctuations u' to the mean flow velocity. A turbulence intensity of 1% is considered low and greater than 10% is considered high.

```
# Turbulence intensity %
'turbulence intensity': 0.01,
# Turbulence intensity for sustainment %
'ambient turbulence intensity': 0.01,
```

The eddy viscosity ratio (μ_t/μ) varies depending type of flow. For external flows this ratio varies from 0.1 to 1 (wind tunnel 1 to 10)

For internal flows there is greater dependence on Reynolds number as the largest eddies in the flow are limited by the characteristic lengths of the geometry (e.g. The height of the channel or diameter of the pipe). Typical values are:

Re	3000	5000	10,000	15,000	20,000	> 100,000
eddy	11.6	16.5	26.7	34.0	50.1	100

```
# Eddy viscosity ratio
'eddy viscosity ratio': 0.1,
# Eddy viscosity ratio for sustainment
'ambient eddy viscosity ratio': 0.1,
```

Velocity Profile

The user can also provide functions to specify a 'wall-function' - or the turbulence viscosity profile near a boundary.

Keyword	Re- quired	Default	Valid values	Description
'abl'	No		Dict	Specify an <i>ABL</i> (Atmospheric Boundary Layer)
<i>'field'</i>	No		File name	Specify a field of data that is used as a lookup for setting the flow conditions.
'use wall distance'	No	False	True/False	Use wall distance in place of z coordinate in field during interpolation process. This can be used in setting the profile of flows on a terrain mesh with a variable ground location at the boundary

field

The file specified using the 'field' parameter should be in the ParaView/VTK VTP format. It should contain a node array with one or more of the following array names: 'Pressure', 'Temperature', 'Velocity', 'TI' and 'EddyViscosity'. zCFD will then look up those values in the solution by looking up the nearest point in the VTP file.

```
..
'profile' : {
    'field' : 'inflow_field.vtp',
    # Localise field using wall distance rather than z coordinate
    'use wall distance' : True,
},
..
```

Note: Note the field will override the conditions specified previously therefore the user can specify only the conditions that are different from default.

ABL

Keyword	Re-quired	Default	Valid values	Description
'roughness length'	Yes		Float	It is a measure of the height at which the mean velocity of the wind becomes zero, due to the frictional effects between the air and the surface.
'friction velocity'	Yes		Float	Specify a field of data that is used as a lookup for setting the flow conditions.
'surface layer height'	No		Float	The surface layer height, also known as the aerodynamic or boundary layer height.
'monin-obukhov length'	No		Float	The Monin-Obukhov length.
'tke'	No		Float	Set the turbulent kinetic energy.
'z0'	No		Float	Set the z location of the ground rather than using the z coordinate in the mesh.
'up'	No	[0,0,1]	Vector	Direction of gravity

roughness length

Is a measure of the height at which the mean velocity of the wind becomes zero, due to the frictional effects between the air and the surface.

The roughness length is typically denoted by the symbol " z_o " and is defined as the vertical distance between the Earth's surface and the height at which the logarithmic wind profile intersects the surface. The logarithmic wind profile is a mathematical relationship that describes the variation of wind speed with height in the atmospheric boundary layer.

The roughness length depends on the surface characteristics of the terrain or objects present on the Earth's surface. Different surfaces, such as forests, urban areas, or bodies of water, have different roughness lengths. For example, a smooth surface like open water would have a small roughness length, while a densely forested area would have a larger roughness length.

friction velocity

Friction velocity, often denoted as " u_\star " (pronounced "u-star"), is another important parameter in the study of atmospheric boundary layers. It represents the characteristic velocity of turbulent motions in the surface layer of the atmosphere, generated by the shear stress between the air and the Earth's surface.

Friction velocity is defined as the square root of the shear stress divided by the air density:

$$u_\star = \sqrt{\frac{\tau}{\rho}}$$

where:

- u_\star is the friction velocity,
- τ is the shear stress between the air and the surface, and
- ρ is the density of the air.

The shear stress, τ , arises from the momentum transfer between the moving air and the surface roughness elements. It is related to the wind speed and the roughness length through a logarithmic wind profile, described by the following equation:

$$u(z) = \left(\frac{u^*}{\kappa}\right) * \ln \frac{z}{z_o}$$

where:

- $u(z)$ is the wind speed at height z above the surface,
- κ is the von Kármán constant (approximately 0.4), and
- z_o is the roughness length.

The friction velocity provides a measure of the intensity of turbulence near the Earth's surface. It influences several atmospheric processes, including heat and moisture exchange, pollutant dispersion, and the formation of atmospheric boundary layer structures. The magnitude of the friction velocity depends on surface roughness, wind speed, and atmospheric stability, among other factors.

surface layer height

The surface layer height, also known as the aerodynamic or boundary layer height, refers to the vertical extent of the atmospheric boundary layer near the Earth's surface. It represents the region where the physical properties, such as wind speed, temperature, humidity, and turbulence, are influenced by the underlying surface. The height of the surface layer is often estimated based on empirical relationships or atmospheric stability conditions. It can vary from a few meters to a few hundred meters above the ground, depending on factors such as surface roughness length, wind speed, and atmospheric stability. Additionally, the surface layer height can change diurnally, with variations due to daytime heating and nighttime cooling effects.

monin-obukhov length

The Monin-Obukhov length, often denoted as “ L ”, is a parameter used in the study of atmospheric boundary layers to characterise the stability of the air near the Earth's surface. It is named after the Russian scientists A. S. Monin and A. M. Obukhov, who made significant contributions to the understanding of turbulence and boundary layer physics.

The Monin-Obukhov length is defined as the ratio of the potential temperature difference to the buoyancy flux. It is given by the following equation:

$$L = -\frac{u^*{}^3 * \theta_v}{\kappa * g * w\theta}$$

where:

- L is the Monin-Obukhov length,
- u^* is the friction velocity,
- θ_v is the virtual potential temperature,
- κ is the von Kármán constant (approximately 0.4),
- g is the acceleration due to gravity, and
- $w\theta$ is the vertical flux of virtual potential temperature.

The Monin-Obukhov length is an indicator of atmospheric stability. It quantifies the relationship between the mechanical production of turbulence due to wind shear and the buoyancy effects caused by vertical temperature gradients. Positive values of L indicate stable atmospheric conditions, while negative values indicate unstable conditions. A neutral atmosphere corresponds to $L = 0$.

The Monin-Obukhov length influences various atmospheric processes, such as turbulence structure, heat and moisture exchange, and dispersion of pollutants. It plays a significant role in determining the behaviour of the atmospheric boundary layer, including the vertical mixing of air masses and the development of turbulence. The value of L is influenced by factors such as surface properties, wind speed, temperature, and humidity gradients.

1.4.9 Reference Conditions

Reference Conditions enable a set of conditions to be specified relative to a base set of *initial conditions*. This is typically used to set conditions for flow entering (inflow) or leaving (outflow) the domain

Reference condition properties are defined in the same way as initial conditions using consecutively numbered blocks.

```
'IC_2' : {...},
'IC_3' : {...},
```

Note: Reference conditions can not be used for “IC_1”

Keyword	Re-quired	Default	Valid values	Description
'reference'	Yes		Float	Specify the base condition as the reference for this set of conditions
'static pressure ratio'	No		Float or <i>Function</i> or <i>File</i>	Set the static pressure using a ratio relative to the reference static pressure. Where static pressure = reference static pressure * static pressure ratio
'total pressure ratio'	No		Float or <i>Function</i> or <i>File</i>	Set the total pressure using a ratio relative to the reference total pressure. Where total pressure = reference total pressure * total pressure ratio
'total temperature ratio'	No		Float or <i>Function</i> or <i>File</i>	Set the total temperature using a ratio relative to the reference total temperature. Where total temperature = reference total temperature * total temperature ratio
'mass flow ratio'	No		Float	Specify a <i>mass flow</i> ratio.
'mass flow rate'	No		Float	Specify a <i>mass flow</i> rate.
'vector'	No		[X, Y, Z] or <i>Function</i>	Specify direction vector used to specify the direction of the flow for specific boundary conditions.
'mach'	No		Float	Specify a mach number used for specific boundary conditions like inflows/jets.

Example usage:

```
parameters = {
..
'IC_2' : {
    'reference' : 'IC_1',
    'total temperature ratio' : 1.0,
    'mass flow rate' : 10.0,
    'vector' : [1,0,0],
    'mach' : 0.5,
},
```

(continues on next page)

(continued from previous page)

```
..  
},
```

Mass Flow

Mass flow ratio is defined as:

$$ratio = (density * area * V) / (density_{ref} * area * V_{ref}) = (density * V) / (density_{ref} * V_{ref})$$

Mass flow rate is defined as:

$$\dot{m} = density * area * V$$

Note: Note area is in mesh units squared

Using a file

A file can be used to provide a lookup for the pressure and temperature ratios. This file should be in the Paraview/VTK VTP format. The file should contain a surface with specific values as node arrays data. zCFD then looks up the values by finding the nearest point to the mesh location.

The node array data in the VTP should be named specifically for each keyword:

Keyword	Node Array Name
'static pressure ratio'	StaticPressureRatio
'total pressure ratio'	TotalPressureRatio
'total temperature ratio'	TotalTemperatureRatio

1.4.10 Mesh Transformation

This dictionary is used to setup an initial deformation of the mesh. Typically a known deformation of a surface in the mesh is propagated out into the volume using either radial basis function or inverse distance weighted interpolation. Deforming an aircraft wing or wind turbine blade to a static load shape are two uses of this functionality.

Keyword	Re- quire	Default	Valid values	Description
'type'	Yes		'rbf' 'rbf multiscale' 'idw'	Selects the <i>interpolation</i> method used.
'base point fraction'	No		Float	Fraction of points included in the base set when using ' rbf multiscale '
'alpha'	No		Float	Sets the support radius (the radius of influence) of the rbf surface points.
'zone'	Yes		List of zone ID integers	Sets a list of surface zones to deform
'fixed zones'	No		List of zone ID integers	Sets the surface zones which remain fixed in position when using ' idw ', useful if you have surfaces that are within the influence of the interpolation that should remain fixed.
'func'	Yes		<i>Transform Function</i>	A python function that describes the surface deformation to be propagated into the volume mesh. The function is called for each node on the surfaces specified in the 'zones' key.
'basis'	No		<i>c0 c2 tps gaussian</i>	Selects the type of radial basis function used. Can be Welland's c0 or c2 function, thin plate spline (tps) or Gaussian.
'tol'	No		Float	The maximum permissible distance error between the deformed surface shape and that obtained using the greedy ' rbf ' method. No more points will be added to the system once this tolerance is reached.
'power'	No	[3,5,10]	List of int	A list of three exponents used in the ' idw ' interpolation scheme.
'n nearest'	No	100	Int	The number of nodes closest to the current point used to determine the ' idw ' interpolation weight.
'deformation distance'	No	1	Float	The distance over which the surface deformation is blended into the volume mesh.
'blending stiffness'	No	0.5	Float	The stiffness of the blending function used to propagate the ' idw ' interpolation of the surface deformation into the volume mesh.

Interpolation method

Selects the interpolation method used to propagate the surface deformation into the volume mesh. Three methods are available:

'rbf' uses the 'greedy' method of [Allan et al.](#) where the deformation is started with a subset of points and additional points are added until the surface deformation reaches the requested tolerance.

'rbf multiscale' uses the *multiscale* rbf method where a subset of surface points with a fixed support radius are solved implicitly and the remaining points are solved explicitly with a support radius determined as part of the solution process. The fraction of points included in the base set can be set with '**base point fraction**'. The base set of points are assigned the support radius '**alpha**' and hence can have a wider sphere of influence than the

remaining points which are used in the multiscale process.

Note: Increasing the number of points in the base set and/or increasing alpha generally makes the surface deformation propagate further into the volume mesh reducing the likelihood of generating poor quality cells

'**idw**' uses a simple inverse distance weighted interpolation. The '**power**' parameter can provide a list of three exponents used in the IDW scheme. The first (p1) is applied to the interpolation weight of points close to the surface, the second (p2) to points which are the deformation distance away from the surface and the third (p3) is used to blend between the two extremes.

$$wt_1 = (deformationdistance/distance)^{p1} \quad wt_2 = (deformationdistance/distance)^{p2} \quad blend = ((deformationdistance - distance)/deformationdistance)^{p3}$$

Then the weight is:

$$wt = (wt_1 * (1.0 - blend) + blend * wt_2)$$

Examples

RBF Example

```
import zutil

rotation = 10.0

def my_transform(x, y, z):
    v = [x, y, z]
    v = zutil.rotate_vector(v, rotation, 0.0)
    return {"v1": v[0], "v2": v[1], "v3": v[2]}

parameters = {
    ...
    "TR_1": {
        "type": "rbf",
        "zone": [4],
        "func": my_transform,
        "alpha": 200.0,
        "basis": "c2",
        "tol": 0.01,
    },
    ...
}
```

RBF Multiscale Example

```
import zutil

rotation = 10.0

def my_transform(x, y, z):
    v = [x, y, z]
    v = zutil.rotate_vector(v, rotation, 0.0)
    return {"v1": v[0], "v2": v[1], "v3": v[2]}
```

(continues on next page)

(continued from previous page)

```
parameters = {  
    ...  
    "TR_1": {  
        "type": "rbf multiscale",  
        "base point fraction": 0.1,  
        "zone": [4],  
        "func": my_transform,  
        "alpha": 200.0,  
        "basis": "c2",  
    },  
    ...  
}
```

IDW Example

```
import zutil  
  
rotation = 10.0  
  
def my_transform(x, y, z):  
    v = [x, y, z]  
    v = zutil.rotate_vector(v, rotation, 0.0)  
    return {"v1": v[0], "v2": v[1], "v3": v[2]}  
  
parameters = {  
    ...  
    "TR_1": {  
        "type": "idw",  
        "power": [4.0, 8.0, 10.0],  
        "fixed zones": [1],  
        "n nearest": 500,  
        "deformation distance": 100.0,  
        "blending stiffness": 0.5,  
        "zone": [4],  
        "func": my_transform,  
    },  
    ...  
}
```

1.4.11 Overset

zCFD is capable of automatically oversetting multiple meshes into a single simulation. To run an overset case you need to provide an *override file*.

Override file

The override file tells zCFD which combinations of mesh and control dictionary to load and overset. The first entry in the list should be the background mesh, this is typically the largest of the meshes that the other meshes overlap with. The following entries in the list are then overset onto the background mesh when the solver starts. The meshes are overlapped in the order they appear in the list, starting with the background mesh.

The list should be defined in a separate python file containing an **override** dictionary.

Example **override** dictionary (e.g. override.py):

```
override = {
    'problem_case_pair': [
        ("background_mesh.h5", "background.py"),
        ("overset_1.h5", "overset_1.py"),
        ("overset_2.h5", "overset_2.py"),
    ]
}
```

Running an overset case:

```
(zCFD)> run_zcfd -f override.py
```

Mapping

The **mapping** dictionary sets additional mapping options for overset methods and should be defined in the background control file.

Keyword	Re- quired	Default	Valid values	Description
'idw from cells order'	0	–	0 or 1	Sets the order of accuracy for IDW mapping
'number of additional overset active layers'	Yes	0	Positive integer	Adds additional active cells to overlapped mesh

Example usage:

```
parameters = {
    ..
    'mapping': {
        'idw from cells order': 0,
        'number of additional overset active layers': 0,
    }
    ..
}
```

idw from cells order

If **'idw from cells order'** is set to 0, this provides a 0th order interpolation where we only utilise data from cell a mapped point is located within. If set to 1, a first order interpolation is achieved using an IDW interpolation, using the cell a point is found in, and its neighbours.

number of additional overset active layers

Adds additional active cells which may have been made inactive by an overlapping mesh. If for example, we have a rotating domain, the resolution of the rotating boundary may result in rotated overset mesh boundary points, entering cells made inactive. This will result in no mapping between background and overset meshes at these points. To resolve this issue, it is possible to add additional active cells (for safety) to ensure a mapping between overset and background meshes. Whilst not necessary, this parameter may be useful if issues with mapping between meshes occur.

1.4.12 Write Output

write output

Controls the frequency and contents of the files output into the the **output** directory and the **VISUALISATION** subdirectory.

The **output** directory will be created in the working directory from which the solver is run and is named using the following format:

```
<case_name>_P<number of mpi ranks>_OUTPUT
```

Keyword	Required	Default	Valid values
'frequency'	Yes	Positive integer or {}	See <i>"frequency"</i>
'format'	Yes	'vtk'	'none' 'vtk'
'scripts'	No	[]	List of catalyst script filenames
'variable_name_alias'	No	{}	Dict
'surface variables'	Yes	["p", "T", "rho"]	List of <i>"variable"</i> names
'volume variables'	Yes	[...]	List of <i>"variable"</i> names
'volume interpolate'	No		List of surface file filenames
'compute average and rms'	No	False	True False
'average start time cycle'	No		Positive integer

Example usage:

```
parameters = {
    ..
    'write output' : {
        'format' : 'vtk',
        'surface variables': ['V','p'],
        'volume variables' : ['V','p'],
        'volume interpolate' : ['mesh.stl'],
        'scripts' : ['paraview_catalyst1.py'],
        'variable_name_alias' : { "V" : "VELOCITY", },
        "frequency": 500,
        'calculate average and rms': True,
        'average start time cycle': 1000
    },
}
```

(continues on next page)

(continued from previous page)

```
..  
}
```

format

Selects the file format to output the data in. Using 'none' as format will output no files. 'vtk' outputs in legacy vtk format for reading into [ParaView](#).

scripts

zCFD is capable of calling ParaView catalyst scripts while running, this allows you to generate "in situ" visualisation output while the solver is running.

This allows you to extract data as your simulation progresses without needing to store the full solution at every timestep. For instance a video of a slice through the dataset could be generated for an unsteady solution.

For more information about Catalyst see: <https://www.paraview.org/hpc-insitu/>

variable_name_alias

Maps the zCFD variable names to a different variable name in the output file. If downstream processes need variables named using a specific convention a naming alias dictionary can be supplied.

surface variables

A list of *variables* to output on the boundaries of the mesh. This is useful for visualisation of the flow variables on the wall of the mesh for post processing. For the 'vtk' format the surface data is written to the *output* directory with the file name:

```
<case_name>_<boundary>.pvd
```

volume variables

A list of *variables* to output in a volumetric format.

For the 'vtk' format the volume data is written to the *output* directory with the file name:

```
<case_name>.pvd
```

volume interpolate

zCFD can interpolate volume data to a supplied surface. This parameter lets you list the filenames of surfaces to interpolate to. The supported file formats are VTK (vtu or vtp files) and STL.

compute average and rms

Enables computation of time averaged and RMS values for pressure, temperature and velocity. Enabling this adds these variables to the list of variables to be output automatically.

This options only applies to *unsteady* cases.

average start time cycle

If **compute average and rms** is True, this controls first real time cycle to start calculating the running average. This allows you to run the solver for a number of time cycles before you start calculating the average and RMS values.

Frequency

Sets how frequently the solver should output the flow solution. A single integer value will control output of both the volume and surface data output. A dictionary value here allows for fine grained control over the frequency with which each individual output is done. If the solver is running an unsteady simulation then this is the frequency of the real time step otherwise the pseudo cycle.

Keyword	Required	Default	Valid values
'volume data'	Yes	1.00E+08	Positive integer
'surface data'	Yes	1.00E+08	Positive integer
'volume_interpolate'	Yes	1.00E+08	Positive integer
'checkpoint'	Yes	1.00E+08	Positive integer
'volume data start'	Yes	1	Positive integer
'surface data start'	Yes	1	Positive integer
'volume interpolate start'	Yes	1	Positive integer
'checkpoint start'	Yes	1	Positive integer

volume data, **surface data**, **volume_interpolate** and **checkpoint** control the frequency at which the solution data of the given type is written. The frequency is specified as the solver cycle number. The **checkpoint** option writes a *restartable* checkpoint of the flow solution at that point.

volume data start, **surface data start**, **volume interpolate start** and **checkpoint start** specifies the first cycle that the solver should start writing that particular output.

Note: On systems with slower file I/O the overhead of writing data can slow the overall solve time, reducing the output frequency lets you address this.

Example usage:

```
parameters = {
    ..
    'write output' : {
        'format' : 'vtk',
        'surface variables': ['V','p'],
        'volume variables' : ['V','p'],
        "frequency": {
            # Output visualisation files every 3 cycles
            "volume data": 3,
            "surface data": 3,
            "volume interpolate": 3,
            "checkpoint": 3,
```

(continues on next page)

(continued from previous page)

```

        # Start output every 3 cycles after 1 cycle (default = 1)
        "volume data start": 1
        "surface data start": 1,
        "volume interpolate start": 1,
        "checkpoint start": 1,
    },
},
..
}

```

1.4.13 Reporting

zCFD has the capability to output certain parameters to a <casename>_report.csv file as the solver progresses. These can be used to monitor the solver's convergence. By default, the solver outputs volume integrated residuals for each solution variable to the <casename>_report.csv file, but adding to the report dictionary means other quantities of interest can also be monitored as the simulation progresses.

Keyword	Re-quired	Default	Valid values
'frequency'	Yes	1	Positive integer
'monitor'	No	–	Dictionary of monitor point configs (MR_?)
'forces'	No	–	Dictionary of force configs (FR_?)
'massflow'	No	–	Dictionary of massflow configs (MF_?)

'frequency' sets how frequently a new line is appended to the <casename>_report.csv dictionary. If frequency = x, the solver will output to the <casename>_report.csv every x solver cycles. For a dual time-stepping simulation, this is the inner (pseudo-time), not outer, cycles.

'monitor', **'forces'** and **'massflow'** should be dictionaries of the required format. The dictionary's keys should be consecutively numbered blocks prefixed with the correct string:

Reporting on	Key name
'monitor'	MR_?
'forces'	FR_?
'massflow'	MF_?

Example usage:

For a simulation with 1000's of cycles, it can be unnecessary to report every time cycle, which slows the solver down. For a dual timestepping simulation with 20 inner time cycles, outputting every 10 cycles generally gives enough information without substantially slowing the solver down

```

# Report every 10 cycles
'report' : {
    ...
    'frequency': 10
    ...
}

```

A simulation with two monitor points and one forces block.

In addition to standard flow field outputs (see below), zCFD can provide information at monitor points in the flow domain, and integrated forces across all parallel partitions, any number of 'MR_', 'FR_' or 'MF_' blocks may be specified.

```
# Report every 10 cycles
'report' : {
  ...
  'frequency': 10
  'monitor' {
    'MR_1': {
      ...
    },
    'MR_2': {
      ...
    },
  }
  'forces' {
    'FR_1': {
      ...
    }
  }
  ...
}
```

Monitor Points

Monitor points report the specified variable at fixed mesh locations.

Keyword	Re-quired	Default	Valid values
'name'	Yes	–	String; Name of the monitor point
'point'	No	–	[x,y,z] position vector specifying a valid location in the mesh
'variables'	No	–	List of variables to report (see Output Variables)

'name' sets the name that appears in the <casename>_report.csv column heading for variables from this monitor point.

'point' should be the x,y,z location of the point of interest in the mesh as it appears in the solver (i.e. after any mesh scaling due to parameters *scaling* parameters)

'variables' controls which variables are reported at this point. In the <casename>_report.csv the column name will be a combination of the **'name'** and the variable name.

Example usage:

Tracking pressure and velocity is useful for determining shedding cycle behaviour, or in the case of a scale resolving simulation, to determine the turbulence spectrum which is being resolved. It may be important to track other variables (e.g. turbulence intensity) may also be appropriate depending on the simulation setup.

```
'report' : {
  'frequency' : 10,
  'monitor' : {
    'MR_1' : {
```

(continues on next page)

(continued from previous page)

```

        'name' : 'monitor_1',
        'point' : [180.0, 100.0, 50.0],
        'variables' : ['V','p','T',"Ti"],
    },
},

```

Forces

Force reporting outputs the x,y,z total forces and moments on a surface or set of surfaces. These are presented as force coefficients (using the non-dimensionalisation convention used for aerofoil lift, drag and moment coefficients), as opposed to dimensional values. The force and moment coefficients resulting exclusively from viscous forces and exclusively from pressure forces are also given.

Keyword	Required	Default	Valid values	Description
'name'	Yes	–	String	Sets the name that appears in the <casename>_report.csv column headings for variables from this force monitor.
'zone'	Yes	–	List of valid mesh zone IDs (integers)	All the mesh zone IDs for the surfaces used in this force report. The forces and moments over all the zones are summed to give the forces and moments outputted in the force report.
'transform'	No	–	An (optional) transform function.	See Transform function . A transformation function may be supplied to the force report block to transform the force into a different coordinate system.
'reference area'	No	–	Positive number	Sets the dimensional reference area which is used to non-dimensionalise the reported force and moment coefficients
'reference length'	No	–	Positive number	Sets the dimensional reference length which is used to non-dimensionalise the moment coefficients
'reference point'	No	–	[x,y,z] position vector	Sets the reference point which is used to non-dimensionalise the moment coefficients
'reference pressure'	No	–	Positive number	For a wetted surface, this sets the pressure on the non-wetted side of the surface. Pressure forces on the surface are calculated by integrating (p - pRef) over the surface

Example usage:

```

'report' : {
    'frequency' : 10,
    # Report force coefficient in grid axis as well as using user defined
    -transform
    'forces' : {

```

(continues on next page)

(continued from previous page)

```

        'FR_1' : {
            'name' : 'force_1',
            # Required: Zones to be included
            'zone' : [1, 2, 3],
            # Transformation function
            'transform' : my_transform,
            'reference area' : 0.112032,
            'reference length' : 1.0,
            'reference point' : [0.0, 0.0, 0.0],
            # Calculate forces using a specified reference pressure
            'reference pressure': 0.0
        },
    },
},

```

→ rather than absolute

Output names

The forces will be written into the <casename>_report.csv prefixed with the supplied **'name'**. The forces will be written with the following names:

Item	Reporting output name
Total forces and moments	'name' _F[x,y,z] and 'name' _M[x,y,z]
Forces and moments due only to pressure forces	'name' _Fp[x,y,z] and 'name' _Mp[x,y,z]
Forces and moments due only to viscous forces	'name' _Fv[x,y,z] and 'name' _Mv[x,y,z]
Transformed total forces and moments (if transform function is set)	'name' _Ft[x,y,z] and 'name' _Mt[x,y,z]
Transformed forces and moments due only to pressure forces (if transform function is set)	'name' _Ftp[x,y,z] and 'name' _Mtp[x,y,z]
Transformed Forces and moments due only to viscous forces (if transform function is set)	'name' _Ftv[x,y,z] and 'name' _Mtv[x,y,z]
Total forces and moments in static frame of reference (if specified zone is rotating)	'name' _Fif[x,y,z] and 'name' _Mif[x,y,z]
Forces and moments due only to pressure forces in static frame of reference (if specified zone is rotating)	'name' _Fifp[x,y,z] and 'name' _Mifp[x,y,z]
Forces and moments due only to viscous forces in static frame of reference (if specified zone is rotating)	'name' _Fifv[x,y,z] and 'name' _Mifv[x,y,z]

Additional information

Total force

Total force, \mathbf{F} , is simply , $\mathbf{F}_p + \mathbf{F}_v$, and likewise for moments.

Non-dimensionalisation

Forces are non-dimensionalised into force coefficients as $C_x = \frac{\mathbf{F}_x}{q_{\text{inf}} S}$ Where q_{inf} = reference dynamic pressure and S = reference area

Moments are non-dimensionalised into force coefficients as $C_{Mx} = \frac{\mathbf{M}_x}{q_{\text{inf}} S c}$ Where c = reference length

Dimensional pressure force

$$\mathbf{F}_p = \oint -(p - p_{\text{ref}}) \hat{\mathbf{n}} \, dA$$

Where p is surface pressure and $\hat{\mathbf{n}}$ is the surface normal (pointing towards the wetted area).

Dimensional viscous force

$$\mathbf{F}_v = \oint \mu \nabla \cdot \mathbf{V} \, dA$$

Where μ is dynamic viscosity and \mathbf{V} is the velocity vector at the wall.

Dimensional pressure moment

$$\mathbf{M}_p = \oint -(p - p_{\text{ref}}) \hat{\mathbf{n}} (x - x_{\text{ref}}) \, dA$$

Dimensional viscous moment

$$\mathbf{M}_p = \oint \mu \nabla \cdot \mathbf{V} (x - x_{\text{ref}}) \, dA$$

Note: Reference pressure p_{ref} is dynamic pressure ($\frac{1}{2} \rho V^2$), taken from the *reference state*.

Mass flow

Keyword	Required	Default	Valid values	Description
'name'	Yes	–	String	Sets the name that appears in the <casename>_report.csv column headings for variables from this force monitor.
'zone'	Yes	–	List of valid mesh zone IDs (integers)	All the mesh zone IDs used in this mass flow monitor

`name` Sets the name that appears in the <casename>_report.csv column heading for variables from this mass flow monitor. For example, setting this to 'pipe_outflow' would mean the massflow would appear as 'pipe_outflow_massflow' in the <casename>_report.csv file

‘zones’ The mass flows through all the zones are summed to give a single output value for the mass flow monitor. Flow out of the domain is considered positive massflow, flow into the domain is considered negative massflow and the massflows are dimensional (typically kg per second).

Example usage:

```
'report' : {
  'frequency' : 10,
  # Report massflow ratio
  'massflow' : {
    'MF_1' : {
      # Output name
      'name' : 'massflow_1',
      # Zones to be included
      'zone' : [1, 2 ,3],
    },
  },
},
```

1.4.14 Output variables

Output Variables

Variable Name	Alias	Definition
temperature	T, t	Temperature in (K)
temperaturegrad		Temperature gradient vector
potentialtemperature		Potential temperature in (K)
pressure	p	Pressure (Pa)
gauge_pressure		Pressure relative to the reference value (Pa)
density	rho	Density (kg/m ³)
velocity	V, v	Velocity vector (m/s)
velocitygradient		Velocity gradient tensor
cp		Pressure coefficient
totalcp		Total pressure coefficient
mach	m	Mach number
viscosity	mu	Dynamic viscosity (Pa/s)
kinematicviscosity	nu	Kinematic viscosity (m ² /s)
vorticity		Vorticity vector (1/s)
Qcriterion		Q criterion
reynoldstress		Reynolds stress tensor
helicity		Helicity
enstrophy		
ek		
lesregion		
turbulenceintensity	ti	Turbulence intensity
turbulencekineticenergy		Turbulence kinetic energy (J/kg)
turbulenceddyfrequency		Turbulence eddy frequency (1/s)
eddy		Eddy viscosity (Pa/s)
cell_velocity		
cellzone		
cellorder		
centre		Cell centre location
viscouslengthscale		Minimum distance between cell and its neighbours
walldistance		Wall distance (m)
sponge		Sponge layer damping coefficient

continues on next page

Table 2 – continued from previous page

Variable Name	Alias	Definition
menterfl		Menter SST blending function

Surface Only Quantities

Variable Name	Alias	Definition
pressureforce		Pressure component of force on a face
pressuremoment		Pressure component of moment on a face
pressuremomentx		Component of pressure moment around x axis
pressuremomenty		Component of pressure moment around y axis
pressuremomentz		Component of pressure moment around z axis
frictionforce		Skin friction component of force on a face
frictionmoment		Skin friction component of moment on a face
frictionmomentx		Component of skin friction moment around x axis
frictionmomenty		Component of skin friction moment around y axis
frictionmomentz		Component of skin friction moment around z axis
roughness		Wall roughness height
yplus		Non-dimensional wall distance
zone		Boundary zone number
cf		Skin friction coefficient
facecentre		Face centre location
frictionvelocity	ut	Friction velocity at the wall

1.5 zCFD Functions

Several parameters in the zCFD control dictionary will accept functions as arguments. These functions are then evaluated by the solver when required. This allows you to customise & tune to solver as it runs.

1.5.1 Scale Mesh Function

Description	Transform the location of a supplied point.
Valid for parameter	<i>scale_mesh</i>
Parameters	[x, y, z]: Point to transform
Returns	{'coord': [x, y, z]}: Transformed coordinates

Example:

```
# Custom function to scale z coordinate by 100
def my_scale_func(point):
    point[2] = point[2] * 100.0
    return {'coord': point}
```

```
parameters = {
    ...
    'scale': my_scale_func
    ...
}
```


1.5.2 Transform Mesh Function

Description	Transform the location of a supplied point.
Valid for parameter	<i>mesh transform func</i>
Parameters	[x, y, z]: Point to transform
Returns	{"v1": x, "v2": y, "v3": z}: Transformed coordinates

Example:

```
rotation = 10.0

def my_transform(x, y, z):
    v = [x, y, z]
    v = zutil.rotate_vector(v, rotation, 0.0)
    return {"v1": v[0], "v2": v[1], "v3": v[2]}
```

1.5.3 Ramp CFL Function

There may be cases where more detailed control of the CFL number is desired - for example in some aerodynamic simulations where a specific physical event occurs at a given time. The CFL Ramp function lets you do this.

The ramp function returns a single floating point number (the CFL number) and can also be used to update elements of the 'cfl' Python object such as cfl.min_cfl, cfl.max_cfl, cfl.current_cfl, cfl.coarse_cfl, cfl.transport_cfl, cfl.cfl_ramp, cfl.cfl_pmg, or cfl.transport_cfl_pmg.

Description	Provide a dynamic CFL number
Valid for parameter	<i>ramp func</i>
Parameters	solve_cycle, real_time_cycle, cfl
Returns	cfl: float

Example:

```
# Custom function to ramp CFL based on cycle, updates the cfl object variables and
↳ returns a CFL
def my_cfl_ramp(solve_cycle, real_time_cycle, cfl):
    cfl.min_cfl = 1.0
    cfl.max_cfl = 10.0
    cfl.cfl_ramp = 1.005
    cfl_transport = 5.0
    if solve_cycle < 500:
        cfl_new = min(cfl.min_cfl * cfl.cfl_ramp ** (max(0, solve_cycle - 1)), cfl.max_
↳ cfl)
        cfl.transport_cfl = cfl_transport * cfl_new / cfl.max_cfl
        return cfl_new

    elif solve_cycle < 1000:
        cfl.transport_cfl = 7.5
        cfl.max_cfl = 15.0
        return 15.0

    else:
        cfl.transport_cfl = 10.0
        cfl.max_cfl = 30.0
        return 30.0
```

```
parameters = {
    ...
    'time marching': {
        ...
        'ramp func': my_cfl_ramp,
        ...
    }
    ...
}
```

1.5.4 Transform Function

A transformation function may be supplied to the force report block to transform the force into a different coordinate system. This is particularly useful for reporting lift and drag, which are often rotated from the solver coordinate system.

Description	Transform a supplied point - rotate, scale or translate.
Valid for parameter	<i>Forces transform</i>
Parameters	(x, y, z): floats
Returns	(x, y, z): floats

Example:

```
#zutil is a Zenotech python library providing various utilities, available within a
↳zCFD installation
import zutil

# Angle of attack
alpha = 10.0
# Transform into wind axis
def my_transform(x,y,z):
    v = [x,y,z]
    v = zutil.rotate_vector(v,alpha,0.0)
    return {v[0], v[1], v[2]}
```

1.5.5 Initialisation Function

Description	Provide the initial flow field variables on a cell-by-cell basis
Valid for parameter	<i>initial</i>
Parameters	kwargs dictionary containing “pressure”, “temperature”, “velocity”, “wall_distance”, “location”
Returns	dictionary containing one or more of “pressure”, “temperature” or “velocity”

```
def my_initialisation(**kwargs):
    # Dimensional primitive variables
    pressure = kwargs['pressure']
    temperature = kwargs['temperature']
    velocity = kwargs['velocity']
    wall_distance = kwargs['wall_distance']
    # Cell centre location [X, Y, Z]
```

(continues on next page)

(continued from previous page)

```
location = kwargs['location']

if location[0] > 10.0:
    velocity[0] *= 2.0

# Return a dictionary with user defined quantity.
return { 'velocity' : velocity }
```

```
parameters = {
    ...
    'initial': {
        ...
        'func': my_initialisation,
        ...
    }
    ...
}
```

1.5.6 Driven initial condition

A ‘driving function’ provides another way of prescribing a farfield initial condition, which on evaluation returns an initial condition dictionary.

The driving function is re-evaluated at zCFD’s reporting frequency, meaning that the condition (e.g. inlet velocity) can be programmed to change as the simulation progresses.

At startup, the function is only provided with the key word arguments `RealTimeStep=0`, `Cycle=0`. However, the driving function is subsequently provided with key word arguments containing all the data in the ‘_report.csv’ file, evaluated at the previous timestep. For any driven initial condition, every value in the initial condition dictionary is also appended to the _report.csv file.

This means that the initial condition can be programmed to respond to the flow. An example is shown below, where the driven IC will continually adjust inlet angle of attack until a specified lift coefficient is achieved.

If the driven initial condition has been programmed to respond to changes in the flow, it is important to ensure that the flow has had enough time to propagate from the farfield through to the region of interest and settle before readjusting the driven initial condition. For simulations where the farfield is distant from the geometry, local and implicit time-stepping will likely give the fastest propagation of adjusted farfield conditions through the domain.

Note: Driven initial conditions **cannot** be used as reference conditions, to initialise the flow (e.g. ‘IC_1’) or within a restarted simulation.

Description	Provides a farfield initial condition that can respond to changes in the flow.
Valid for parameter	<i>initial condition</i>
Parameters	kwargs dictionary containing “RealTimeStep”, “Cycle” and all reporting variables
Returns	dictionary containing valid keys for an <i>initial condition</i>

```
def example_ic_func(**kwargs):
    """
    Example driver function to target a lift coefficient by varying
    angle of attack
    """
```

(continues on next page)

(continued from previous page)

```

alpha_init = 0 # Initial angle of attack
lift_target= 0.5 # Targeted lift coefficient
update_period = 1000 # How often alpha should be updated
flow_settling_period = 1500

assumed_d_cL_d_alpha = 0.1 # Used to estimate alpha which would give required lift
relaxation_factor = 1.15 # <1: under-relaxation, >1: over-relaxation

if 'lift_target_alpha' in kwargs.keys(): # If timestep > 1
    alpha_current = kwargs['lift_target_alpha']
    F_xyz = [kwargs['wall_Fx'], kwargs['wall_Fy'], kwargs['wall_Fz']]
    F_LDS = zutil.rotate_vector(F_xyz, alpha_current, 0.0)
    lift_current = F_LDS[2] # Lift coefficient, having rotated to account for alpha
else:
    lift_current = 0 # placeholder value

if kwargs['Cycle'] < flow_settling_period:
    alpha_new = alpha_init
else:
    if (kwargs['Cycle'] % update_period) == 0:
        d_cL_required = lift_target - lift_current
        d_alpha = relaxation_factor / assumed_d_cL_d_alpha * d_cL_required
        alpha_new = alpha_current + d_alpha
        print("Alpha updated from {} to {}".format(alpha_current, alpha_new), flush_
    else:
        alpha_new = alpha_current

dict_out = {
    "temperature": 300,
    "pressure": 101325.0,
    'v': {
        'mach' : 0.15,
        'vector' : zutil.vector_from_angle(alpha_new, 0.0)
    },
    "reynolds no": 6.0e6,
    "eddy viscosity ratio": 1.0,
    "monitor": { # Monitor entries can be floats or lists of floats
        "prefix": "lift_target",
        "alpha": alpha_new, # Extra keys can be added to a driven IC
    },
    "lift": lift_current, # allowing monitoring of key parameters
}

return dict_out

```

```

parameters = {
    ...
    'IC_2' : example_ic_func
    ...
}

```

1.5.7 Static Pressure Ratio

The python function takes in three values (x, y, z) and returns the static pressure ratio.

Description	Returns a static pressure ratio for a given point.
Valid for parameter	<i>Static Pressure Ratio</i>
Parameters	(x, y, z): floats
Returns	float

1.5.8 Total Pressure Ratio

The python function takes in three values (x, y, z) and returns the total pressure ratio.

Description	Returns a total pressure ratio for a given point.
Valid for parameter	<i>Total Pressure Ratio</i>
Parameters	(x, y, z): floats
Returns	float

1.5.9 Total Temperature Ratio

The python function takes in three values (x, y, z) and returns the temperature pressure ratio.

Description	Returns a total temperature ratio for a given point.
Valid for parameter	<i>Total Temperature Ratio</i>
Parameters	(x, y, z): floats
Returns	float

1.5.10 Direction Vector

The python function takes in three values (x, y, z) and returns a tuple (x, y, z).

Description	Returns a direction vector for a given point.
Valid for parameter	<i>vector</i>
Parameters	(x, y, z): floats
Returns	(x, y, z): floats

```
def inflow_direction(x, y, z):
    # x, y, and z are the coordinates of the face centre
    cen = [1.0, 0.0, 0.0]
    y1 = y - cen[1]
    z1 = z - cen[2]
    rad = math.sqrt(z1*z1 + y1*y1)
    phi = math.atan2(y1,z1)
    angle = -0.24
    x2 = math.cos(angle)
    y2 = math.sin(phi) * math.sin(angle)
    z2 = math.cos(phi) * math.sin(angle)
    return (x2, y2, z2)
```

```
parameters = {  
    ...  
    'IC_2' : {  
        'reference' : 'IC_1',  
        'vector' : inflow_direction  
    },  
    ...  
}
```

1.6 Mesh Conversion

zCFD uses unstructured meshes written in an [HDF5](#) file format. HDF5 provides a flexible, self describing specification supporting parallel I/O that can be tuned per filesystem type (e.g NFS, GPFS, Lustre etc).

Meshes from a wide variety of sources can be easily converted into this format as follows:

1.6.1 OpenFOAM-x.x.x

We provide a range of converters for popular mesh types via a special version of the open-source CFD code OpenFOAM, available freely for download [here](#)

Once downloaded and installed, the version of OpenFOAM will convert a range of file formats to the zCFD format. Prior to running any of these, you will need to activate your OpenFOAM environment using

```
source $FOAM_INST_DIR/OpenFOAM-x.x.x/etc/bashrc
```

1.6.2 OpenFOAM Mesh Converter

To convert from an OpenFOAM format mesh to zCFD, run the following command in the MESH directory.

```
foamTozCFD
```

This will create a new folder called *zInterface/* containing the HDF5 file.

1.6.3 Fluent Mesh Converter

The converter for [ANSYS Fluent](#) files is a utility called *fluent_convert*. This is included in the path set by activating the zCFD command line environment.

To run the utility, use

```
(zCFD): fluent_convert <filename>.msh <new_filename>.h5
```

or

```
(zCFD): fluent_convert <filename>.cas <new_filename>.h5
```

The will produce 2 files: the zCFD HDF5 file and the *name_zone.py* python file which holds the fluid and boundary zone names.

1.6.4 Star CCM+ Mesh Converter

There are a number of different file formats for CD-Adapco Star CCM+ meshes. The `<filename>.sim` file is in a proprietary format and at this stage cannot be converted. The `<filename>.ccm` can be converted using

```
(zCFD): ccmconvert <filename>.ccm <new_filename>.h5
```

This produces the zCFD HDF5 file.

1.6.5 CGNS Mesh Converter

This utility will convert an unstructured, non-chimera, hexahedral mesh in CGNS (ref) format. The converter will handle meshes with element types (HEXA_8):

```
(zCFD): cgnsconvert <filename>.cgns <new_filename>.h5
```

This produces the zCFD HDF5 file. If you require support for additional element types please contact us: <mailto:zcfid@zenotech.com>.

1.6.6 UGRID Mesh Converter

UGRID is a NASA format for meshes. You must follow the naming convention for UGRID files, which describes the format and *endian-ness* of the file data ("ascii8", "b8", "lb8", or "r8") depending upon which language (C or FORTRAN) was used to create the file. The mapbc file is optional and if not provided the boundary conditions of the zones default to wall.

```
(zCFD): ugridconvert <filename>.[ascii8, b8, lb8, r8].ugrid <new_filename>.h5
-><filename>.mapbc
```

This produces the zCFD HDF5 file.

1.6.7 DLR Tau Mesh Converter

Tau is a CFD solver produced by the DLR (<http://tau.dlr.de/startseite/>). Note that Tau is a node-based solver so flow field variables are calculated for and stored at the mesh nodes (or vertices) rather than at cell centres (the approach used by Star CCM+, OpenFOAM, CFX and zCFD). Thus simply converting the file format will not guarantee a good result. In many cases, the conversion will not result in a valid cell-centred zCFD mesh.

```
(zCFD): tauconvert <filename>.XXX <new_filename>.h5
```

This produces the zCFD HDF5 file.

1.6.8 SU2 Mesh Converter

SU2 is an open source CFD solver (<https://su2code.github.io/>). Note that conversion of 2D meshes is not supported as they are not handled in zCFD.

```
(zCFD): su2convert <filename>.su2 <new_filename>.h5
```

This produces the zCFD HDF5 file.

1.6.9 CBA Mesh Converter

CBA is a structured multiblock mesh format used within the University of Bristol and HMB projects. Note 2D meshes will have a symmetry plane added to extend them into 3D for use in zCFD.

```
(zCFD): cba_convert <filename>.[cba, blk] <new_filename>.h5
```

This produces the zCFD HDF5 file.

1.7 Visualisation

zCFD by default will output data in **VTK** format. This format can be read directly by many post-processing tools including **ParaView** by Kitware.

Output in other formats is also possible, including **TECPLOT** and **EnSight** as follows:

1.7.1 VTK Output

By default, zCFD will output data in VTK format. To explicitly force VTK output, use the following option in the 'write output' part of the control dictionary:

```
'write output' : {  
    # Output format  
    'format' : 'vtk',
```

1.7.2 EnSight Output

To output in EnSight format, use the following option in the 'write output' part of the control dictionary:

```
'write output' : {  
    # Output format  
    'format' : 'ensight',
```

1.7.3 Native HDF5 Output

To output in HDF5 format (the native format for zCFD), use the following option in the 'write output' part of the control dictionary:

```
'write output' : {  
    # Output format  
    'format' : 'native',
```

1.7.4 ParaView Catalyst Scripts

ParaView provides a powerful yet lightweight interface that allows parallel processing of simulation data during programme execution called **ParaView Catalyst**. This is driven by scripts (Python files) that can be called when data is output:

```
'write output' : {  
    # Output format MUST be VTK  
    'format' : 'vtk',  
    # The scripts should be in the same directory as the input files  
    'scripts' : ['paraview_catalyst1.py', 'paraview_catalyst2.py']
```


1.7.5 ParaView Client

To download the free ParaView software for visualising VTK format data on the local device, just visit the [Paraview website](#).

1.7.6 ParaView Client-Server

In addition to running entirely locally on a device, ParaView can interface to a remote server. This allows users to run ParaView to access data that is held (and processed) on a different computer, potentially running larger simulation tasks that would be possible on the local machine. This also means that there is no need to transfer the large output files back to a local machine for post-processing. The remote machine can easily be set up to run a ParaView Server in parallel - meaning that very large post-processing jobs can be run quickly.

ParaView Server

To download and install ParaView Server, you can either use the version on the main ParaView website and follow the instructions [here](#).

Alternatively or else use the version bundled with zCFD. The 'pvserver' included in the zCFD distribution includes plugins for reading the zCFD HDF5 mesh format directly.

To start a ParaView Server on your computer within the zCFD environment run:

```
> pvserver
```

ParaViewConnect

[ParaviewConnect](#) is a helper utility for connecting to remote ParaView servers. It reduces the complexity of setting up the required ssh connections and works well with zCFD. More information and installation instructions can be found on the [Github page](#).

1.7.7 Jupyter Notebooks

We also recommend the use of [Jupyter Notebooks](#) for post-processing zCFD runs. This is one of the easiest ways to use Python, via an interactive notebook on your local computer. The notebook is a locally hosted server that you can access via a web-browser. Jupyter is included in the zCFD distribution and notebooks for visualising the residual data will automatically be created when you run a zCFD case. In addition there are several example notebooks available in the [zPost](#).

To automatically start up notebook server on your computer within the zCFD environment run:

```
> start_notebook
```

1.8 Utilities

zCFD is bundled with a number of utility functions to streamline specific workflows:

1.8.1 Windfarm Modelling

Overview

Windfarms consist of a set of specific turbine types at geographic locations. zCFD allows users to specify the turbine characteristics and locations, and will automatically create turbine models within an existing mesh and update the local flow conditions to match the thrust coefficient and tip speed ratio for each turbine.

The locations and TRBX turbine definition

zCFD provides a utility function `create_trbx_zcfd_data` that can be called from within the zCFD environment and Python interactive shell. To start the zCFD command line environment, type:

```
> source /INSTALL_LOCATION/zCFD-version/bin/activate
```

The command prompt will now appear with a (zCFD) prefix. To run the `create_trbx_zcfd_data` utility, start the interactive Python shell:

```
> (zCFD) > python
```

The utility takes several arguments, depending on the turbine model to be used. For *simple* and *induction* models (where a reference velocity point is used to set the power, thrust and torque for the turbine) the function is used to look up data in a *TRBX* file format:

```
import zutil.farm as farm
farm.create_trbx_zcfd_input(case_name='windfarm_name',
                           wind_direction=267.0,
                           reference_wind_speed=10.0,
                           terrain_file=None,
                           report_frequency=100,
                           update_frequency=1,
                           reference_point_offset=1.0,
                           turbine_zone_length_factor=2.5,
                           model='simple',
                           turbine_files=[['xy_file_1.txt', 'turbine_type_1.trbx'],
                                           ['xy_file_2.txt', 'turbine_type_2.trbx']])
```

The utility will read each `[<xy_file>, <trbx_file>]` pair provided. The terrain file is any file format that can be read by ParaView (STL, VTK) to use as the basis for the ground level at any given location. The default 'None' sets ground level to 0. The model uses a reference velocity at a point upstream of the turbine. The point is offset upstream by a factor applied to the rotor diameter. The fluid zone associated with the turbine is a cylinder with diameter equal to the rotor diameter and length given by the turbine zone length factor. The model is either an *induction* model where the induction factor is automatically calculated from the thrust coefficient and 1D momentum theory, or the *simple* model where the reference velocity is equal to the velocity at the rotor. The `<xy_file>` is a 3-column data file in ASCII format with `<turbine name>`, `<easting>` and `<northing>` data such as:

```
T001 251865.0 646486.0
T002 252240.0 646200.0
...
T015 253308.0 647985.0
```

The TRBX file is a data file with turbine information provided by manufacturers including a description of the turbine geometry and aerodynamic performance characteristics.

The utility extracts key information from the TRBX file to automatically create a turbine definition (`<case_name>_zones.py`) with an entry for each turbine in the array:

```
turb_zone = {
    'FZ_1':{
        'type': 'disc',
        'def': './turbine_vtp/T001-267.0.vtp',
        'thrust coefficient': 0.821,
        'thrust coefficient curve': [[0.0, 0.0], [1.0, 0.0], ..., [51.0, 0.0]],
        'tip speed ratio': 8.79645943005,
        'tip speed ratio curve': [[0.0, 0.0], [1.0, 0.0], ..., [51.0, 0.0]],
        'centre': [251865.0, 646486.0, 338.5],
        'up': [0.0, 0.0, 1.0],
        'normal': [-0.998629534755, -0.0523359562429, -0.0],
        'inner radius': 1.95500004292,
        'outer radius': 60.0,
        'reference point': [251745.164456, 646479.719685, 338.5],
    },
    ...
}
```

The *'thrust coefficient'* may be defined as a single value, and if a data point curve is present in the TRBX file this data is also supplied as the tuple array *'thrust coefficient curve'*, where the wind speed in metres per second is the index. If this curve is provided, the utility will interpolate the curve at the reference speed to create the single value otherwise a default value (10 m/s) is used.

The same approach is taken for the *'tip speed ratio'* single value and curve - which is automatically calculated from the rotor speed array (revolutions per minute) in the TRBX file.

The *'reference point'* defines the location in the flow domain that is used as the reference value of wind velocity for this turbine. This velocity is used in combination with the thrust coefficient and the tip speed ratio for zCFD to calculate the momentum sources associated with the turbine. By default the reference point is automatically located 1.0 turbine diameters upstream of the disc centre, assuming that the reference wind direction is also the local wind direction. This is easy to modify.

The *'centre'* is the centre of the disc, which is automatically determined from the nominal hub height in the TRBX file as an offset to the ground height at the specified location. The local ground height is automatically determined from a supplied VTK files, or from a previous solver run. Note that the VTK ground data can be created with a single cycle of the solver, and does not need to include any turbines.

The vertical orientation is defined by the *'up'* vector - normally this will be the unit vector in the z-direction. The *'normal'* defines the vector perpendicular to the disc. The inner and outer radii are based on the TRBX definition of the size of the disc. No account is made of the hub or tower geometry.

For the *blade element model* the TRBX file is replaced with a dictionary that contains information about the blades and aerofoil sections used on the rotor, plus information that can be specified to inform the controller how to adjust the rotation rate and blade pitch each cycle:

```
farm.create_trbx_zcfd_input(
    case_name='windfarm_name',
    wind_direction=280.0,
    reference_wind_speed=8.0,
    terrain_file=None,
    report_frequency=100,
    update_frequency=1,
    turbine_zone_length_factor=2.5,
    model='blade element theory',
    turbine_files=[['data/xy_file_1.txt', bet_dict_1],
                  ['data/xy_file_2.txt', bet_dict_2]],
)
```

The *xy_file* is as above and the *bet_dict* is a Python dictionary with details of the rotor and blade, including sectional aerodynamic characteristics and dimensions:

```
bet_dict = {
    'name': 'T001',
    'status': 'on',
    'number of blades': 3,
    'rotation direction': 'clockwise',
    'hub height': 70.0,
    'inner radius': 4.0,
    'outer radius': 40.0,
    'rated power': 2000000.0,
    'tip speed limit': 80.0,
    'verbose': False,
    'tilt': 6.0,
    'yaw': 0.0,
    'auto yaw': True,
    'cut in speed': 4.0,
    'cut out speed': 25.0,
    'number of segments': 12,
    'up': [0.0, 0.0, 1.0],
    'airfoil profile':
        {'source': 'http://airfoiltools.com/airfoil/details?airfoil=n63415-il',
         'upper surface': [[0.0, 0.0], [0.003, 0.01287], ..., [0.95028, 0.00931], [1.
-0, 0.0]],
         'lower surface': [[0.0, 0.0], [0.007, -0.01087], ..., [0.94972, 0.00333], [1.
-0, 0.0]]},
    'airfoil cl': [[-90.0, -0.0], [-49.869, -0.202], ..., [49.907, 1.823], [90.0, 0.
-0]],
    'airfoil cd': [[-90.0, 2.0], [-70.099, 1.796], ..., [60.11, 1.645], [90.087, 1.
-996]],
    'blade chord': [[0.0, 0.1], [0.1, 0.1], ..., [0.7, 0.034], [1.0, 0.018]],
    'blade twist': [[0.0, 21.924], [0.1, 21.924], ..., [0.7, 2.461], [1.0, 0.023]],
    'blade pitch range': [-10.0, 10.0],
    'blade pitch': 1.0,
    'blade pitch tol': 0.01,
    'blade pitch step': 0.1,
    'mean blade material density': 200.0,
    'blade pitch tol': 0.01,
    'dt': 0.2,
    'inertia': True,
    'damage ti': 0.15,
    'damage speed': 10.0,
    'friction loss': 0.01,
    'thrust factor': 1.10,
    'tip loss correction': 'acos-fit',
    'rpm ramp': [[4.0, 6.0], [13.0, 16.0]],
}
```

The *'name'* key is used to tag results associated with the turbine.

The *'status'* key indicates whether the turbine should be active or not. This makes it straightforward to turn a turbine off without regenerating the model. The *'number of blades'* is typically 3 (which is also the default value) but some turbines have 2 blades. The *'rotation direction'* is typically clockwise (when viewed from the front) for modern turbines, but the keyword values allow *'clockwise'* or *'anticlockwise'*. This alters the rotation of the wake.

The *'hub height'*, *'inner radius'* and *'outer radius'* define the vertical offset from the ground in metres, and the rotor dimensions respectively as above. The *'rated power'* (Watts) of the turbine defines an operating limit of power production that will not be exceeded.

The *'tip speed limit'* is an environmental limit on the rate or rotor rotation, and is typically set to 80m/s. Note

that the tip speed is based on the absolute rotation rate of the rotor, and the actual tip speed relative to the air may be increased by angular induction.

The model can produce various diagnostics. Setting *'verbose'* to *True* will output these.

The rotor *'tilt'* is an upward rotation of the entire rotor, to allow for tower clearance under blade deflection. The value is typically a few degrees. The *'yaw'* is a rotation angle in degrees from the prescribed wind direction, with the option to specify *'auto yaw'* which will automatically over-ride the *'yaw'* value with a rotation into the local (disc average) wind direction. A warning is issued if *'auto yaw'* requests a *'yaw'* value exceeding 10 degrees in either direction.

The manufacturer typically specifies a *'cut in speed'* and *'cut out speed'* range for the local reference wind speed (for blade elements this is the average windspeed on the rotor disc). The rotor is automatically stowed outside these limits.

The *'number of segments'* defines the resolution of the actuator disc discretisation (not the computational domain mesh) with a default value of 12.

The *'aerofoil profile'* is used to integrate the blade unit sectional area between the *'upper surface'* and *'lower surface'* over the range $[0,1]$. Once integrated, the value is stored in the turbine zone dictionary. The optional *'source'* can be provided as a reference for the data. The sectional area multiplied by local radius is integrated over the length of each blade and multiplied by the *'mean blade material density'* (kilograms per cubic metre, typically 200.0) to provide a value for the *'rotor moment'*.

The turbine controller assumes that the physical time between iterations is *'dt'*. This does not have to be equal to the CFD timestep. If *'inertia'* is *True* then the available torque is divided by the *'rotor moment'* to determine the rotor acceleration. Otherwise the rotor is accelerated with a 10% increase in rotational rate capped per iteration. When the rotor is positively accelerated, half of the available torque is used to accelerate the rotor and half is supplied to the generator (unless doing so would exceed the rated power). This is an arbitrary value and it is expected that users will modify this behaviour when modelling more sophisticated control laws.

The aerodynamic characteristics of the aerofoil section are critical to the blade element theory model and are not calculated automatically. These should be specified as points on the *'aerofoil cl'* (local lift coefficient) and *'aerofoil cd'* (local drag coefficient) curves over a range of angles of attack in degrees covering at least $(-30,30)$. Values beyond this range will be extrapolated as needed.

The *'blade chord'* is the local chord length in metres used to scale the aerofoil along the normalised blade length $[0,1]$. The *'blade twist'* is the twist angle in degrees of the blade over the normalised blade length $[0,1]$.

The turbine controller will automatically optimise the power production (up to the limit) by pitching the blades over the range *'blade pitch range'* in degrees using a Golden Section Search to a tolerance of *'blade pitch tol'* degrees. All blades are pitched equally and the optimum pitch value accounts for the contribution of all blades averaged over the disc. The *'blade pitch'* can be set initially and a step size limit *'blade pitch step'* can be set to the range over which the blade pitch is optimised to within *'blade pitch tol'* on each iteration. Typically the blades are pitched to their maximum setting on startup and then the pitch value is reduced as the rotor accelerates. A negative value of *'blade pitch'* may be achieved at high rates of rotation as the local angle of attack of the blade will still be positive. A warning is issued if the aerofoil angle of attack is less than zero anywhere on the rotor.

The turbine controller will determine whether (anywhere on the disc) the *'damage ti'* (turbulence intensity) and *'damage speed'* are simultaneously exceeded. If so, a warning is issued and the rotor is stowed. It is intended that this function may be modified by users to provide more sophisticated controller rules and wind farm behaviour.

To account for frictional losses in the system, 1% (or other value of *'friction loss'*) is applied to the rate of rotor rotation each iteration.

The *'blade element theory'* fluid zones follow the *'simple'* and *'induction'* model example above, with inclusion of the *'blade element theory'* parameters.

A *'thrust factor'* can be applied to the rotor to include an approximation for the effect of the tower and the hub on the obstruction to airflow past the turbine.

The blade element theory model assumed 2D flow over each aerofoil section, and a 3D correction can be applied at the rotor tips. Options for the *'tip loss correction'* keyword are *'elliptic'* (which is not recommended

for most modern turbines), *'acos-fit'*, *'acos shift-fit'* and *'f-fit'*. Definitions for these functions are provided in the Reference Guide.

In addition to the tip speed limit imposed by environmental considerations, some manufacturers also apply a calibrated ramp factor to the revolutions per minute that the rotor can achieve for any given freestream hub-height wind speed. This is to avoid overspeeds at low wind speeds. The *'rpm ramp'* keyword takes a pair of points `[[cut in speed, lowest rpm],[full speed, rpm at full speed]]` defining the ends of the linear limit curve applied.

For all models, the *turbine_vtk/<turbine>.vtp* file defining the fluid zone for each turbine is also automatically created.

The utility also automatically creates a set of monitor points for each turbine, all in a single file (*<case_name>_probes.py*):

```
turb_probe = {
    'report' : {
        'frequency' : 100,
        'monitor' : {
            'MR_1' : {
                'name' : 'probe1@MHH@87',
                'point' : [251865.0, 646486.0, 338.5],
                'variables' : ['V', 'ti'],
            },
            ...
        }
    }
}
```

The *'frequency'* is the number of solver cycles between outputs, and the *'monitor'* defines the name of the probe using the WindFarmer standard notation.

Because the zone and probe files are automatically created, the following lines must be added to the end of the standard zCFD parameter definition file *<case_name>.py* to insert the data:

```
z = zutil.get_zone_info('<case_name>_zones')
for key,value in z.turb_zone.items():
    parameters[key]=value

p = zutil.get_zone_info('<case_name>_probes')
for key,value in p.turb_probe.items():
    parameters[key]=value
```

When run, zCFD will include the probe data in the *<case_name>_report.csv* file. Note that this utility may take a few seconds to run, especially if there are large numbers of turbines, or points on the mesh boundary.

Writing WindFarmer Data Files

In order to export the data from a zCFD run in a format that can be read by WindFarmer, we provide the utility *write_windfarmer_data*, with usage:

```
import zutil.farm as farm
farm.write_windfarmer_data(case_name='windfarm_name',
                           num_processes=48,
                           up = [0,0,1])
```

The *up* vector is used to check that the orientation expected by WindFarmer is that same as the orientation used in the simulation. In most cases this will be the z-axis.

The utility will output the probe information plus additional fields, calculated automatically.

1.8.2 Propellor Modelling

Overview

Propellors are similar to wind turbines except that they are designed to produce thrust rather than torque from lift. zCFD includes a blade element fluid zone model based on an actuator disc, for propellors:

```
propellor_zones = {
  'FZ_1': {
    'name': 'R01',
    'type': 'disc',
    'model': 'blade element propellor',
    'number of blades': 2,
    'status': 'on',
    'outer radius': 0.175,
    'inner radius': 0.039025,
    'def': './propellor_vtp/R01.vtp'
    'rotation direction': 'clockwise',
    'verbose': True,
    'update frequency': 1,
    'centre': [0.0, 0.0, 0.0],
    'reference plane': True,
    'normal': [0.0, 0.0, 1.0],
    'up': [1.0, 0.0, 0.0],
    'blade chord': [[0.2333, 0.1468], [0.2667, 0.1681], ... , [1.0, 0.0581]],
    'blade twist': [[0.2333, 28.6202], [0.2667, 25.5228], ... , [1.0, 0.0]],
    'aerofoil cd': [[-60.0, 1.4552], [-50.0, 1.0992], ... , [60.0, 2.3542]],
    'aerofoil cl': [[-60.0, -0.7978], [-50.0, -0.8195], ... , [60.0, 1.3818]],
    'number of segments': 24,
    'tip loss correction': 'elliptic',
    'tip loss correction radius': 0.8,
  }
}
```

The *'name'* key is used to tag results associated with the propellor.

The *'type'* defines the fluid zone type for propellors.

The *'model'* should be set to 'blade element propellor'.

The *'number of blades'* can be any positive integer - typically 2, 3 or 4.

The *'status'* can be set to on or off, as a quick way to disable a propellor without re-generating the model.

The *'inner radius'* and *'outer radius'* refer to the rotor disc.

The *'def'* is a path to a file containing the VTP file defining the disc fluid zone geometry. This can easily be created interactively in ParaView or else using the *ParaView Simple* library in Python:

```
line = Line()
line.Resolution = 10
line.Point1 = (0.0, 0.0, -0.5 * 0.175)
line.Point2 = (0.0, 0.0, 0.5 * 0.175)
tube = Tube(Input=line)
tube.NumberofSides = 128
tube.Radius = 0.175
transform = Transform(Input=tube)
transform.Transform = "Transform"
transform.Transform.Rotate = [0.0, 0.0, 0.0]
transform.Transform.Translate = [0.0, 0.0, 0.0]
```

(continues on next page)

(continued from previous page)

```
writer = CreateWriter('./propellor_vtp/R01.vtp')
writer.Input = transform
writer.UpdatePipeline()
```

where the above code block would produce a fluid zone for a propellor with normal [0.0,0.0,1.0]. Note that general use of the ParaView rotate command should follow the (default) ZXY convention, for which the following is a reasonable estimate:

```
def rotation_matrix(axis, theta):
    # Rotation matrix for counterclockwise rotation about axis by theta (radians)
    axis = np.asarray(axis)
    axis = axis / math.sqrt(np.dot(axis, axis))
    a = math.cos(theta / 2.0)
    b, c, d = -axis * math.sin(theta / 2.0)
    aa, bb, cc, dd = a * a, b * b, c * c, d * d
    bc, ad, ac, ab, bd, cd = b * c, a * d, a * c, a * b, b * d, c * d
    return np.array([[aa + bb - cc - dd, 2 * (bc + ad), 2 * (bd - ac)],
                    [2 * (bc - ad), aa + cc - bb - dd, 2 * (cd + ab)],
                    [2 * (bd + ac), 2 * (cd - ab), aa + dd - bb - cc]])

def trans_rot(v, vec, ang):
    v2 = np.dot(rotation_matrix(vec, ang), v)
    return [v2[0], v2[1], v2[2]]

# ParaView rotation emulator - note that ParaView (i.e. VTK) uses the order ZXY for
# rotation.
def pv_rotate(pt, args):
    pt1 = trans_rot(pt, [0.0, 0.0, 1.0], math.radians(args[2]))
    x1 = trans_rot([1.0, 0.0, 0.0], [0.0, 0.0, 1.0], math.radians(args[2]))
    y1 = trans_rot([0.0, 1.0, 0.0], [0.0, 0.0, 1.0], math.radians(args[2]))
    pt2 = trans_rot(pt1, x1, math.radians(args[0]))
    y2 = trans_rot(y1, x1, math.radians(args[0]))
    pt3 = trans_rot(pt2, y2, math.radians(args[1]))
    return pt3
```

The *'rotation direction'* can be clockwise or anticlockwise. zCFD will apply the necessary orientations to the forces and wake rotation.

The *'verbose'* keyword (True or False) specifies the level of output from the model.

The *'update frequency'* for propellers should be 1 - meaning that the model is evaluated on every solver cycle.

The *'centre'* is the centre of the disc rotor in 3D, and the *'normal'* defines the orientation.

The *'up'* vector is used to define θ_0 on the rotor: the radial vector from the centre to the rotor tip at θ_0 is defined by the cross product of the up vector and disc normal. All forces on the disc are evaluated by incrementing θ over the range $[0, 2\pi]$.

The *'blade chord'* and *'blade twist'* are each defined as a list of points over the domain [0,1]. Note that the twist is measured in degrees and the chord is scaled by the outer radius in zCFD, so the input has to be scaled for a radius of 1.

The *'airfoil cl'* and *'airfoil cd'* curves are lists of points defining the airfoil characteristics. zCFD interpolates values between these points and will extrapolate if necessary.

The *'number of segments'* used in the model should be chosen to match the mesh spacing in the CFD mesh around the propellor. zCFD does not generate a new mesh in order to apply the propellor model.

A *'tip loss correction'* can be applied to the blade element model, and the only option is *'elliptic'*. The *'tip loss correction radius'* is the radius from which the tip correction is applied and has a default value of 0.8.