



**CA4K™**

**iLock For Continental App**

**User Guide**

Revision: Rev L

Date: 2/9/2022



## DISCLAIMER

Continental Instruments LLC makes no representations or warranties with respect to the contents hereof and specifically disclaim any implied warranties of merchantability or fitness for any particular purpose. Further, Continental Instruments LLC reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Continental Instruments LLC to notify any person of such revision or changes.

**Copyright © 2019 by Continental Instruments LLC.** All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, or stored in a retrieval system, without the prior written permission of Continental Instruments LLC, 355 Bayview Avenue, Amityville, NY 11701. Telephone: 631-842-9400 • FAX: 631-842-9135

This document contains proprietary information of NAPCO Security Technologies. Unauthorized reproduction of any portion of this manual without the written authorization of NAPCO Security Technologies is prohibited. The information in this manual is for informational purposes only. It is subject to change without notice. Companies, names and data used in examples herein are fictitious unless otherwise noted. NAPCO Security Technologies assumes no responsibility for incorrect information this manual may contain.

*A NAPCO SECURITY TECHNOLOGIES COMPANY*  
Publicly traded on NASDAQ Symbol: NSSC

Visit our websites:

<http://www.cicaccess.com/>

<http://www.napcosecurity.com/>

<http://www.alarmlock.com/>

# Table of Contents

<i>DISCLAIMER.....</i>	<i>1</i>
<i>Must Read/Overview.....</i>	<i>3</i>
<i>Prerequisites.....</i>	<i>3</i>
<i>Downloading the iLock for Continental App.....</i>	<i>4</i>
<i>Installing the iLock for Continental App .....</i>	<i>5</i>
<i>Configuring the CA4K™ Software for iLock for Continental App.....</i>	<i>6</i>
<i>Log In to CA4K™.....</i>	<i>6</i>
<i>Configure a 64-bit Badge Format .....</i>	<i>7</i>
<i>Reader configuration for Locks and Panels .....</i>	<i>7</i>
<i>Similarly, User can configure other available readers (if required) for the Locks and Panels.....</i>	<i>8</i>
<i>Add a Bluetooth Credential .....</i>	<i>9</i>
<i>Add New Door (QR Code Scan) .....</i>	<i>12</i>
<i>Import Door.....</i>	<i>13</i>
<i>Unlock Selected Door.....</i>	<i>15</i>
<i>Editing Door Information.....</i>	<i>21</i>
<i>Delete All Doors .....</i>	<i>21</i>
<i>Send mobile credentials via Email or SMS.....</i>	<i>22</i>
<i>Configure Mobile Credential Field Settings in System Settings .....</i>	<i>22</i>
<i>Configure Personnel Custom Fields in System Settings.....</i>	<i>22</i>
<i>Enable Scripting in System Settings.....</i>	<i>23</i>
<i>Configure Messaging in System Settings .....</i>	<i>24</i>
<i>Advanced Administrative Options .....</i>	<i>27</i>

## Must Read before you begin installation

- Prior to programming the CA4K™, verify you have an Android (Jellybean 4.0 or later) or iOS mobile device with an internet connection to download the CA4K™ iLock for Continental app.
- Verify you have a wireless lock model that contains Bluetooth LE technology or a continental panel that includes one or more Bluetooth Reader
- Bluetooth credentials that reside within the iLock for Continental App works essentially as any other type of proximity credential; simply launch the iLock for Continental app and tap the Unlock button to allow entry.
- The Mobile credential can be sent to the mobile device via SMS, Email, upload a file to cloud or “On the Screen QR code”. This document will only cover the “On the Screen QR code” method.

## Overview


This document provides an overview of downloading and installing the CA4K™ iLock for Continental app on an Android or iOS mobile device. Once downloaded and installed, the CA4K software can create and send a Bluetooth credential to the iOS or Android Mobile device. The credential can be sent via Email, SMS, a scanned QR code or a file on the cloud. This document will only cover one of these available methods. The method discussed will be the scanning of a QR code. Once the credential is on the mobile device, it can be imported, thus making that mobile device a valid "User" of the lock/Panel. Only wireless locks or Continental panels containing Bluetooth LE technology is supported with the iLock for Continental app.

## Prerequisites

- A functional CA4K System with version 1.1.5x or later.
- An Android (Jellybean 4.0) or iOS (V9.0 or later) mobile device with Bluetooth connectivity.
- A Continental panel reader / lock model that contains Bluetooth LE technology.

## Downloading the iLock for Continental App

- Download the iLock for Continental Android or iOS app from the app store (Google Play Store / Apple App Store).
- If the App is still in testing, the user can download it from the following link.  
<https://www.ibridgeonline.com/apps/iLockForContinental/>
- Upon accessing the link, a menu will display with two options. The first option is iOS (iPhone/iPad), and the second option is for Android.
- Download the app that is compatible with the user's mobile device.




## Installing the iLock for Continental App


- Upon downloading the iLock for Continental app onto the user's Android or IOS mobile device, install the iLock for Continental App on the IOS or Android device.

**Note:** Due to the iLock for Continental app being downloaded from a website, the user might have to modify the security settings in the Mobile device to allow an unknown app to install. The user might be prompted for this setting automatically, or the user might have to go into Settings>Security on the mobile device.

- After the installation is done, click the Settings button (Marked in the Picture).



- Upon clicking the Settings button, the below screen will appear with options: **Add New Door (QR Code Scan)**, **Advanced Options**, and **Delete All Locks**.



- **Add New Door (QR Code Scan)** menu could be the frequently used menu to import doors and mobile credentials.

- Advanced Options can add Admin Door (**Add New Admin door**) and Manual Credential (**Add Manual Credential**). These options are used for administrative purposes only.

## Configuring the CA4K™ Software for iLock for Continental App

- To Launch the CA4K™ software, Click the CardAccess 4K icon on the desktop.



- The CA4K™ Log In screen will display.

## Log In to CA4K™

- Type the default **User name** (admin) and **password** (admin@4k) or valid credentials given by the access control administrator. Click **Login**. The CA4K™ event grid will display.

Continental Access  
A Navigo Security Group Company

User Name:

Password:

☐ Remember user

**Please Log In**

## Configure a 64-bit Badge Format

- Mobile credentials require a 64-bit custom badge format.
- Click **Administration/Badge Formats** from the main menu. The **Badge Format** screen will display.
- Click **New**.
- Configure a 64-bit badge format precisely as per the screen below.
- Click **Save** and **Close**.

The screenshot shows the 'Badge Format' configuration window. At the top is a menu bar with options: System, Control, Access, Administration, Configuration, Lockdown Control, View, Help. Below the menu is a toolbar with icons for Personnel, Schedule, Access Groups, Doors, Relays, Links, Activity Links, Mapping, Status, Reports, Log Out, Plugin Embed, and Plugin Popup. The main area contains a table of badge formats. The 'MobileCredential' format is selected and highlighted in blue. Below the table is the 'General' tab for configuring the selected format.

Format	Description Text	Format Length	First Type	Number Len	Number Offset	Facility Len	Facility offset	Last Edit
Format1		36	2	16	17	16	1	3/1/2021 10:46:17 AM
Format2		19	1	6	7	5	1	3/1/2021 10:46:17 AM
Format3		26	0	16	9	8	1	3/1/2021 10:46:17 AM
Format4		31	0	16	14	8	6	3/1/2021 10:46:17 AM
Format5		37	0	16	17	16	1	3/1/2021 10:46:17 AM
MobileCredential		64	0	64	0	0	0	3/4/2021 3:56:59 PM
PV200		40	25	6	11	4	6	4/2/2021 11:43:40 AM

**General**

Format No:  Name:  Partition Group:

Badge Format Type:  BitChar Len:

All Types

Badge ID	Offset	Length	EvenParity	Offset	Length
Facility	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
Issue	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>

## Reader configuration for Locks and Panels

- Enter the **last eight characters** of the Bluetooth readers MAC address, in the **Bluetooth MAC Address** field in the reader screen (MAC address will be printed as text or barcode on the back of the Reader).



Readers

New Delete Save Cancel Search Refresh Export Grid to Excel Print Grid Close

Reader	Description Text	Enabled	Ext Shunt	Escort
22 - 12	SDC_AC72 Reader 12	Yes	No	No
22 - 13	SDC_AC72 Reader 13	Yes	No	No
22 - 14	SDC_AC72 Reader 14	Yes	No	No
22 - 15	SDC_AC72 Reader 15	Yes	No	No
22 - 16	SDC_AC72 Reader 16	Yes	No	No
23 - 1	Lock 7710068D Reader	Yes	No	No
24 - 1	Lock 21293781 Reader	Yes	No	No
25 - 1	Lock 65A52E38 Reader	Yes	No	No
26 - 1	Lock 2D4C8700 Reader	Yes	No	No
27 - 1	Super2 FrontDoor	Yes	No	No
27 - 2	Super2 BackDoor	Yes	No	No

Device Name **Super2 FrontDoor** Partition Group Admin Partition

General Door Control Options Category Counters Priorities Location / Remarks

Panel **Super2** Reader # **1**

Reader Type  
☒ Door ☐ Badge Validator ☐ Wireless Lock

Assign to Access Group from Reader **None**

Bluetooth MAC Address **19C84601**

☒ Enabled  
☒ Report Bypass  
☒ Bypass Unlocks  
☐ No Transaction for Valid  
☐ Time Schedule Violate Override  
☐ Report Access After Open  
☒ Badge Use Limit Controller  
☐ Escort Enabled  
☐ Double Read Holds Door Unlocked  
☐ Alarm Shunt Reader

- Similarly, the user can configure other available readers (if required) for the Locks and Panels.

Readers [X]

New Delete Save Cancel Search Refresh Export Grid to Excel Print Grid Close

Reader	Description Text	Enabled	Ext Shunt	Escort
22 - 12	SDC_AC72 Reader 12	Yes	No	No
22 - 13	SDC_AC72 Reader 13	Yes	No	No
22 - 14	SDC_AC72 Reader 14	Yes	No	No
22 - 15	SDC_AC72 Reader 15	Yes	No	No
22 - 16	SDC_AC72 Reader 16	Yes	No	No
23 - 1	Lock 7710068D Reader	Yes	No	No
24 - 1	Lock 21293781 Reader	Yes	No	No
25 - 1	Lock 65A52E38 Reader	Yes	No	No
26 - 1	Lock 2D4C8700 Reader	Yes	No	No
27 - 1	Super2 FrontDoor	Yes	No	No
27 - 2	Super2 BackDoor	Yes	No	No

Device Name: Super2 BackDoor Partition Group: Admin Partition

General Door Control Options Category Counters Priorities Location / Remarks

Panel: Super2 Reader #: 2

Reader Type: ☒ Door ☐ Badge Validator ☐ Wireless Lock


Assign to Access Group from Reader: None

Bluetooth MAC Address: 19C845FF

☒ Enabled  
☒ Report Bypass  
☒ Bypass Unlocks  
☐ No Transaction for Valid  
☐ Time Schedule Violate Override  
☐ Report Access After Open  
☒ Badge Use Limit Controller  
☐ Escort Enabled  
☐ Double Read Holds Door Unlocked  
☐ Alarm Shunt Reader

## Add a Bluetooth Credential

- From System Settings, update the Max Badge Digits at Panel to 19 Digits.  
**System-> System Settings -> System-wide-Settings->Badges->Max Badge Digits at Panel-> 19 Digits**



- Perform Full Data Download
- Click **Personnel** on the main toolbar. The **Personnel** screen will display.
- Click **New Person**.
- Click the **Generate Mobile Credential** button. Upon clicking the button, a random badge number will be generated for the Badge Number.

**Very Important:** The user must have the 64-Bit Badge format configured for the **Generate Mobile Credential** button to be enabled.

- Type in the First and Last Name of the Badge holder.
- Click the **Mobile Credential** tab on the badge record. Enter the following information for each badge record.
- **Email Address** (optional- only required to send mobile credential by email)
- **Mobile Phone number** (optional-only required to send mobile credential by SMS)
- **SMSDomain** (optional-only required to send mobile credential by SMS)

**Note:** Refer Page 21, 25, 26 and 27 for detail

- Click **Send Mobile Credential** button. Upon clicking this button, the **Reader Lookup** screen will display.

The screenshot shows the 'Personnel' application window. At the top, there's a menu bar with 'New Person', 'Delete', 'Save', 'Cancel', 'Search', 'Refresh', 'Batch Modify', and 'Close'. Below this is a 'Badge Holders' table:

Last Name	First Name	Middle Nam	Badge
Jim	Jones		2731401
Peter	Long		3733111

Below the table, there's a 'Badges for Selected Badge Holder' section. It shows a table with columns 'Facility', 'Badge No', and 'Enabled'. The first row shows Facility '0', Badge No '273140174757377782', and 'Enabled' checked.

The main form area has tabs: 'General', 'Access Groups', 'Control', and 'Personal'. The 'Personal' tab is active. It contains fields for 'Std' (Badge Number: 273140174757377782), 'PIV' (First Name: Jones, Last Name: Jim, Middle Name: ), 'PIN Code', 'Access Time' (0), 'Badge Use Limit' (0), 'Activation Date Time', 'Expiration Date Time', and 'Partition Group' (Admin Partition). There are checkboxes for 'Enabled', 'Tracked', 'Escorted', and 'First In Control'. A yellow button labeled 'Send Mobile Credential' is at the bottom.

- Select the Reader(s) to send the credential. Upon selecting the Reader(s), the **Send SMS**, **Show QR Code**, **Send Email**, **Upload File** Tabs will enable. For our demonstration in this document, we will only perform the **On-Screen QR Code**.


The screenshot shows the 'Reader Lookup' application window. It has a 'Select All' checkbox and a list of readers. The 'Super2 FrontDoor' reader is selected and highlighted in blue. Below the list, there are buttons for 'Send SMS', 'Show QR Code', 'Send Email', 'Upload File', 'Ok', and 'Cancel'.

- Click the **Show QR Code** Tab. Upon clicking **Show QR Code**, the QR code will display on the right side of the screen.




- Follow the same steps to add Bluetooth credentials with Panels' other available readers (if required).


## Add New Door (QR Code Scan)




- On the Settings screen, click the **+ Add New Door (QR Code Scan)** button.
- Align the camera with the QR Code within the guidelines.
- On the iLock for Continental app, click the **Scan QR Code** button.
- Upon clicking the **scan QR code**, the door information will display on the **Import Doors** screen. Click Import to import the doors.

## Import Door






- Upon the Doors being imported, the imported door will display under **All Doors** with a Lock icon. Refer to the screen below.



- Once doors are imported, can add selected doors to “Favorite Doors”. Click the menu “Add doors to favorite” to select and add.


## Unlock Selected Door

- To unlock the Door, Tap the Lock icon on the Door Screen. While opening, an **Unlocking** icon (Red Lock icon) and Bluetooth signal strength will continue to display on the Door Screen. If the Door Unlocked executes successfully, an **Unlocked** icon (Green Lock icon) icon will display.




(Unlocking is in Progress)






(Unlocking Complete)


- **Unlock When Near** in the door status screen option can restrict the distance to execute the door open operation. By default, **Unlock When Near** is turned off.



(Unlock When Near is Disabled)

- Suppose the user enables **Unlock When Near** option, then he/she needs to come in reasonable proximity to the reader to execute the door open operation. Distance is based on the RSSI threshold level set at settings for each door.





(Unlock When Near is Enabled)

- The User receives a **Password Accepted** message if he/she tries to execute a door unlock operation, but for some reason, did not receive a feedback signal from the panel.



## Editing Door Information

- To edit the door information, select the door and click the **Settings** button on the right top corner.
- Edit the door information.
- Click **Save Changes**.

Super2 FrontDoor(Jones Jim )

Lock Id: **19C84601**

Firmware Version: **20a**

Battery: **100%**

Color:

Change Lock Name

☐ Enable Toggle Mode

☐ Add to favorites


RSSI threshold(-75dB)

Near -45dB      Close -60dB      Far -75dB


**Save Changes**      **Delete**

## Delete All Doors

- To delete all the Doors, click **Delete All Doors**.



- Upon clicking **Delete All Doors**, a confirmation message will display as per the screen below.
- Click **Yes**.



## Send mobile credentials via Email or SMS


### Configure Mobile Credential Field Settings in System Settings

- Click **System/System Settings/System-wide Settings**. The System Settings screen will display.
- On the General tab, configure the **Mobile Credential Field Settings** as per the screen below.
- Click **Save**.

The screenshot shows the 'System Settings' window with the 'General' tab selected. The 'Mobile Credential Field Settings' section is highlighted with a red border. It contains four text input fields: 'User Field Tab Name' (MobileCredential), 'Mobile Number Field Name' (MobileNumber), 'SMS Domain Field Name' (SMSDomain), and 'Email Field Name' (Email). Other settings visible include 'Alert Processing' with 'Enable Auto Acknowledge' checked and 'Auto Acknowledge Set-Point' set to 5. The 'Privacy Settings' section at the bottom has 'Enable Privacy Mode' checked and 'Privacy Mode Delay' set to 0 days. The status bar at the bottom indicates 'Last Change: Today 2:25 PM'.

### Configure Personnel Custom Fields in System Settings


- Upon configuring the previous screen, the Personnel Custom Fields will be automatically configured as per the screen below. Please verify that they have been preconfigured. If they have not been preconfigured, they must be manually configured.



## Enable Scripting in System Settings

- Enable Scripting in System Settings.





## Configure Messaging in System Settings

- Click the **Messaging** tab.
- Configure the Messaging tab (Email and SMS) as per the screens below.
- Click **Save**.

**Note:** Refer to the CA4K online help file for details on configuring the Email and SMS settings screens as per below.

System Settings

Save

Cancel

Close

Workstation Settings

System-wide Settings

Operator - admin - Settings

General

Badges

Custom Fields

Alarm Panel Integration

Script Server(s)

LDAP

Archive Settings

Custom Menus

☒ Use Scripting

Script Servers

Messaging

Message Templates

Email Settings

Email Server Name

smtp.gmail.com

Email Server Port

587

Email From Address

napcosoft@gmail.com

Email Password

\*\*\*\*\*


SNPP Provider Settings

Provider Name	Server URL	Port
<div>Add</div> <div>Remove</div>		

SMS Provider Setting

Provider Name	Server URL
<div>Add</div> <div>Remove</div>	

Last Change: 6/10/2021 12:36 PM



**Add SMS Provider**

Please obtain this setting from your service provider

Provider Name  
Verizon

Server URL  
vtext.com

SMS Type  
EMAIL


Parameters from which SMS will be sent

**Server=smtg.gmail.com**  
**Email=napcosoft@gmail.com**  
**Port=587**

Password

Ok Cancel

- Once customer fields are created and messaging and scripting are configured, the user needs to enter the phone number and email address in the personal screen for a badge holder to receive mobile credentials by email or SMS.
- Click the SMS or Email button in the Reader Lookup screen to receive credentials by email or SMS. Upon receiving, click the link to import doors/credentials to the mobile device.



**Reader Lookup**


Select All

- ☐ superterm reader 01
- ☐ superterm reader 06
- ☐ Accetelem\_DOWN reader 02
- ☐ Lock B9229E79 Reader
- ☐ SDC\_BDA0 Reader 01
- ☐ Accetelem\_UP Reader 02
- ☐ Lock BC9777CA Reader 1
- ☐ Lock BD499EA4 Reader
- ☒ Super2 Front Door
- ☐ Super2 Back Door




QR Code

Send SMS Show QR Code Send Email Upload File Ok Cancel

## Advanced Administrative Options




1. The administrator or installer can use some admin functions (Output operation mode select, adjusting Bluetooth advertising transmit strength, etc.) during construction or installation time.
2. To access admin functions, set the module into admin enroll mode by pressing the Module's Pushbutton once, and there will be three quick RED LED flashes with beeps followed by one GREEN LED flash and then a continuous beeping with green LED flashes.
3. While green LED flashes with continuous beeps, the user can configure the admin Door in two ways:
  - a) By Clicking **Add Maintenance Credential** and selecting **MYLOCK** from the available Doors list.





b) By **MAC Entry**:


- i) Check **By MAC Entry** and tap on + Add Maintenance Credential




- ii) Enter the last Six digits of the MAC Address and the password when the Manual Credential window prompt, click Connect.



- A. **Enroll successful Message** displays when the Lock enrolled successfully.




- B. Now the Admin mode door will be displayed under **All doors**.



- C. Select the admin door and click unlock icon to connect to the door and enable admin mode. Once the connection is made, a new icon will appear for the keypad to perform various system configurations: (Output operation mode select, adjusting Bluetooth advertising transmit strength etc.).





4. Once the connection is made, a keypad will appear to perform admin functions.
5. The admin Users can perform the following functions using the keypad screen.
  - a. Configure output operation modes  
**Command: AL, 1, AL, Arg1, \***  
 Arg1 = Mode,  
 0= Automatic (default), based on detected credential and serial port status.  
 1= Serial Only  
 2= Wiegand Only (64bit)  
 3= Wiegand 160Bit Only
  - b. Configure device address  
**Command: AL, 2, AL, Arg1, \***  
 Arg1 = Address,  
 5= Door 1(default)  
 6= Door 2, for Networx panel second door
  - c. Configure a sounder on Unlock event  
**Command: AL, 5, AL, Arg1, \***  
 Arg1 = Sounder On/ Off,  
 0 = No Sounder on Unlock Detect  
 1= Sound Beep on Unlock Detect (Default)
  - d. Configure Bluetooth Advertisement transmit strength  
**Command: AL, 7, AL, Arg1, \***  
 Arg1 = indexing strength, 0 being the weakest and 7 being the strongest,  
 0 = -19.1 dBm  
 1 = -15.1 dBm  
 2 = -10.9 dBm  
 3 = -6.9 dBm  
 4 = -2.5 dBm  
 5 = 1.6 dBm

6 = 5.8 dBm  
7 = 7.5 dBm (default)

- e. Exiting Program mode  
**Command: AL, 8, \***  
(User can also exit program mode by holding down **AL** key)
- f. Default and restart  
**Command: AL, 9, 9, AL, 0, 0, 0**

**Note:** Defaulting can be performed in two ways

**Default Method 1:** Remove the power and wait for 10 seconds and power up the module and waits for three RED LED flashes with Beeps. After that, hold the Button for approximately three (3) seconds. The user will observe three GREEN LED flashes with Beeps followed by three quick RED LED flashes for two consecutive times with 1-second interval and a terminating GREEN LED flash with a beep.

**Default Method 2:** When the module is already powered up, press and hold the Button, and there will be periodic RED LED flashes with Beeps ended with a green led flash with beep followed by consecutive RED LED flashes for approximately 20 seconds. Release the Button once the four quick RED LED flashes with Beeps stop with a green LED flash. The module will be defaulted after three GREEN LED flashes with Beeps followed by three quick RED LED flashes for two consecutive times with a 1-second interval and a terminating GREEN LED flash with a beep.

**THE END**