

403 Forbidden

本电子书由CyberArticle制作。点击[这里](#)下载CyberArticle。注册版本不会显示该信息。[删除广告](#)

V7瘦AP切换为V5胖AP配置案例方法

目录

[V7瘦AP切换为V5胖AP配置案例方法](#)

[1.1 适用产品系列](#)

[1.1.1 AP瘦切胖配置案例（Bootrom）](#)

1.1 适用产品系列

本手册适用于如下产品：WA4320i-X、WA4320i-ACN、WA4320H-ACN、WA4320-ACN、WA2620i-AGN、WA2610E、WA2620E、WA2620X等AP。

有一些场景下，之前注册过V7无线控制器的瘦AP，需要切换成胖AP使用，但是对应的胖

AP版本是V5平台的，那就涉及到本案例的内容。需要先降级bootrom，再做版本上传。

1.1.1 AP瘦切胖配置案例（Bootrom）

操作风险提示：AP瘦切胖有风险，操作不当或者意外断电会导致设备故障，操作需谨慎。命令行升级需在PC上搭建TFTP Server（推荐用户使用3CDaemon搭建TFTP服务器）

将软件版本下载到设备FLASH内，然后通过命令行加载Bootrom版本，再加载主机软件版本，加载时输入的文件名一定要一致，建议复制黏贴，然后升级过程中避免断电重启操作。


1. 从新华三的官网下载对应AP型号的胖版本

https://www.h3c.com/cn/d_201805/1083983_30005_40.htm

下载压缩包WA4300S-CMW520-R1509P01-FAT.zip，解压生成bin文件，放到电脑桌面上，下载后，需修改文件名，以WA4320为例子，修改对应的启动文件名wa4300s_fat.bin，需要注意文件名称修改正确。

2. 电脑通过网线连接到ap的一个网口

电脑网卡设置为：192.168.0.1 255.255.255.0，如下例子打开TFTP服务器，把bin软件版本放到电脑桌面上，TFTP服务器目录指向电脑桌面，然后点击确定。



3. console口操作刷版本

console口登录方法参考《1.03 设备管理-Console登录方法》

在AP重启的时候按住不停地按Ctrl+B进入设备的bootroom菜单，以下标黑部分为设备自动打印部分。

System is starting...

Press Ctrl+D to access BASIC-BOOTWARE MENU

Booting Normal Extend BootWare

The Extend BootWare is self-decompressing.....

Done!

按住ctrl+b进到boot

```
*****
*
*
*      H3C WA4320-ACN-C BootWare, Version 7.07      *
*
*
*****
```

Copyright (c) 2004-2016 Hangzhou H3C Technologies Co., Ltd.

Compiled Date : Jul 25 2016

CPU Type : Atheros AR9563

CPU L1 Cache : 32KB

CPU Clock Speed : 775MHz

Memory Type : SDRAM
 Memory Size : 128MB
 Memory Speed : 560MHz
 BootWare Size : 512KB
 Flash Size : 16MB
 PCB Version : Ver.B

BootWare Validating...

Press Ctrl+B to access EXTENDED-BOOTWARE MENU...

Password recovery capability is enabled.

Note: The current operating device is flash

Enter < Storage Device Operation > to select device.

3.1、更新扩展bootrom版本

=====<EXTENDED-BOOTWARE
 MENU>=====

<1> Boot System		
<2> Enter Serial SubMenu		
<3> Enter Ethernet SubMenu		
<4> File Control		
<5> Restore to Factory Default Configuration		
<6> Skip Current System Configuration		
<7> BootWare Operation Menu		
<8> Skip Authentication for Console Login		
<9> Storage Device Operation		
<0> Reboot		

=====

Ctrl+Z: Access EXTENDED ASSISTANT MENU

Ctrl+F: Format File System

Ctrl+C: Display Copyright

Enter your choice(0-9):

此时按住ctrl+F 格式化flash, “Y”需要手工输入

Warning:All files on flash will be lost! Are you sure to format? [Y/N]Y.....

.....

.....

Format success.

```
=====<EXTENDED-BOOTWARE
MENU>=====
```

```
|<1> Boot System |
|<2> Enter Serial SubMenu |
|<3> Enter Ethernet SubMenu |
|<4> File Control |
|<5> Restore to Factory Default Configuration |
|<6> Skip Current System Configuration |
|<7> BootWare Operation Menu |
|<8> Skip Authentication for Console Login |
|<9> Storage Device Operation |
|<0> Reboot |
```

```
=====
```

Ctrl+Z: Access EXTENDED ASSISTANT MENU

Ctrl+F: Format File System

Ctrl+C: Display Copyright

Enter your choice(0-9): **3** //进入以太网子菜单

```
=====<Enter Ethernet
SubMenu>=====
```

```
|Note:the operating device is flash |
|<1> Download Image Program To SDRAM And Run |
|<2> Update Main Image File |
|<3> Update Backup Image File |
|<4> Download Files(*.*) |
|<5> Modify Ethernet Parameter |
|<0> Exit To Main Menu |
|<Ensure The Parameter Be Modified Before Downloading!> |
```

```
=====
```

Enter your choice(0-5): **5** //更改以太网参数

```
=====<ETHERNET PARAMETER
```

```

SET>=====
|Note:      '.' = Clear field.                |
|          '.' = Go to previous field.        |
|          Ctrl+D = Quit.                    |
=====

Protocol (FTP or TFTP) :tftp
//忽略输出内容，直接输入TFTP，然后回车
Load File Name       :wa4300s_fat.bin
//忽略输出内容，直接输入wa4300s_fat.bin，然后回车
Target File Name     :wa4300s_fat.bin
//忽略输出内容，直接输入wa4300s_fat.bin，然后回车
Server IP Address    :192.168.0.1
//忽略输出内容，直接输入电脑主机的 IP，如192.168.0.1，然后回车
Local IP Address     :192.168.0.19
//忽略输出内容，直接输入和电脑主机的ip同一网段，比如192.168.0.19，然后回车
Subnet Mask          :255.255.255.0
//忽略输出内容，直接回车
Gateway IP Address   :0.0.0.0
//忽略输出内容，直接回车

=====<Enter                                     Ethernet
SubMenu>=====
|Note:the operating device is flash                |
|<1> Download Image Program To SDRAM And Run        |
|<2> Update Main Image File                        |
|<3> Update Backup Image File                      |
|<4> Download Files(*.*)                          |
|<5> Modify Ethernet Parameter                    |
|<0> Exit To Main Menu                          |
|<Ensure The Parameter Be Modified Before Downloading!>|
=====

Enter your choice(0-5): 1          //此时为更新bootware版本
Loading.....
.....
.....
.Done.
11248640 bytes downloaded!

```

```

Extended BootWare Version is not equal,updating? [Y/N]
Updating Extended BootWare.....Done.
BootWare updated,System is rebooting now.
System is starting...
Press Ctrl+D to access BASIC-BOOTWARE MENU
Booting Normal Extend BootWare
The Extend BootWare is self-decompressing.....Done!

```

3.2、升级bin版本

此时bootware版本更新完成，进扩展boot升级设备版本。

```

*****
*                                     *
*           H3C WA4320-ACN-C BootWare, Version 1.05           *
*                                     *
*****

Copyright (c) 2004-2016 Hangzhou H3C Technologies Co., Ltd.

Compiled Date      : Jun 28 2016
CPU Type          : Atheros AR9563
CPU L1 Cache      : 32KB
CPU Clock Speed    : 775MHz
Memory Type       : SDRAM
Memory Size       : 128MB
Memory Speed      : 560MHz
BootWare Size     : 512KB
Flash Size        : 16MB
PCB Version       : Ver.B

```

```

Read net params from bootrom failed, use the default value
BootWare Validating...
Press Ctrl+B to enter extended boot menu...
Starting to get the main application file--flash:/wa4300s_fit.bin!
The main application file does not exist--flash:/wa4300s_fit.bin!

```

Starting to get the backup application file--flash:/backup.bin!
 The backup application file does not exist--flash:/backup.bin!
 Starting to get the secure application file--flash:/secure.bin!
 The secure application file does not exist--flash:/secure.bin!
 Booting App fails!
 Trying to get the IP address from the DHCP server.....
 Getting IP Address Failed, the system will reboot.
 [State : Idle] Reset request, rebooting the AP
 Rebooting.....

System is starting...
 Press Ctrl+D to access BASIC-BOOTWARE MENU
 Booting Normal Extend BootWare
 The Extend BootWare is self-decompressing.....Done!

按住ctrl+b进到boot

```
*****
*
*
*          H3C WA4320-ACN-C BootWare, Version 1.05          *
*
*
*****

Copyright (c) 2004-2016 Hangzhou H3C Technologies Co., Ltd.

Compiled Date      : Jun 28 2016
CPU Type          : Atheros AR9563
CPU L1 Cache      : 32KB
CPU Clock Speed    : 775MHz
Memory Type       : SDRAM
Memory Size       : 128MB
Memory Speed      : 560MHz
BootWare Size     : 512KB
Flash Size        : 16MB
PCB Version       : Ver.B
```

BootWare Validating...

Press Ctrl+B to enter extended boot menu...

BootWare password: Not required. Please press Enter to continue.

Password recovery capability is enabled.

Note: The current operating device is flash

Enter < Storage Device Operation > to select device.

=====<EXTEND-BOOTWARE
MENU>=====

```
|<1> Boot System |
|<2> Enter Serial SubMenu |
|<3> Enter Ethernet SubMenu |
|<4> File Control |
|<5> Restore to Factory Default Configuration |
|<6> Skip Current System Configuration |
|<7> BootWare Operation Menu |
|<8> Clear Super Password |
|<9> Storage Device Operation |
|<0> Reboot |
=====
```

Ctrl+C: Display Copyright

Ctrl+Y: Change AP Mode

Ctrl+F: Format File System

Enter your choice(0-9):

按住ctrl+F,再次格式化 //第二次格式化，“Y”需要手工输入

Warning:All files on flash will be lost! Are you sure to format? [Y/N]Y.....

.....

.....

Format success.

=====<EXTEND-BOOTWARE
MENU>=====

```
|<1> Boot System |
|<2> Enter Serial SubMenu |
|<3> Enter Ethernet SubMenu |
```



```

|<4> File Control |
|<5> Restore to Factory Default Configuration |
|<6> Skip Current System Configuration |
|<7> BootWare Operation Menu |
|<8> Clear Super Password |
|<9> Storage Device Operation |
|<0> Reboot |
=====

```

Ctrl+C: Display Copyright

Ctrl+Y: Change AP Mode

Ctrl+F: Format File System

Enter your choice(0-9): **3** //进到以太网子菜单

```

=====<Enter Ethernet
SubMenu>=====
|Note:the operating device is flash |
|<1> Download Application Program To SDRAM And Run |
|<2> Update Main Application File |
|<3> Modify Ethernet Parameter |
|<0> Exit To Main Menu |
|<Ensure The Parameter Be Modified Before Downloading!> |
=====

```

Enter your choice(0-3): **3** //更改以太网参数

```

=====<ETHERNET PARAMETER
SET>=====
|Note:      '.' = Clear field. |
|      '.' = Go to previous field. |
|      Ctrl+D = Quit. |
=====

```

Protocol (FTP or TFTP) :**tftp**

//忽略输出内容，直接输入TFTP，然后回车

Load File Name :**wa4300s_fat.bin**

//忽略输出内容，直接输入**wa4300s_fat.bin**，然后回车

Target File Name :**wa4300s_fat.bin**

//忽略输出内容，直接输入**wa4300s_fat.bin**，然后回车

Server IP Address :192.168.0.1

//忽略输出内容，直接输入电脑主机的 IP，如192.168.0.1，然后回车

Local IP Address :192.168.0.19

//忽略输出内容，直接输入和电脑主机的ip同一网段，比如192.168.0.19，然后回车

Subnet Mask :255.255.255.0

//忽略输出内容，直接回车

Gateway IP Address :0.0.0.0

//忽略输出内容，直接回车

```

=====<Enter                                     Ethernet
SubMenu>=====
|Note:the operating device is flash                |
|<1> Download Application Program To SDRAM And Run    |
|<2> Update Main Application File                    |
|<3> Modify Ethernet Parameter                      |
|<0> Exit To Main Menu                             |
|<Ensure The Parameter Be Modified Before Downloading!>|
=====
Enter your choice(0-3): 2 //更新主应用文件，此时为AP版本文件
Loading.....
.....
.....
Done!
11248640 bytes downloaded!
Updating File flash:/wa4300s_fat.bin.....
.....
.....Done!

```

```

=====<Enter                                     Ethernet
SubMenu>=====
|Note:the operating device is flash                |
|<1> Download Application Program To SDRAM And Run    |
|<2> Update Main Application File                    |
|<3> Modify Ethernet Parameter                      |
|<0> Exit To Main Menu                             |
|<Ensure The Parameter Be Modified Before Downloading!>|

```

```
=====
Enter your choice(0-3): 0 //返回主菜单
```

```
=====<EXTEND-BOOTWARE
MENU>=====
```

```
|<1> Boot System |
|<2> Enter Serial SubMenu |
|<3> Enter Ethernet SubMenu |
|<4> File Control |
|<5> Restore to Factory Default Configuration |
|<6> Skip Current System Configuration |
|<7> BootWare Operation Menu |
|<8> Clear Super Password |
|<9> Storage Device Operation |
|<0> Reboot |
```

```
=====
Ctrl+C: Display Copyright
Ctrl+Y: Change AP Mode
Ctrl+F: Format File System
Enter your choice(0-9): 0 //重启
System is starting...
Press Ctrl+D to access BASIC-BOOTWARE MENU
Booting Normal Extend BootWare
The Extend BootWare is self-decompressing.....Done!
```

```
*****
*                                     *
*          H3C WA4320-ACN-C BootWare, Version 1.05          *
*                                     *
*****
```

Copyright (c) 2004-2016 Hangzhou H3C Technologies Co., Ltd.

```
Compiled Date      : Jun 28 2016
CPU Type           : Atheros AR9563
CPU L1 Cache       : 32KB
CPU Clock Speed    : 775MHz
```

Memory Type : SDRAM
Memory Size : 128MB
Memory Speed : 560MHz
BootWare Size : 512KB
Flash Size : 16MB
PCB Version : Ver.B

BootWare Validating...

Press Ctrl+B to enter extended boot menu...

Starting to get the main application file--flash:/wa4300s_fat.bin!.....

.....

.....

.....

The App file is self-decompressing.....

.....

.....

.....

.....

.....

.....

.....

.

.....Done!

System application is starting...

Startup configuration file does not exist.

User interface con0 is available.

4. 切换成V5胖模式完成。

重启设备完成后就可以使用默认的管理地址192.168.0.50登录AP进行管理的。登录AP的默认用户名是admin，密码是h3capadmin.