

403 Forbidden

本电子书由CyberArticle制作。点击[这里](#)下载CyberArticle。注册版本不会显示该信息。[删除广告](#)

WA4300系列云AP版本瘦切胖配置案例方法

目录

[WA4300系列云AP版本瘦切胖配置案例方法](#)

[1.1 适用产品系列](#)

[1.1.1 AP瘦切胖配置案例（Bootrom）](#)

1.1 适用产品系列

本手册适用于如下产品：比如WA4320H-SI、WAP711H、WAP712H、WAP712C-LI、WA4320H等WA4300系列云AP。

1.1.1 AP瘦切胖配置案例（Bootrom）

操作风险提示：AP瘦切胖有风险，操作不当或者意外断电会导致设备故障，操作需谨慎。命令行升级需在PC上搭建TFTP Server（推荐用户使用3CDaemon搭建TFTP服务器）


将软件版本下载到设备FLASH内，然后通过命令行加载Bootrom版本，再加载主机软件版本，加载时输入的文件名一定要一致，建议复制黏贴，然后升级过程中避免断电重启操作。

1、先从官网下载WA4300云AP的胖版本，本案例以WA4320H-SI举例

https://www.h3c.com/cn/d_201909/1225207_30005_40.htm

下载压缩包WA4300S-WPT330-E1105-OASIS.zip，解压生成bin文件，把从官网下载的云AP版本文件改成wa4300s-oasis.bin，放到电脑桌面上。

2、电脑通过网线连接到ap的一个网口，电脑网卡设置为：192.168.0.1 255.255.255.0，如下例子打开TFTP服务器，把bin软件版本放到电脑桌面上，TFTP服务器目录指向电脑桌面，然后点击确定。



3、console口上传版本，console口登录方法参考《1.03 设备管理-Console登录方法》

在AP重启的时候按住不停地按Ctrl+B进入设备的bootroom菜单。

Enter your choice(0-9): ystem is starting...

Press Ctrl+D to access BASIC-BOOTWARE MENU

Booting Normal Extend BootWare....

The Extend BootWare is self-decompressing.....Done!

```
*****
*
*
*      H3C WA4320H-SI BootWare, Version 1.07      *
*
*
*****
```

Copyright (c) 2004-2017 New H3C Technologies Co., Ltd.

```
Compiled Date      : Jun 19 2017
CPU Type           : Atheros AR9531
CPU L1 Cache       : 32KB
CPU Clock Speed    : 650MHz
Memory Type        : SDRAM
Memory Size        : 128MB
Memory Speed       : 450MHz
BootWare Size      : 512KB
Flash Size         : 16MB
PCB Version        : Ver.A
```

BootWare Validating...

Press **Ctrl+B** to enter extended boot menu...

BootWare password: Not required. Please press Enter to continue.

Password recovery capability is enabled.

Note: The current operating device is flash

Enter < Storage Device Operation > to select device.

3.1、升级扩展bootrom版本

要求扩展boot必须为7.13。版本文件中可获取.如果当前版本已经为7.13，直接忽略此步骤。

```
=====
|<1> Boot System                               |
|<2> Enter Serial SubMenu                       |
|<3> Enter Ethernet SubMenu                     |
|<4> File Control                             |
|<5> Restore to Factory Default Configuration   |
|<6> Skip Current System Configuration         |
|<7> BootWare Operation Menu                   |
|<8> Clear Super Password                       |
|<9> Storage Device Operation                   |
|<0> Reboot                                    |
=====
Ctrl+C: Display Copyright
Ctrl+F: Format File System
Enter your choice(0-9): 7 //进入bootware子菜单

=====
|Note:the operating device is flash             |
|<1> Update BootWare By Serial                   |
|<2> Update BootWare By Ethernet                 |
|<0> Exit To Main Menu                           |
=====
Enter your choice(0-2): 2 //设置更新bootware方式通过网线
```

```

=====
|<1> Update Full BootWare                                     |
|<2> Update Extend BootWare                                   |
|<3> Update Basic BootWare                                    |
|<4> Modify Ethernet Parameter                               |
|<0> Exit To Main Menu                                       |
=====
Enter your choice(0-4): 4 //修改以太网参数

```

```

=====
|Note:      "." = Clear field.                                |
|           "-" = Go to previous field.                       |
|           Ctrl+D = Quit.                                    |
=====
Protocol (FTP or TFTP) :tftp
Load File Name       :wap712h_art_v5.bin
                     :apwtu41039757_v7.13.btw //bootware版本名称, 如boot版本已经
是V7.13了, 可忽略本步骤, 继续升级bin版本
Target File Name     :wap712h_art_v5.bin
                     :apwtu41039757_v7.13.btw
Server IP Address    :192.168.1.251 192.168.0.1 //电脑ip地址
Local IP Address     :192.168.1.2 192.168.0.19 //配置和电脑同网段任意地址
Gateway IP Address   :0.0.0.0

```

```

=====
|<1> Update Full BootWare                                     |
|<2> Update Extend BootWare                                   |
|<3> Update Basic BootWare                                    |
|<4> Modify Ethernet Parameter                               |
|<0> Exit To Main Menu                                       |
=====
Enter your choice(0-4): 1 //更新bootware版本
Loading.....Done!
381952 bytes downloaded!
Updating Basic BootWare? [Y/N]Y //手工输入“Y”

```

```
Updating Basic BootWare.....Done!  
Updating Extend BootWare? [Y/N]Y //手工输入“Y”  
Updating Extend BootWare.....Done!
```

3.2、升级bin版本

升级完扩展boot之后重启设备（可以看到此时扩展boot已经是7.13版本），进扩展boot升级设备版本。

```
System is starting...  
Press Ctrl+D to access BASIC-BOOTWARE MENU...  
Booting Normal Extended BootWare  
The Extended BootWare is self-decompressing.....Done.
```

```
*****  
*                                     *  
*           H3C WA4320H-SI BootWare, Version 7.13           *  
*                                     *  
*****  
Copyright (c) 2004-2019 New H3C Technologies Co., Ltd.
```

```
Compiled Date   : Jul 31 2019  
CPU Type       : Atheros AR9531  
CPU L1 Cache   : 32KB  
CPU Clock Speed : 650MHz  
Memory Type    : SDRAM  
Memory Size    : 128MB  
Memory Speed   : 450MHz  
BootWare Size  : 512KB  
Flash Size     : 16MB  
PCB Version    : Ver.A
```

```
BootWare Validating...  
Press Ctrl+B to access EXTENDED-BOOTWARE MENU...
```

Password recovery capability is enabled.
Note: The current operating device is flash

Enter < Storage Device Operation > to select device.

上传版本文件

```
=====
|<1> Boot System                               |
|<2> Enter Serial SubMenu                       |
|<3> Enter Ethernet SubMenu                     |
|<4> File Control                             |
|<5> Restore to Factory Default Configuration   |
|<6> Skip Current System Configuration         |
|<7> BootWare Operation Menu                   |
|<8> Skip Authentication for Console Login     |
|<9> Storage Device Operation                   |
|<0> Reboot                                   |
=====
Ctrl+Z: Access EXTENDED ASSISTANT MENU
Ctrl+F: Format File System
Ctrl+Y: Change AP Mode
Enter your choice(0-9): 3 //进入以太口子菜单
```

```
=====
|Note:the operating device is flash           |
|<1> Download Image Program To SDRAM And Run   |
|<2> Update Main Image File                   |
|<3> Download Files(*.*)                     |
|<4> Modify Ethernet Parameter                 |
|<0> Exit To Main Menu                       |
|                                             |
=====
Enter your choice(0-4): 4 //修改以太口参数
```

```
=====
|Note:    "." = Clear field.                  |
|         "-" = Go to previous field.         |
|         Ctrl+D = Quit.                      |
|                                             |
```

```
=====
```

```
Protocol (FTP or TFTP) :tftp
```

```
Load File Name      :apwtu41039757_v7.13.btw
```

```
                  :wa4300s-oasis.bin //此处注意修改版本文件名称,为wa4300s-  
oasis.bin
```

```
Target File Name    :apwtu41039757_v7.13.btw
```

```
                  :wa4300s-oasis.bin //此处注意修改版本文件名称,为wa4300s-  
oasis.bin
```

```
Server IP Address   :192.168.0.1 //电脑ip地址
```

```
Local IP Address    :192.168.0.19 //配置和电脑同网段任意地址
```

```
Subnet Mask         :0.0.0.0
```

```
Gateway IP Address  :0.0.0.0
```

```
=====
```

```
|Note:the operating device is flash |
```

```
|<1> Download Image Program To SDRAM And Run |
```

```
|<2> Update Main Image File |
```

```
|<3> Download Files(*.*) |
```

```
|<4> Modify Ethernet Parameter |
```

```
|<0> Exit To Main Menu |
```

```
| |
```

```
=====
```

```
Enter your choice(0-4): 3 //更新版本
```

```
Loading.....
```

```
.....
```

```
.....
```

```
.....Done.
```

```
13698048 bytes downloaded!
```

```
Saving file flash:/wa4300s-oasis.bin .....
```

```
.....
```

```
.....
```

```
.....
```

```
.....Done.
```

切换ap模式

```
=====
```

Note:the operating device is flash	
<1> Download Image Program To SDRAM And Run	
<2> Update Main Image File	
<3> Download Files(*.*)	
<4> Modify Ethernet Parameter	
<0> Exit To Main Menu	

Enter your choice(0-4): 0

```
=====
|<1> Boot System                               |
|<2> Enter Serial SubMenu                       |
|<3> Enter Ethernet SubMenu                     |
|<4> File Control                             |
|<5> Restore to Factory Default Configuration   |
|<6> Skip Current System Configuration          |
|<7> BootWare Operation Menu                   |
|<8> Skip Authentication for Console Login      |
|<9> Storage Device Operation                  |
|<0> Reboot                                   |
```

Ctrl+Z: Access EXTENDED ASSISTANT MENU

Ctrl+F: Format File System

Ctrl+Y: Change AP Mode

Enter your choice(0-9):

Please select the new mode

Current mode is Fit

```
|NO. Mode                                     |
|1  Oasis Mode                               |
|2  Fit  Mode                                |
|0  Exit                                     |
=====
```


Enter your choice(0-2):1 //切换为云模式

This operation takes several minutes.Please wait...

Changed to Oasis mode successfully! Please reboot the system now!

切换完成后重启设备

```
=====
|<1> Boot System                               |
|<2> Enter Serial SubMenu                       |
|<3> Enter Ethernet SubMenu                     |
|<4> File Control                             |
|<5> Restore to Factory Default Configuration   |
|<6> Skip Current System Configuration         |
|<7> BootWare Operation Menu                   |
|<8> Skip Authentication for Console Login     |
|<9> Storage Device Operation                  |
|<0> Reboot                                   |
=====
```

Ctrl+Z: Access EXTENDED ASSISTANT MENU

Ctrl+F: Format File System

Ctrl+Y: Change AP Mode

Enter your choice(0-9): 0 //重启

System is starting...

Press Ctrl+D to access BASIC-BOOTWARE MENU...

Booting Normal Extended BootWare

The Extended BootWare is self-decompressing.....Done.

```
*****
*
*          H3C WA4320H-SI BootWare, Version 7.13          *
*
*****
```

Copyright (c) 2004-2019 New H3C Technologies Co., Ltd.

Compiled Date : Jul 31 2019
CPU Type : Atheros AR9531
CPU L1 Cache : 32KB
CPU Clock Speed : 650MHz
Memory Type : SDRAM
Memory Size : 128MB
Memory Speed : 450MHz
BootWare Size : 512KB
Flash Size : 16MB
PCB Version : Ver.A

BootWare Validating...

Press Ctrl+B to access EXTENDED-BOOTWARE MENU...

starting...

配置关键点:

- 1、第三步选择**Download Files**，否则会出现报错；
- 2、需要上传版本文件之后再切换**ap**模式；
- 3、刷完版本之后只能通过**web**管理；
- 4、云**ap**里，只有**WAP712C-LI** 型号，是要用7.17的**boot**的，该版本适配的其他款型均用7.13的**boot**；
- 5、严格按照案例中操作步骤执行，关键注意先上传版本文件之后再切换**ap**模式；
- 6、把从官网下载的云**AP**版本文件改成**wa4300s-oasis.bin**；
- 7、操作完成后设备启动会停留在**starting...**阶段，实际可能已经完成，如果能搜索到**SSID**为**H3C_XXXXXX**（**mac**后6位）的**SSID**说明已经转换完成并启动。

云**AP**是**Fat AP**。初次使用云**AP**，给云**AP**上电后，云**AP**会默认开启4个无线服务：

- 其中一个称之为管理**WIFI**，也称内部**WIFI**，**SSID**为**H3C_XXXXXX**，**XXXXXX**为设备**mac**地址后六位。管理**WIFI**供商铺内部员工管理使用，一般在**2.4G**频段工作，当设备未连接到绿洲时，通过连接管理**WIFI**在浏览器输入**10.40.94.1**或**myap.h3c.com**访问本地**web**页面可进行本设备下的无线服务管理配置，一旦连接上绿洲，将只能通过绿洲平台进行统一的无线服务配置管理。
- 其余3个称为用户**WIFI**，也称商业**WIFI**，**SSID**为**H3C_WiFi_1**、**H3C_WiFi_2**、

H3C_WiFi_3，不加密，不认证，不隐藏。当设备连接到外网，可为已经连接上用户WIFI的用户提供上网服务。