

# 403 Forbidden

本电子书由CyberArticle制作。点击[这里](#)下载  
CyberArticle。注册版本不会显示该信息。 [删除广告](#)

本电子书由CyberArticle制作。点击[这里](#)下载  
CyberArticle。注册版本不会显示该信息。 [删除广告](#)

本电子书由CyberArticle制作。点击[这里](#)下载  
CyberArticle。注册版本不会显示该信息。 [删除广告](#)

## V7防火墙常见冗余组网配置举例（上下路由器三层组网）

### 目录

#### [1 配置需求及说明](#)

##### [1.1 适用的产品系列](#)

##### [1.2 配置需求及实现的效果](#)

#### [2 组网图](#)

#### [3 配置步骤](#)

### [3.1 路由器A配置](#)

#### [3.1.1 配置路由器A下联防火墙接口](#)

### [3.2 防火墙配置](#)

#### [3.2.1 FWA与FWB建立堆叠](#)

#### [3.2.2 配置track联动上下行接口的物理状态](#)

#### [3.2.3 配置冗余组关联冗余接口](#)

#### [3.2.4 开启会话热备](#)

#### [3.2.5 安全策略配置](#)

### [4 检验配置结果](#)

#### [4.1.1 正常时查看冗余组状态](#)

#### [4.1.2 手动关闭1/0/2接口后时查看冗余组状态](#)

#### [4.1.3 注意事项](#)

## 1 配置需求及说明

### 1.1 适用的产品系列

本案例适用于软件平台为Comware V7系列防火墙：F100-X-G2、F1000-X-G2、F100-X-WiNet、F1000-AK、F10X0等。


### 1.2 配置需求及实现的效果

防火墙A与防火墙B堆叠后上联路由器A下联路由器

B，应用户业务需求：

- 1、 防火墙做主备运行
- 2、 正常情况下业务流量全部负载在FWA，FWA出现故障后流量全部切到FWB运行

## 2 组网图



## 3 配置步骤

### 3.1 路由器A配置

### 3.1.1 配置路由器A下联防火墙接口

```
<H3C>system
[H3C]interface GigabitEthernet 1/0/1
[H3C-GigabitEthernet1/0/1] ip address 1.1.1.1 24
[H3C-GigabitEthernet1/0/1]quit
[H3C]ospf 1
[H3C-ospf-1]area 0
[H3C-ospf-1-area-0.0.0.0]network 1.1.1.1 0.0.0.0
路由器B、C、D配置相同不再赘述
```

## 3.2 防火墙配置

### 3.2.1 FWA与FWB建立堆叠

具体配置可参考防火墙虚拟化配置举例，本章不做介绍。

### 3.2.2 配置track联动上下行接口的物理状态

配置track检测上下行端口的物理状态

```
[H3C] track 1 interface gigabitethernet 1/0/1
physical
[H3C-track-1] quit
[H3C] track 2 interface gigabitethernet 1/0/2
physical
[H3C-track-2] quit
```

```
[H3C] track 3 interface gigabitethernet 2/0/1
physical
[H3C-track-3] quit
[H3C] track 4 interface gigabitethernet 2/0/2
physical
[H3C-track-4] quit
```

### 3.2.3 配置冗余组关联冗余接口

#### 1. 创建节点1与防火墙A所有接口绑定

```
[H3C] redundancy group aaa
[H3C-redundancy-group-aaa] node 1
[H3C-redundancy-group-aaa-node1] bind slot 1
[H3C-redundancy-group-aaa-node1] priority 100
[H3C-redundancy-group-aaa-node1] node-
member interface gigabitethernet 1/0/1
[H3C-redundancy-group-aaa-node1] node-
member interface gigabitethernet 1/0/2
[H3C-redundancy-group-aaa-node1] track 1
interface gigabitethernet 1/0/1
[H3C-redundancy-group-aaa-node1] track 2
interface gigabitethernet 1/0/2
[H3C-redundancy-group-aaa-node1] quit
```

#### 2. 创建节点2与防火墙B所有接口绑定

```
[H3C-redundancy-group-aaa] node 2
[H3C-redundancy-group-aaa-node2] bind slot 2
[H3C-redundancy-group-aaa-node2] priority 50
[H3C-redundancy-group-aaa-node2] node-
member interface gigabitethernet 2/0/1
[H3C-redundancy-group-aaa-node2] node-
member interface gigabitethernet 2/0/2
[H3C-redundancy-group-aaa-node2] track 3
interface gigabitethernet 2/0/1
[H3C-redundancy-group-aaa-node2] track 4
interface gigabitethernet 2/0/2
[H3C-redundancy-group-aaa-node2] quit
```

### 3.2.4 开启会话热备

```
[H3C] session synchronization enable
```

### 3.2.5 安全策略配置

#### 1. 将接口加入安全域

将1/0/1与2/0/1加入Untrust区域

```
[H3C]security-zone name Untrust
[H3C-security-zone-Untrust]import      interface
GigabitEthernet 1/0/1
[H3C-security-zone-Untrust]import      interface
GigabitEthernet 2/0/1
```

将1/0/2与2/0/2加入trust区域

```
[H3C]security-zone name trust
```

```
[H3C-security-zone-trust]import          interface
GigabitEthernet 1/0/2
```

```
[H3C-security-zone-trust]import          interface
GigabitEthernet 2/0/2
```

```
[H3C-security-zone-trust]quit
```

防火墙目前版本存在两套安全策略，请在放通安全策略前确认设备运行那种类型的安全策略？以下配置任选其一。

2. 通过命令 “display cu | in security-policy” 如果查到命令行存在 “security-policy disable” 或者没有查到任何信息，则使用下面策略配置。

```
[H3C]display cu | in security-policy
```

```
security-policy disable
```

#创建对象策略pass。

```
[H3C]object-policy ip pass
```

```
[H3C-object-policy-ip-pass] rule 0 pass
```

```
[H3C-object-policy-ip-pass]quit
```

#创建Trust到Untrust域的域间策略调用pass策略。

```
[H3C]zone-pair security source Trust destination
```

local

[H3C-zone-pair-security-Trust- local]object-policy  
apply ip pass

[H3C-zone-pair-security-Trust- local]quit

[H3C]zone-pair security source local destination  
Trust

[H3C-zone-pair-security-local -trust]object-policy  
apply ip pass

[H3C-zone-pair-security-local -trust]quit

[H3C]zone-pair security source Untrust  
destination local

[H3C-zone-pair-security-Untrust- local]object-  
policy apply ip pass

[H3C-zone-pair-security-Untrust- local]quit

[H3C]zone-pair security source local destination  
Untrust

[H3C-zone-pair-security-local -Untrust]object-  
policy apply ip pass

[H3C-zone-pair-security-local -Untrust]quit

[H3C]zone-pair security source Trust destination  
Untrust

[H3C-zone-pair-security-Trust -Untrust]object-  
policy apply ip pass

[H3C-zone-pair-security-Trust -Untrust]quit



3. 通过命令 “display cu | in security-policy” 如果查到命令行存在 “security-policy ip” 并且没有查到 “security-policy disable” ， 则使用下面策略配置。

```
[H3C]display cu | in security-policy
```

```
security-policy ip
```

创建安全策略并放通local到trust和trust到local的安全策略。

```
[H3C]security-policy ip
```

```
[H3C-security-policy-ip]rule 10 name test
```

```
[H3C-security-policy-ip-10-test]action pass
```

```
[H3C-security-policy-ip-10-test]source-zone local
```

```
[H3C-security-policy-ip-10-test]source-zone Trust
```

```
[H3C-security-policy-ip-10-test]source-zone
```

```
Untrust
```

```
[H3C-security-policy-ip-10-test]destination-zone
```

```
local
```

```
[H3C-security-policy-ip-10-test]destination-zone
```

```
Trust
```

```
[H3C-security-policy-ip-10-test]destination-zone
```

```
Untrust
```

```
[H3C-security-policy-ip-10-test]quit
```

## 4 检验配置结果

### 4.1.1 正常时查看冗余组状态

节点1为主用状态，节点二为备用状态。

```
[H3C-redundancy-group-aaa] display redundancy group aaa
```

Redundancy group aaa (ID 1):

Node ID	Slot	Priority	Status	Track weight
1	Slot1	100	Primary	255
2	Slot2	50	Secondary	255

Preempt delay time remained : 0 min

Preempt delay timer setting : 1 min

Remaining hold-down time : 0 sec

Hold-down timer setting : 1 sec

Manual switchover request : No

Member interfaces:

Node 1:

Node member	Physical status
-------------	-----------------

GE1/0/1 UP

GE1/0/2 UP

Track info:

Track	Status	Reduced weight	Interface
1	Positive	255	GE1/0/1
2	Positive	255	GE1/0/2

Node 2:

Node member Physical status

GE2/0/1 UP

GE2/0/2 UP

Track info:

Track	Status	Reduced weight	Interface
3	Positive	255	GE2/0/1
4	Positive	255	GE2/0/2

#### 4.1.2 手动关闭1/0/2接口后时查看冗余组状态

查看到主备状态已经发生了变化，并且1/0/1与1/0/2的物理状态全部置为down。

[H3C] display redundancy group aaa

Redundancy group aaa (ID 1):

Node ID	Slot	Priority	Status	Track weight
1	Slot1	100	Secondary	-255
2	Slot2	50	Primary	255

Preempt delay time remained : 0 min  
Preempt delay timer setting : 1 min  
Remaining hold-down time : 0 sec  
Hold-down timer setting : 1 sec  
Manual switchover request : No

Member interfaces:

Node 1:

Node member	Physical status
GE1/0/1	DOWN(redundancy down)
GE1/0/2	DOWN

Track info:

Track	Status	Reduced weight	Interface
1	Negative	255	GE1/0/1
2	Negative	255	GE1/0/2

(Fault)

Node 2:

Node member	Physical status
GE2/0/1	UP
GE2/0/2	UP

Track info:

Track	Status	Reduced weight	Interface
3	Positive	255	GE2/0/1
4	Positive	255	GE2/0/2

#### 4.1.3 注意事项

- 1、配置冗余组后需要加入冗余接口的物理口全部连接，否则会造成冗余组异常。