

Previous topic

[gnuradio.trellis](#)

Next topic

[gnuradio.vocoder](#)

This Page

[Show Source](#)

Quick search

Go

Enter search terms or a module,
class or function name.

gnuradio.uhd

```
class gnuradio.uhd.usrp_block(*args, **kwargs)
```

Base class for USRP blocks.

Note that many of the functions defined here differ between Rx and Tx configurations. As an example, `set_center_freq()` will set the Rx frequency for a `usrp_source` object, and the Tx frequency on a `usrp_sink` object.