

SDK6 API Middleware (Flow)

Version 1.2
June 24, 2015



Confidentiality Notice:

Copyright © 2015 Ambarella Inc.

The contents of this document are proprietary and confidential information of Ambarella Inc.

The material in this document is for information only. Ambarella assumes no responsibility for errors or omissions and reserves the right to change, without notice, product specifications, operating characteristics, packaging, ordering, etc. Ambarella assumes no liability for damage resulting from the use of information contained in this document. All brands, product names and company names are trademarks of their respective owners.

US

3101 Jay Street
Ste. 110
Santa Clara, CA 95051, USA
Phone: +1.408.734.8888
Fax: +1.408.734.0788

Hong Kong

Unit A&B, 18/F, Spectrum Tower
53 Hung To Road
Kwun Tong, Kowloon
Phone: +85.2.2806.8711
Fax: +85.2.2806.8722

Korea

6 Floor, Hanwon-Bldg.
Sunae-Dong, 6-1, Bundang-Gu
SeongNam-City, Kyunggi-Do
Republic of Korea 463-825
Phone: +031.717.2780
Fax: +031.717.2782

China - Shanghai

9th Floor, Park Center
1088 Fangdian Road, Pudong New District
Shanghai 201204, China
Phone: +86.21.6088.0608
Fax: +86.21.6088.0366

Taiwan

Suite C1, No. 1, Li-Hsin Road 1
Science-Based Industrial Park
Hsinchu 30078, Taiwan
Phone: +886.3.666.8828
Fax: +886.3.666.1282

Japan - Yokohama

Shin-Yokohama Business Center Bldg. 5th Floor
3-2-6 Shin-Yokohama, Kohoku-ku,
Yokohama, Kanagawa, 222-0033, Japan
Phone: +81.45.548.6150
Fax: +81.45.548.6151

China - Shenzhen

Unit E, 5th Floor
No. 2 Finance Base
8 Ke Fa Road
Shenzhen, 518057, China
Phone: +86.755.3301.0366
Fax: +86.755.3301.0966

I Contents

1	Display	1
1.1	Display: Overview	1
1.2	Display: List of Functions	1
2	OSD	25
2.1	OSD: Overview	25
2.2	OSD: List of Functions	25
3	FIFO	44
3.1	FIFO: Overview	44
3.2	FIFO: List of Functions	44
4	ImgDzoom	61
4.1	ImgDzoom: Overview	61
4.2	ImgDzoom: List of APIs	61
5	Initialization	81
5.1	Initialization: Overview	81
5.2	Initialization: List of APIs	81
6	Flow Pipeline	87
6.1	Flow Pipeline: Overview	87
6.2	Flow Pipeline: List of APIs for DecodeMgr Pipeline	87
6.3	Flow Pipeline: List of APIs for EncodeMgr Pipeline	101
7	Codec	117
7.1	Codec: Overview	117
7.2	Codec: List of APIs	117
7.3	Codec: List of APIs for DummyDec	129
7.4	Codec: List of APIs for StillDec	133
7.5	Codec: List of APIs for VideoDec	147
7.6	Codec: List of APIs for AudioEnc	161
7.7	Codec: List of APIs for DummyEnc	169
7.8	Codec: List of APIs for StillEnc	174

7.9	Codec: List of APIs for VideoEnc.	189
8	VIN	215
8.1	VIN: Overview	215
8.2	VIN: List of APIs	215
9	System Errors	225
9.1	System Errors: Overview	225
9.2	System Errors: Error Code List	225
Appendix 10	Important Notice	A230
Appendix 11	Revision History	A231

Confidential
For HAOTEK Only

1 Display

1.1 Display: Overview

This chapter provides information regarding the display module which is used to control an output device. In most cases, two video output channels are provided: a digital-only channel as well as a fully functional channel.

1.2 Display: List of Functions

- (Section 1.2.1) [AmpDisplay_Create](#)
- (Section 1.2.2) [AmpDisplay_CreateWindow](#)
- (Section 1.2.3) [AmpDisplay_Delete](#)
- (Section 1.2.4) [AmpDisplay_DeleteWindow](#)
- (Section 1.2.5) [AmpDisplay_GetDefaultCfg](#)
- (Section 1.2.6) [AmpDisplay_GetDefaultInitCfg](#)
- (Section 1.2.7) [AmpDisplay_GetDefaultWindowCfg](#)
- (Section 1.2.8) [AmpDisplay_GetDeviceCfg](#)
- (Section 1.2.9) [AmpDisplay_GetInfo](#)
- (Section 1.2.10) [AmpDisplay_GetWindowCfg](#)
- (Section 1.2.11) [AmpDisplay_Init](#)
- (Section 1.2.12) [AmpDisplay_SetDeviceCfg](#)
- (Section 1.2.13) [AmpDisplay_SetWindowActivateFlag](#)
- (Section 1.2.14) [AmpDisplay_SetWindowCfg](#)
- (Section 1.2.15) [AmpDisplay_Start](#)
- (Section 1.2.16) [AmpDisplay_Stop](#)
- (Section 1.2.17) [AmpDisplay_Update](#)
- (Section 1.2.18) [AmpDisplay_SetMaxVoutSize](#)

1.2.1 AmpDisplay_Create

API Syntax:

AmpDisplay_Create (AMP_DISP_CFG_s * Cfg, AMP_DISP_HDLR_s ** DispHdlr)

Function Description:

- This function is used to create a display handler, which manages window handler memory.

Parameters:

Type	Parameter	Description
AMP_DISP_CFG_s *	Cfg	Display handler configuration parameters (Section 1.2.1.1)
AMP_DISP_HDLR_s **	DispHdlr	The display handler instance for the user (Section 1.2.1.4)

Table 1-1. Parameters for SDK6 API Middleware Display API **AmpDisplay_Create()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-2. Returns for SDK6 Middleware Display API **AmpDisplay_Create()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.1.1 AmpDisplay_Create > AMP_DISP_CFG_s

Type	Field	Description
AMP_DISP_DEV_CFG_s	Device	Device information (Section 1.2.1.2)
UINT32	MaxNumWindow	Maximum number of window handlers set from upper-layer VOUT system type
AMP_DISP_VOUT_SYSTEM_e	SystemType	Device system type AMP_DISP_NTSC: NTSC AMP_DISP_PAL: PAL / SECAM
UINT32	ScreenRotate	Flag for device screen rotation
UINT8	Out3dMode	3D output mode
AMP_CALLBACK_f	CbCfgUpdated	Callback for VOUT change use
AMP_CALLBACK_f	CbCodecEvent	Callback for VOUT change use

Table 1-3. Definition of **AMP_DISP_CFG_s** for Display API **AmpDisplay_Create()**.

1.2.1.2 AmpDisplay_Create > AMP_DISP_DEV_CFG_s

Type	Field	Description
AMP_DISP_CHANNEL_IDX_e	Channel	Channel used by the device AMP_DISP_CHANNEL_DCHAN: VOUT channel 0, for digital output only AMP_DISP_CHANNEL_FCHAN: VOUT channel 1, for full-function output only AMP_DISP_CHANNEL_NUM: Total number of VOUT channels
AMP_DISP_DEV_IDX_e	Deviceld	Device type AMP_DISP_LCD: Display handler on LCD AMP_DISP_CVBS: Display handler on CVBS AMP_DISP_HDMI: Display handler on HDMI AMP_DISP_NONE: Display handler on Nothing
UINT32	DeviceMode	Resolution
UINT32	DeviceAr	Device aspect ratio
AMP_DISP_CUSTOM_CFG_s	CustomCfg	Customize CFG, set only if you do not want default value

Table 1-4. Definition of **AMP_DISP_DEV_CFG_s** for Display API **AmpDisplay_Create()**.

1.2.1.3 AmpDisplay_Create > AMP_DISP_CUSTOM_CFG_s

Type	Field	Description
UINT8	EnCustomCfg	Enable custom config for the device or not
AMBA_HDMI_VIDEO_FRAME_LAYOUT_e	Cgf.HDMI.FrameLayout	2D/2D video transmission

Type	Field	Description
AMBA_DSP_VOUT_HDMI_OUTPUT_MODE_e	Cgf.HDMI.PixelFormat	RGB/YCbCr color space
AMBA_HDMI_QUANTIZATION_RANGE_e	Cgf.HDMI.QuantRange	Quantization range of RGB/YCC
HDMI_AUDIO_SAMPLE_RATE_e	Cgf.HDMI.SampleRate	Audio sample rate
HDMI_AUDIO_CHANNEL_ALLOC_e	Cgf.HDMI.SpeakerAlloc	Audio channel/speaker allocation ID
HDMI_AUDIO_CLOCK_FREQUENCY_e	Cgf.HDMI.OverSample	Audio clock oversampling ratio
AMP_DISP_LCD_BACKLIGHT_e	Cgf.LCD.BackLight	LCD backlight control

Table 1-5. Definition of **AMP_DISP_CUSTOM_CFG_s** for Display API **AmpDisplay_Create()**.

1.2.1.4 AmpDisplay_Create > AMP_DISP_HDLR_s

Type	Field	Description
void *	Ctx	Pointer to codec context

Table 1-6. Definition of **AMP_DISP_HDLR_s** for Display API **AmpDisplay_Create()**.

1.2.2 AmpDisplay_CreateWindow

API Syntax:

AmpDisplay_CreateWindow (AMP_DISP_HDLR_s * DispHdlr, AMP_DISP_WINDOW_CFG_s * Cfg, AMP_DISP_WINDOW_HDLR_s ** WindowHdlr)

Function Description:

- This function is used to create a window handler, which manages the location of elements on the display.

Parameters:

Type	Parameter	Description
AMP_DISP_HDLR_s **	DispHdlr	The display handler instance for the user (Section 1.2.1.4)
AMP_DISP_WINDOW_CFG_s *	Cfg	Window configuration parameters (Section 1.2.2.1)
AMP_DISP_WINDOW_HDLR_s **	WindowHdlr	Window handler instance for the user (Section 1.2.2.5)

Table 1-7. Parameters for SDK6 API Middleware Display API **AmpDisplay_CreateWindow()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-8. Returns for SDK6 Middleware Display API **AmpDisplay_CreateWindow()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.2.1 AmpDisplay_CreateWindow > AMP_DISP_WINDOW_CFG_s

Type	Field	Description
AMP_DISP_WINDOW_SRC_e	Source	Source of the window AMP_DISP_OSD: OSD window source AMP_DISP_ENC: ENC window source AMP_DISP_DEC: DEC window source AMP_DISP_DEFIMG: Default image window source AMP_DISP_BACKGROUND_COLOR: Background window source
union { struct { void * OsdHdlr } Osd struct { AMBA_DSP_CHANNEL_ID_u VinCh AMP_2D_BUFFER_s Blend- Table UINT8 ViewZoneID AMP_ROTATION_e Rotate } Enc struct { void * DecHdlr } Dec struct { AMP_YUV_BUFFER_s * Image UINT8 FieldRepeat } DefImage }	Source-Desc	Information to fetch source. For OSD, it will be OsdHdlr . For ENC it will be VinCh . For DEC, it will be video/still DecHdlr . VinCh : VIN channel source BlendTable : Blend table used when overlapping with other ENC windows (Section 1.2.2.2) ViewZoneID : Indicates the view zone of the larger input; Default 0 Rotate : Rotate the source Image : (Section 1.2.2.3)
AMP_AREA_s	CropArea	The crop area of the window source buffer (Section 1.2.2.4)
AMP_AREA_s	TargetAreaOnPlane	Window display position on the device (Section 1.2.2.4)
UINT32	Layer	A small number of layers would be placed at the bottom.

Table 1-9. Definition of **AMP_DISP_WINDOW_CFG_s** for Display API **AmpDisplay_CreateWindow()**.

1.2.2.2 AmpDisplay_CreateWindow > AMP_2D_BUFFER_s

Type	Field	Description
UINT8 *	Buf	Buffer
UINT32	Width	Buffer width
UINT32	Height	Buffer height
UINT32	Pitch	Buffer pitch

Table 1-10. Definition of **AMP_2D_BUFFER_s** for Display API **AmpDisplay_CreateWindow()**.

1.2.2.3 AmpDisplay_CreateWindow > AMP_YUV_BUFFER_s

Type	Field	Description
AMP_COLOR_FORMAT_e	ColorFmt	Color format of the YUV buffer
UINT32	Width	Buffer width
UINT32	Height	Buffer height
UINT32	Pitch	Buffer pitch
UINT8 *	LumaAddr	Luma address
UINT8*	ChromaAddr	Chroma address
AMP_AREA_s	AOI	Area of interest (Section 1.2.2.4)

Table 1-11. Definition of **AMP_YUV_BUFFER_s** for Display API **AmpDisplay_CreateWindow()**.

1.2.2.4 AmpDisplay_CreateWindow > AMP_AREA_s

Type	Field	Description
UINT32	X	X offset of the area
UINT32	Y	Y offset of the area
UINT32	Width	Width of the area
UINT32	Height	Height of the area

Table 1-12. Definition of **AMP_AREA_s** for Display API **AmpDisplay_CreateWindow()**.

1.2.2.5 AmpDisplay_Create > AMP_DISP_WINDOW_HDLR_s

Type	Field	Description
void *	Ctx	Pointer to codec context

Table 1-13. Definition of **AMP_DISP_WINDOW_HDLR_s** for Display API **AmpDisplay_CreateWindow()**.

1.2.3 AmpDisplay_Delete

API Syntax:

AmpDisplay_Delete (AMP_DISP_HDLR_s * DispHdlr)

Function Description:

- This function is used to delete a window handler, which clears the display handler structure.

Parameters:

Type	Parameter	Description
AMP_DISP_HDLR_s **	DispHdlr	The display handler instance for the user (Section 1.2.1.4)

Table 1-14. Parameters for SDK6 API Middleware Display API **AmpDisplay_Delete()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-15. Returns for SDK6 Middleware Display API **AmpDisplay_Delete()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.4 AmpDisplay_DeleteWindow

API Syntax:

AmpDisplay_DeleteWindow (AMP_DISP_WINDOW_HDLR_s * WindowHdlr)

Function Description:

- This function is used to delete a window handler, which clears the window handler structure.

Parameters:

Type	Parameter	Description
AMP_DISP_WINDOW_HDLR_s **	WindowHdlr	Window handler instance for the user (Section 1.2.2.5)

Table 1-16. Parameters for SDK6 API Middleware Display API **AmpDisplay_DeleteWindow()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-17. Returns for SDK6 Middleware Display API **AmpDisplay_DeleteWindow()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.5 AmpDisplay_GetDefaultCfg

API Syntax:

AmpDisplay_GetDefaultCfg (AMP_DISP_CFG_s * Cfg)

Function Description:

- This function is used to retrieve the default configuration in order to create a display handler.

Parameters:

Type	Parameter	Description
AMP_DISP_CFG_s *	Cfg	Display handler configuration parameters (Section 1.2.1.1)

Table 1-18. Parameters for SDK6 API Middleware Display API **AmpDisplay_GetDefaultCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-19. Returns for SDK6 Middleware Display API **AmpDisplay_GetDefaultCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.6 AmpDisplay_GetDefaultInitCfg

API Syntax:

AmpDisplay_GetDefaultInitCfg (AMP_DISP_INIT_CFG_s * Cfg)

Function Description:

- This function is used to retrieve the default initial configuration in order to initialize the display module.

Parameters:

Type	Parameter	Description
AMP_DISP_INIT_CFG_s *	Cfg	Display module initialization configuration parameters (Section 1.2.6.1)

Table 1-20. Parameters for SDK6 API Middleware Display API **AmpDisplay_GetDefaultInitCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-21. Returns for SDK6 Middleware Display API **AmpDisplay_GetDefaultInitCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.6.1 AmpDisplay_GetDefaultInitCfg > AMP_DISP_INIT_CFG_s

Type	Field	Description
UINT8 *	MemoryPoolAddr	Buffer start address used by the display module to create the display handler array
UINT32	MemoryPoolSize	Buffer size
UINT32	MaxDeviceInterHdlr	The desired number of device handlers
UINT32	MaxWindowInterHdlr	The total desired number of window handlers
UINT32	MaxHdmiCheck	The maximum number of HDMI check occurrences

Table 1-22. Definition of **AMP_DISP_INIT_CFG_s** for Display API **AmpDisplay_GetDefaultInitCfg()**.

Confidential
For HAOTEK Only

1.2.7 AmpDisplay_GetDefaultWindowCfg

API Syntax:

AmpDisplay_GetDefaultWindowCfg (AMP_DISP_WINDOW_CFG_s * Cfg)

Function Description:

- This function is used to retrieve default window configuration parameters.

Parameters:

Type	Parameter	Description
AMP_DISP_WINDOW_CFG_s *	Cfg	Window configuration parameters (Section 1.2.2.1)

Table 1-23. Parameters for SDK6 API Middleware Display API **AmpDisplay_GetDefaultWindowCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-24. Returns for SDK6 Middleware Display API **AmpDisplay_GetDefaultWindowCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.8 AmpDisplay_GetDeviceCfg

API Syntax:

AmpDisplay_GetDeviceCfg (AMP_DISP_HDLR_s * DispHdlr, AMP_DISP_DEV_CFG_s * DevCfg)

Function Description:

- This function is used to retrieve and send device information to a display handler.

Parameters:

Type	Parameter	Description
AMP_DISP_HDLR_s **	DispHdlr	The display handler instance for the user (Section 1.2.1.4)
AMP_DISP_DEV_CFG_s *	DevCfg	Device configuration parameters (Section 1.2.1.2)

Table 1-25. Parameters for SDK6 API Middleware Display API **AmpDisplay_GetDeviceCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-26. Returns for SDK6 Middleware Display API **AmpDisplay_GetDeviceCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.9 AmpDisplay_GetInfo

API Syntax:

AmpDisplay_GetInfo (AMP_DISP_HDLR_s * DispHdlr, AMP_DISP_INFO_s * OutputInfo)

Function Description:

- This function is used to retrieve and send device/system information to the DSP.

Parameters:

Type	Parameter	Description
AMP_DISP_HDLR_s **	DispHdlr	The display handler instance for the user (Section 1.2.1.4)
AMP_DISP_INFO_s *	OutputInfo	Device VOUT information (Section 1.2.9.1)

Table 1-27. Parameters for SDK6 API Middleware Display API **AmpDisplay_GetInfo()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-28. Returns for SDK6 API Middleware Display API **AmpDisplay_GetInfo()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.9.1 AmpDisplay_GetInfo > AMP_DISP_INFO_s

Type	Field	Description
AMP_DISP_VOUT_INFO_s	DeviceInfo	Device VOUT information from the driver or DSP
AMP_DISP_WINDOW_HDLR_s *	WindowHdlr	Active window handler instance (Section 1.2.2.5)

Table 1-29. Definition of **AMP_DISP_INFO_s** for Display API **AmpDisplay_GetInfo()**.

1.2.10 AmpDisplay_GetWindowCfg

API Syntax:

AmpDisplay_GetWindowCfg (AMP_DISP_WINDOW_HDLR_s * WindowHdlr, AMP_DISP_WINDOW_CFG_s * Cfg)

Function Description:

- This function is used to retrieve window handler information.

Parameters:

Type	Parameter	Description
AMP_DISP_WINDOW_HDLR_s **	WindowHdlr	Window handler instance for the user (Section 1.2.2.5)
AMP_DISP_WINDOW_CFG_s *	Cfg	Window configuration parameters (Section 1.2.2.1)

Table 1-30. Parameters for SDK6 API Middleware Display API **AmpDisplay_GetWindowCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-31. Returns for SDK6 Middleware Display API **AmpDisplay_GetWindowCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.11 AmpDisplay_Init

API Syntax:

AmpDisplay_Init (AMP_DISP_INIT_CFG_s * Cfg)

Function Description:

- This function is used to initialize the display module, as well as arrange display handler memory and initialize related flags.

Parameters:

Type	Parameter	Description
AMP_DISP_INIT_CFG_s *	Cfg	Display module initialization configuration parameters (Section 1.2.6.1)

Table 1-32. Parameters for SDK6 API Middleware Display API **AmpDisplay_Init()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-33. Returns for SDK6 Middleware Display API **AmpDisplay_Init()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.12 AmpDisplay_SetDeviceCfg

API Syntax:

AmpDisplay_SetDeviceCfg (AMP_DISP_HDLR_s * DispHdlr, AMP_DISP_DEV_CFG_s * DevCfg)

Function Description:

- This function is used to set/update and send device information to a display handler. Takes effect upon starting the display.

Parameters:

Type	Parameter	Description
AMP_DISP_HDLR_s **	DispHdlr	The display handler instance for the user (Section 1.2.1.3)
AMP_DISP_DEV_CFG_s *	DevCfg	Device configuration parameters (Section 1.2.1.2)

Table 1-34. Parameters for SDK6 API Middleware Display API **AmpDisplay_SetDeviceCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-35. Returns for SDK6 Middleware Display API **AmpDisplay_SetDeviceCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.13 AmpDisplay_SetWindowActivateFlag

API Syntax:

AmpDisplay_SetWindowActivateFlag (AMP_DISP_WINDOW_HDLR_s * WindowHdlr, UINT8 ActiveFlag)

Function Description:

- This function is used to activate a window on a device. Takes effect after **AmpDisplay_UpdateWindowState**.

Parameters:

Type	Parameter	Description
AMP_DISP_WINDOW_HDLR_s **	WindowHdlr	Window handler instance for the user to show OSD (Section 1.2.2.5)
UINT8	ActiveFlag	

Table 1-36. Parameters for SDK6 API Middleware Display API **AmpDisplay_SetWindowActivateFlag()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-37. Returns for SDK6 Middleware Display API **AmpDisplay_SetWindowActivateFlag()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.14 AmpDisplay_SetWindowCfg

API Syntax:

AmpDisplay_SetWindowCfg (AMP_DISP_WINDOW_HDLR_s * WindowHdlr, AMP_DISP_WINDOW_CFG_s * Cfg)

Function Description:

- This function is used to set/update window handler information and send the event to the application to process if the relevant window is active.

Parameters:

Type	Parameter	Description
AMP_DISP_WINDOW_HDLR_s **	WindowHdlr	Window handler instance for the user (Section 1.2.2.5)
AMP_DISP_WINDOW_CFG_s *	Cfg	Updated window configuration parameters (Section 1.2.2.1)

Table 1-38. Parameters for SDK6 API Middleware Display API **AmpDisplay_SetWindowCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-39. Returns for SDK6 Middleware Display API **AmpDisplay_SetWindowCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.15 AmpDisplay_Start

API Syntax:

AmpDisplay_Start (AMP_DISP_HDLR_s * DispHdlr)

Function Description:

- This function is used to set-up the device. The driver should be instructed to initialize the device, after which a callback event should be sent to the application.

Parameters:

Type	Parameter	Description
AMP_DISP_HDLR_s **	DispHdlr	The display handler instance for the user (Section 1.2.1.4)

Table 1-40. Parameters for SDK6 API Middleware Display API **AmpDisplay_Start()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-41. Returns for SDK6 Middleware Display API **AmpDisplay_Start()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.16 AmpDisplay_Stop

API Syntax:

AmpDisplay_Stop (AMP_DISP_HDLR_s * DispHdlr)

Function Description:

- This function is used to disable the device. The driver should be instructed to shut-down the device, after which a callback event should be sent to the application.

Parameters:

Type	Parameter	Description
AMP_DISP_HDLR_s **	DispHdlr	The display handler instance for the user (Section 1.2.1.4)

Table 1-42. Parameters for SDK6 API Middleware Display API **AmpDisplay_Stop()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-43. Returns for SDK6 Middleware Display API **AmpDisplay_Stop()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.17 AmpDisplay_Update

API Syntax:

AmpDisplay_Update (AMP_DISP_HDLR_s * DispHdlr)

Function Description:

- This function is used to update the window state on a display. Both **AmpDisplay_SetWindowCfg** and **AmpDisplay_ActivateWindow** take effect after this function is invoked.

Parameters:

Type	Parameter	Description
AMP_DISP_HDLR_s **	DispHdlr	The display handler instance for the user (Section 1.2.1.4)

Table 1-44. Parameters for SDK6 API Middleware Display API **AmpDisplay_Update()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-45. Returns for SDK6 Middleware Display API **AmpDisplay_Update()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

1.2.18 AmpDisplay_SetMaxVoutSize

API Syntax:

AmpDisplay_SetMaxVoutSize (UINT32 width, UINT32 height)

Function Description:

- This function is used to setup max vout0 size. The function **MUST** be invoked before middleware initialization if you want to enable seamless feature for memory allocation (seamless is an optional feature and may not be supported on every chip).

Parameters:

Type	Parameter	Description
UINT32	Width	Max width of out0
UINT32	Height	Max height of vout0

Table 1-46. Parameters for SDK6 API Middleware Display API **AmpDisplay_SetMaxVoutSize()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 1-47. Returns for SDK6 Middleware Display API **AmpDisplay_SetMaxVout0Size()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2 OSD

2.1 OSD: Overview

This chapter provides information regarding on-screen display (OSD) APIs. The OSD command set provides functions used to set-up the on-screen display buffer, which should be prepared with data in the specified format. The DSP will blend the buffer according to video settings.

2.2 OSD: List of Functions

- [\(Section 2.2.1\) AmpOsd_Create](#)
- [\(Section 2.2.2\) AmpOsd_Delete](#)
- [\(Section 2.2.3\) AmpOsd_GetBufferCfg](#)
- [\(Section 2.2.4\) AmpOsd_GetCfg](#)
- [\(Section 2.2.5\) AmpOsd_GetClutCfg](#)
- [\(Section 2.2.6\) AmpOsd_GetDefaultCfg](#)
- [\(Section 2.2.7\) AmpOsd_GetDefaultInitCfg](#)
- [\(Section 2.2.8\) AmpOsd_GetHdrInfo](#)
- [\(Section 2.2.9\) AmpOsd_GetTransparentCfg](#)
- [\(Section 2.2.10\) AmpOsd_Init](#)
- [\(Section 2.2.11\) AmpOsd_SetBufferCfg](#)
- [\(Section 2.2.12\) AmpOsd_SetCfg](#)
- [\(Section 2.2.13\) AmpOsd_SetClutCfg](#)
- [\(Section 2.2.14\) AmpOsd_SetTransparentCfg](#)

2.2.1 AmpOsd_Create

API Syntax:

AmpOsd_Create (AMP_OSD_CFG_s * cfg, AMP_OSD_HDLR_s ** osdHdlr)

Function Description:

- This function is used to create an OSD handler. Note that an OSD handler must be registered in order to manage OSD-related operations.

Parameters:

Type	Parameter	Description
AMP_OSD_CFG_s *	cfg	OSD handler configuration parameters (Section 2.2.1.2)
AMP_OSD_HDLR_s *	osdHdlr	OSD handler instance (Section 2.2.1.1)

Table 2-1. Parameters for SDK6 API Middleware OSD API **AmpOsd_Create()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-2. Returns for SDK6 Middleware OSD API **AmpOsd_Create()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.1.1 AmpOsd_ActivateOsdWindow > AMP_OSD_HDLR_s

Type	Field	Description
void *	Ctx	Pointer to codec context

Table 2-3. Definition of **AMP_OSD_HDLR_s** for OSD API **AmpOsd_ActivateOsdWindow()**.

2.2.1.2 AmpOsd_Create > AMP_OSD_CFG_s

Type	Field	Description
AMP_OSD_BUF-FER_CFG_s	BufCfg	OSD buffer configuration (Section 2.2.1.3)
AMP_OSD_CLUT_CFG_s	ColorLookupTable	Color lookup table address (Section 2.2.1.4)
AMP_OSD_TRANS-PARENT_CFG_s	TransparentColor	Transparency color configuration (Section 2.2.1.5)
AMP_DISP_OSD_HW_RESCALER_TYPE_e	HwScalerType	The hardware scaler type HW_OSD_RESCALER_NONE: No scale HW_OSD_RESCALER_INT: Scale to N times HW_OSD_RESCALER_ANY: Scale to any size (aligned) HW_OSD_RESCALER_UP: Only scale up
UINT8	OsdBufRepeatField	Repeat OSD buffer for top field and bottom field in interlaced mode
UINT8	GlobalBlend	Determines the OSD transparency color

Table 2-4. Definition of **AMP_OSD_CFG_s** for OSD API **AmpOsd_Create()**.

2.2.1.3 AmpOsd_Create > AMP_OSD_BUFFER_CFG_s

Type	Field	Description
AMP_DISP_OSD_FORMAT_e	PixelFormat	OSD buffer color format AMP_OSD_8BIT_CLUT_MODE: 8-bit color look-up table mode AMP_OSD_16BIT_VYU_RGB_565: VYU_RGB_565 AMP_OSD_16BIT_UYV_BGR_565: UYV_BGR_565 AMP_OSD_16BIT_AYUV_4444: AYUV_4444 AMP_OSD_16BIT_RGBA_4444: RGBA_4444 AMP_OSD_16BIT_BGRA_4444: BGRA_4444 AMP_OSD_16BIT_ABGR_4444: ABGR_4444 AMP_OSD_16BIT_ARGB_4444: ARGB_4444 AMP_OSD_16BIT_AYUV_1555: AYUV_1555 AMP_OSD_16BIT_YUV_1555: YUV_1555, MSB ignored AMP_OSD_16BIT_RGBA_5551: RGBA_5551 AMP_OSD_16BIT_BGRA_5551: BGRA_5551 AMP_OSD_16BIT_ABGR_1555: ABGR_1555 AMP_OSD_16BIT_ARGB_1555: ARGB_1555 AMP_OSD_32BIT_AYUV_8888: AYUV_8888 AMP_OSD_32BIT_RGBA_8888: RGBA_8888 AMP_OSD_32BIT_BGRA_8888: BGRA_8888 AMP_OSD_32BIT_ABGR_8888: ABGR_8888 AMP_OSD_32BIT_ARGB_8888: ARGB_8888
UINT32	BufWidth	OSD buffer width
UINT32	BufHeight	OSD buffer height
UINT32	BufPitch	OSD buffer pitch
UINT32	BufAddr	Current buffer

Table 2-5. Definition of **AMP_OSD_BUFFER_CFG_s** for OSD API **AmpOsd_Create()**.

2.2.1.4 AmpOsd_Create > AMP_OSD_CLUT_CFG_s

Type	Field	Description
UINT8 *	RgbTable	CLUT RGB Table
UINT8 *	BlendTable	CLUT Blend Table
UINT8 *	YuvTable	CLUT YUV Table

Table 2-6. Definition of **AMP_OSD_CLUT_CFG_s** for OSD API **AmpOsd_Create()**.

2.2.1.5 AmpOsd_Create > AMP_OSD_TRANSPARENT_CFG_s

Type	Field	Description
UINT8	Enable	Enable transparency
UINT16	Color	Transparency color (one only)

Table 2-7. Definition of **AMP_OSD_TRANSPARENT_CFG_s** for OSD API **AmpOsd_Create()**.

Confidential
For HAOTEK Only

2.2.2 AmpOsd_Delete

API Syntax:

AmpOsd_Delete (AMP_OSD_HDLR_s * osdHdlr)

Function Description:

- This function is used to delete an OSD handler, which clears the OSD handler information and de-registers the handler.

Parameters:

Type	Parameter	Description
AMP_OSD_HDLR_s *	osdHdlr	OSD handler instance (Section 2.2.1.1)

Table 2-8. Parameters for SDK6 API Middleware OSD API **AmpOsd_Delete()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-9. Returns for SDK6 Middleware OSD API **AmpOsd_Delete()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.3 AmpOsd_GetBufferCfg

API Syntax:

AmpOsd_GetBufferCfg (AMP_OSD_HDLR_s * osdHdlr, AMP_OSD_BUFFER_CFG_s * cfg)

Function Description:

- This function is used to retrieve the buffer-related configuration settings of a specified OSD handler.

Parameters:

Type	Parameter	Description
AMP_OSD_HDLR_s *	osdHdlr	OSD handler instance (Section 2.2.1.1)
AMP_OSD_BUFFER_CFG_s *	cfg	OSD configuration parameters (Section 2.2.1.3)

Table 2-10. Parameters for SDK6 API Middleware OSD API **AmpOsd_GetBufferCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-11. Returns for SDK6 Middleware OSD API **AmpOsd_GetBufferCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.4 AmpOsd_GetCfg

API Syntax:

AmpOsd_GetCfg (AMP_OSD_HDLR_s * osdHdlr, AMP_OSD_CFG_s * cfg)

Function Description:

- This function is used to retrieve OSD configuration settings of a specified OSD handler.

Parameters:

Type	Parameter	Description
AMP_OSD_HDLR_s *	osdHdlr	OSD handler instance (Section 2.2.1.1)
AMP_OSD_CFG_s *	cfg	OSD configuration parameters (Section 2.2.1.2)

Table 2-12. Parameters for SDK6 API Middleware OSD API **AmpOsd_GetCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-13. Returns for SDK6 Middleware OSD API **AmpOsd_GetCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.5 AmpOsd_GetClutCfg

API Syntax:

AmpOsd_GetClutCfg (AMP_OSD_HDLR_s * osdHdlr, AMP_OSD_CLUT_CFG_s * cfg)

Function Description:

- This function is used to retrieve the CLUT configuration settings of a specified OSD handler.

Parameters:

Type	Parameter	Description
AMP_OSD_HDLR_s *	osdHdlr	OSD handler instance (Section 2.2.1.1)
AMP_OSD_CLUT_CFG_s *	cfg	OSD CLUT configuration parameters (Section 2.2.1.4)

Table 2-14. Parameters for SDK6 API Middleware OSD API **AmpOsd_GetClutCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-15. Returns for SDK6 Middleware OSD API **AmpOsd_GetClutCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.6 AmpOsd_GetDefaultCfg

API Syntax:

AmpOsd_GetDefaultCfg (AMP_OSD_CFG_s * cfg)

Function Description:

- This function is used to retrieve default configuration settings for the creation of an OSD handler.

Parameters:

Type	Parameter	Description
AMP_OSD_CFG_s *	cfg	OSD handler configuration parameters (Section 2.2.1.2)

Table 2-16. Parameters for SDK6 API Middleware OSD API **AmpOsd_GetDefaultCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-17. Returns for SDK6 Middleware OSD API **AmpOsd_GetDefaultCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.7 AmpOsd_GetDefaultInitCfg

API Syntax:

AmpOsd_GetDefaultInitCfg (AMP_OSD_INIT_CFG_s * cfg)

Function Description:

- This function is used to retrieve default initial configuration settings for the initialization of the OSD mini-module.

Parameters:

Type	Parameter	Description
AMP_OSD_CFG_s *	cfg	Initialization configuration parameters (Section 2.2.7.1)

Table 2-18. Parameters for SDK6 API Middleware OSD API **AmpOsd_GetDefaultInitCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-19. Returns for SDK6 Middleware OSD API **AmpOsd_GetDefaultInitCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.7.1 AmpOsd_GetDefaultInitCfg > AMP_OSD_INIT_CFG_s

Type	Field	Description
UINT8 *	MemoryPoolAddr	Buffer start address used by the OSD module to create the OSD handler array
UINT32	MemoryPoolSize	Size of the buffer
UINT32	MaxOsdInterHdlr	The desired number of OSD handlers

Table 2-20. Definition of **AMP_OSD_INIT_CFG_s** for OSD API **AmpOsd_GetDefaultInitCfg()**.

Confidential
For HAOTEK Only

2.2.8 AmpOsd_GetHdlrInfo

API Syntax:

AmpOsd_GetHdlrInfo (int channel, AMP_OSD_HDLR_INFO_s * outputInfo)

Function Description:

- This function is used to retrieve the OSD active handler system information.

Parameters:

Type	Parameter	Description
int	channel	The channel on which the OSD is shown
AMP_OSD_HDLR_INFO_s *	OutputInfo	Returns OSD active handler and window handler information (Section 2.2.8.1)

Table 2-21. Parameters for SDK6 API Middleware OSD API **AmpOsd_GetHdlrInfo()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-22. Returns for SDK6 Middleware OSD API **AmpOsd_GetHdlrInfo()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.8.1 AmpOsd_GetHdlrInfo > AMP_OSD_HDLR_INFO_s

Type	Field	Description
AMP_OSD_HDLR_s *	OsdHdlr	Active OSD handler instance (Section 2.2.1.1)
AMP_DISP_WIN- DOW_HDLR_s *	WindowHdlr	Active window handler instance (Section 2.2.1.2)

Table 2-23. Definition of **AMP_OSD_HDLR_INFO_s** for OSD API **AmpOsd_GetHdlrInfo()**.

Confidential
For HAOTEK Only

2.2.9 AmpOsd_GetTransparentCfg

API Syntax:

AmpOsd_GetTransparentCfg (AMP_OSD_HDLR_s * osdHdlr, AMP_OSD_TRANSPARENT_CFG_s * cfg)

Function Description:

- This function is used to retrieve transparency configuration settings for the OSD handler.

Parameters:

Type	Parameter	Description
AMP_OSD_HDLR_s *	osdHdlr	OSD handler instance (Section 2.2.1.1)
AMP_OSD_TRANSPARENT_CFG_s *	cfg	OSD transparency configuration parameters (Section 2.2.1.5)

Table 2-24. Parameters for SDK6 API Middleware OSD API **AmpOsd_GetTransparentCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-25. Returns for SDK6 Middleware OSD API **AmpOsd_GetTransparentCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.10 AmpOsd_Init

API Syntax:

AmpOsd_Init (AMP_OSD_INIT_CFG_s * cfg)

Function Description:

- This function is used to initialize the OSD mini-module, arrange OSD handler memory, and initialize related flags.

Parameters:

Type	Parameter	Description
AMP_OSD_INIT_CFG_s *	cfg	Initialization configuration parameters (Section 2.2.7.1)

Table 2-26. Parameters for SDK6 API Middleware OSD API **AmpOsd_Init()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-27. Returns for SDK6 Middleware OSD API **AmpOsd_Init()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.11 AmpOsd_SetBufferCfg

API Syntax:

AmpOsd_SetBufferCfg (AMP_OSD_HDLR_s * osdHdlr, AMP_OSD_BUFFER_CFG_s * cfg)

Function Description:

- This function is used to set/update the buffer-related configuration settings of a specified OSD handler. When the OSD buffer configuration information is updated in the OSD handler, the new settings will take effect immediately (assuming OSD is active).

Parameters:

Type	Parameter	Description
AMP_OSD_HDLR_s *	osdHdlr	OSD handler instance (Section 2.2.1.1)
AMP_OSD_BUFFER_CFG_s *	cfg	OSD configuration parameters (Section 2.2.1.3)

Table 2-28. Parameters for SDK6 API Middleware OSD API **AmpOsd_SetBufferCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-29. Returns for SDK6 Middleware OSD API **AmpOsd_SetBufferCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.12 AmpOsd_SetCfg

API Syntax:

AmpOsd_SetCfg (AMP_OSD_HDLR_s * osdHdlr, AMP_OSD_CFG_s * cfg)

Function Description:

- This function is used to set/update OSD configuration settings of a specified OSD handler. When the OSD configuration information is updated in the OSD handler, the new settings will take effect immediately (assuming OSD is active).

•

Parameters:

Type	Parameter	Description
AMP_OSD_HDLR_s *	osdHdlr	OSD handler instance (Section 2.2.1.1)
AMP_OSD_CFG_s *	cfg	OSD configuration parameters (Section 2.2.1.2)

Table 2-30. Parameters for SDK6 API Middleware OSD API **AmpOsd_SetCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-31. Returns for SDK6 Middleware OSD API **AmpOsd_SetCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.13 AmpOsd_SetClutCfg

API Syntax:

AmpOsd_SetClutCfg (AMP_OSD_HDLR_s * osdHdlr, AMP_OSD_CLUT_CFG_s * cfg)

Function Description:

- This function is used to set/update the CLUT configuration settings of a specified OSD handler. When the CLUT configuration information is updated in the OSD handler, the new settings will take effect immediately (assuming OSD is active).

Parameters:

Type	Parameter	Description
AMP_OSD_HDLR_s *	osdHdlr	OSD handler instance (Section 2.2.1.1)
AMP_OSD_CLUT_CFG_s *	cfg	OSD CLUT configuration parameters (Section 2.2.1.4)

Table 2-32. Parameters for SDK6 API Middleware OSD API **AmpOsd_SetClutCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-33. Returns for SDK6 Middleware OSD API **AmpOsd_SetClutCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

2.2.14 AmpOsd_SetTransparentCfg

API Syntax:

AmpOsd_SetTransparentCfg (AMP_OSD_HDLR_s * osdHdlr, AMP_OSD_TRANSPARENT_CFG_s * cfg)

Function Description:

- This function is used to set/update transparency configuration settings for the OSD handler. When the transparency configuration information is updated in the OSD handler, the new settings will take effect immediately (assuming OSD is active).

Parameters:

Type	Parameter	Description
AMP_OSD_HDLR_s *	osdHdlr	OSD handler instance (Section 2.2.1.1)
AMP_OSD_TRANSPARENT_CFG_s *	cfg	OSD transparency configuration parameters (Section 2.2.1.5)

Table 2-34. Parameters for SDK6 API Middleware OSD API **AmpOsd_SetTransparentCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 2-35. Returns for SDK6 Middleware OSD API **AmpOsd_SetTransparentCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3 FIFO

3.1 FIFO: Overview

This chapter provides information regarding the bitstream descriptor manager.

Features include:

- FIFO is used to manage the bits buffer descriptor
- FIFO enables handshaking between the format and the codec
- More than one virtual FIFO can be created to read data from the base FIFO

3.2 FIFO: List of Functions

- [\(Section 3.2.1\) AmpFifo_Create](#)
- [\(Section 3.2.2\) AmpFifo_Delete](#)
- [\(Section 3.2.3\) AmpFifo_EraseAll](#)
- [\(Section 3.2.4\) AmpFifo_GetDefaultCfg](#)
- [\(Section 3.2.5\) AmpFifo_GetInfo](#)
- [\(Section 3.2.6\) AmpFifo_GetInitDefaultCfg](#)
- [\(Section 3.2.7\) AmpFifo_Init](#)
- [\(Section 3.2.8\) AmpFifo_PeekEntry](#)
- [\(Section 3.2.9\) AmpFifo_PrepareEntry](#)
- [\(Section 3.2.10\) AmpFifo_RemoveEntry](#)
- [\(Section 3.2.11\) AmpFifo_WriteEntry](#)
- [\(Section 3.2.12\) AmpFifo_Resume](#)

3.2.1 AmpFifo_Create

API Syntax:

AmpFifo_Create (AMP_FIFO_CFG_s * cfg, AMP_FIFO_HDLR_s ** fifo)

Function Description:

- This function is used to create a virtual FIFO on a codec, manage the bits descriptor generated by the codec, or feed data to the codec. On creation, the **getNumDesc()** function of the codec will be invoked to allocate the virtual descriptor queue in the FIFO.
- Note that only one write FIFO per codec is permitted.

Parameters:

Type	Parameter	Description
AMP_FIFO_CFG_s *	cfg	FIFO configuration parameters (Section 3.2.1.1)
AMP_FIFO_HDLR_s **	fifo	The FIFO handler instance (Section 3.2.1.3)

Table 3-1. Parameters for SDK6 API Middleware FIFO API **AmpFifo_Create()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-2. Returns for SDK6 Middleware FIFO API **AmpFifo_Create()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3.2.1.1 AmpFifo_Create > AMP_FIFO_CFG_s

Type	Field	Description
void *	hCodec	The codec the FIFO is working on
UINT32	NumEntries	Number of entries of a FIFO
UINT32	IsVirtual	Creating virtual FIFO (for data flow) or not (for codec)
AMP_CALLBACK_f	cbEvent	The callback function for FIFO event
UINT32	EventDataConsumedThreshold	The threshold for event AMP_FIFO_CALLBACK_EVENT_DATA_CONSUMED . The event is only triggered if the remaining data is under the threshold. 0 to disable.
UINT32	EventDataReadySkipNum	If not 0, AMP_FIFO_CALLBACK_EVENT_DATA_READY will not be triggered for every frame encoded. Instead, it will be triggered every (EventDataReadySkipNum frame+1) frames.
AMP_CALLBACK_f	cbGetWritePoint	The callback function invoked when prepareSpace is received. Note that this should only be used on the FIFO linked to the codec. Only takes effect on a codec read FIFO. The callback should be registered by a decode manager for all decode codecs.
UINT8	SyncRpOnWrite	If 0, RP of base FIFO will be updated on removal of the virtual FIFO. If 1, RP of base FIFO will be updated on write of base FIFO. ONLY takes effect on base FIFO.
UINT32	RawBaseAddr	When sync RP on write is on and RawBaseAddr/RawLimitAddr is given, base fifo will remove desc automatically on overwrite. Only needed on base FIFO and sync on write is on.
UINT32	RawLimitAddr	When sync RP on write is on and RawBaseAddr/RawLimitAddr is given, base FIFO will remove desc automatically on overwrite. Only needed on base FIFO and sync on write is on.
UINT64	TickPerSecond	TickPerSecond used for PTS for the FIFO. Could be 0 if we would NOT like to use init data.
AMP_FIFO_CFG_INIT_DATA_s	InitData	Init status for virtual FIFO

Table 3-3. Definition of AMP_FIFO_CFG_s for FIFO API AmpFifo_Create().

3.2.1.2 AmpFifo_Create > AMP_FIFO_CFG_INIT_DATA_s

Type	Field	Description
UINT8	CreateFifoWithInitData	If create FIFO with init data (if data valid)
AMP_FIFO_CFG_INIT_DATA_FETCH_CONDITION_e	InitCondition	Defines how to descript initial data required.
UINT64	TimeLength	In normal case, the value of backward fetch is 0. This means FIFO will output frames only after FIFO is created. As the value is not 0, FIFO will try to determine the longest valid frames
UINT64	NumFrame	Number of frame
UINT64	StartTime	Start time in ms
AMP_FIFO_FRMAE_TYPE_e	FirstFrameType	Frame type of first frame for valid data; used on video stream to ensure start with IDR.

Type	Field	Description
UINT64	OnCreateFirst-FramePts	[OUT] PTS of first frame; 0xFFFFFFFFFFFFFFFF if first frame is not valid on create
UINT64	OnCreateTimeLength	[OUT] Data length in FIFO on create in ms

Table 3-4. Definition of **AMP_FIFO_CFG_INIT_DATA_s** for FIFO API **AmpFifo_Create()**.

3.2.1.3 AmpFifo_Create > AMP_FIFO_s_AMP_FIFO_HDLR_s

Type	Field	Description
UINT32	nFifold	Unique FIFO ID
void *	Ctx	Private data of the FIFO

Table 3-5. Definition of **AMP_FIFO_s_AMP_FIFO_HDLR_s** for FIFO API **AmpFifo_Create()**.

Confidential
For HAOTEK Only

3.2.2 AmpFifo_Delete

API Syntax:

AmpFifo_Delete (AMP_FIFO_HDLR_s * fifo)

Function Description:

- This function is used to close a FIFO.

Parameters:

Type	Parameter	Description
AMP_FIFO_HDLR_s **	fifo	The FIFO to be closed (Section 3.2.1.3)

Table 3-6. Parameters for SDK6 API Middleware FIFO API **AmpFifo_Delete()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-7. Returns for SDK6 Middleware FIFO API **AmpFifo_Delete()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3.2.3 AmpFifo_EraseAll

API Syntax:

AmpFifo_EraseAll (AMP_FIFO_HDLR_s * fifo)

Function Description:

- This function is used to erase all data in a specified FIFO. Resets the read and write points.

Parameters:

Type	Parameter	Description
AMP_FIFO_HDLR_s **	fifo	The target FIFO (Section 3.2.1.3)

Table 3-8. Parameters for SDK6 API Middleware FIFO API **AmpFifo_EraseAll()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-9. Returns for SDK6 Middleware FIFO API **AmpFifo_EraseAll()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3.2.4 AmpFifo_GetDefaultCfg

API Syntax:

AmpFifo_GetDefaultCfg (AMP_FIFO_CFG_s * defaultCfg)

Function Description:

- This function is used to retrieve the default FIFO configuration settings.

Parameters:

Type	Parameter	Description
AMP_FIFO_CFG_s *	defaultCfg	FIFO configuration parameters (Section 3.2.1.1)

Table 3-10. Parameters for SDK6 API Middleware FIFO API **AmpFifo_GetDefaultCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-11. Returns for SDK6 Middleware FIFO API **AmpFifo_GetDefaultCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3.2.5 AmpFifo_GetInfo

API Syntax:

AmpFifo_GetInfo (AMP_FIFO_HDLR_s * fifo, AMP_FIFO_INFO_s * info)

Function Description:

- This function is used to retrieve FIFO-related information.

Parameters:

Type	Parameter	Description
AMP_FIFO_HDLR_s **	fifo	The target FIFO (Section 3.2.1.3)
AMP_FIFO_INFO_s *	info	FIFO information (Section 3.2.5.1)

Table 3-12. Parameters for SDK6 API Middleware FIFO API **AmpFifo_GetInfo()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-13. Returns for SDK6 Middleware FIFO API **AmpFifo_GetInfo()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3.2.5.1 AmpFifo_GetInfo > AMP_FIFO_INFO_s

Type	Field	Description
UINT32	TotalEntries	Total number of entries
UINT32	AvailEntries	Number of entries containing data

Table 3-14. Definition of **AMP_FIFO_INFO_s** for FIFO API **AmpFifo_GetInfo()**.

3.2.6 AmpFifo_GetInitDefaultCfg

API Syntax:

AmpFifo_GetInitDefaultCfg (AMP_FIFO_INIT_CFG_s * defaultCfg)

Function Description:

- This function is used to retrieve the default FIFO configuration settings for initialization.

Parameters:

Type	Parameter	Description
AMP_FIFO_INIT_CFG_s *	defaultCfg	FIFO configuration parameters (Section 3.2.6.1)

Table 3-15. Parameters for SDK6 API Middleware FIFO API **AmpFifo_GetInitDefaultCfg()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-16. Returns for SDK6 Middleware FIFO API **AmpFifo_GetInitDefaultCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3.2.6.1 AmpFifo_GetInitDefaultCfg > AMP_FIFO_INIT_CFG_s

Type	Field	Description
UINT8 *	MemoryPoolAddr	Buffer start address for FIFO module including descriptor
UINT32	MemoryPoolSize	Buffer size
UINT32	NumMaxFifo	Maximum supported number of virtual FIFOs
UINT32	NumMaxCodec	Maximum supported number of codecs
AMP_TASK_INFO_s	TaskInfo	Task-related information (Section 3.2.6.2)

Table 3-17. Definition of **AMP_FIFO_INIT_CFG_s** for FIFO API **AmpFifo_GetInitDefaultCfg()**.

3.2.6.2 AmpFifo_GetInitDefaultCfg > AMP_TASK_INFO_s

Type	Field	Description
UINT32	Priority	Task priority
UINT32	StackSize	Task stack size

Table 3-18. Definition of **AMP_TASK_INFO_s** for FIFO API **AmpFifo_GetInitDefaultCfg()**.

Confidential
For HAOTEK Only

3.2.7 AmpFifo_Init

API Syntax:

AmpFifo_Init (AMP_FIFO_INIT_CFG_s * cfg)

Function Description:

- This function is used to initialize the FIFO module. Note that this function should only be invoked once, and must be invoked prior to using the FIFO module. The memory pool for the module will be provided by the user.

Parameters:

Type	Parameter	Description
AMP_FIFO_INIT_CFG_s *	cfg	FIFO configuration parameters (Section 3.2.6.1)

Table 3-19. Parameters for SDK6 API Middleware FIFO API **AmpFifo_Init()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-20. Returns for SDK6 Middleware FIFO API **AmpFifo_Init()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3.2.8 AmpFifo_PeekEntry

API Syntax:

AmpFifo_PeekEntry (AMP_FIFO_HDLR_s * fifo, AMP_BITS_DESC_s ** desc, UINT32 distanceToLastEntry)

Function Description:

- This function is used to peek at a target FIFO entry using a specified distance.
- For example, if there are three entries in the current FIFO:
 - (wp) [entry A] [entry B] [entry C] (rp)
 - **AmpFifo_PeekEntry**(hFifo, &desc, 0) will retrieve entry C ;
 - **AmpFifo_PeekEntry**(hFifo, &desc, 1) will retrieve entry B ;
 - **AmpFifo_PeekEntry**(hFifo, &desc, 2) will retrieve entry A ;
 - **AmpFifo_PeekEntry**(hFifo, &desc, 3) will return as failed.

Parameters:

Type	Parameter	Description
AMP_FIFO_HDLR_s *	fifo	The target FIFO (Section 3.2.1.3)
AMP_BITS_DESC_s **	desc	The specified entry (Section 3.2.8.1)
UINT32	distanceToLastEntry	Distance to the last entry

Table 3-21. Parameters for SDK6 API Middleware FIFO API **AmpFifo_PeekEntry()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-22. Returns for SDK6 Middleware FIFO API **AmpFifo_PeekEntry()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3.2.8.1 AmpFifo_PeekEntry > AMP_BITS_DESC_s

Type	Field	Description
UINT32	SeqNum	Sequential number of bits buffer
UINT32	Pts	Presentation time stamp in ticks
AMP_FIFO_FRAME_TYPE_e	Type	Entry data type AMP_FIFO_TYPE_IDR_FRAME: IDR frame type. AMP_FIFO_TYPE_I_FRAME: I frame type AMP_FIFO_TYPE_P_FRAME: P frame type AMP_FIFO_TYPE_B_FRAME: B frame type AMP_FIFO_TYPE_JPEG_FRAME: JPEG main frame AMP_FIFO_TYPE_THUMBNAIL_FRAME: JPEG scrennail frame AMP_FIFO_TYPE_SCREENNAIL_FRAME: JPEG thumbnail frame AMP_FIFO_TYPE_AUDIO_FRAME: Audio frame AMP_FIFO_TYPE_UNDEFINED: Others AMP_FIFO_TYPE_EOS_MARK: Special frame type to indicate state of feeding. AMP_FIFO_TYPE_DECODE_MARK: Used when feeding bit-stream to DSP will push out all frames. AMP_FIFO_TYPE_EOS: EOS bits that feed to raw buffer
UINT8	Completed	Whether the buffer contains a complete entry
UINT16	Align	
UINT8 *	StartAddr	Data size alignment (in bytes, align = 2^n, where n is a integer) start address of data
UINT32	Size	Actual data size

Table 3-23. Definition of AMP_BITS_DESC_s for FIFO API AmpFifo_PeekEntry().

3.2.9 AmpFifo_PrepareEntry

API Syntax:

AmpFifo_PrepareEntry (AMP_FIFO_HDLR_s * fifo, AMP_BITS_DESC_s * desc)

Function Description:

- This function is used to prepare space to write data to FIFO. Note that this function must be used to retrieve the correct descriptor of the write point.

Parameters:

Type	Parameter	Description
AMP_FIFO_HDLR_s *	fifo	The target FIFO (Section 3.2.1.3)
AMP_BITS_DESC_s *	desc	The descriptor of the space (Section 3.2.8.1)

Table 3-24. Parameters for SDK6 API Middleware FIFO API **AmpFifo_PrepareEntry()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-25. Returns for SDK6 Middleware FIFO API **AmpFifo_PrepareEntry()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3.2.10 AmpFifo_RemoveEntry

API Syntax:

AmpFifo_RemoveEntry (AMP_FIFO_HDLR_s * fifo, UINT32 n)

Function Description:

- This function is used to remove the last **n** entry.
- For example, if there are three entries in the current FIFO:
(wp) [entry A] [entry B] [entry C] (rp)
After **AmpFifo_RemoveEntry**(hFifo, 2)
it becomes
(wp) [entry A] (rp)
- Note that the remove function only operates on the virtual FIFO indicated by the **n** parameter. If there are other FIFOs operating on the same codec, their read points will not be changed.

Parameters:

Type	Parameter	Description
AMP_FIFO_HDLR_s *	fifo	The target FIFO (Section 3.2.1.3)
UINT32	n	The number of the entry to be removed

Table 3-26. Parameters for SDK6 API Middleware FIFO API **AmpFifo_RemoveEntry()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-27. Returns for SDK6 Middleware FIFO API **AmpFifo_RemoveEntry()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3.2.11 AmpFifo_WriteEntry

API Syntax:

AmpFifo_WriteEntry (AMP_FIFO_HDLR_s * fifo, AMP_BITS_DESC_s * desc)

Function Description:

- This function is used to write data to a FIFO.
- For example, if there is one entry in the current FIFO:
(wp) [entry A] (rp)
After AmpFifo_WriteDataToFifo(hFifo, descEntryB)
it becomes
(wp) [entry B][entry A] (rp)
- The write points of all FIFOs working on the same codec will be updated after this function is invoked.

Parameters:

Type	Parameter	Description
AMP_FIFO_HDLR_s *	fifo	The target FIFO (Section 3.2.1.3)
AMP_BITS_DESC_s *	desc	The descriptor of the data to write (Section 3.2.8.1)

Table 3-28. Parameters for SDK6 API Middleware FIFO API **AmpFifo_WriteEntry()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-29. Returns for SDK6 Middleware FIFO API **AmpFifo_WriteEntry()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

3.2.12 AmpFifo_Resume

API Syntax:

AmpFifo_Resume (AMP_FIFO_HDLR_s * fifo, AMP_FIFO_CFG_INIT_DATA_s * initData)

Function Description:

- This function is used to resume a FIFO created with the init condition paused.
- We could apply initial condition on resume as start time/number of frames

Parameters:

Type	Parameter	Description
AMP_FIFO_HDLR_s *	fifo	The target FIFO (Section 3.2.1.3)
AMP_FIFO_CFG_INIT_DATA_s *	initData	Init data on resume (Section 3.2.1.2)

Table 3-30. Parameters for SDK6 API Middleware FIFO API **AmpFifo_Resume()**.

Returns:

Return	Description
0	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 3-31. Returns for SDK6 Middleware FIFO API **AmpFifo_Resume()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4 ImgDzoom

4.1 ImgDzoom: Overview

This chapter provides the APIs for Digital Zoom control module implementation, including:

1. Init Digital Zoom control module function
2. Create Digital Zoom control module function
3. Delete Digital Zoom control module function
4. Reset Digital Zoom control module current context
5. Callback of VIN ISR handler
6. Digital Zoom control APIs
7. Get Digital Zoom module information

4.2 ImgDzoom: List of APIs

- [AmplmgDzoom_ChangeResolutionHandler](#)
- [AmplmgDzoom_Create](#)
- [AmplmgDzoom_Delete](#)
- [AmplmgDzoom_GetDefaultCfg](#)
- [AmplmgDzoom_GetDzoomInfo](#)
- [AmplmgDzoom_GetDzoomStatus](#)
- [AmplmgDzoom_GetInitDefaultCfg](#)
- [AmplmgDzoom_Init](#)
- [AmplmgDzoom_PresetDzoomJump](#)
- [AmplmgDzoom_RegDzoomTable](#)
- [AmplmgDzoom_ResetStatus](#)
- [AmplmgDzoom_SetDzoomJump](#)
- [AmplmgDzoom_SetDzoomPosition](#)
- [AmplmgDzoom_StopDzoom](#)
- [AmplmgDzoom_Enable](#)
- [AmplmgDzoom_MainTask](#)

4.2.1 AmplmgDzoom_ChangeResolutionHandler

API Syntax:

AmplmgDzoom_ChangeResolutionHandler (AMP_IMG_DZOOM_HDLR_s * ImgDzoom, AMP_IMG_DZOOM_VIN_INVALID_INFO_s * Info)

Function Description:

- This function is used to change resolution for ImgDzoom.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_HDLR_s *	ImgDzoom	ImgDzoom. (AMP_IMG_DZOOM_HDLR_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.1 for more details.
AMP_IMG_DZOOM_VIN_INVALID_INFO_s *	Info	VinInvalidInfo. (AMP_IMG_DZOOM_VIN_INVALID_INFO_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.2 for more details.

Table 4-1. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_ChangeResolutionHandler()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-2. Returns for ImgDzoom SDK6 API **AmplmgDzoom_ChangeResolutionHandler()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.1.1 AmplmgDzoom_ChangeResolutionHandler > AMP_IMG_DZOOM_HDLR_s

Type	Field	Description
void *	Ctx	Private data of the dzoom

Table 4-3. Definition of **AMP_IMG_DZOOM_HDLR_s** for ImgDzoom SDK6 API **AmplmgDzoom_ChangeResolutionHandler()**.

4.2.1.2 AmplmgDzoom_ChangeResolutionHandler > AMP_IMG_DZOOM_VIN_INVALID_INFO_s

Type	Field	Description
UINT32	CapW	Capture Width
UINT32	CapH	Capture Height

Table 4-4. Definition of AMP_IMG_DZOOM_VIN_INVALID_INFO_s for ImgDzoom SDK6 API AmplmgDzoom_ChangeResolutionHandler().

Confidential
For HAOTEK Only

4.2.2 AmplmgDzoom_Create

API Syntax:

AmplmgDzoom_Create (AMP_IMG_DZOOM_CFG_s *Cfg, AMP_IMG_DZOOM_HDLR_s **ImgDzoom)

Function Description:

- This function is used for the ImgDzoom handler creation.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_CFG_s*	Cfg	ImgDzoom module config. (AMP_IMG_DZOOM_CFG_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.2.1 for more details.
AMP_IMG_DZOOM_HDLR_s**	ImgDzoom	ImgDzoom to create. (AMP_IMG_DZOOM_HDLR_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.1 for more details.

Table 4-5. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_Create()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-6. Returns for ImgDzoom SDK6 API **AmplmgDzoom_Create()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes and **AMP_BITS_DESC_s**.

4.2.2.1 AmplmgDzoom_Create > AMP_IMG_DZOOM_CFG_s

Type	Type	Description
AMP_TASK_INFO_s	TaskInfo	Task information
UINT32	MaxDzoomFactor	The maximum dzoom factor
UINT32	ImgModeContextId	The image mode context Id
UINT32	ImgModeBatchId	The image mode batch Id

Table 4-7. Definition of **AMP_IMG_DZOOM_CFG_s** for ImgDzoom SDK6 API **AmplmgDzoom_Create()**.

4.2.3 AmplmgDzoom_Delete

API Syntax:

AmplmgDzoom_Delete (AMP_IMG_DZOOM_HDLR_s * ImgDzoom)

Function Description:

- This function is used to delete the image dzoom task of this handler.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_HDLR_s *	ImgDzoom	ImgDzoom to delete. (AMP_IMG_DZOOM_HDLR_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.1 for more details.

Table 4-8. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_Delete()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-9. Returns for ImgDzoom SDK6 API **AmplmgDzoom_Delete()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.4 AmplmgDzoom_GetDefaultCfg

API Syntax:

AmplmgDzoom_GetDefaultCfg (AMP_IMG_DZOOM_CFG_s * DefaultCfg)

Function Description:

- This function is used to get the ImgDzoom handler default configuration.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_CFG_s *	DefaultCfg	ImgDzoom module config. (AMP_IMG_DZOOM_CFG_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.2.1 for more details.

Table 4-10. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_GetDefaultCfg()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-11. Returns for ImgDzoom SDK6 API **AmplmgDzoom_GetDefaultCfg()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.5 AmplmgDzoom_GetDzoomInfo

API Syntax:

AmplmgDzoom_GetDzoomInfo (AMP_IMG_DZOOM_HDLR_s * ImgDzoom, AMP_IMG_DZOOM_INFO_s * Info)

Function Description:

- This function is used to get the current Dzoom information.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_HDLR_s *	ImgDzoom	ImgDzoom. (AMP_IMG_DZOOM_HDLR_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.1 for more details.
AMP_IMG_DZOOM_INFO_s *	Info	Dzoom Information. (AMP_IMG_DZOOM_INFO_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.5.1 for more details.

Table 4-12. Parameters for `ImgDzoom SDK6 API AmplmgDzoom_GetDzoomInfo()`.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-13. Returns for `ImgDzoom SDK6 API AmplmgDzoom_GetDzoomInfo()`.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.5.1 AmplmgDzoom_GetDzoomInfo > AMP_IMG_DZOOM_INFO_s

Type	Field	Description
UINT32	TotalStepNumber	Total step number of the dzoom
UINT32	MaxDzoomFactor	The maximum dzoom factor (16.16 format)

Table 4-14. Definition of **AMP_IMG_DZOOM_INFO_s** for `ImgDzoom SDK6 API AmplmgDzoom_GetDzoomInfo()`.

4.2.6 AmplmgDzoom_GetDzoomStatus

API Syntax:

AmplmgDzoom_GetDzoomStatus (AMP_IMG_DZOOM_HDLR_s * ImgDzoom, AMP_IMG_DZOOM_STATUS_s * Status)

Function Description:

- This function is to get the current ImageDzoom Status.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_HDLR_s *	ImgDzoom	ImgDzoom. (AMP_IMG_DZOOM_HDLR_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.1 for more details.
AMP_IMG_DZOOM_STATUS_s *	Status	Dzoom Status. (AMP_IMG_DZOOM_STATUS_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.6.1 for more details.

Table 4-15. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_GetDzoomStatus()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-16. Returns for ImgDzoom SDK6 API **AmplmgDzoom_GetDzoomStatus()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.6.1 AmplmgDzoom_GetDzoomStatus > AMP_IMG_DZOOM_STATUS_s

Type	Field	Description
UINT32	Region	0: OPT_ZOOM_REGION 1: DIGI_ZOOM_REGION
UINT32	IsProcessing	0: DZOOM_NOTPROC 1: DZOOM_PROC
UINT32	Step	The current dzoom step
UINT32	Factor	Dzoom status (16.16 format)
int	ShiftX	Parameter of horizontal offset. Range: -1~1. '0': horizontal center of image. '-1': leftmost of horizontal image. '1': rightmost of horizontal image. (format: 16.16)
int	ShiftY	Parameter of vertical offset. Range: -1~1. '0': vertical center of the image. '-1': top of vertical image. '1': bottom of vertical image. (format: 16.16)

Table 4-17. Definition of **AMP_IMG_DZOOM_STATUS_s** for *ImgDzoom SDK6 API AmplmgDzoom_GetDzoomStatus()*.

4.2.7 AmplmgDzoom_GetInitDefaultCfg

API Syntax:

AmplmgDzoom_GetInitDefaultCfg (AMP_IMG_DZOOM_INIT_CFG_s * DefaultCfg)

Function Description:

- This function is to get ImgDzoom module default config for initializing.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_INIT_CFG_s *	DefaultCfg	ImgDzoom module config. (AMP_IMG_DZOOM_INIT_CFG_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.7.1 for more details.

Table 4-18. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_GetInitDefaultCfg()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-19. Returns for ImgDzoom SDK6 API **AmplmgDzoom_GetInitDefaultCfg()**.

Example

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.7.1 AmplmgDzoom_GetInitDefaultCfg > AMP_IMG_DZOOM_INIT_CFG_s

Type	Field	Description
int	NumOfMaxDzoom	The number of maximum Dzoom

Table 4-20. Definition of **AMP_IMG_DZOOM_INIT_CFG_s** for ImgDzoom SDK6 API **AmplmgDzoom_GetInitDefaultCfg()**.

4.2.8 AmplmgDzoom_Init

API Syntax:

AmplmgDzoom_Init (AMP_IMG_DZOOM_INIT_CFG_s * Cfg)

Function Description:

- This function is to initialize ImgDzoom module.
- This function should only be invoked once. User MUST invoke this function before using ImgDzoom module. The memory pool of the module will be provided by the user.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_INIT_CFG_s *	cfg	ImgDzoom module config. (AMP_IMG_DZOOM_INIT_CFG_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.7.1 for more details.

Table 4-21. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_Init()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-22. Returns for ImgDzoom SDK6 API **AmplmgDzoom_Init()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.9 AmplmgDzoom_PresetDzoomJump

API Syntax:

AmplmgDzoom_PresetDzoomJump (AMP_IMG_DZOOM_HDLR_s * ImgDzoom, AMP_IMG_DZOOM_JUMP_s * Jump)

Function Description:

- This function is to preset Dzoom Jump for ImgDzoom. Jump information will take effect after mode switch done.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_HDLR_s *	ImgDzoom	ImgDzoom. (AMP_IMG_DZOOM_HDLR_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.1 for more details.
AMP_IMG_DZOOM_JUMP_s *	Jump	Dzoom Jump. (AMP_IMG_DZOOM_JUMP_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.9.1 below for more details.

Table 4-23. Parameters for SDK6 API **AmplmgDzoom_PresetDzoomJump()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-24. Returns for SDK6 API **AmplmgDzoom_PresetDzoomJump()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 21 for more details on error codes.

4.2.9.1 AmplmgDzoom_PresetDzoomJump > AMP_IMG_DZOOM_JUMP_s

Type	Field	Description
UINT32	Step	Step correspond to the dzoom table index
int	ShiftX	Parameter of horizontal offset. Range: -1~1. '0': horizontal center of image. '-1': leftmost of horizontal image. '1': rightmost of horizontal image. (format: s16.16)
int	ShiftY	Parameter of vertical offset. Range: -1~1. '0': vertical center of image. '-1': top of vertical image. '1': bottom of vertical image. (format: s16.16)

Table 4-25. Definition of **AMP_IMG_DZOOM_JUMP_s** for SDK6 API **AmplmgDzoom_PresetDzoomJump()**.

Confidential
For HAOTEK Only

4.2.10 AmplmgDzoom_RegDzoomTable

API Syntax:

AmplmgDzoom_RegDzoomTable (AMP_IMG_DZOOM_HDLR_s * ImgDzoom, AMP_IMG_DZOOM_TABLE_s * Table)

Function Description:

- This function is to register the Dzoom table for ImgDzoom.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_HDLR_s *	ImgDzoom	ImgDzoom. (AMP_IMG_DZOOM_HDLR_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.1 for more details.
AMP_IMG_DZOOM_TABLE_s *	Table	Dzoom Table. (AMP_IMG_DZOOM_TABLE_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.10.1 for more details.

Table 4-26. Parameters for ImDzoom SDK6 API **AmplmgDzoom_RegDzoomTable()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-27. Returns for ImDzoom SDK6 API **AmplmgDzoom_RegDzoomTable()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.10.1 AmplmgDzoom_RegDzoomTable > AMP_IMG_DZOOM_TABLE_s

Type	Field	Description
UINT32	TotalStepNumber	Total step number of the dzoom
UINT32	MaxDzoomFactor	The maximum dzoom factor (16.16 format)
int(* GetDzoom-Factor)	(int Step, UINT32 *Factor)	Get the dzoom factor under corresponding status.

Table 4-28. Definition of **AMP_IMG_DZOOM_TABLE_s** for ImDzoom SDK6 API **AmplmgDzoom_RegDzoomTable()**.

4.2.11 AmplmgDzoom_ResetStatus

API Syntax:

AmplmgDzoom_ResetStatus (AMP_IMG_DZOOM_HDLR_s * ImgDzoom)

Function Description:

- This function is to reset the status in a ImgDzoom.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_HDLR_s *	ImgDzoom	ImgDzoom to reset the status. (AMP_IMG_DZOOM_HDLR_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.1 for more details.

Table 4-29. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_ResetStatus()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-30. Returns for ImgDzoom SDK6 API **AmplmgDzoom_ResetStatus()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.12 AmplmgDzoom_SetDzoomJump

API Syntax:

AmplmgDzoom_SetDzoomJump (AMP_IMG_DZOOM_HDLR_s * ImgDzoom, AMP_IMG_DZOOM_JUMP_s * Jump)

Function Description:

- This function is to set Dzoom Jump for ImgDzoom.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_HDLR_s *	ImgDzoom	ImgDzoom. (AMP_IMG_DZOOM_HDLR_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.1 for more details.
AMP_IMG_DZOOM_JUMP_s *	Jump	Dzoom Jump. (AMP_IMG_DZOOM_JUMP_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.9.1 for more details.

Table 4-31. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_SetDzoomJump()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-32. Returns for ImgDzoom SDK6 API **AmplmgDzoom_SetDzoomJump()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.13 AmplmgDzoom_SetDzoomPosition

API Syntax:

AmplmgDzoom_SetDzoomPosition (AMP_IMG_DZOOM_HDLR_s * ImgDzoom, AMP_IMG_DZOOM_POSITION_s * Position)

Function Description:

- This function is to set Dzoom Position for ImgDzoom.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_HDLR_s *	ImgDzoom	ImgDzoom. (AMP_IMG_DZOOM_HDLR_s is defined in <i>ImgDzoom.h</i>) Please refer to Section 4.2.1.1 for more details.
AMP_IMG_DZOOM_POSITION_s *	Position	Dzoom Position. (AMP_IMG_DZOOM_POSITION_s is defined in <i>ImgDzoom.h</i>) Please refer to Section 4.2.13.1 for more details.

Table 4-33. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_SetDzoomPosition()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-34. Returns for ImgDzoom SDK6 API **AmplmgDzoom_SetDzoomPosition()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.13.1 AMP_IMG_DZOOM_POSITION_s

Type	Field	Description
UINT32	Direction	Direction for set dzoom position
UINT32	Speed	Speed for set dzoom position
UINT32	Distance	Distance for set dzoom position
int	ShiftX	Shift X for set dzoom position (16.16 format)
int	ShiftY	Shift Y for set dzoom position (16.16 format)

Table 4-35. Definition of **AMP_IMG_DZOOM_POSITION_s** for ImgDzoom SDK6 API **AmplmgDzoom_SetDzoomPosition()**.

4.2.14 AmplmgDzoom_StopDzoom

API Syntax:

AmplmgDzoom_StopDzoom (MP_IMG_DZOOM_HDLR_s * ImgDzoom)

Function Description:

- This function is to stop ImgDzoom. It will stop ImgDzoom during Moving or Jumping for ImgDzoom.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_HDLR_s *	imgDzoomin	ImgDzoom. (AMP_IMG_DZOOM_HDLR_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.1 for more details.

Table 4-36. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_StopDzoom()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-37. Returns for ImgDzoom SDK6 API **AmplmgDzoom_StopDzoom()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.15 AmplmgDzoom_Enable

API Syntax:

AmplmgDzoom_Enable (AMP_IMG_DZOOM_HDLR_s * ImgDzoom, UINT32 Enable)

Function Description:

- This function is used to enable/disable dzoom.

Parameters:

Type	Parameter	Description
AMP_IMG_DZOOM_HDLR_s *	imgDzoomin	ImgDzoom. (AMP_IMG_DZOOM_HDLR_s is defined in <code>ImgDzoom.h</code>) Please refer to Section 4.2.1.1 for more details.
UINT32	Enable	0: Disable dzoom function 1: Enable dzoom function

Table 4-38. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_Enable()**.

Returns:

Return	Description
0 (AMP_OK)	Success
All other	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 4-39. Returns for ImgDzoom SDK6 API **AmplmgDzoom_Enable()**.

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

4.2.16 AmplmgDzoom_MainTask

API Syntax:

AmplmgDzoom_MainTask (UINT32 Input)

Function Description:

- This function is used to enable/disable dzoom.

Parameters:

Type	Parameter	Description
UINT32	Input	The task identification

Table 4-40. Parameters for ImgDzoom SDK6 API **AmplmgDzoom_MainTask()**.

Returns:

None

Example:

Please refer to Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

5 Initialization

5.1 Initialization: Overview

This chapter provides details on how to initialize the middleware of SDK6. It provides middleware level APIs for SDK6. The middleware utilizes system support package (SSP) with more easy-to-use APIs so that customers can develop product software's quickly and with ease. All initialization APIs are covered under this chapter as well.

5.2 Initialization: List of APIs

This section lists the following initialization APIs:

- [AmpMW_GetDefaultInitCfg](#)
- [AmpMW_Init](#)
- [AmpResource_SetDspWorkArea](#)
- [AmpMW_GetFlowPipeVer](#)
- [AmpMW_GetDataPipeVer](#)

Confidential
For HAOTEK Only

5.2.1 AmpMW_GetDefaultInitCfg

API Syntax:

AmpMW_GetDefaultInitCfg (AMP_MW_INIT_CFG_s * cfg)

Function Description:

- This function gets the initial default configuration of the middleware.

Parameters:

Type	Parameter	Description
AMP_MW_INIT_CFG_s	cfg	Default built-in initialization configuration (AMP_MW_INIT_CFG_s is defined in <code>mw.h</code>) Please refer to Section 5.2.1.1 for more details.

Table 5-1. Parameters for Initialization SDK6 API **AmpMW_GetDefaultInitCfg()**.

Returns:

Return	Description
AMP_OK	Success
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 5-2. Returns for Initialization SDK6 API **AmpMW_GetDefaultInitCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

5.2.1.1 AmpMW_GetDefaultInitCfg > AMP_MW_INIT_CFG_s

Type	Field	Description
UINT8 *	DspDbgLogDataArea	DSP debug message buffer start address
UINT32	SizeDspDbgLogDataArea	DSP debug message buffer size
UINT8 *	DspWorkingArea	DSP working buffer start address
UINT32	SizeDspWorkArea	DSP working buffer size
UINT8 *	ImgKernelWorkArea	Image kernel working buffer start address
UINT32	SizeImgKernelWorkArea	Image kernel working buffer size
UINT16	NumImgKernelPipe	Image kernel pipeline number
UINT16	NumImgKernelBufNum	Image kernel ring buffer number. Will get from ImgKernelWorkArea
AMBA_DSP_IMG_PIPE_INFO_s *	ImgKernelPipeInfo	Image kernel pipeline configuration

Type	Field	Description
UINT8	EnSeamless	If enable seamless function

Table 5-3. Definition of **AMP_MW_INIT_CFG_s** for Initialization SDK6 API **AmpMW_GetDefaultInitCfg()**.

Confidential
For HAOTEK Only

5.2.2 AmpMW_Init

API Syntax:

AmpMW_Init (AMP_MW_INIT_CFG_s * cfg)

Function Description:

- This function initializes the middleware.

Parameters:

Type	Parameter	Description
AMP_MW_INIT_CFG_s	cfg	Default built-in initialization configuration (AMP_MW_INIT_CFG_s is defined in <code>mw.h</code>). Please refer to Section 5.2.1.1 for more details.

Table 5-4. Parameters for Initialization SDK6 API **AmpMW_Init()**.

Returns:

Return	Description
AMP_OK	Success
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes

Table 5-5. Returns for Initialization SDK6 API **AmpMW_Init()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

5.2.3 AmpMW_GetFlowPipeVer

API Syntax:

AmpMW_GetFlowPipeVer (void)

Function Description:

- This function gets the flow pipe SVN version.

Returns:

Return	Description
Version	SVN version number

Table 5-6. Returns for Initialization SDK6 API **AmpMW_GetFlowPipeVer()**.

Example:

Please refer to the Unit Test document.

See Also:

None

Confidential
For HAOTEK Only

5.2.4 AmpMW_GetDataPipeVer

API Syntax:

AmpMW_GetDataPipeVer (void)

Function Description:

- This function gets the data pipe SVN version.

Returns:

Return	Description
Version	SVN version number

Table 5-7. Returns for Initialization SDK6 API **AmpMW_GetDataPipeVer()**.

Example:

Please refer to the Unit Test document.

See Also:

None

Confidential
For HAOTEK Only

6 Flow Pipeline

6.1 Flow Pipeline: Overview

This chapter provides details on the encode / decode flow pipelines. Flow pipeline manages a group of codecs which take action together and share the same state.

6.2 Flow Pipeline: List of APIs for DecodeMgr Pipeline

This section lists the decoder pipeline API functions. The decode pipe is designed for codecs that need to be operated with time sync. In most cases, it is used for video decoding sync audio and video playback.

- [AMPDec_GetDefaultCfg](#)
- [AMPDec_Create](#)
- [AMPDec_Delete](#)
- [AMPDec_Add](#)
- [AMPDec_Remove](#)
- [AMPDec_Start](#)
- [AMPDec_Pause](#)
- [AMPDec_Resume](#)
- [AMPDec_StopWithLastFrm](#)
- [AMPDec_Stop](#)
- [AMPDec_Step](#)
- [AMPDec_GetInfo](#)

6.2.1 AMPDec_GetDefaultCfg

API Syntax:

AmpDec_GetDefaultCfg (AMP_DEC_PIPE_CFG_s * cfg)

Function Description:

- This function gets the default configuration of the decode manager.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_CFG_s*	cfg	Configuration of the decode manager (AMP_DEC_PIPE_CFG_s is defined in <code>Decode.h</code>) Please refer to Section 6.2.1.1 below for more details.

Table 6-1. Parameters for Flow Pipeline SDK6 API **AmpDec_GetDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-2. Returns for Flow Pipeline SDK6 API **AmpDec_GetDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.1.1 AmpDec_GetDefaultCfg > AMP_DEC_PIPE_CFG_s

Type	Field	Description
UINT32	NumDecoder	Number of handler(s) in the pipe
void*	Decoder [MAX_DEC_PIPE_CO-DEC]	Pointer to handler(s) in the pipe
AMP_CALLBACK_f	CbEvent	Video decode pipe call back function

Table 6-3. Definition of **AMP_DEC_PIPE_CFG_s** for Flow Pipeline SDK6 API **AmpDec_GetDefaultCfg()**.

6.2.2 AMPDec_Create

API Syntax:

AmpDec_Create (AMP_DEC_PIPE_CFG_s * cfg, AMP_DEC_PIPE_HDLR_s ** pipe)

Function Description:

- This function creates the decode manager.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_CFG_s*	cfg	Configuration of the decode manager (AMP_DEC_PIPE_CFG_s is defined in <code>Decode.h</code>) Please refer to Section 6.2.1.1 for more details.
AMP_DEC_PIPE_HDLR_s**	pipe	Output pipe handler. (AMP_DEC_PIPE_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 6.2.2.1 for more details.

Table 6-4. Parameters for Flow Pipeline SDK6 API **AmpDec_Create()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-5. Returns for Flow Pipeline SDK6 API **AmpDec_Create()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.2.1 AmpDec_Create> AMP_DEC_PIPE_HDLR_s

Type	Field	Description
void*	Ctx	The context of the pipe.

Table 6-6. Definition of **AMP_DEC_PIPE_HDLR_s** for Flow Pipeline SDK6 API **AmpDec_Create()**.

6.2.3 AMPDec_Delete

API Syntax:

AmpDec_Delete (AMP_DEC_PIPE_HDLR_s * pipe)

Function Description:

- This function deletes a pipe handler.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_HDLR_s*	pipe	The pipe to delete. (AMP_DEC_PIPE_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 6.2.2.1 for more details.

Table 6-7. Parameters for Flow Pipeline SDK6 API **AmpDec_Delete()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-8. Returns for Flow Pipeline SDK6 API **AmpDec_Delete()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.4 AMPDec_Add

API Syntax:

AmpDec_Add (AMP_DEC_PIPE_HDLR_s * pipe)

Function Description:

- This function adds a pipe to the decode manager.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_HDLR_s*	pipe	The pipe to add. (AMP_DEC_PIPE_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 6.2.2.1 for more details.

Table 6-9. Parameters for Flow Pipeline SDK6 API **AmpDec_Add()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-10. Returns for Flow Pipeline SDK6 API **AmpDec_Add()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.5 AMPDec_Remove

API Syntax:

AmpDec_Remove (AMP_DEC_PIPE_HDLR_s * pipe)

Function Description:

- This function removes the pipe from the decode manager.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_HDLR_s*	pipe	The pipe to remove. (AMP_DEC_PIPE_HDLR_s is defined in Decode.h) Please refer to Section 6.2.2.1 for more details.

Table 6-11. Parameters for Flow Pipeline SDK6 API **AmpDec_Remove()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-12. Returns for Flow Pipeline SDK6 API **AmpDec_Remove()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.6 AMPDec_Start

API Syntax:

AMPDec_Start (AMP_DEC_PIPE_HDLR_s * pipe, AMP_AVDEC_TRICKPLAY_s * trick, AMP_VIDEODEC_DISPLAY_s * display)

Function Description:

- This function is used to start the sync pipe.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_HDLR_s*	pipe	The pipe to remove. (AMP_DEC_PIPE_HDLR_s is defined in Decode.h) Please refer to Section 6.2.2.1 for more details.
AMP_AVDEC_TRICKPLAY_s*	trick	The trickplay status (AMP_AVDEC_TRICKPLAY_s is defined in Decode.h) Please refer to Section 6.2.6.1 for more details.
AMP_VIDEODEC_DISPLAY_s*	display	(AMP_VIDEODEC_DISPLAY_s is defined in Decode.h) Please refer to Section 6.2.6.2 for more details.

Table 6-13. Parameters for Flow Pipeline SDK6 API AMPDec_Start().

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-14. Returns for Flow Pipeline SDK6 API AMPDec_Start().

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.6.1 AmpDec_Start> AMP_AVDEC_TRICKPLAY_s

Type	Field	Description
UINT32	TimeOffsetOfFirstFrame	The first frame to push to stream in ms
AMP_AVDEC_PLAY_DIRECTION_e	Direction	The playback direction

Type	Field	Description
UINT32	Speed	The playback speed

Table 6-15. Definition of **AMP_AVDEC_TRICKPLAY_s** for Flow Pipeline SDK6 API **AmpDec_Start()**.

6.2.6.2 AmpDec_Start> AMP_VIDEODEC_DISPLAY_s

Type	Field	Description
UINT16	SrcWidth	The video width
UINT16	SrcHeight	The video height
AMP_AREA_s	AOI	The area to display

Table 6-16. Definition of **AMP_AVDEC_TRICKPLAY_s** for Flow Pipeline SDK6 API **AmpDec_Start()**.

Confidential
For HAOTEK Only

6.2.7 AMPDec_Pause

API Syntax:

AMPDec_Pause (AMP_DEC_PIPE_HDLR_s * pipe)

Function Description:

- This function is used to pause the sync pipe.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_HDLR_s*	pipe	The pipe to remove. (AMP_DEC_PIPE_HDLR_s is defined in Decode.h) Please refer to Section 6.2.2.1 for more details.

Table 6-17. Parameters for Flow Pipeline SDK6 API **AMPDec_Pause()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-18. Returns for Flow Pipeline SDK6 API **AMPDec_Pause()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.8 AMPDec_Resume

API Syntax:

AMPDec_Resume (AMP_DEC_PIPE_HDLR_s * pipe)

Function Description:

- This function resumes the sync pipe feature.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_HDLR_s*	pipe	The pipe to remove. (AMP_DEC_PIPE_HDLR_s is defined in Decode.h) Please refer to Section 6.2.2.1 for more details.

Table 6-19. Parameters for Flow Pipeline SDK6 API **AMPDec_Resume()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-20. Returns for Flow Pipeline SDK6 API **AMPDec_Resume()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.9 AMPDec_StopWithLastFrm

API Syntax:

AMPDec_StopWithLastFrm (AMP_DEC_PIPE_HDLR_s * pipe)

Function Description:

- This function is used to stop the pipe and hold the last frame on-screen.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_HDLR_s*	pipe	The pipe to remove. (AMP_DEC_PIPE_HDLR_s is defined in Decode.h) Please refer to Section 6.2.2.1 for more details.

Table 6-21. Parameters for Flow Pipeline SDK6 API **AMPDec_StopWithLastFrm()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-22. Returns for Flow Pipeline SDK6 API **AMPDec_StopWithLastFrm()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.10 AMPDec_Stop

API Syntax:

AMPDec_Stop (AMP_DEC_PIPE_HDLR_s * pipe)

Function Description:

- This function is used to stop the pipe.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_HDLR_s*	pipe	The pipe to remove. (AMP_DEC_PIPE_HDLR_s is defined in Decode.h) Please refer to Section 6.2.2.1 for more details.

Table 6-23. Parameters for Flow Pipeline SDK6 API AMPDec_Stop().

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-24. Returns for Flow Pipeline SDK6 API AMPDec_Stop().

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.11 AMPDec_Step

API Syntax:

AMPDec_Step (AMP_DEC_PIPE_HDLR_s * pipe)

Function Description:

- This function is used to make one step forward on the pipe.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_HDLR_s*	pipe	The pipe to remove. (AMP_DEC_PIPE_HDLR_s is defined in Decode.h) Please refer to Section 6.2.2.1 for more details.

Table 6-25. Parameters for Flow Pipeline SDK6 API **AMPDec_Step()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-26. Returns for Flow Pipeline SDK6 API **AMPDec_Step()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.12 AMPDec_GetInfo

API Syntax:

AMPDec_GetInfo (AMP_DEC_PIPE_HDLR_s * pipe, AMP_DEC_PIPE_INFO_s * info)

Function Description:

- This function is used to decode manager information.

Parameters:

Type	Parameter	Description
AMP_DEC_PIPE_HDLR_s*	pipe	The pipe to remove. (AMP_DEC_PIPE_HDLR_s is defined in Decode.h) Please refer to Section 6.2.2.1 for more details.
AMP_DEC_PIPE_INFO_s*	pipe	The pipe to remove. (AMP_DEC_PIPE_INFO_s is defined in Decode.h) Please refer to Section 6.2.12.1 for more details.

Table 6-27. Parameters for Flow Pipeline SDK6 API **AMPDec_GetInfo()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-28. Returns for Flow Pipeline SDK6 API **AMPDec_GetInfo()**

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.2.12.1 AmpDec_GetInfo> AMP_DEC_PIPE_INFO_s

Type	Field	Description
AMP_DEC_PIPE_STATE_e	State	

Table 6-29. Definition of **AMP_DEC_PIPE_INFO_s** for Flow Pipeline SDK6 API **AmpDec_GetInfo()**.

6.3 Flow Pipeline: List of APIs for EncodeMgr Pipeline

This section lists the APIs for the encode pipeline module implementation. The APIs are used to create encode, delete, add, remove encode pipeline module, start/stop liveview, start/stop/pause/resume encode, run/stop still capture, and get encode pipeline module information.

- [AmpEnc_GetDefaultCfg](#)
- [AmpEnc_Create](#)
- [AmpEnc_Delete](#)
- [AmpEnc_Add](#)
- [AmpEnc_Remove](#)
- [AmpEnc_StartLiveview](#)
- [AmpEnc_StopLiveview](#)
- [AmpEnc_RunScript](#)
- [AmpEnc_StopRunScript](#)
- [AmpEnc_StartRecord](#)
- [AmpEnc_PauseRecord](#)
- [AmpEnc_ResumeRecord](#)
- [AmpEnc_StopRecord](#)
- [AmpEnc_GetInfo](#)

Confidential
For HAOTEK Only

6.3.1 AmpEnc_GetDefaultCfg

API Syntax:

AmpEnc_GetDefaultCfg (AMP_ENC_PIPE_CFG_s * cfg)

Function Description:

- This function gets the default pipeline configuration.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_CFG_S*	cfg	Pipeline Configuration. (AMP_ENC_PIPE_CFG_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.1.1 for more details.

Table 6-30. Parameters for Flow Pipeline SDK6 API **AmpEnc_GetDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-31. Returns for Flow Pipeline SDK6 API **AmpEnc_GetDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.1.1 AmpEnc_GetDefaultCfg> AMP_ENC_PIPE_CFG_s

Type	Field	Description
AMP_ENC_PIPE_TYPE_e	type	Pipeline Type
UINT32	numEncoder	Number of handler(s) in the pipe
void*	encoder[MAX_ENC_PIPE_CO-DEC]	Pointer to handler(s) in the pipe
AMP_CALLBACK_f	cbEvent	Callback function

Table 6-32. Definition of **AMP_DEC_PIPE_CFG_s** for Flow Pipeline SDK6 API **AmpEnc_GetDefaultCfg()**.

6.3.2 AmpEnc_Create

API Syntax:

AmpEnc_Create (AMP_ENC_PIPE_CFG_s * cfg, AMP_ENC_PIPE_HDLR_s ** pipe)

Function Description:

- This function is used to create an encoder pipeline and set the initial configuration.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_CFG_S*	cfg	Pipeline Configuration. (AMP_ENC_PIPE_CFG_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.1.1 for more details.
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.

Table 6-33. Parameters for Flow Pipeline SDK6 API **AMPEnc_Create()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-34. Returns for Flow Pipeline SDK6 API **AMPEnc_Create()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.2.1 AmpEnc_Create> AMP_ENC_PIPE_HDLR_s

Type	Field	Description
void	ctx	Pipeline handler: Context of the pipe

Table 6-35. Definition of **AMP_DEC_PIPE_CFG_s** for Flow Pipeline SDK6 API **AmpEnc_GetDefaultCfg()**.

6.3.3 AmpEnc_Delete

API Syntax:

AmpEnc_Delete (AMP_ENC_PIPE_HDLR_s * pipe)

Function Description:

- This function is used to delete an encoder pipeline.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.

Table 6-36. Parameters for Flow Pipeline SDK6 API **AMPEnc_Delete()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-37. Returns for Flow Pipeline SDK6 API **AMPEnc_Delete()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.4 AmpEnc_Add

API Syntax:

AmpEnc_Add (AMP_ENC_PIPE_HDLR_s * pipe)

Function Description:

- This function is used to add a pipeline to the encode manager.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.

Table 6-38. Parameters for Flow Pipeline SDK6 API **AMPEnc_Add()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-39. Returns for Flow Pipeline SDK6 API **AMPEnc_Add()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.5 AmpEnc_Remove

API Syntax:

AmpEnc_Remove (AMP_ENC_PIPE_HDLR_s * pipe)

Function Description:

- This function is used to remove a pipeline from the encode manager.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.

Table 6-40. Parameters for Flow Pipeline SDK6 API **AMPEnc_Remove()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-41. Returns for Flow Pipeline SDK6 API **AMPEnc_Remove()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.6 AmpEnc_StartLiveview

API Syntax:

AmpEnc_StartLiveview (AMP_ENC_PIPE_HDLR_s * pipe, UINT32 flag)

Function Description:

- This function is used to ask a pipeline to start liveview.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.
UINT32	flag	/* No effect */ AMP_ENC_FUNC_FLAG_NONE /* blocked operation */ AMP_ENC_FUNC_FLAG_WAIT /* do not show previous video frame */ AMP_ENC_FUNC_FLAG_NO_SHOW_VIDEO_PLANE /* enter DSP suspend mode when stop liveview */ AMP_ENC_FUNC_FLAG_SUS_DSP_ON_STOP

Table 6-42. Parameters for Flow Pipeline SDK6 API **AMPEnc_StartLiveview()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-43. Returns for Flow Pipeline SDK6 API **AMPEnc_StartLiveview()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.7 AmpEnc_StopLiveview

API Syntax:

AmpEnc_StopLiveview (AMP_ENC_PIPE_HDLR_s * pipe, UINT32 flag)

Function Description:

- This function is used to ask a pipeline to stop liveview.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.

Table 6-44. Parameters for Flow Pipeline SDK6 API **AMPEnc_StopLiveview()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-45. Returns for Flow Pipeline SDK6 API **AMPEnc_StopLiveview()**.

Example

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.8 AmpEnc_RunScript

API Syntax:

AmpEnc_RunScript (AMP_ENC_PIPE_HDLR_s * pipe, void * script)

Function Description:

- This function is used to ask a pipeline to run script (still encode operation)

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.
void*	script	Script Address

Table 6-46. Parameters for Flow Pipeline SDK6 API **AMPEnc_RunScript()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-47. Returns for Flow Pipeline SDK6 API **AMPEnc_RunScript()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.9 AmpEnc_StopRunScript

API Syntax:

AmpEnc_StopRunScript (AMP_ENC_PIPE_HDLR_s * pipe, UINT32 rule, UINT32 scriptID)

Function Description:

- This function is used to ask a pipeline to stop script (still encode operation).

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.
UINT32	rule	Stop rule /* stop running script at last stage */ AMP_ENC_STOP_SCRIPT_NONE /* stop running script right away, whole pending data will be discard */ AMP_ENC_STOP_SCRIPT_RIGHT_AWAY
UINT32	scriptID	Script unique ID

Table 6-48. Parameters for Flow Pipeline SDK6 API **AMPEnc_StopRunScript()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-49. Returns for Flow Pipeline SDK6 API **AMPEnc_StopRunScript()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.10 AmpEnc_StartRecord

API Syntax:

AmpEnc_StartRecord (AMP_ENC_PIPE_HDLR_s * pipe, UINT32 flag)

Function Description:

- This function is used to ask a pipeline to start record.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.
UINT32	flag	Please refer to the flag description.

Table 6-50. Parameters for Flow Pipeline SDK6 API **AMPEnc_StartRecord()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 6-51. Returns for API Flow Pipeline SDK6 API **AMPEnc_StartRecord()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.11 AmpEnc_PauseRecord

API Syntax:

AmpEnc_PauseRecord (AMP_ENC_PIPE_HDLR_s * pipe, UINT32 flag)

Function Description:

- This function is used to ask a pipeline to pause record.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.
UINT32	flag	Please refer to the flag description

Table 6-52. Parameters for Flow Pipeline SDK6 API **AMPEnc_PauseRecord()**.

Returns:

Return	Description
0	Success
- 1	Failure

Table 6-53. Returns for Flow Pipeline SDK6 API **AMPEnc_PauseRecord()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.12 AmcEnc_ResumeRecord

API Syntax:

AmcEnc_ResumeRecord (AMP_ENC_PIPE_HDLR_s * pipe, UINT32 flag)

Function Description:

- This function is used to ask a pipeline to resume record.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.
UINT32	flag	Please refer to flag description.

Table 6-54. Parameters for Flow Pipeline SDK6 API **AMPEnc_ResumeRecord()**.

Returns:

Return	Description
0	Success
- 1	Failure

Table 6-55. Returns for Flow Pipeline SDK6 API **AMPEnc_ResumeRecord()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.13 AmcEnc_StopRecord

API Syntax:

AmpEnc_StopRecord (AMP_ENC_PIPE_HDLR_s * pipe, UINT32 flag)

Function Description:

- This function is used to ask a pipeline to stop record.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in <code>Encode.h</code>) Please refer to Section 6.3.2.1 for more details.
UINT32	flag	Please refer to flag description.

Table 6-56. Parameters for Flow Pipeline SDK6 API **AMPEnc_StopRecord()**.

Returns:

Return	Description
0	Success
- 1	Failure

Table 6-57. Returns for Flow Pipeline SDK6 API **AMPEnc_StopRecord()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.14 AmpEnc_GetInfo

API Syntax:

AmpEnc_GetInfo (AMP_ENC_PIPE_HDLR_s * pipe, AMP_ENC_PIPE_INFO_s * info)

Function Description:

- This function is used to get encode manager information.

Parameters:

Type	Parameter	Description
AMP_ENC_PIPE_HDLR_S*	pipe	Pipeline Handler. (AMP_ENC_PIPE_HDLR_s is defined in Encode.h) Please refer to Section 6.3.2.1 for more details.
AMP_ENC_PIPE_INFO_S*	info	Pipeline State (AMP_ENC_PIPE_INFO_s is defined in Encode.h) Please refer to Section 6.3.2.1 for more details.

Table 6-58. Parameters for Flow Pipeline SDK6 API AMPEnc_GetInfo().

Returns:

Return	Description
0	Success
- 1	Failure

Table 6-59. Returns for Flow Pipeline SDK6 API AMPEnc_GetInfo().

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

6.3.14.1 AmpEnc_GetInfo> AMP_ENC_PIPE_INFO_s

Type	Field	Description
AMP_ENC_PIPE_STATE_e	state	Pipeline State AMP_ENC_PIPE_STATE_IDLE Idle State AMP_ENC_PIPE_STATE_LIVEVIEW Liveview State AMP_ENC_PIPE_STATE_RECORDING A/V recording state AMP_ENC_PIPE_STATE_RECORDING_PAUSED... A/V record-pause state AMP_ENC_PIPE_STATE_SCRIPT_PROCESSING...Still encode processing state

Type	Field	Description
AMP_ENC_PIPE_TYPE_e	type	Pipeline Type <i>AMP_ENC_AV_PIPE</i> Audio or video pipeline <i>AMP_ENC_STILL_PIPE</i> Still pipeline

Table 6-60. Definition of **AMP_DEC_PIPE_CFG_s** for Flow Pipeline SDK6 API **AmpEnc_GetDefaultCfg()**.

Confidential
For HAOTEK Only

7 Codec

7.1 Codec: Overview

This chapter provides details on the encoder and decoder engines. This is the basic unit of encoder and decoder implementation. Each codec can perform a specific function such as video encoding, audio encoding or video decoding and audio decoding.

7.2 Codec: List of APIs

This section lists the Amba Audio decoder APIs. This section provides the Amba audio decoder implementation. The audio decode module provides functions on the audio decode. Currently, Ambarella provides two decoding modes; PURE_AUDIO and VIDEO_AUDIO. The module also provides functions that initialize audio output which should be invoked before decode.

- [AmpAudioDec_GetInitDefaultCfg](#)
- [AmpAudioDec_Init](#)
- [AmpAudioDec_GetDefaultCfg](#)
- [AmpAudioDec_Create](#)
- [AmpAudioDec_Delete](#)
- [AmpAudioDec_DecoderCfg](#)
- [AmpAudio_OutputInit](#)
- [AmpDummyDec_GetDefaultCfg](#)
- [AmpDummyDec_Create](#)
- [AmpDummyDec_Delete](#)
- [AmpStillDec_GetInitDefaultCfg](#)
- [AmpStillDec_Init](#)
- [AmpStillDec_GetDefaultCfg](#)
- [AmpStillDec_Create](#)
- [AmpStillDec_Delete](#)
- [AmpStillDec_Decode](#)
- [AmpStillDec_Rescale](#)
- [AmpStillDec_Display](#)
- [AmpStillDec_Blend](#)
- [AmpVideoDec_GetInitDefaultCfg](#)
- [AmpVideoDec_Init](#)
- [AmpVideoDec_GetDefaultCfg](#)
- [AmpVideoDec_Create](#)
- [AmpVideoDec_Delete](#)
- [AmpVideoDec_DumpFrame](#)
- [AmpVideoDec_GetTime](#)
- [AmpVideoDec_SetEosPts](#)

- AmpVideoDec_GetXCodec
- AmpVideoDec_SetFadingEffect
- AmpAudioEnc_GetInitDefaultCfg
- AmpAudioEnc_Init
- AmpAudioEnc_GetDefaultCfg
- AmpAudioEnc_Create
- AmpAudioEnc_Delete
- AmpAudioEnc_Config
- AmpDummyEnc_GetDefaultCfg
- AmpDummyEnc_Create
- AmpDummyEnc_Delete
- AmpStillEnc_GetInitDefaultCfg
- AmpStillEnc_Init
- AmpStillEnc_GetDefaultCfg
- AmpStillEnc_Create
- AmpStillEnc_Delete
- AmpStillEnc_ConfigVinMain
- AmpStillEnc_StartRawCapture
- AmpStillEnc_StartFollowingRawCapture
- AmpStillEnc_UpdateVinMain
- AmpStillEnc_EnableLiveviewCapture
- AmpVideoEnc_GetInitDefaultCfg
- AmpVideoEnc_Init
- AmpVideoEnc_GetDefaultCfg
- AmpVideoEnc_Create
- AmpVideoEnc_Delete
- AmpVideoEnc_ConfigVinMain
- AmpVideoEnc_GetLayout
- AmpVideoEnc_SetBitstreamConfig
- AmpVideoEnc_SetBitstreamBuffer
- AmpVideoEnc_GetBitstreamConfig
- AmpVideoEnc_GetDefaultH264Header
- AmpVideoEnc_SetRuntimeBitrate
- AmpVideoEnc_SetRuntimeQuality
- AmpVideoEnc_CaptureTimeLapsedFrame
- AmpVideoEnc_SetRuntimeFrameRate
- AmpVideoEnc_SetEncodeBlend
- AmpVideoEnc_FeedEncodeRaw
- AmpVideoEnc_GetEncodingInfo

7.2.1 AmpAudioDec_GetInitDefaultCfg

API Syntax:

AmpAudioDec_GetInitDefaultCfg (AMP_AUDIODEC_INIT_CFG_s * cfg)

Function Description:

- This function is used to get the default value for the initial configuration for the audio decode module.

Parameters:

Type	Parameter	Description
AMP_AUDIO-DEC_INIT_CFG_s	cfg	Default module configuration (AMP_AUDIODEC_INIT_CFG_s is defined in <code>AudioDec.h</code>) Please refer to Section 7.2.1.1 for more details.

Table 7-1. Parameters for Codec SDK6 API **AmpAudioDec_GetInitDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-2. Returns for Codec SDK6 API **AmpAudioDec_GetInitDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.2.1.1 AmpAudioDec_GetinitDefaultCfg> AMP_AUDIODEC_INIT_CFG_s

Type	Field	Description
UINT32	MaxHdlr	Maximum audio decoder codec that the user can create
AMP_TASK_INFO_s	TaskInfo	Audio decode task information (AMP_TASK_INFO_s is defined in <code>common.h</code>) Please refer to Section 7.2.1.1.1 for more details.
UINT8	WorkBuff	Audio decode working buffer
UINT32	WorkBuffSize	Size of the audio decode working buffer

Table 7-3. Definition of **AMP_AUDIODEC_INIT_CFG_s** for Codec SDK6 API **AmpAudioDec_GetinitDefaultCfg()**.

7.2.1.1.1 AMP_AUDIODEC_INIT_CFG_s > AMP_TASK_INFO_s

Type	Field	Description
UINT32	Priority	Task priority
UINT32	StackSize	Task stack size

Table 7-4. Definition of **AMP_TASK_STREAM_INFO_s** for Codec SDK6 API **AmpAudioDec_GetInitDefaultCfg()**.

Confidential
For HAOTEK Only

7.2.2 AmpAudioDec_Init

API Syntax:

AmpAudioDec_Init (AMP_AUDIODEC_INIT_CFG_s * cfg)

Function Description:

- This function is used to set the initial configuration for the audio decode module.

Parameters:

Type	Parameter	Description
AMP_AUDIO- DEC_INIT_ CFG_s	cfg	Default module configuration (AMP_AUDIODEC_INIT_CFG_s is defined in <code>AudioDec.h</code>) Please refer to Section 7.2.1.1 for more details.

Table 7-5. Parameters for Codec SDK6 API **AmpAudioDec_Init()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-6. Returns for Codec SDK6 API **AmpAudioDec_Init()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.2.3 AmpAudioDec_GetDefaultCfg

API Syntax:

AmpAudioDec_GetDefaultCfg (AMP_AUDIODEC_HDLR_CFG_s * cfg)

Function Description:

- This function is used to get the audio decode codec default configuration.

Parameters:

Type	Parameter	Description
AMP_AUDIO- DEC_HDLR_ CFG_s	cfg	Default codec configuration (AMP_AUDIODEC_HDLR_CFG_s is defined in <code>AudioDec.h</code>) Please refer to Section 7.2.3.1 for more details.

Table 7-7. Parameters for Codec SDK6 API **AmpAudioDec_GetDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-8. Returns for Codec SDK6 API **AmpAudioDec_GetDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.2.3.1 AmpAudioDec_GetDefaultCfg> AMP_AUDIODEC_HDLR_CFG_s

Type	Field	Description
UINT8	DecoderTaskPriority	Audio decoder task priority
AMBA_AUDIO_ DEC_FLOW_e	PureAudio	Codec for pure audio or video audio
AMBA_AUDIO_ TYPE_e	DecType	Audio decoder type
UINT32	FadeInTime	Fade in when decode starts
UINT32	FadeOutTime	Fade out when decode stops
UINT32	SrcSampleRate	Sample frequency of the input
UINT32	DstSampleRate	Sample frequency of the output

Type	Field	Description
UINT16	SrcChannelMode	Channel mode of the input
UINT16	DstChannelMode	Channel mode of the output
UINT32	MaxSampleRate	Maximum supporting sample frequency
UINT32	MaxChannelNum	Maximum channel number
UINT32	MaxFrameSize	Maximum frame size
UINT32	MaxChunkNum	Maximum chunk number
UINT8	I2SIndex	I2S Index of output
UINT8*	CodecCacheWorkBuff	Buffer address for audio codec
UINT32	CodecCacheWorkSize	Buffer size for audio codec
union{AMBA_AUDIO_PCM_CONFIG_s PCMCfg, AMBA_AUDIO_AACDEC_CONFIG_s AACCFg}	Spec	Decode information
AMP_CALLBACK_f	CbCfgUpdated	Setting takes effect
AMP_CALLBACK_f	CbEvent	Event related to the encoder
UINT8*	RawBuffer	Buffer address for audio raw file
UINT32	RawBufferSize	Size of buffer address for audio raw file
AMP_BITS_DESC_s*	DescBuffer	Buffer address for audio descriptor
UINT32	DescBufferNum	Size of buffer address for audio descriptor

Table 7-9. Definition of **AMP_AUDIODEC_HDLR_CFG_s** for Codec SDK6 API **AmpAudioDec_GetDefaultCfg()**.

7.2.4 AmpAudioDec_Create

API Syntax:

AmpAudioDec_Create (AMP_AUDIODEC_HDLR_CFG_s * cfg, AMP_AVDEC_HDLR_s ** hdlr)

Function Description:

- This function is used to create the audio decode codec.

Parameters:

Type	Parameter	Description
AMP_AUDIO- DEC_HDLR_ CFG_s*	cfg	Default codec configuration (AMP_AUDIODEC_HDLR_CFG_s is defined in <code>AudioDec.h</code>) Please refer to Section 7.2.3.1 for more details.
AMP_AVDEC_ HDLR_s**	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.

Table 7-10. Parameters for Codec SDK6 API **AmpAudioDec_Create()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-11. Returns for Codec SDK6 API **AmpAudioDec_Create()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.2.4.1 AmpAudioDec_Create> AMP_AVDEC_HDLR_s

Type	Field	Description
void*	Ctx	Pointer to codec context
AMP_AVDEC_ CODEC_s*	Function	Pointer to codec operation functions

Table 7-12. Definition of **AMP_AVDEC_HDLR_s** for Codec SDK6 API **AmpAudioDec_Create()**.

7.2.5 AmpAudioDec_Delete

API Syntax:

AmpAudioDec_Delete (AMP_AVDEC_HDLR_s * hdlr)

Function Description:

- This function is used to delete the audio decode codec.

Parameters:

Type	Parameter	Description
AMP_AVDEC_HDLR_s	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.

Table 7-13. Parameters for Codec SDK6 API **AmpAudioDec_Delete()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-14. Returns for Codec SDK6 API **AmpAudioDec_Delete()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.2.6 AmpAudioDec_DecoderCfg

API Syntax:

AmpAudioDec_DecoderCfg (AMP_AUDIODEC_DECODER_CFG_s *cfg, AMP_AVDEC_HDLR_s *hdlr)

Function Description:

- This function is used to configure the decoder parameters when in idle state.

Parameters:

Type	Parameter	Description
AMP_AUDIO-DEC_DECODER_CFG_s	cfg	Audio Decoder configuration (AMP_AUDIODEC_DECODER_CFG_s is defined in <code>AudioDec.h</code>) Please refer to Section 7.2.6.1 for more details.
AMP_AVDEC_HDLR_s	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.

Table 7-15. Parameters for Codec SDK6 API **AmpAudioDec_DecoderCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-16. Returns for Codec SDK6 API **AmpAudioDec_DecoderCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.2.6.1 AmpAudioDec_DecoderCfg> AMP_AUDIODEC_DECODER_CFG_s

Type	Field	Description
AMBA_AUDIO_TYPE_e	DecType	
UINT32	FadeInTime	Fade in when decode starts
UINT32	FadeOutTime	Fade out when decode stops
UINT32	SrcSampleRate	Sample frequency of the input
UINT16	SrcChannelMode	Channel mode of the input

Type	Field	Description
union{AMBA_AUDIO_PCM_CONFIG_s PCMCfg, AMBA_AUDIO_AACDEC_CONFIG_s AACCfg}	Spec	Decode information

Table 7-17. Definition of **AMP_AVDEC_HDLR_s** for Codec SDK6 API **AmpAudioDec_Create()**.

Confidential
For HAOTEK Only

7.2.7 AmpAudio_OutputInit

API Syntax:

AmpAudio_OutputInit (UINT32 * outputCtrl, UINT8 priority)

Function Description:

- This function is used to initialize the audio output task.

Parameters:

Type	Parameter	Description
UINT32	outputCtrl	Audio output resource
UINT8	priority	Task priority

Table 7-18. Parameters for Codec SDK6 API **AmpAudioDec_OutputInit()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-19. Returns for Codec SDK6 API **AmpAudioDec_OutputInit()**.

Example

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.3 Codec: List of APIs for DummyDec

This section lists the dummy decoder APIs. This section provides the dummy decoder function sets. Dummy decoder is a decoder that only consumes frames without doing anything. It is used for testing purposes only.

- [AmpDummyDec_GetDefaultCfg](#)
- [AmpDummyDec_Create](#)
- [AmpDummyDec_Delete](#)

Confidential
For HAOTEK Only

7.3.1 AmpDummyDec_GetDefaultCfg

API Syntax:

AmpDummyDec_GetDefaultCfg (AMP_DUMMYDEC_CFG_s * cfg)

Function Description:

- This function is used to get the default configuration of a dummy video decode codec.

Parameters:

Type	Parameter	Description
AMP_DUMMYDEC_CFG_s	cfg	Codec configuration (AMP_DUMMYDEC_CFG_s is defined in <code>DummyDec.h</code>) Please refer to Section 7.3.1.1 for more details.

Table 7-20. Parameters for Codec SDK6 API **AmpDummyDec_GetDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-21. Returns for Codec SDK6 API **AmpDummyDec_GetDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.3.1.1 AmpDummyDec_GetDefaultCfg> AMP_DUMMYDEC_CFG_s

Type	Field	Description
AMBA_YUV_COLOR_s	BgColor	Background color
AMP_CALLBACK_f	CbCfgUpdated	Configuration updated cb function
AMP_CALLBACK_f	CbCodecEvent	Codec state cb function
char	RawBuffer	Raw buffer for coded data
UINT32	RawBufferSize	Size of the raw buffer
char	DescBuffer	Desc buffer
UINT32	NumDescBuffer	Size of desc buffer

Table 7-22. Definition of **AMP_DUMMYDEC_CFG_s** for Codec SDK6 API **AmpDummyDec_GetDefaultCfg()**.

7.3.2 AmpDummyDec_Create

API Syntax:

AmpDummyDec_Create (AMP_DUMMYDEC_CFG_s * cfg, AMP_AVDEC_HDLR_s ** hdlr)

Function Description:

- This function is used to create a dummy video decode codec.

Parameters:

Type	Parameter	Description
AMP_DUM- MYDEC_CFG_s	cfg	Codec configuration (AMP_DUMMYDEC_CFG_s is defined in <code>DummyDec.h</code>) Please refer to Section 7.3.1.1 for more details.
AMP_AVDEC_ HDLR_s	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.

Table 7-23. Parameters for Codec SDK6 API **AmpDummyDec_Create()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-24. Returns for Codec SDK6 API **AmpDummyDec_Create()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.3.3 AmpDummyDec_Delete

API Syntax:

AmpDummyDec_Delete (AMP_AVDEC_HDLR_s * hdlr)

Function Description:

- This function is used to delete a dummy video decode codec.

Parameters:

Type	Parameter	Description
AMP_AVDEC_HDLR_s	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.

Table 7-25. Parameters for Codec SDK6 API **AmpDummyDec_Delete()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-26. Returns for Codec SDK6 API **AmpDummyDec_Delete()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.4 Codec: List of APIs for StillDec

This section lists the still image decoder APIs. The still decoder codec provides functions that operate on a single frame. It includes Idr/I frame decode, JPEG decode, YUV rescale, YUV display, and YUV blending.

- [AmpStillDec_GetInitDefaultCfg](#)
- [AmpStillDec_Init](#)
- [AmpStillDec_GetDefaultCfg](#)
- [AmpStillDec_Create](#)
- [AmpStillDec_Delete](#)
- [AmpStillDec_Decode](#)
- [AmpStillDec_Rescale](#)
- [AmpStillDec_Display](#)
- [AmpStillDec_Blend](#)

Confidential
For HAOTEK Only

7.4.1 AmpStillDec_GetInitDefaultCfg

API Syntax:

AmpStillDec_GetInitDefaultCfg (AMP_STILLDEC_INIT_CFG_s * cfg)

Function Description:

- This function is used to get the default value of initial configuration for the video decode module.

Parameters:

Type	Parameter	Description
AMP_STILLDEC_INIT_CFG_s	cfg	Default module configuration Please refer to Section 7.4.1.1 for more details.

Table 7-27. Parameters for Codec SDK6 API **AmpStillDec_GetInitDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-28. Returns for Codec SDK6 API **AmpStillDec_GetInitDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.4.1.1 AmpStillDec_GetInitDefaultCfg> AMP_STILLDEC_INIT_CFG_s

Type	Field	Description
UINT32	MaxHdr	Max hdr supported on the module
AMP_TASK_INFO_s	TaskInfo	Task info for decode task
UINT8*	Buf	Working buffer for still decode module
UINT32	BufSize	Working buffer size for still decode module

Table 7-29. Definition of **AMP_STILLDEC_INIT_CFG_s** for Codec SDK6 API **AmpStillDec_GetInitDefaultCfg()**.

7.4.2 AmpStillDec_Init

API Syntax:

AmpStillDec_Init (AMP_STILLDEC_INIT_CFG_s * cfg)

Function Description:

- This function is used to set the initial configuration for the still decode module.

Parameters:

Type	Parameter	Description
AMP_STILLDEC_INIT_CFG_s	cfg	Default module configuration Please refer to Section 7.4.1.1 for more details.

Table 7-30. Parameters for Codec SDK6 API **AmpStillDec_Init()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-31. Returns for Codec SDK6 API **AmpStillDec_Init()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.4.3 AmpStillDec_GetDefaultCfg

API Syntax:

AmpStillDec_GetDefaultCfg (AMP_STILLDEC_CFG_s * cfg)

Function Description:

- This function is used to get the default configuration of the still decode codec.

Parameters:

Type	Parameter	Description
AMP_STILLDEC_CFG_s	cfg	Default module configuration Please refer to Section 7.4.3.1 for more details.

Table 7-32. Parameters for Codec SDK6 API **AmpStillDec_GetDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-33. Returns for Codec SDK6 API **AmpStillDec_GetDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.4.3.1 AmpStillDec_GetDefaultCfg> AMP_STILLDEC_CFG_s

Type	Field	Description
AMP_YUV_COLOR_s	BgColor	Background color
AMP_CALLBACK_f	CbCodecEvent	Callback function pointer of still decode event
UINT8*	RawBuf	Buffer for still raw file
UINT32	RawBufSize	Buffer size of the raw buffer

Table 7-34. Definition of **AMP_STILLDEC_CFG_s** for Codec SDK6 API **AmpStillDec_GetDefaultCfg()**.

7.4.3.1.1 AmpStillDec_GetDefaultCfg> AMP_YUV_COLOR_s

Type	Field	Description
UINT8	Y	Y part of the color
UINT8	U	U part of the color
UINT8	V	V part of the color

Table 7-35. Definition of **AMP_YUV_COLOR_s** for Codec SDK6 API **AmpStillDec_GetDefaultCfg()**.

Confidential
For HAOTEK Only

7.4.4 AmpStillDec_Create

API Syntax:

AmpStillDec_Create (AMP_STILLDEC_CFG_s * cfg, AMP_STLDEC_HDLR_s ** hdlr)

Function Description:

- This function is used to create still decode codec.

Parameters:

Type	Parameter	Description
AMP_STILLDEC_CFG_s	cfg	Default module configuration Please refer to Section 7.4.3.1 for more details.
AMP_STLDEC_HDLR_s	hdlr	Codec Handler. Please refer to Section 7.4.4.1 for more details

Table 7-36. Parameters for Codec SDK6 API **AmpStillDec_Create()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-37. Returns for Codec SDK6 API **AmpStillDec_Create()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.4.4.1 AmpStillDec_Create> AMP_STLDEC_HDLR_s

Type	Field	Description
void	ctx	Pointer to codec context
AMP_STLDEC_CODEC_s	Function	Pointer to codec operation functions

Table 7-38. Definition of **AMP_STILLDEC_HDLR_s** for Codec SDK6 API **AmpStillDec_Create()**.

7.4.5 AmpStillDec_Delete

API Syntax:

AmpStillDec_Delete (AMP_STLDEC_HDLR_s * hdlr)

Function Description:

- This function deletes still decode codec.

Parameters:

Type	Parameter	Description
AMP_STLDEC_HDLR_s	hdlr	Codec Handler. Please refer to Section 7.4.4.1 for more details

Table 7-39. Parameters for Codec SDK6 API **AmpStillDec_Delete()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-40. Returns for Codec SDK6 API **AmpStillDec_Delete()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.4.6 AmpStillDec_Decode

API Syntax:

AmpStillDec_Decode (AMP_STLDEC_HDLR_s * hdlr, AMP_STILLDEC_DECODE_s * decode)

Function Description:

- This function is used to decode raw data into the YUV data.

Parameters:

Type	Parameter	Description
AMP_STLDEC_HDLR_s	hdlr	Codec Handler. Please refer to Section 7.4.4.1 for more details
AMP_STILLDEC_DECODE_s	decode	Please refer to Section 7.4.6.1 for more details.

Table 7-41. Parameters for Codec SDK6 API **AmpStillDec_Decode()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-42. Returns for Codec SDK6 API **AmpStillDec_Decode()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.4.6.1 AmpStillDec_Decode> AMP_STILLDEC_DECODE_s

Type	Field	Description
UINT32	NumFile	Number of file to decode
UINT8*	DecodeBuf	Decode output buffer
UINT32	SizeDecodeBuf	Size of decode output buffer
UINT32*	DecodedImgPitch	Pitch in decode buffer for last decoded image
UINT32*	DecodeState	U32 array whose size is numFile for store error state for each decode
AMP_AREA_s*	CropFromDecodedBuf	AMP_AREA_S array. Null to skip scaling.

Type	Field	Description
AMP_YUV_BUFFER_s*	RescaleDest	AMP_YUV_BUFFER_s array
AMP_ROTATION_e*	Rotate	Rotation on scaling
UINT8*	OutAddrY	The address of decoded Y data of LAST file
UINT8*	OutAddrUV	The address of decoded UV data of LAST file
AMP_COLOR_FORMAT_e	OutColorFmt	The color format of LAST file

Table 7-43. Definition of **AMP_STILLDEC_DECODE_s** for Codec SDK6 API **AmpStillDec_Decode()**.

Confidential
For HAOTEK Only

7.4.7 AmpStillDec_Rescale

API Syntax:

AmpStillDec_Rescale (AMP_STLDEC_HDLR_s * hdlr, AMP_STILLDEC_RESCALE_s * rescale)

Function Description:

- This function is used to rescale a YUV buffer and the limitation is that it should be aligned with the value depending on the DSP hardware limitation.

Parameters:

Type	Parameter	Description
AMP_STLDEC_HDLR_s	hdlr	Codec Handler. Please refer to Section 7.4.4.1 for more details
AMP_STILLDEC_RESCALE_s	rescale	Rescale Information. (AMP_STILLDEC_RESCALE_s is defined in <code>stillDec.h</code>) Please refer to Section 7.4.7.1 for more details.

Table 7-44. Parameters for Codec SDK6 API **AmpStillDec_Rescale()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-45. Returns for Codec SDK6 API **AmpStillDec_Rescale()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.4.7.1 AmpStillDec_Rescale> AMP_STILLDEC_RESCALE_s

Type	Field	Description
UINT32	NumBuf	Number of buffer to scale
AMP_YUV_BUFFER_s	Src	Scaling source (AMP_YUV_BUFFER_s is defined in <code>common.h</code>) Please refer to Section 7.4.7.1.1 for more details.
AMP_YUV_BUFFER_s	Dest	Scaling target (AMP_YUV_BUFFER_s is defined in <code>common.h</code>) Please refer to Section 7.4.7.1.1 for more details

Type	Field	Description
AMP_ROTATION_e	Rotate	Rotate on scaling
UINT8	LumaGain	Luma gain: 1 ~ 255

Table 7-46. Definition of **AMP_STILLDEC_Rescale_s** for Codec SDK6 API **AmpStillDec_Rescale()**.

7.4.7.1.1 AMP_STILLDEC_RESCALE_s > AMP_YUV_BUFFER_s

Type	Field	Description
AMP_COLOR_FORMAT_e	ColorFmt	Color Format of the YUV buffer
UINT32	Width	Buffer width
UINT32	Height	Buffer height
UINT32	Pitch	Buffer pitch
UINT8	LumaAddr	Luma address
UINT8	ChromaAddr	Chroma address
AMP_AREA_s	AOI	Area of interest

Table 7-47. Definition of **AMP_YUV_BUFFER_s** for Codec SDK6 API **AmpStillDec_Rescale()**.

7.4.8 AmpStillDec_Display

API Syntax:

AmpStillDec_Display (AMP_STLDEC_HDLR_s * hdlr, AMP_STILLDEC_DISPLAY_s * display)

Function Description:

- This function is used to display the buffer on Vout.

Parameters:

Type	Parameter	Description
AMP_STLDEC_HDLR_s	hdlr	Codec Handler. Please refer to Section 7.4.4.1 for more details
AMP_STILLDEC_DISPLAY_s	display	Display Info (AMP_STILLDEC_DISPLAY_s is defined in <code>StillDec.h</code>) Please refer to Section 7.4.8.1 for more details.

Table 7-48. Parameters for Codec SDK6 API **AmpStillDec_Display()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-49. Returns for Codec SDK6 API **AmpStillDec_Display()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.4.8.1 AmpStillDec_Display> AMP_STILLDEC_DISPLAY_s

Type	Field	Description
AMP_DISP_CHANNEL_IDX_e	Vout	This function decides which Vout to display on
AMP_YUV_BUFFER_s	Buf	Buffer to display. Size of AOI must be the same as the Vout size. (AMP_YUV_BUFFER_s is defined in <code>common.h</code>) Please refer to Section 7.4.7.1.1 for more details

Table 7-50. Definition of **AMP_STILLDEC_DISPLAY_s** for Codec SDK6 API **AmpStillDec_Display()**.

7.4.9 AmpStillDec_Blend

API Syntax:

AmpStillDec_Blend (AMP_STLDEC_HDLR_s *hdlr, AMP_STILLDEC_BLEND_s *blend)

Function Description:

- This function is used to blend two YUV buffers with the same height and pitch.

Parameters:

Type	Parameter	Description
AMP_STLDEC_HDLR_s	hdlr	Codec Handler. Please refer to Section 7.4.4.1 for more details
AMP_STILLDEC_BLEND_s	blend	Blending information. Please refer to Section 7.4.9.1 for more details

Table 7-51. Parameters for Codec SDK6 API **AmpStillDec_Blend()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-52. Returns for Codec SDK6 API **AmpStillDec_Blend()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.4.9.1 AmpStillDec_Blend> AMP_STILLDEC_BLEND_s

Type	Field	Description
AMP_YUV_BUFFER_s	Src1	Scaling source. (AMP_YUV_BUFFER_s is defined in <code>common.h</code>) Please refer to Section 7.4.7.1.1 for more details
AMP_YUV_BUFFER_s	Src2	Scaling source. (AMP_YUV_BUFFER_s is defined in <code>common.h</code>) Please refer to Section 7.4.7.1.1 for more details
AMP_YUV_BUFFER_s	Dest	Scaling target. (AMP_YUV_BUFFER_s is defined in <code>common.h</code>) Please refer to Section 7.4.7.1.1 for more details
UINT8	AlphaMap	Pointer to alpha map

Type	Field	Description
UINT32	GlobalAlpha	Take effect when alphaMap = NULL

Table 7-53. Definition of **AMP_STILLDEC_BLEND_s** for Codec SDK6 API **AmpStillDec_Blend()**.

Confidential
For HAOTEK Only

7.5 Codec: List of APIs for VideoDec

This section lists the Amba video decoder APIs. The video decode module provides functions on video decode. In most cases, the user controls video decode via the decode pipe. Some functions like GetInfo, SetEos, and DumpFrame can run directly.

- [AmpVideoDec_GetInitDefaultCfg](#)
- [AmpVideoDec_Init](#)
- [AmpVideoDec_GetDefaultCfg](#)
- [AmpVideoDec_Create](#)
- [AmpVideoDec_Delete](#)
- [AmpVideoDec_DumpFrame](#)
- [AmpVideoDec_GetTime](#)
- [AmpVideoDec_SetEosPts](#)
- [AmpVideoDec_GetXCodec](#)
- [AmpVideoDec_SetFadingEffect](#)

Confidential
For HAOTEK Only

7.5.1 AmpVideoDec_GetInitDefaultCfg

API Syntax:

AmpVideoDec_GetInitDefaultCfg (AMP_VIDEODEC_INIT_CFG_s *cfg)

Function Description:

- This function is used to get the default value of the initial configuration for the video decode module.

Parameters:

Type	Parameter	Description
AMP_VIDEODEC_INIT_CFG_s	cfg	Default module configuration. (AMP_VIDEODEC_INIT_CFG_s is defined in <code>VideoDec.h</code>) Please refer to Section 7.5.1.1 for more details

Table 7-54. Parameters for Codec SDK6 API **AmpVideoDec_GetInitDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-55. Returns for Codec SDK6 API **AmpVideoDec_GetInitDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.5.1.1 AmpVideoDec_GetInitDefaultCfg> AMP_VIDEODEC_INIT_CFG_s

Type	Field	Description
UINT32	MaxHdlr	
AMP_TASK_INFO_s	TaskInfo	(AMP_TASK_INFO_s is defined in <code>common.h</code>) Please refer to Section 7.5.1.1 for more details
UINT8	Buf	
UINT32	BufSize	

Table 7-56. Definition of **AMP_VIDEODEC_INIT_CFG_s** for Codec SDK6 API **AmpVideoDec_GetInitDefaultCfg()**.

7.5.1.1.1 AMP_VIDEODEC_INIT_CFG_s > AMP_TASK_INFO_s

Type	Field	Description
UINT32	Priority	Task Priority
UINT32	StackSize	Task stack size

Table 7-57. Definition of **AMP_TASK_INFO_s** for Codec SDK6 API **AmpVideoDec_GetInitDefaultCfg()**.

Confidential
For HAOTEK Only

7.5.2 AmpVideoDec_Init

API Syntax:

AmpVideoDec_Init (AMP_VIDEODEC_INIT_CFG_s * cfg)

Function Description:

- This function is used to set the initial configuration for the video decode module.

Parameters:

Type	Parameter	Description
AMP_VIDEO- DEC_INIT_ CFG_s	cfg	Default module configuration. (AMP_VIDEODEC_INIT_CFG_s is defined in <code>VideoDec.h</code>) Please refer to Section 7.5.1.1 for more details

Table 7-58. Parameters for Codec SDK6 API AmpVideoDec_Init().

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-59. Returns for Codec SDK6 API AmpVideoDec_Init().

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.5.3 AmpVideoDec_GetDefaultCfg

API Syntax:

AmpVideoDec_GetDefaultCfg (AMP_VIDEODEC_CFG_s * cfg)

Function Description:

- This function is used to get the video decode codec default configuration.

Parameters:

Type	Parameter	Description
AMP_VIDEO- DEC_CFG_s	cfg	Default codec configuration. (AMP_VIDEODEC_CFG_s is defined in VideoDec.h) Please refer to Section 7.5.3.1 for more details

Table 7-60. Parameters for Codec SDK6 API AmpVideoDec_GetDefaultCfg().

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-61. Returns for Codec SDK6 API AmpVideoDec_GetDefaultCfg().

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.5.3.1 AmpVideoDec_GetDefaultCfg> AMP_VIDEODEC_CFG_s

Type	Field	Description
AMP_YUV_ COLOR_s	BgColor	Background color
AMP_ CALLBACK_f	CbCfgUpdated	Callback function when configuration is updated
AMP_ CALLBACK_f	CbCodecEvent	Callback function on event
char	RawBuffer	Buffer for raw file as file reading buffer
UINT32	RawBufferSize	Size of raw buffer
char	DescBuffer	Buffer for internal descriptor
UINT32	NumDescBuffer	Number of descriptor

Type	Field	Description
AMP_VIDEO- DEC_FEA- TURE_CFG_s	Feature	Decode video initial configuration

Table 7-62. Definition of **AMP_VIDEODEC_CFG_s** for Codec SDK6 API **AmpVideoDec_GetDefaultCfg()**.

Confidential
For HAOTEK Only

7.5.4 AmpVideoDec_Create

API Syntax:

AmpVideoDec_Create (AMP_VIDEODEC_CFG_s * cfg, AMP_AVDEC_HDLR_s ** hdlr)

Function Description:

- This function is used to create the video decode codec.

Parameters:

Type	Parameter	Description
AMP_VIDEODEC_CFG_s	cfg	Default codec configuration. (AMP_VIDEODEC_CFG_s is defined in <code>VideoDec.h</code>) Please refer to Section 7.5.3.1 for more details
AMP_AVDEC_HDLR_s	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.

Table 7-63. Parameters for Codec SDK6 API **AmpVideoDec_Create()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-64. Returns for Codec SDK6 API **AmpVideoDec_Create()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.5.5 AmpVideoDec_Delete

API Syntax:

AmpVideoDec_Delete (AMP_AVDEC_HDLR_s * hdlr)

Function Description:

- This function is used to delete the codec.

Parameters:

Type	Parameter	Description
AMP_AVDEC_HDLR_s	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.

Table 7-65. Parameters for Codec SDK6 API **AmpVideoDec_Delete()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-66. Returns for Codec SDK6 API **AmpVideoDec_Delete()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.5.6 AmpVideoDec_DumpFrame

API Syntax:

AmpVideoDec_DumpFrame (AMP_AVDEC_HDLR_s * hdlr, AMP_YUV_BUFFER_s * buf)

Function Description:

-
-

Parameters:

Type	Parameter	Description
AMP_AVDEC_HDLR_s	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.
AMP_YUV_BUFFER_S	buf	Buffer to display. Size of AOI must be the same as the Vout size. (AMP_YUV_BUFFER_s is defined in <code>common.h</code>) Please refer to Section 7.4.7.1.1 for more details

Table 7-67. Parameters for Codec SDK6 API AmpVideoDec_DumpFrame().

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-68. Returns for Codec SDK6 API AmpVideoDec_DumpFrame().

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.5.7 AmpVideoDec_GetTime

API Syntax:

AmpVideoDec_GetTime (AMP_AVDEC_HDLR_s * Hdlr, UINT64 * Time)

Function Description:

- This function is used to get the current time.

Parameters:

Type	Parameter	Description
AMP_AVDEC_HDLR_s	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.
UINT64	Time	Current time in ms

Table 7-69. Parameters for Codec SDK6 API **AmpVideoDec_GetTime()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-70. Returns for Codec SDK6 API **AmpVideoDec_GetTime()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.5.8 AmpVideoDec_SetEosPts

API Syntax:

AmpVideoDec_SetEosPts (AMP_AVDEC_HDLR_s * Hdlr, UINT64 EosFileTime, UINT32 DeltaFileTime, UINT32 FileTimeScale)

Function Description:

- This function is used to set EOS points.

Parameters:

Type	Parameter	Description
AMP_AVDEC_HDLR_s	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.
UINT64	EosFileTime	EOS time (of file)
UINT32	DeltaFileTime	EOS delta. It's time (of file) per frame
UINT32	FileTimeScale	Time (of file) per second

Table 7-71. Parameters for Codec SDK6 API **AmpVideoDec_SetEosPts()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-72. Returns for Codec SDK6 API **AmpVideoDec_SetEosPts()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.5.9 AmpVideoDec_GetXCodec

API Syntax:

```
AmpVideoDec_GetXCodec (AMP_AVDEC_HDLR_s * hdlr, AMP_AVDEC_HDLR_s ** xcodeHdlr)
```

Function Description:

- This function is used to get the transcode codec.

Parameters:

Type	Parameter	Description
AMP_AVDEC_HDLR_s	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.
AMP_AVDEC_HDLR_s	xcodeHdlr	Transcode codec (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.

Table 7-73. Parameters for Codec SDK6 API **AmpVideoDec_GetXCodec()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-74. Returns for Codec SDK6 API **AmpVideoDec_GetXCodec()**

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.5.10 AmpVideoDec_SetFadingEffect

API Syntax:

AmpVideoDec_SetFadingEffect (AMP_AVDEC_HDLR_s * hdlr, UINT8 numFadingCfg, AMP_VIDEODEC_FADING_EFFECT_s * fadingCfg)

Function Description:

- This function is used to set the fading effect on video playback.

Parameters:

Type	Parameter	Description
AMP_AVDEC_HDLR_s	hdlr	Codec handler structure for video decode (AMP_AVDEC_HDLR_s is defined in <code>Decode.h</code>) Please refer to Section 7.2.4.1 for more details.
UINT8	numFadingCfg	Number of fading effect. Maximum value is 2 to support fade in and fade out.
AMP_VIDEODEC_FADING_EFFECT_s	fadingCfg	

Table 7-75. Parameters for Codec SDK6 API **AmpVideoDec_SetFadingEffect()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-76. Returns for Codec SDK6 API **AmpVideoDec_SetFadingEffect()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.5.10.1 AmpVideoDec_SetFadingEffect> AMP_VIDEODEC_FADING_EFFECT_s

Type	Field	Description
UINT32	StartTime	Fading start time in ms
UINT32	Duration	Fading duration in ms, 0 to disable
UINT16	StartMatrix	Fading start matrix
INT16	StartYOffset	
INT16	StartUOffset	

Type	Field	Description
INT16	StartVOffset	
UINT16	EndMatrix	Fading end matrix
INT16	EndYOffset	
INT16	EndUOffset	
INT16	EndVOffset	

Table 7-77. Definition of **AMP_VIDEDEC_FADING_EFFECT_s** for Codec SDK6 API **AmpVideoDec_SetFadingEffect()**.

Confidential
For HAOTEK Only

7.6 Codec: List of APIs for AudioEnc

This section lists the Amba audio encoder APIs. The implementation of the Amba audio encode module includes the initialization Amba audio encode module, create Amba audio encode module, delete Amba audio encode module, and get Amba audio encode module functions..

- [AmpAudioEnc_GetInitDefaultCfg](#)
- [AmpAudioEnc_Init](#)
- [AmpAudioEnc_GetDefaultCfg](#)
- [AmpAudioEnc_Create](#)
- [AmpAudioEnc_Delete](#)
- [AmpAudioEnc_Config](#)

Confidential
For HAOTEK Only

7.6.1 AmpAudioEnc_GetInitDefaultCfg

API Syntax:

AmpAudioEnc_GetInitDefaultCfg (AMP_AUDIOENC_INIT_CFG_s * defInitCfg)

Function Description:

- This function is used to get audio encode module default configuration for initialization.

Parameters:

Type	Parameter	Description
AMP_AUDIOENC_INIT_CFG_s	defInitCfg	Initial configuration

Table 7-78. Parameters for Codec SDK6 API **AmpAudioEnc_GetInitDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-79. Returns for Codec SDK6 API **AmpAudioEnc_GetInitDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.6.2 AmpAudioEnc_Init

API Syntax:

AmpAudioEnc_Init (AMP_AUDIOENC_INIT_CFG_s * cfg)

Function Description:

- This function is used to initialize audio encode module. The function should only be invoked once. The user MUST invoke this function before using audio encode module. The memory pool of the module will be provided by the user.

Parameters:

Type	Parameter	Description
AMP_AUDIO- ENC_INIT_ CFG_s	cfg	Audio Encode module configuration

Table 7-80. Parameters for Codec SDK6 API **AmpAudioEnc_Init()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-81. Returns for Codec SDK6 API **AmpAudioEnc_Init()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.6.3 AmpAudioEnc_GetDefaultCfg

API Syntax:

AmpAudioEnc_GetDefaultCfg (AMP_AUDIOENC_HDLR_CFG_s * defCfg)

Function Description:

- This function is used to get the full default setting of the audio codec.

Parameters:

Type	Parameter	Description
AMP_AUDIOENC_HDLR_CFG_s	defCfg	Default Configuration

Table 7-82. Parameters for Codec SDK6 API **AmpAudioEnc_GetDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-83. Returns for Codec SDK6 API **AmpAudioEnc_GetDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.6.3.1 AmpAudioEnc_GetDefaultCfg> AMP_AUDIOENC_HDLR_CFG_s

Type	Field	Description
AMBA_AUDIO_TYPE_e	EncType	Audio Encode Type
UINT8	EventDataReadySkipNum	Fire “data ready” event to FIFO per (1 + evenDataReadySkipNum) frames
UINT8	EncoderTaskPriority	Audio encoder task priority
UINT8	InputTaskPriority	Audio input receiver task priority
UINT32	FadeInTime	Fade in when encode starts
UINT32	FadeOutTime	Fade out when encode starts
UINT32	SrcSampleRate	Sample frequency of the input
UINT32	DstSampleRate	Sample frequency of the output

Type	Field	Description
UINT16	SrcChannelMode	Channel mode of the input
UINT16	DstChannelMode	Channel mode of the output
UINT8	NumInstance	Number of audio instance in this handler
AMP_AUDIO_INSTANCE_s*	AudioInstance	Audio encode instance relative to audio_lib
union	Spec	Audio encode specification
AMP_CALLBACK_f	cbCfgUpdated	Setting take effect
AMP_CALLBACK_f	cbEvent	Event related to the encoder
AMP_ENC_BITSBUFFER_CFG_s	BitsBufCfg	Buffer configuration
INT8*	CalibCurveAddr	Calib Curve Address
INT32*	CalibworkBuffer	Calibration working buffer address

Table 7-84. Definition of **AMP_AUDIOENC_HDLR_CFG_s** for Codec SDK6 API **AmpAudioEnc_GetDefaultCfg()**.

Confidential
For HAOTEK Only

7.6.4 AmpAudioEnc_Create

API Syntax:

```
AmpAudioEnc_Create ( AMP_AUDIOENC_HDLR_CFG_s * cfg, AMP_AVENC_HDLR_s ** aencHdlr)
```

Function Description:

- This function is used to create an audio handler and set the initial configuration.

Parameters:

Type	Parameter	Description
AMP_AUDIOENC_HDLR_CFG_s	cfg	AudioEnc handler configuration
AMP_AVENC_HDLR_s	aencHdlr	Common handler structure for video encode

Table 7-85. Parameters for Codec SDK6 API **AmpAudioEnc_Create()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-86. Returns for Codec SDK6 API **AmpAudioEnc_Create()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.6.5 AmpAudioEnc_Delete

API Syntax:

AmpAudioEnc_Delete (AMP_AVENC_HDLR_s * hdlr)

Function Description:

- This function is used to delete an audio handler.

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Audio encode instance

Table 7-87. Parameters for Codec SDK6 API **AmpAudioEnc_Delete()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-88. Returns for Codec SDK6 API **AmpAudioEnc_Delete()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.6.6 AmpAudioEnc_Config

API Syntax:

AmpAudioEnc_Config (AMP_AVENC_HDLR_s * hdlr, AMP_AUDIOENC_CFG_s * cfg)

Function Description:

- This function is used to configure the audio encode handler.

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Audio encode instance
AMP_AUDIOENC_CFG_s	cfg	Encoder configuration

Table 7-89. Parameters for Codec SDK6 API **AmpAudioEnc_Config()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-90. Returns for Codec SDK6 API **AmpAudioEnc_Config()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.7 Codec: List of APIs for DummyEnc

This section lists the sample encoder APIs. The implementation of the sample encode module includes create sample encode module and delete sample encode module functions..

- [AmpDummyEnc_GetDefaultCfg](#)
- [AmpDummyEnc_Create](#)
- [AmpDummyEnc_Delete](#)

Confidential
For HAOTEK Only

7.7.1 AmpDummyEnc_GetDefaultCfg

API Syntax:

AmpDummyEnc_GetDefaultCfg (AMP_DUMMYENC_CFG_s * cfg)

Function Description:

- This function is used to get full default settings of the module.

Parameters:

Type	Parameter	Description
AMP_DUMMY-ENC_CFG_s	cfg	Encode video configuration

Table 7-91. Parameters for Codec SDK6 API **AmpDummyEnc_GetDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-92. Returns for Codec SDK6 API **AmpDummyEnc_GetDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.7.1.1 AmpDummyEnc_GetDefaultCfg> AMP_DUMMY_ENC_CFG_s

Type	Field	Description
AMBA_YUV_COLOR_s	bgColor	Background color
AMP_CALLBACK_f	cbCfgUpdated	Callback when configuration is updated
AMP_CALLBACK_f	cbCodecEvent	Callback event
WCHAR	rawFn[DUMMY_MAX_FILE-NAME_LENGTH]	Raw data file name
WCHAR	idxFn[DUMMY_MAX_FILE-NAME_LENGTH]	Index data file name
UINT8	idrltvl	IDR interval

Type	Field	Description
Char *	rawBuffer	Raw data buffer address
UINT32	rawBufferSize	Raw data buffer size
Char *	descBuffer	Descriptor buffer
UINT32	numDescBuffer	Descriptor buffer entry
UINT32	frmDly	Frame sent delay
UINT32	memRunOutAlarmThr	runout memory threshold

Table 7-93. Definition of **AMP_DUMMY_ENC_CFG_s** for Codec SDK6 API **AmpDummyEnc_GetDefaultCfg()**.

Confidential
For HAOTEK Only

7.7.2 AmpDummyEnc_Create

API Syntax:

```
AmpDummyEnc_Create (AMP_DUMMYENC_CFG_s * cfg, AMP_AVENC_HDLR_s ** hdlr)
```

Function Description:

- This function is used to set the initial configuration for the video encode module.

Parameters:

Type	Parameter	Description
AMP_DUMMY-ENC_CFG_s	cfg	Encode video configuration
AMP_AVENC_HDLR_s	hdlr	Common handler structure for video encode

Table 7-94. Parameters for Codec SDK6 API **AmpDummyEnc_Create()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-95. Returns for Codec SDK6 API **AmpDummyEnc_Create()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.7.3 AmpDummyEnc_Delete

API Syntax:

AmpDummyEnc_Delete (AMP_AVENC_HDLR_s * hdlr)

Function Description:

- This function is used to delete the configuration for the video encode module

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Common handler structure for video encode

Table 7-96. Parameters for Codec SDK6 API **AmpDummyEnc_Delete()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-97. Returns for Codec SDK6 API **AmpDummyEnc_Delete()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.8 Codec: List of APIs for StillEnc

This section lists the still encoder APIs. The implementation of the still encode module includes initial still encode module, create still encode module, delete still encode module, config still encode module window layout, trigger to start raw capture, update window layout in IDLE state, control LiveView capture between LiveView and Still-Capture functions..

- [AmpStillEnc_GetInitDefaultCfg](#)
- [AmpStillEnc_Init](#)
- [AmpStillEnc_GetDefaultCfg](#)
- [AmpStillEnc_Create](#)
- [AmpStillEnc_Delete](#)
- [AmpStillEnc_ConfigVinMain](#)
- [AmpStillEnc_StartRawCapture](#)
- [AmpStillEnc_StartFollowingRawCapture](#)
- [AmpStillEnc_UpdateVinMain](#)
- [AmpStillEnc_EnableLiveviewCapture](#)

Confidential
For HAOTEK Only

7.8.1 AmpStillEnc_GetInitDefaultCfg

API Syntax:

AmpStillEnc_GetInitDefaultCfg (AMP_STILLENC_INIT_CFG_s * defInitCfg)

Function Description:

- This function is used to get the still encoder module default configuration for initialization.

Parameters:

Type	Parameter	Description
AMP_STILLENC_INIT_CFG_s	defInitCfg	Initial default configuration

Table 7-98. Parameters for Codec SDK6 API **AmpStillEnc_GetInitDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-99. Returns for Codec SDK6 API **AmpStillEnc_GetInitDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.8.1.1 AmpStillEnc_GetInitDefaultCfg> AMP_STILLENC_INIT_CFG_s

Type	Field	Description
UINT8	MaxLayerPerEncoder	Maximum number of layers per encoder layout
AMP_YUV_COLOR_s	BgColor	Background color of LiveView
AMP_TASK_INFO_s	MainTaskInfo	General task information
AMP_TASK_INFO_s	RawCapTaskInfo	Raw capture task information
AMP_TASK_INFO_s	RawEncTaskInfo	Raw encode task information
UINT32	MsgQueueNum	Number of entries per message queue
UINT8*	MemoryPoolAddr	Working buffer start address

Type	Field	Description
UINT32	MemoryPoolSize	Size of the buffer
UINT32	ScriptBufSize	Size of Still encode script buffer

Table 7-100. Definition of **AMP_STILLENC_INIT_CFG_s** for Codec SDK6 API **AmpStillEnc_GetInitDefaultCfg()**.

Confidential
For HAOTEK Only

7.8.2 AmpStillEnc_Init

API Syntax:

AmpStillEnc_Init (AMP_STILLENC_INIT_CFG_s * cfg)

Function Description:

- This function is used to initialize the still encode module. The function should only be invoked once. The user must invoke this function before using the still encode module. The memory pool of the module will be provided by the user.

Parameters:

Type	Parameter	Description
AMP_STILLENC_INIT_CFG_s	defInitscfg	Initial default configuration

Table 7-101. Parameters for Codec SDK6 API **AmpStillEnc_Init()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-102. Returns for Codec SDK6 API **AmpStillEnc_Init()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.8.3 AmpStillEnc_GetDefaultCfg

API Syntax:

AmpStillEnc_GetDefaultCfg (AMP_STILLENC_HDLR_CFG_s * defCfg)

Function Description:

- This function is used to get the full default setting of the module.

Parameters:

Type	Parameter	Description
AMP_STILLENC_HDLR_CFG_s	defCfg	Still encoder handler configuration. Please see Section 7.8.3.1 for more details.

Table 7-103. Parameters for Codec SDK6 API **AmpStillEnc_Init()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-104. Returns for Codec SDK6 API **AmpStillEnc_Init()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.8.3.1 AmpStillEnc_GetDefaultCfg> AMP_STILLENC_HDLR_CFG_s

Type	Field	Description
AMP_SYSTEM_FREQ_s	SysFreq	System frequency when handler state is not idle. Primary stream handler only.
UINT8*	DspWorkBufAddr	DSP working area address, only AMP_VIDEOENC_STREAM_PRIMARY check this field, 0 = no change
UINT32	DspWorkBufSize	DSP working area size, only AMP_VIDEOENC_STREAM_PRIMARY check this field, 0 = no change
AMP_CALLBACK_f	cbCfgUpdated	Setting take effect
AMP_CALLBACK_f	cbEvent	Event related to the encoder
UINT8:2	EnableMultiView	Enable MultiView or not

Type	Field	Description
UINT8:1	LiveViewProcMode	Enable Hybrid LiveView or not
UINT8:2	LiveViewAlgoMode	Algo Mode in Hybrid proc mode
UINT8:1	LiveViewOSMode	Enable express oversampling or not
UINT8:1	LiveViewHdrMode	Enable Hybrid HDR or not, A12 only
UINT8:1	Interlace	Interlaced encoding
AMP_VIDEO- ENC_LAYOUT_ CFG_s	MainLayout	Main Window layout
UINT32	MainTimeScale	Frame rate time scale
UINT32	MainTickPerPicture	Frame rate tick per picture. Frame_rate = TimeScale/TickPerPicture/(1 + interlace) 29.97i: Timescale = 60000, TickPerPic = 1001: frame_rate = 60000/1001/(1+1)=29.97 59.94p: Timescale = 60000, TickPerPic = 1001: frame_rate = 60000/1001/(1+0)=59.94
AMP_ENC_ BITSBUFFER_ CFG_s	BitsBufCfg	Buffer config
AMP_VID- EOENC_BIT- STREAM_ CFG_s	BitsCfg	Bitstream config
UINT8	LiveviewOBModeEn- able	Enable Liveview OB (Optical Black)

Table 7-105. Definition of **AMP_STILLENC_HDLR_CFG_s** for Codec SDK6 API **AmpStillEnc_GetDefaultCfg()**.

7.8.4 AmpStillEnc_Create

API Syntax:

AmpStillEnc_Create (AMP_STILLENC_HDLR_CFG_s * cfg, AMP_STLENC_HDLR_s ** sencHdlr)

Function Description:

- This function is used to create an still encoder pipeline and set the initial configuration.

Parameters:

Type	Parameter	Description
AMP_STILLENC_HDLR_CFG_s	cfg	Still encoder handler configuration
AMP_STLENC_HDLR_s	sencHdlr	Common handler structure for still encode. Please see Section 7.8.4.1 for more details.

Table 7-106. Parameters for Codec SDK6 API **AmpStillEnc_Create()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-107. Returns for Codec SDK6 API **AmpStillEnc_Create()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.8.4.1 AmpStillEnc_Create> AMP_STLENC_HDLR_s

Type	Field	Description
Void*	ctx	Pointer to CODEC context
	function	Pointer to CODEC operation functions

Table 7-108. Definition of **AMP_STLENC_HDLR_s** for Codec SDK6 API **AmpStillEnc_Create()**.

7.8.5 AmpStillEnc_Delete

API Syntax:

AmpStillEnc_Delete (AMP_STLENC_HDLR_s * hdlr)

Function Description:

- This function deletes a still encoder pipeline.

Parameters:

Type	Parameter	Description
AMP_STLENC_HDLR_s	sencHdlr	Common handler structure for still encode. Please see Section 7.8.4.1 for more details.

Table 7-109. Parameters for Codec SDK6 API **AmpStillEnc_Delete()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-110. Returns for Codec SDK6 API **AmpStillEnc_Delete()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.8.6 AmpStillEnc_ConfigVinMain

API Syntax:

```
AmpStillEnc_ConfigVinMain (UINT32 numVin, AMP_VIN_RUNTIME_CFG_s * vinCfg, AMP_STILLENC_MAIN_CFG_s * mainCfg)
```

Function Description:

- This function is the template for getting the configuration.

Parameters:

Type	Parameter	Description
UINT32	numVin	Number of VIN to be configured
AMP_VIN_RUNTIME_CFG_s	vinCfg	VIN configuration array. Please see Section 7.8.6.1 for more details.
AMP_STILLENC_MAIN_CFG_s	mainCfg	Main window configuration array. Please see Section 7.8.6.2 for more details.

Table 7-111. Parameters for Codec SDK6 API **AmpStillEnc_ConfigVinMain()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-112. Returns for Codec SDK6 API **AmpStillEnc_ConfigVinMain()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.8.6.1 AmpStillEnc_ConfigVinMain> AMP_VIN_RUNTIME_CFG_s

Type	Field	Description
AMBA_VIN_HDLR_s*	Hdlr	Point to VIN handler
AMP_AREA_s	HwCaptureWindow	HW capture window
AMBA_SENSOR_MODE_ID_u	Mode	Mode ID
UINT32	LayourNumber	How many main windows will be produced from this VIN

Type	Field	Description
AMP_VIN_LAYOUT_CFG_s*	Layout	Layout list

Table 7-113. Definition of AMP_VIN_RUNTIME_CFG_s for Codec SDK6 API **AmpStillEnc_ConfigVinMain()**.

7.8.6.2 AmpStillEnc_ConfigVinMain> AMP_STILLENC_MAIN_CFG_s

Type	Field	Description
AMBA_STLENC_HDLR_s*	Hdlr	Point to Still encode handler
AMP_SYSTEM_FREQ_s	SysFreq	System frequency when handler state is not idle. Primary stream handler only.
UINT8*	DspWorkBufAddr	DSP working area address, only AMP_VIDEOENC_STREAM_PRIMARY checks this field, 0 = no change
UINT32	DspWorkBufSize	DSP working area size, only AMP_VIDEOENC_STREAM_PRIMARY check this field, 0 = no change
UINT8:1	LiveViewProcMode	Enable Hybrid LiveView or not
UINT8:4	LiveViewAlgoMode	Algo Mode in Hybrid proc mode
UINT8:1	LiveViewOSMode	Enable Express OverSampling or not
UINT8:1	LiveViewHdrMode	Enable Hybrid HDR or not, A12 only
UINT8:1	Interlace	Interlaced encoding
AMP_VIDEOENC_LAYOUT_CFG_s	MainLayout	Main window layout
UINT32	MainTimeScale	Frame rate time scale
UINT32	MainTickPerPicture	Frame rate tick per picture. $\text{Frame_rate} = \text{TimeScale} / \text{TickPerPicture} / (1 + \text{interlace})$ 29.97i: Timescale = 6000, TickPerPic = 1001: frame_rate = 6000/1001/(1+1)=29.97 29.97p: timescale = 3000, TickPerPic = 1001: frame_rate = 3000/1001/(1+0)=29.97 59.94p: Timescale = 6000, TickPerPic = 1001: frame_rate = 6000/1001/(1+0)=59.94

Table 7-114. Definition of AMP_STILLENC_MAIN_CFG_s for Codec SDK6 API **AmpStillEnc_ConfigVinMain()**.

7.8.7 AmpStillEnc_StartRawCapture

API Syntax:

AmpStillEnc_StartRawCapture (AMP_STLENC_HDLR_s * hdlr, AMP_STILLENC_RAWCAP_DSP_CTRL_s * ctrl)

Function Description:

- This function is used to start raw capture. This API should be invoked after LiveView stops and the sensor program is completed.

Parameters:

Type	Parameter	Description
AMP_STLENC_HDLR_s	sencHdlr	Common handler structure for still encode
AMP_STILLENC_RAWCAP_DSP_CTRL_s	ctrl	DSP control information. Please see Section 7.8.7.1 for more details.

Table 7-115. Parameters for Codec SDK6 API **AmpStillEnc_StartRawCapture()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-116. Returns for Codec SDK6 API **AmpStillEnc_StartRawCapture()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.8.7.1 AmpStillEnc_StartRawCapture> AMP_STILLENC_RAWCAP_DSP_CTRL_s

Type	Field	Description
AMBA_DSP_CHANNEL_ID_u	VinChan	VIN channel
UINT8	VidSkip	Skip frame number
UINT32	RawCapNum	Raw capture number in one round

Type	Field	Description
UINT32	StillProc	Still Process mode

Table 7-117. Definition of **AMP_STILLENC_RAWCAP_DSP_CTRL_s** for Codec SDK6 API **AmpStillEnc_StartRawCapture()**.

Confidential
For HAOTEK Only

7.8.8 AmpStillEnc_StartFollowingRawCapture

API Syntax:

AmpStillEnc_StartFollowingRawCapture (AMP_STLENC_HDLR_s * hdlr, AMP_STILLENC_RAWCAP_DSP_CTRL_s * dspCtrl)

Function Description:

- This function is used to start following raw capture. This API should be invoked after the first raw capture is done.

Parameters:

Type	Parameter	Description
AMP_STLENC_HDLR_s	sencHdlr	Common handler structure for still encode
AMP_STILLENC_RAWCAP_DSP_CTRL_s	ctrl	DSP control information. Please see Section 7.8.7.1 for more details.

Table 7-118. Parameters for Codec SDK6 API **AmpStillEnc_StartFollowingRawCapture()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-119. Returns for Codec SDK6 API **AmpStillEnc_StartFollowingRawCapture()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.8.9 AmpStillEnc_UpdateVinMain

API Syntax:

AmpStillEnc_UpdateVinMain (UINT32 numVin, AMP_VIN_RUNTIME_CFG_s * vinCfg, AMP_STILLENC_MAIN_CFG_s * mainCfg)

Function Description:

- This function is used to update VIN/MAIN configuration when in IDLE state.

Parameters:

Type	Parameter	Description
UINT32	numVin	Number of VIN to be configured
AMP_VIN_RUNTIME_CFG_s	vinCfg	VIN configuration array
AMP_STILLENC_MAIN_CFG_s	mainCfg	Main window configuration array. Please see Section 7.8.6.2 for more details.

Table 7-120. Parameters for Codec SDK6 API **AmpStillEnc_UpdateVinMain()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-121. Returns for Codec SDK6 API **AmpStillEnc_UpdateVinMain()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.8.10 AmpStillEnc_EnableLiveviewCapture

API Syntax:

AmpStillEnc_EnableLiveviewCapture (UINT8 Enable, UINT8 ShowVideoPlane)

Function Description:

- This function is used to control LiveView capture between LiveView and StillCapture.

Parameters:

Type	Parameter	Description
UINT8	Enable	Enable or disable liveview capture: AMP_STILL_STOP_LIVEVIEW_0 AMP_STILL_PREPARE_TO_VIDEO_LIVEVIEW_1 AMP_STILL_PREPARE_TO_STILL_CAPTURE_2 AMP_STILL_PREPARE_TO_STILL_LIVEVIEW_3 AMP_STILL_SWITCH_TO_STILL_LIVEVIEW_4
UINT8	ShowVideoPlane	Show Video Plane

Table 7-122. Parameters for Codec SDK6 API **AmpStillEnc_EnableLiveviewCapture()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-123. Returns for Codec SDK6 API **AmpStillEnc_EnableLiveviewCapture()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9 Codec: List of APIs for VideoEnc

This section lists the video encoder APIs. The implementation of the video encode module includes initial video encode module, create video encode module, delete video encode module, config video encode module window layout, config bitrate/quality control, config Bitstream buffer, trigger TimeLapse video capture, config encode blending, and trigger VideoTuning flow functions..

- [AmpVideoEnc_GetInitDefaultCfg](#)
- [AmpVideoEnc_Init](#)
- [AmpVideoEnc_GetDefaultCfg](#)
- [AmpVideoEnc_Create](#)
- [AmpVideoEnc_Delete](#)
- [AmpVideoEnc_ConfigVinMain](#)
- [AmpVideoEnc_GetLayout](#)
- [AmpVideoEnc_SetBitstreamConfig](#)
- [AmpVideoEnc_SetBitstreamBuffer](#)
- [AmpVideoEnc_GetBitstreamConfig](#)
- [AmpVideoEnc_GetDefaultH264Header](#)
- [AmpVideoEnc_SetRuntimeBitrate](#)
- [AmpVideoEnc_SetRuntimeQuality](#)
- [AmpVideoEnc_CaptureTimeLapsedFrame](#)
- [AmpVideoEnc_SetRuntimeFrameRate](#)
- [AmpVideoEnc_SetEncodeBlend](#)
- [AmpVideoEnc_FeedEncodeRaw](#)
- [AmpVideoEnc_GetEncodingInfo](#)

Confidential
For HAOTEK Only

7.9.1 AmpVideoEnc_GetInitDefaultCfg

API Syntax:

AmpVideoEnc_GetInitDefaultCfg (AMP_VIDEOENC_INIT_CFG_s * defInitCfg)

Function Description:

- This function is used to get video encoder module default configuration for initialization.

Parameters:

Type	Parameter	Description
AMP_VIDEOENC_INIT_CFG_s	defInitCfg	Video Encode Module Configuration. Please refer to Section 7.9.1.1 for more details.

Table 7-124. Parameters for Codec SDK6 API **AmpVideoEnc_GetInitDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-125. Returns for Codec SDK6 API **AmpVideoEnc_GetInitDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.1.1 AmpVideoEnc_GetInitDefaultCfg> AMP_VIDEOENC_INIT_CFG_s

Type	Field	Description
UINT8	MaxLayerPerEncoder	Maximum number of layers per encoder layout
AMP_YUV_COLOR_s	BackgroundColor	Background color of video
AMP_TASK_INFO_s	TaskInfo	vdsp/general task information
UINT32	MsgQueueNumber	Number of entries per message queue
UINT8*	MemoryPoolAddr	Working buffer start address
UINT32	MemoryPoolSize	Size of the buffer

Table 7-126. Definition of **AMP_VIDEOENC_INIT_CFG_s** for Codec SDK6 API **AmpVideoEnc_GetInitDefaultCfg()**.

7.9.2 AmpVideoEnc_Init

API Syntax:

AmpVideoEnc_Init (AMP_VIDEOENC_INIT_CFG_s * cfg)

Function Description:

- This function is used to initialize the video encode module. This function should be invoked only once. The user must invoke this function before using the video encode module. The memory pool of the module will be provided by the user.

Parameters:

Type	Parameter	Description
AMP_VIDEOENC_INIT_CFG_s	cfg	Video Encode module configuration. Please refer to Section 7.9.1.1 for more details.

Table 7-127. Parameters for Codec SDK6 API **AmpVideoEnc_Init()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-128. Returns for Codec SDK6 API **AmpVideoEnc_Init()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.3 AmpVideoEnc_GetDefaultCfg

API Syntax:

AmpVideoEnc_GetDefaultCfg (AMP_VIDEOENC_HDLR_CFG_s * defCfg)

Function Description:

- This function is used to get the full default setting of the module.

Parameters:

Type	Parameter	Description
AMP_VIDEOENC_HDLR_CFG_s	defCfg	Configuration. Please see Section 7.9.3.1 for more details.

Table 7-129. Parameters for Codec SDK6 API **AmpVideoEnc_GetDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-130. Returns for Codec SDK6 API **AmpVideoEnc_GetDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.3.1 AmpVideoEnc_GetDefaultCfg> AMP_VIDEOENC_HDLR_CFG_s

Type	Field	Description
AMP_VIDEOENC_STREAM_ID_e	StreamId	Stream ID
UINT8	EventDataReadySkipNum	Fire “data ready” event to FIFO per (1 + evenDataReadySkipNum) frames
AMP_SYSTEM_FREQ_s	SysFreq	System frequency when handler state is not idle. Primary stream handler only
UINT8*	DspWorkBufAddr	DSP working area address, only AMP_VIDEOENC_STREAM_PRIMARY checks this field, 0 = no change
UINT32	DspWorkBufSize	DSP working area size, only AMP_VIDEOENC_STREAM_PRIMARY checks this field, 0 = no change

Type	Field	Description
AMP_CALLBACK_f	cbCfgUpdated	Setting take effect
AMP_CALLBACK_f	cbEvent	Event related to the encoder
UINT8:1	EnableLowDelayLiveview	Enable low delay mode or not. A9 only. Other chips no effect
UINT8:2	EnableMultiView	Enable MultiView or not
UINT8:1	LiveViewProcMode	Enable Hybrid LiveView or not. A12 only.
UINT8:2	LiveViewAlgoMode	Algo mode in hybrid proc mode. A12 only.
UINT8:1	LiveViewOSMode	Enable Express OverSampling or not. A12 only.
UINT8:1	LiveViewHdrMode	Enable Hybrid HDR or not, A12 only
UINT8:1	Interlace	Interlaced encoding
AMP_VIDEO-ENC_LAYOUT_CFG_s	MainLayout	Main window layout
UINT32	MainTimeScale	Frame rate time scale
UINT32	MainTickPerPicture	Frame rate tick per picture. Frame_rate = TimeScale/TickPerPicture/(1+interlace) 29.97i: Timescale = 6000, TickPerPic = 1001: frame_rate = 6000/1001/(1+1)=29.97 59.94p: Timescale = 6000, TickPerPic = 1001: frame_rate = 6000/1001/(1+0)=59.94
AMP_ENC_BITSBUFFER_CFG_s	BitsBufCfg	Buffer configuration
AMP_VID-EOENC_BIT-STREAM_CFG_s	BitsCfg	Bitstream configuration
AMP_VIN_SOURCE_e	VinSource	Vin source
UINT8	LiveviewOBModeEnable	Enable Liveview OB (Optical Black)

Table 7-131. Definition of **AMP_VIDEOENC_HDLR_CFG_s** for Codec SDK6 API **AmpVideoEnc_GetDefaultCfg()**.

7.9.4 AmpVideoEnc_Create

API Syntax:

AmpVideoEnc_Create (AMP_VIDEOENC_HDLR_CFG_s * cfg, AMP_AVENC_HDLR_s ** vencHdlr)

Function Description:

- This function is used to set the initial configuration for the video encode module.

Parameters:

Type	Parameter	Description
AMP_VIDEOENC_HDLR_CFG_s	Cfg	Configuration. Please see Section 7.9.3.1 for more details.
AMP_AVENC_HDLR_s	vencHdlr	Encoder Instance pointer. Please see Section 7.9.4.1 for more details.

Table 7-132. Parameters for Codec SDK6 API **AmpVideoEnc_Create()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-133. Returns for Codec SDK6 API **AmpVideoEnc_Create()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.4.1 AmpVideoEnc_Create> AMP_AVENC_HDLR_s

Type	Field	Description
Void*	ctx	Pointer to CODEC context
AMP_AVENC_CODEC_s*	function	Pointer to CODEC operation functions

Table 7-134. Definition of **AMP_AVENC_HDLR_s** for Codec SDK6 API **AmpVideoEnc_Create()**.

7.9.5 AmpVideoEnc_Delete

API Syntax:

AmpVideoEnc_Delete (AMP_AVENC_HDLR_s * hdlr)

Function Description:

- This function is used to delete instance.

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Encoder instance. Please see Section 7.9.4.1 for more details.

Table 7-135. Parameters for Codec SDK6 API **AmpVideoEnc_Delete()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-136. Returns for Codec SDK6 API **AmpVideoEnc_Delete()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.6 AmpVideoEnc_ConfigVinMain

API Syntax:

AmpVideoEnc_ConfigVinMain (UINT32 numVin, AMP_VIN_RUNTIME_CFG_s * vinCfg, UINT32 numMain, AMP_VIDEOENC_MAIN_CFG_s * mainCfg)

Function Description:

- This function is used to configure VIN/MAIN after the handler is created.

Parameters:

Type	Parameter	Description
UINT32	numVin	Number of VINs to be configured
AMP_VIN_RUNTIME_CFG_s	vinCfg	VIN configuration array
UINT32	numMain	Number of main windows to be configured
AMP_VIDEOENC_MAIN_CFG_s	mainCfg	Main window configuration array. Please refer to Section 7.9.6.1 for more details.

Table 7-137. Parameters for Codec SDK6 API **AmpVideoEnc_ConfigVinMain()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-138. Returns for Codec SDK6 API **AmpVideoEnc_ConfigVinMain()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.6.1 AmpVideoEnc_ConfigVinMain> AMP_VIDEOENC_MAIN_CFG_s

Type	Field	Description
AMP_AVENC_HDLR_s*	Hdlr	Point to which VideoEncode handler
UINT16	EventDataReadySkipNum	Fire “data ready” event to FIFO per (1 + evenDataReadySkipNum) frames
AMP_SYSTEM_FREQ_s	SysFreq	System frequency when handler state is not idle. Primary stream handler only.

Type	Field	Description
UINT8*	DspWorkBufAddr	DSP working area address, only AMP_VIDEOENC_STREAM_PRIMARY checks this field, 0 = no change
UINT32	DspWorkBufSize	DSP working area size, only AMP_VIDEOENC_STREAM_PRIMARY check this field, 0 = no change
UINT8:1	LiveViewProcMode	Enable Hybrid LiveView or not, A12 only
UINT8:4	LiveViewAlgoMode	Algo Mode in Hybrid proc mode, A12 only
UINT8:1	LiveViewOSMode	Enable Express OverSampling or not, A12 only
UINT8:1	LiveViewHdrMode	Enable Hybrid HDR or not, A12 only
UINT8:1	Interlace	Interlaced encoding
AMP_VIDEOENC_LAYOUT_CFG_s	MainLayout	Main window layout
UINT32	MainTimeScale	Frame rate time scale
UINT32	MainTickPerPicture	Frame rate tick per picture. $\text{Frame_rate} = \text{TimeScale} / \text{TickPerPicture} / (1 + \text{interlace})$ 29.97i: Timescale = 6000, TickPerPic = 1001: frame_rate = 6000/1001/(1+1)=29.97 59.94p: Timescale = 6000, TickPerPic = 1001: frame_rate = 6000/1001/(1+0)=59.94

Table 7-139. Definition of **AMP_VIDEOENC_MAIN_CFG_s** for Codec SDK6 API **AmpVideoEnc_Create()**.

7.9.7 AmpVideoEnc_GetLayout

API Syntax:

AmpVideoEnc_GetLayout (AMP_AVENC_HDLR_s * hdlr, AMP_VIDEOENC_LAYOUT_CFG_s * layout)

Function Description:

- This function is used to get the current layout.

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Encoder instance. Please see Section 7.9.4.1 for more details.
AMP_VIDEOENC_LAYOUT_CFG_s	layout	Current layout..Please refer to Section 7.9.7.1 for more details.

Table 7-140. Parameters for Codec SDK6 API **AmpVideoEnc_GetLayout()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-141. Returns for Codec SDK6 API **AmpVideoEnc_GetLayout()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 21 for more details on error codes.

7.9.7.1 AmpVideoEnc_GetLayout> AMP_VIDEOENC_LAYOUT_CFG_s

Type	Field	Description
UINT16	Width	Main Output Width
UINT16	height	Main output height
UINT32	LayerNumber	Number of layouts
AMP_VIDEOENC_LAYER_DESC_s*	Layer	Layout descriptor

Table 7-142. Definition of **AMP_VIDEOENC_LAYOUT_CFG_s** for Codec SDK6 API **AmpVideoEnc_GetLayout()**

7.9.7.2 AmpVideoEnc_GetLayout> AMP_VIDEOENC_LAYER_DESC_s

Type	Field	Description
UINT8	LayerId	Layer ID
UINT8	EnableSourceArea	SourceArea is valid or not. If not, use full source resolution.
UNIT8	EnableTargetArea	targetArea is valid or not
AMP_ENC_SOURCE_TYPE_e	SourceType	From VIN or memory
Void*	Source	From which VIN
UINT32	SourceLayoutId	From Nth layout of the source
AMP_AREA_s	SourceArea	Area cropped from the source plane
AMP_AREA_s	TargetArea	Area within output plane (vinWidth and vinHeight)
AMP_AREA_s	MultiChanEncSrcArea	Area within encode input plane
AMP_AREA_s	MultiChanEncDestArea	Area within Encode output plane
AMP_2D_BUFFER_s	MultiChanEncBlendTable	Blending Table buffer
AMP_ROTATION_e	SourceRotate	Rotate after crop
AMBA_DSP_BUF_s	MemorySource	Memory starting buffer when VIN comes from memory
UINT16	MemoryBufferNumber	Memory buffer total number when VIN comes from memory
UINT8	MemoryRawBayerPattern	Raw file bayer pattern when VIN comes from memory
UINT8	MemoryRawDataBits	Raw file bits resolution when VIN comes from memory

Table 7-143. Definition of AMP_VIDEOENC_LAYER_DESC_s for Codec SDK6 API AmpVideoEnc_GetLayout()

7.9.8 AmpVideoEnc_SetBitstreamConfig

API Syntax:

```
AmpVideoEnc_SetBitstreamConfig (AMP_AVENC_HDLR_s * hdlr, AMP_VIDEOENC_BITSTREAM_CFG_s *cfg )
```

Function Description:

- This function is used to configure bitstream before encoding.

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Encoder instance.. Please see Section 7.9.4.1 for more details.
AMP_VIDEOENC_BITSTREAM_CFG_s	cfg	Configuration. Please see Section 7.9.8.1 for more details.

Table 7-144. Parameters for Codec SDK6 API **AmpVideoEnc_SetBitstreamConfig()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-145. Returns for Codec SDK6 API **AmpVideoEnc_SetBitstreamConfig()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.8.1 AmpVideoEnc_SetBitstreamConfig> AMP_VIDEOENC_BITSTREAM_CFG_s

Type	Field	Description
AMP_VIDEOENC_STREAM_SPEC_e	StreamSpec	Stream spec
UINT8	TimeLapse	Time lapse encoding, only pri_stream can trigger
UINT8	VideoThumbnail	Video thumbnail
AMP_ROTATION_e	Rotate	Encode rotation
UNION	Spec	Encode specification

Table 7-146. Definition of **AMP_VIDEOENC_BITSTREAM_CFG_s** for Codec SDK6 API **AmpVideoEnc_SetBitstreamConfig()**

7.9.9 AmpVideoEnc_SetBitstreamBuffer

API Syntax:

```
AmpVideoEnc_SetBitstreamConfig (AMP_AVENC_HDLR_s * hdlr, AMP_ENC_BITSBUF_CFG_s *  
cfg )
```

Function Description:

- This function is used to configure bitstream before encoding.

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Encoder instance. Please see Section 7.9.4.1 for more details.
AMP_ENC_BITSBUF_CFG_s	cfg	Buffer configuration. Please see Section 7.9.9.1 for more details.

Table 7-147. Parameters for Codec SDK6 API **AmpVideoEnc_SetBitstreamBuffer()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-148. Returns for Codec SDK6 API **AmpVideoEnc_SetBitstreamBuffer()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.9.1 AmpVideoEnc_SetBitstreamBuffer> AMP_ENC_BITSBUF_CFG_s

Type	Field	Description
UINT8*	BitsBufAddr	Bitstream buffer address
UINT32	BitsBufSize	Bitstream buffer size. Must be multiple of 16384
UINT8*	DescBufAddr	Descriptor buffer address
UINT32	DescBufSize	Descriptor buffer size
UINT32	BitsRunoutThreshold	Indicates Bitstream's capacity is almost full, Byte Unit

Table 7-149. Definition of **AMP_ENC_BITSBUF_CFG_s** for Codec SDK6 API **AmpVideoEnc_SetBitstreamBuffer()**

7.9.10 AmpVideoEnc_GetBitstreamConfig

API Syntax:

AmpVideoEnc_GetBitstreamConfig (AMP_AVENC_HDLR_s * hdlr, AMP_VIDEOENC_BITSTREAM_CFG_s * cfg)

Function Description:

- This function is used to get the current bitstream configuration.

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Encoder instance. Please see Section 7.9.4.1 for more details.
AMP_VIDEOENC_BITSTREAM_CFG_s	cfg	Configuration

Table 7-150. Parameters for Codec SDK6 API **AmpVideoEnc_GetBitstreamConfig()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-151. Returns for Codec SDK6 API **AmpVideoEnc_GetBitstreamConfig()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.11 AmpVideoEnc_GetDefaultH264Header

API Syntax:

```
AmpVideoEnc_GetDefaultCfg ( AMP_VIDEOENC_H264_HEADER_INFO_s * info, AMP_VIDEOENC_H264_SPS_s * sps, AMP_VIDEOENC_H264_VUI_s * vui)
```

Function Description:

- This function is used to get the default H.264 headers based on the current configuration.

Parameters:

Type	Parameter	Description
AMP_VIDEOENC_H264_HEADER_INFO_s	info	Information for the header generation. Please refer to Section 7.9.11.1 for more details.
AMP_VIDEOENC_H264_SPS_s	sps	Default SPS header. Please refer to Section 7.9.11.2 for more details.
AMP_VIDEOENC_H264_VUI_s	vui	Default VUI header

Table 7-152. Parameters for Codec SDK6 API AmpVideoEnc_GetDefaultH264Header().

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-153. Returns for Codec SDK6 API AmpVideoEnc_GetDefaultH264Header().

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.11.1 AmpVideoEnc_GetDefaultH264Header> AMP_VIDEOENC_H264_HEADER_INFO_s

Type	Field	Description
UINT16	Width	Clip width
UINT16	Height	Clip Height

Type	Field	Description
UINT8	Interlace	Interlace
UINT8	GopM	Gop M number
AMP_ROTATION_e	Rotation	Rotation

Table 7-154. Definition of **AMP_VIDEOENC_H264_HEADER_INFO_s** for Codec SDK6 API **AmpVideoEnc_GetDefaultH264Header()**

7.9.11.2 AmpVideoEnc_GetDefaultH264Header> AMP_VIDEOENC_H264_SPS_s

Type	Field	Description
UINT8	profile_idc	Please refer to ITU-T H.264
UINT8	level_idc	Please refer to ITU-T H.264
UINT8	frame_cropping_flag	Please refer to ITU-T H.264
UINT8	num_ref_frame	Please refer to ITU-T H.264
UINT16	frame_crop_left_offset	Please refer to ITU-T H.264
UINT16	frame_crop_right_offset	Please refer to ITU-T H.264
UINT16	frame_crop_top_offset	Please refer to ITU-T H.264
UINT16	frame_crop_bottom_offset	Please refer to ITU-T H.264
UINT8	log2_max_frame_num_minus4	Please refer to ITU-T H.264
UINT8	log2_max_pic_order_cnt_lsb_minus4	Please refer to ITU-T H.264

Table 7-155. Definition of **AMP_VIDEOENC_H264_SPS_s** for Codec SDK6 API **AmpVideoEnc_GetDefaultH264Header()**

7.9.12 AmpVideoEnc_SetRuntimeBitrate

API Syntax:

AmpVideoEnc_SetRuntimeBitrate (AMP_AVENC_HDLR_s * hdlr, AMP_VIDEOENC_RUNTIME_BITRATE_CFG_s * cfg)

Function Description:

- This function is used in runtime to control bitrate during the video recording state.

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Encoder instance. Please see Section 7.9.4.1 for more details.
AMP_VIDEOENC_RUNTIME_BITRATE_CFG_s	cfg	Runtime control configuration. Please see Section 7.9.12.1 for more details.

Table 7-156. Parameters for Codec SDK6 API **AmpVideoEnc_SetRuntimeBitrate()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-157. Returns for Codec SDK6 API **AmpVideoEnc_SetRuntimeBitrate()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.12.1 AmpVideoEnc_SetRuntimeBitrate> AMP_VIDEOENC_RUNTIME_BITRATE_CFG_s

Type	Field	Description
UINT32	AverageBitrate	Average bitrate in Byte unit

Table 7-158. Definition of **AMP_VIDEOENC_RUNTIME_BITRATE_CFG_s** for Codec SDK6 API **AmpVideoEnc_SetRuntimeBitrate()**

7.9.13 AmpVideoEnc_SetRuntimeQuality

API Syntax:

AmpVideoEnc_SetRuntimeQuality (AMP_AVENC_HDLR_s * hdlr, AMP_VIDEOENC_RUNTIME_QUALITY_CFG_s * cfg)

Function Description:

- This function is used in runtime to control quality during the video recording state.

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Encoder instance. Please see Section 7.9.4.1 for more details.
AMP_VIDEOENC_RUNTIME_QUALITY_CFG_s	cfg	Runtime control configuration. Please refer to Section 7.9.13.1 for more details.

Table 7-159. Parameters for Codec SDK6 API **AmpVideoEnc_SetRuntimeQuality()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-160. Returns for Codec SDK6 API **AmpVideoEnc_SetRuntimeQuality()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.13.1 AmpVideoEnc_SetRuntimeQuality> AMP_VIDEOENC_RUNTIME_QUALITY_CFG_s

Type	Field	Description
UINT32	Cmd	Quality control command #define RC_BITRATE (1<<0) #define RC_GOP (1<<1) #define RC_QP (1<<2) #define RC_QMODEL (1<<3) #define RC_ROI (1<<4) #define RC_HQP (1<<5) #define RC_ZMV (1<<6) #define RC_FORCE_IDR (1<<7)
UINT32	BitRate	Desired bit rate
UINT8	Enable	Enable or not
UINT8	M	Gop structure M
UINT8	N	Gop structure N
UINT8	IDR	Gop structure IDR
UINT8	QpMinI	QP min value on I frame
UINT8	QpMaxI	QP max value on I frame
UINT8	QpMinP	QP min value on P frame
UINT8	QpMaxP	QP max value on P frame
UINT8	QpMinB	QP min value on B frame
UINT8	QpMaxB	QP max value on B frame
UINT8	HQpMax	High quality P frame max QP value
UINT8	HQpMin	High quality P frame min QP value
UINT8	HQpReduce	High quality P frame reduce number
UINT8	HPNumber	High quality P frame number
UINT8	IorIDRFrameNeedsRateControlMask	Please refer to AQP control
UINT8	QPReduceNearIDRFrame	Please refer to AQP control
UINT8	ClassNumberLimitOfQPReduceNearIDRFrame	Please refer to AQP control
UINT8	QPReduceNearIFrame	Please refer to AQP control
UINT8	ClassNumberLimitOfQPReduceNearIFrame	Please refer to AQP control
INT8	Intra16x16Bias	-64 ~ 64
INT8	Intra4x4Bias	-64 ~ 64
INT8	Inter16x16Bias	-64 ~ 64
INT8	Inter8x8Bias	-64 ~ 64
INT8	Direct16x16Bias	-64 ~ 64
INT8	Direct8x8Bias	-64 ~ 64
INT8	MELambdaQpOffset	-64 ~ 64
INT8	AQPStrength	0 - auto, 1-81: fixed strength, 1 for no AQP, -1 for inverse AQP
INT8	LoopFilterAlpha	-6 ~ 6
INT8	LoopFilterBeta	-6 ~ 6
INT8	Alpha	Please refer to AQP control
INT8	Beta	Please refer to AQP control

Type	Field	Description
UINT32*	RoiBufferAddr	Region of interest buffer address
INT8	RoiDelta[3][4]	Region of interest definition array
UINT32	ZmvThres	Zero motion vector threshold

Table 7-161. Definition of **AMP_VIDEOENC_RUNTIME_QUALITY_CFG_s** for Codec SDK6 API **AmpVideoEnc_SetRuntimeQuality()**

Confidential
For HAOTEK Only

7.9.14 AmpVideoEnc_CaptureTimeLapsedFrame

API Syntax:

AmpVideoEnc_CaptureTimeLapsedFrame (AMP_VIN_HDLR_s * hdlr)

Function Description:

- This function is used to capture and encode one frame when there is time-lapsed recoding.

Parameters:

Type	Parameter	Description
AMP_VIN_HDLR_s	hdlr	Vin instance. Please see Section 8.2.4.1 for more details.

Table 7-162. Parameters for Codec SDK6 API **AmpVideoEnc_CaptureTimeLapsedFrame()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-163. Returns for Codec SDK6 API **AmpVideoEnc_CaptureTimeLapsedFrame()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.15 AmpVideoEnc_SetRuntimeFrameRate

API Syntax:

AmpVideoEnc_SetRuntimeFrameRate (UINT32 numHdlr, AMP_VIDEOENC_RUNTIME_FRAMERATE_CFG_s * cfg)

Function Description:

- This function is used to change framerate in runtime.

Parameters:

Type	Parameter	Description
UINT32	numHdlr	Number of handlers to change
AMP_VIDEOENC_RUNTIME_FRAMERATE_CFG_s	cfg	Handler and configuration array. Please refer to Section 7.9.15.1 for more details.

Table 7-164. Parameters for Codec SDK6 API **AmpVideoEnc_SetRuntimeFrameRate()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-165. Returns for Codec SDK6 API **AmpVideoEnc_SetRuntimeFrameRate()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.15.1 AmpVideoEnc_SetRuntimeFrameRate> AMP_VIDEOENC_RUNTIME_FRAMERATE_CFG_s

Type	Field	Description
AMP_AVENC_HDLR_s*	Hdlr	Point to which video encode handler
UINT32	Divisor	Frame rate divisor

Table 7-166. Definition of **AMP_VIDEOENC_RUNTIME_FRAMERATE_CFG_s** for Codec SDK6 API **AmpVideoEnc_SetRuntimeFrameRate()**

7.9.16 AmpVideoEnc_SetEncodeBlend

API Syntax:

AmpVideoEnc_SetEncodeBlend (AMP_AVENC_HDLR_s * hdlr, AMP_VIDEOENC_BLEND_INFO_s * info)

Function Description:

- This function is used to set the encode blend information.

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Encoder instance. Please see Section 7.9.4.1 for more details.
AMP_VIDEOENC_BLEND_INFO_s	info	Blend information. Please refer to Section 7.9.16.1 for more details.

Table 7-167. Parameters for Codec SDK6 API **AmpVideoEnc_SetEncodeBlend()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-168. Returns for Codec SDK6 API **AmpVideoEnc_SetEncodeBlend()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.16.1 AmpVideoEnc_SetEncodeBlend> AMP_VIDEOENC_BLEND_INFO_s

Type	Field	Description
UINT8	BufferID	Blend buffer ID, 0~ 31 (at most 32 blending areas)
UINT8	Enable	0: Disable, 1: Enable
UINT16	OffsetX	Horizontal offset with respect to main picture
UINT16	OffsetY	Vertical offset with respect to main picture
UINT16	Pitch	Blend buffer pitch
UINT16	Width	Blend buffer width
UINT16	Height	Blend buffer height
UINT8*	YAddr	Blend buffer luma address

Type	Field	Description
UINT8*	UVAddr	Blend buffer chroma address
UINT8*	AlphaYAddr	Alpha plane luma address
UINT8*	AlphaUVAddr	Alpha plane chroma address

Table 7-169. Definition of **AMP_VIDEOENC_BLEND_INFO_s** for Codec SDK6 API **AmpVideoEnc_SetEncodeBlend()**

Confidential
For HAOTEK Only

7.9.17 AmpVideoEnc_FeedEncodeRaw

API Syntax:

AmpVideoEnc_FeedEncodeRaw (AMP_ENC_RAW_INFO_s * raw, UINT8 lastFrame)

Function Description:

- This function is used to feed RAW/YUV for video RawEncode.

Parameters:

Type	Parameter	Description
AMP_ENC_RAW_INFO_s	raw	Raw buffer information. Please refer to Section 7.9.17.1 for more details.
UINT8	lastFrame	Indicates the last encode frame

Table 7-170. Parameters for Codec SDK6 API **AmpVideoEnc_FeedEncodeRaw()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-171. Returns for Codec SDK6 API **AmpVideoEnc_FeedEncodeRaw()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.17.1 AmpVideoEnc_FeedEncodeRaw> AMP_ENC_RAW_INFO_s

Type	Field	Description
UINT8	compressed	CFA Raw buffer format
UINT8*	RawAddr	CFA Raw buffer address
UINT16	RawPitch	CFA Raw buffer pitch
UINT16	RawWidth	CFA Raw buffer width
UINT16	RawHeight	CFA Raw buffer height
UINT16	OBWidth	CFA Raw buffer OB region width
UINT16	OBHeight	CFA Raw buffer OB region height
UINT16	OBOffsetX	CFA Raw buffer OB region offset in x-axis
UINT16	OBOffsetY	CFA Raw buffer OB region offset in y-axis

Table 7-172. Definition of **AMP_ENC_RAW_INFO_s** for Codec SDK6 API **AmpVideoEnc_FeedEncodeRaw()**

7.9.18 AmpVideoEnc_GetEncodingInfo

API Syntax:

```
AmpVideoEnc_GetEncodingInfo (AMP_AVENC_HDLR_s * hdlr, AMP_VIDEOENC_ENCODING_INFO_s * info)
```

Function Description:

- This function is used to get the encoding session information.

Parameters:

Type	Parameter	Description
AMP_AVENC_HDLR_s	hdlr	Encoder instance. Please see Section 7.9.4.1 for more details.
AMP_VIDEOENC_ENCODING_INFO_s	info	Encoding information. Please see Section 7.9.18.1 for more details.

Table 7-173. Parameters for Codec SDK6 API **AmpVideoEnc_GetEncodingInfo()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 7-174. Returns for Codec SDK6 API **AmpVideoEnc_GetEncodingInfo()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

7.9.18.1 AmpVideoEnc_GetEncodingInfo> AMP_VIDEOENC_ENCODING_INFO_s

Type	Field	Description
UINT32	TotalFrames	Total encoded frames until now
UINT32	AverageBitrate	Average bitrate until now, unit: kbps
UINT64	TotalBytes	Total encoded bytes until now, unit: Bytes

Table 7-175. Definition of **AMP_VIDEOENC_ENCODING_INFO_s** for Codec SDK6 API **AmpVideoEnc_GetEncodingInfo()**

8 VIN

8.1 VIN: Overview

This chapter provides information on the VIN manager implementation. When the user implements the VIN manager/handler, the user is able to initialize the VIN manager function, create the VIN manager function, delete the VIN manager function, and configure the VIN manager after the VIN manager has been created. For details on these functions, please refer to the sections below.

8.2 VIN: List of APIs

This section lists the VIN API functions.

- [AmpVin_GetInitDefaultCfg](#)
- [AmpVin_Init](#)
- [AmpVin_GetDefaultCfg](#)
- [AmpVin_Create](#)
- [AmpVin_Delete](#)
- [AmpVin_ConfigHandler](#)

Confidential
For HAOTEK Only

8.2.1 AmpVin_GetInitDefaultCfg

API Syntax:

AmpVin_GetInitDefaultCfg (AMP_VIN_INIT_CFG_s * defaultCfg)

Function Description:

- This function gets the default VIN configuration values to start initialization.

Parameters:

Type	Parameter	Description
AMP_VIN_INIT_CFG_s	defaultCfg	Default values for VIN initialization. (AMP_VIN_INIT_CFG_s is defined in <code>vin.h</code>) Please refer to Section 8.2.1.1 below for more details.

Table 8-1. Parameters for VIN SDK6 API **AmpVin_GetInitDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 8-2. Returns for VIN SDK6 API **AmpVin_GetInitDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

8.2.1.1 AmpVin_GetInitDefaultCfg > AMP_VIN_INIT_CFG_s

Type	Field	Description
UINT32	NumMaxVin	Maximum VIN number
UINT8 *	MemoryPoolAddr	Start Address of the buffer for the VIN module
UINT32	MemoryPoolSize	Size of the buffer

Table 8-3. Definition of **AMP_VIN_INIT_CFG_s** for VIN SDK6 API **AmpVin_GetInitDefaultCfg()**.

8.2.2 AmpVin_Init

API Syntax:

AmpVin_Init (AMP_VIN_INIT_CFG_s * cfg)

Function Description:

- This function initializes the VIN module. The function should only be invoked once. The user MUST invoke this function before using the VIN module. The memory pool of the module will be provided by the user.

Parameters:

Type	Parameter	Description
AMP_VIN_INIT_CFG_s	Cfg	Default values for VIN instance configuration (AMP_VIN_INIT_CFG_s is defined in <code>vin.h</code>). Please refer to Section 8.2.1.1 for more details.

Table 8-4. Parameters for VIN SDK6 API **AmpVin_Init()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 8-5. Returns for VIN SDK6 API **AmpVin_Init()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

8.2.3 AmpVin_GetDefaultCfg

API Syntax:

AmpVin_GetDefaultCfg (AMP_VIN_HDLR_CFG_s * cfg)

Function Description:

- This function gets the default VIN instance configuration.

Parameters:

Type	Parameter	Description
AMP_VIN_HDLR_CFG_s	Cfg	Default Values for individual VIN instance configuration. (AMP_VIN_HDLR_CFG_s is defined in <code>vin.h</code>) Please refer to Section 8.2.3.1 below for more details.

Table 8-6. Parameters for VIN SDK6 API **AmpVin_GetDefaultCfg()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 8-7. Returns for VIN SDK6 API **AmpVin_GetDefaultCfg()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

8.2.3.1 AmpVin_GetDefaultCfg > AMP_VIN_HDLR_CFG_s

Type	Field	Description
AMBA_DSP_CHANNEL_ID_u	Channel	Hardware device description
AMBA_SENSOR_MODE_ID_u	Mode	Mode ID
AMBA_YUV_MODE_ID_u	YuvMode	YUV mode ID
UINT16	LayoutNumber	Number of main windows that are produced from this VIN
AMP_VIN_LAYOUT_CFG_s *	Layout	Main window
AMP_AREA_s	HwCaptureWindow	Hardware capture window
AMP_CALLBACK_f	cbSwitch	Mode switch callback
AMP_CALLBACK_f	cbEvent	General event callback
AMP_CALLBACK_f	cbCfgUpdated	TBD
AMP_TASK_INFO_s	TaskInfo	Task information
AMP_VIN_SOURCE_e	VinSource	VIN Source

Table 8-8. Definition of **AMP_VIN_HDLR_CFG_s** for VIN SDK6 API **AmpVin_GetDefaultCfg()**.

8.2.4 AmpVin_Create

API Syntax:

AmpVin_Create (AMP_VIN_HDLR_CFG_s * cfg, AMP_VIN_HDLR_s ** vinHdlr)

Function Description:

- This function creates and sets the initial configuration of a VIN handler.

Parameters:

Type	Parameter	Description
AMP_VIN_HDLR_CFG_s	Cfg	Default values for individual VIN instance configuration (AMP_VIN_HDLR_CFG_s is defined in <code>vin.h</code>). Please refer to Section 8.2.3.1 for more details.
AMP_VIN_HDLR_s	vinHdlr	Initializes the VIN Instance (AMP_VIN_HDLR_s is defined in <code>vin.h</code>). Please refer to Section 8.2.4.1 below for more details.

Table 8-9. Parameters for VIN SDK6 API **AmpVin_Create()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 8-10. Returns for VIN SDK6 API **AmpVin_Create()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

8.2.4.1 AmpVin_Create > AMP_VIN_HDLR_s

Type	Field	Description
void*	Ctx	Private context of the VIN

Table 8-11. Definition of **AMP_VIN_HDLR_s** for VIN SDK6 API **AmpVin_Create()**.

8.2.5 AmpVin_Delete

API Syntax:

AmpVin_Delete (AMP_VIN_HDLR_s * vinHdlr)

Function Description:

- This function deletes the VIN handler.

Parameters:

Type	Parameter	Description
AMP_VIN_HDLR_s	vinHdlr	Deletes the VIN handler instance (AMP_VIN_HDLR_s is defined in <code>vin.h</code>). Please refer to Section 8.2.4.1 for more details.

Table 8-12. Parameters for VIN SDK6 API **AmpVin_Delete()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 8-13. Returns for VIN SDK6 API **AmpVin_Delete()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

8.2.6 AmpVin_ConfigHandler

API Syntax:

AmpVin_ConfigHandler (AMP_VIN_HDLR_s * vinHdlr, AMP_VIN_CFG_s * vinCfg)

Function Description:

- This function changes the VIN settings of a VIN handler when liveview is not running.

Parameters:

Type	Parameter	Description
AMP_VIN_HDLR_s	vinHdlr	Default values for VIN handler instance (AMP_VIN_HDLR_s is defined in <code>vin.h</code>) Please refer to Section 8.2.4.1 for more details.
AMP_VIN_CFG_s	vinCfg	Offline VIN configurations for a given handler (when liveview is not running) (AMP_VIN_CFG_s is defined in <code>vin.h</code>) Please refer to Section 8.2.6.1 below for more details.

Table 8-14. Parameters for VIN SDK6 API **AmpVin_ConfigHandler()**.

Returns:

Return	Description
AMP_OK	Execution Successful
All Others	AMP_ER_CODE_e. Please refer to Chapter 10 for more details on error codes.

Table 8-15. Returns for VIN SDK6 API **AmpVin_ConfigHandler()**.

Example:

Please refer to the Unit Test document.

See Also:

Please refer to Chapter 10 for more details on error codes.

8.2.6.1 AmpVin_ConfigHandler > AMP_VIN_CFG_s

Type	Field	Description
AMBA_DSP_CHANNEL_ID_u	Channel	Hardware device description
AMBA_SENSOR_MODE_ID_u	Mode	Mode ID
AMBA_YUV_MODE_ID_u	YuvMode	YUV mode ID
UINT16	LayoutNumber	The number of main windows produced from this VIN.
AMP_VIN_LAYOUT_CFG_s *	Layout	Main window
AMP_AREA_s	HwCaptureWindow	Hardware capture window
AMP_CALLBACK_f	cbSwitch	Mode Switch callback
AMP_CALLBACK_f	cbEvent	General Event Callback
AMP_CALLBACK_f	cbCfgUpdated	TBD
AMP_VIN_SOURCE_e	VinSource	Vin Source

Table 8-16. Definition of **AMP_VIN_CFG_s** for VIN SDK6 API **AmpVin_ConfigHandler()**.

8.2.6.1.1 AmpVin_ConfigHandler > AMP_VIN_CFG_s > AMP_VIN_LAYOUT_CFG_s

Type	Field	Description
UINT8:1	EnableSourceArea	SourceArea is valid or not
UINT8:1	EnableOBArea	OBArea is valid or not
UINT8:6	AreaEnReserved	
AMP_ROTATION_e	Rotation	Rotate after crop
AMP_AREA_s	SourceArea	Area cropped from the source plane
AMP_AREA_s	ActiveArea	Area of Active cropped from the Vcap plane
AMP_AREA_s	OBArea	Area of OB cropped from the Vcap plane
UINT16	Width	IDSP output width (main window) equal to codec's source plane
UINT16	Height	IDSP output height (main window) equal to codec's source plane
int	(*cfaOutputCallback)(AMBA_DSP_IMG_WARP_CALC_CFA_INFO_s*pCfaInfo)	Customer's CFA output calculation callback
UINT32	DzoomFactorX	Initial horizontal digital zoom factor, 16.16 format
UINT32	DzoomFactorY	Initial vertical digital zoom factor, 16.16 format
INT32	DzoomOffsetX	Initial horizontal digital zoom offset, 16.16 format
INT32	DzoomOffsetY	Initial vertical digital zoom offset, 16.16
UINT8	MainviewReportRate	Mainview status report rate

Table 8-17. Definition of **AMP_VIN_LAYOUT_CFG_s** for VIN SDK6 API **AmpVin_ConfigHandler()**.

8.2.6.1.2 AmpVin_ConfigHandler > AMP_VIN_CFG_s > AMP_VIN_SOURCE_e

Type	Field	Description
Enum	AMP_VIN_EXTERNAL_CFA	VIN signal comes from an external CFA output, i.e. sensor
	AMP_VIN_EXTERNAL_YUV	VIN signal comes from external YUV output, i.e. DVR
	AMP_VIN_MEMORY_CFA	VIN signal comes from memory CFA
	AMP_VIN_MEMORY_YUV	VIN signal comes from memory YUV

Table 8-18. Definition of **AMP_VIN_SOURCE_e** for VIN SDK6 API **AmpVin_ConfigHandler()**.

Confidential
For HAOTEK Only

9 System Errors

9.1 System Errors: Overview

This chapter lists the possible return values (**AMP**) when errors are encountered.

9.2 System Errors: Error Code List

- AMP_ERROR_GENERAL_ERROR
- AMP_ERROR_INCORRECT_PARAM_STRUCTURE
- AMP_ERROR_INCORRECT_PARAM_VALUE_RANGE
- AMP_ERROR_OUT_OF_MEMORY
- AMP_ERROR_RESOURCE_INVALID
- AMP_ERROR_FIFO_TYPE_MISMATCH
- AMP_ERROR_FIFO_LOCKED
- AMP_ERROR_FIFO_EMPTY
- AMP_ERROR_FIFO_FULL
- AMP_ERROR_ILLEGAL_OPERATION
- AMP_ERROR_ILLEGAL_CONTAIN_SOURCE
- AMP_ERROR_IO_ERROR
- AMP_ERROR_OUT_OF_STORAGE
- AMP_ERROR_OPERATION_ABORTED
- AMP_ERROR_OBJ_ALREADY_EXISTS
- AMP_ERROR_OBJ_UNAVAILABLE
- AMP_ERROR_OBJ_CREATION_FAILED

9.2.1 AMP_ERROR_GENERAL_ERROR

Error Value:

AMP_ERROE_GENERAL_ERROR

Error Description:

- General error.

9.2.2 AMP_ERROR_INCORRECT_PARAM_STRUCTURE

Error Value:

AMP_ERROR_INCORRECT_PARAM_STRUCTURE

Error Description:

- Incorrect structure used.

9.2.3 AMP_ERROR_INCORRECT_PARAM_VALUE_RANGE

Error Value:

AMP_ERROR_INCORRECT_PARAM_VALUE_RANGE

Error Description:

- Incorrect value range.

9.2.4 AMP_ERROR_OUT_OF_MEMORY

Error Value:

AMP_ERROR_OUT_OF_MEMORY

Error Description:

- Out of memory.

9.2.5 AMP_ERROR_RESOURCE_INVALID

Error Value:

AMP_ERROR_RESOURCE_INVALID

Error Description:

- Resource for the operation.

9.2.6 AMP_ERROR_FIFO_TYPE_MISMATCH

Error Value:

AMP_ERROR_FIFO_TYPE_MISMATCH

Error Description:

- Incorrect FIFO type.

9.2.7 AMP_ERROR_FIFO_LOCKED

Error Value:

AMP_ERROR_FIFO_LOCKED

Error Description:

- Try to read/write a locked FIFO.

9.2.8 AMP_ERROR_FIFO_EMPTY

Error Value:

AMP_ERROR_FIFO_EMPTY

Error Description:

- No entry in the FIFO.

9.2.9 AMP_ERROR_FIFO_FULL

Error Value:

AMP_ERROR_FIFO_FULL

Error Description:

- FIFO full.

9.2.10 AMP_ERROR_ILLEGAL_OPERATION

Error Value:

AMP_ERROR_ILLEGAL_OPERATION

Error Description:

- Illegal operation.

9.2.11 AMP_ERROR_ILLEGAL_CONTAINER_SOURCE

Error Value:

AMP_ERROR_ILLEGAL_CONTAINER_SOURCE

Error Description:

- Illegal container source.

9.2.12 AMP_ERROR_IO_ERROR

Error Value:

AMP_ERROR_IO_ERROR

Error Description:

- Stream IO error.

9.2.13 AMP_ERROR_OUT_OF_STORAGE

Error Value:

AMP_ERROR_OUT_OF_STORAGE

Error Description:

- Storage media full.

9.2.14 AMP_ERROR_OPERATION_ABORTED

Error Value:

AMP_ERROR_IO_OPERATION_ABORTED

Error Description:

- Operation aborted after a user aborts it.

9.2.15 AMP_ERROR_OBJ_ALREADY_EXISTS

Error Value:

AMP_ERROR_OBJ_ALREADY_EXISTS

Error Description:

- An object has already existed.

9.2.16 AMP_ERROR_OBJ_UNAVAILABLE

Error Value:

AMP_ERROR_OBJ_UNAVAILABLE

Error Description:

- A request object is unavailable.

9.2.17 AMP_ERROR_OBJ_CREATION_FAILED

Error Value:

AMP_ERROR_OBJ_CREATION_FAILED

Error Description:

- Failed to create an object.

Appendix 2 Important Notice

All Ambarella design specifications, datasheets, drawings, files, and other documents (together and separately, “materials”) are provided on an “as is” basis, and Ambarella makes no warranties, expressed, implied, statutory, or otherwise with respect to the materials, and expressly disclaims all implied warranties of noninfringement, merchantability, and fitness for a particular purpose. The information contained herein is believed to be accurate and reliable. However, Ambarella assumes no responsibility for the consequences of use of such information.

Ambarella Incorporated reserves the right to correct, modify, enhance, improve, and otherwise change its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

All products are sold subject to Ambarella’s terms and conditions of sale supplied at the time of order acknowledgment. Ambarella warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with its standard warranty. Testing and other quality control techniques are used to the extent Ambarella deems necessary to support this warranty.

Ambarella assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using Ambarella components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

Ambarella does not warrant or represent that any license, either expressed or implied, is granted under any Ambarella patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which Ambarella products or services are used. Information published by Ambarella regarding third-party products or services does not constitute a license from Ambarella to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from Ambarella under the patents or other intellectual property of Ambarella.

Reproduction of information from Ambarella documents is not permissible without prior approval from Ambarella.

Ambarella products are not authorized for use in safety-critical applications (such as life support) where a failure of the product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Customers acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of Ambarella products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by Ambarella. Further, Customers must fully indemnify Ambarella and its representatives against any damages arising out of the use of Ambarella products in such safety-critical applications.

Ambarella products are neither designed nor intended for use in automotive and military/aerospace applications or environments. Customers acknowledge and agree that any such use of Ambarella products is solely at the Customer’s risk, and they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

Appendix 11 Revision History

NOTE: Page numbers for previous drafts may differ from page numbers in the current version.

Version	Date	Comments
1.0	4 November 2014	Preliminary Release
1.1	17 February 2015	Updated Chapters 5, 6, 7, 8, 9 API syntax, parameters and/or register information; Added Section 1.2.18
1.2	24 June 2015	Updated Sections 1.2.1.2, 5.2.5.1, 7.9.14, 8.8.3.1, and 8.9.14 Added Sections 1.2.1.3 and 3.2.12 Deleted Chapter 5

Table A11-1. Revision History.

Confidential
For HAOTEK Only