

HOW TO TRIGGER LAMP OUT FAULT

The easiest way to trigger a fault for the General fault output is to make the system believe the lamp has gone out. The easiest way to do this is unplugging the terminal block that the Lamp Out signal goes to. Unplug the top right of the 4 terminal blocks on the right to do this. This will trip the alarm output.

