

Index

A

Air Bag Supplemental Restraint System3-31

 Additional Safety Precautions.....3-53

 Air Bag Warning Labels.....3-53

 How Does the Air Bag System Operate?3-37

 Occupant Classification System (OCS)3-41

 SRS Care3-52

 What to Expect After an Air Bag Inflates3-40

 Where Are the Air Bags?.....3-33

 Why Didn’t My Air Bag Go Off in a Collision?3-47

Air cleaner9-23

 Filter Replacement9-23

Air Conditioner Compressor Label2-15

Air Conditioning Refrigerant Label.....2-15

Air Conditioning System2-11

Anti-lock Brake System (ABS)6-32

 Electronic Stability Control (ESC).....6-33

 Good Braking Practices.....6-40

 Hill-Start Assist Control (HAC).....6-39

 Vehicle Stability Management (VSM)6-38

Appearance Care.....9-61

 Exterior Care9-61

 Interior Care9-67

Automatic Climate Control System5-85

 Automatic Heating and Air Conditioning5-86

 Manual Heating and Air Conditioning5-87

 System Maintenance5-95

 System Operation5-94

B

Basic Troubleshooting Guide8-27

Battery9-28

 Battery Capacity Label.....9-29

 Battery Recharging.....9-30

 For Best Battery Service9-29

 Reset Items9-30

Before Driving	6-4
Before Entering the Vehicle	6-4
Before Starting	6-4
Blind-Spot Collision-Avoidance Assist (BCA)	7-20
Blind-Spot Collision-Avoidance Assist Malfunction and Limitations	7-26
Blind-Spot Collision-Avoidance Assist Operation	7-23
Blind-Spot Collision-Avoidance Assist Settings	7-22
Brake System	6-29
Disc Brakes Wear Indicator	6-29
High Performance Brake	6-30
Parking Brake	6-30
Power Brakes	6-29
Brake/Clutch Fluid	9-21
Checking the Brake/Clutch Fluid Level	9-21
Bulb Wattage	2-9

C

Cabin Air Filter	9-25
Filter Inspection	9-25
Filter Replacement	9-25
Center Console Overview	2-5
Child Restraint System (CRS)	3-22
Children Always in the Rear	3-22
Installing a Child Restraint System (CRS)	3-24
Selecting a Child Restraint System (CRS)	3-23
Climate Control Additional Features	5-103
Automatic Ventilation	5-103
Sunroof Inside Air Recirculation	5-103
Cluster Display	4-25
Cluster Display Control	4-25
Trip Computer	4-31
View Mode	4-26
Cruise Control (CC)	7-52
Cruise Control Operation	7-52

D

Declaration Of Conformity	7-80
Rear Corner Radar.....	7-80
Dimensions	2-8
Door Locks	5-22
Automatic Door Lock and Unlock Features	5-26
Child-Protector Rear Door Locks	5-26
Operating Door Locks from Inside the Vehicle.....	5-23
Operating Door Locks from Outside the Vehicle.....	5-22
Drive Mode Integrated Control System.....	6-46
Drive Mode	6-46
N Mode.....	6-48
NGS (N Grin Shift)	6-50
Vehicle Characteristic.....	6-51
Driver Attention Warning (DAW)	7-46
Driver Attention Warning Malfunction and Limitations.....	7-48
Driver Attention Warning Operation.....	7-47
Driver Attention Warning Settings	7-46
Dual Clutch Transmission	6-18
Cluster Display for Transmission Temperature and Warning Message	6-20
Dual Clutch Transmission Operation	6-18
Good Driving Practices	6-27
Paddle Shifter (Manual Shift Mode).....	6-26
Parking	6-26

E

Electronic Control Suspension (ECS)	6-41
Electronic Limited Slip Differential	6-42
Warning Messages.....	6-43
Emission Control System	9-69
1.Crankcase Emission Control System	9-69
2.Evaporative Emission Control System Including Onboard Refueling Vapor Recovery (ORVR)	9-69
3.Exhaust Emission Control System	9-70
Engine Compartment Overview	2-7, 9-3
Engine Coolant	9-17
Changing Engine Coolant	9-20
Checking the Engine Coolant Level.....	9-17

Engine Number.....	2-15
Engine Oil.....	9-14
Checking the Engine Oil and Filter.....	9-15
Checking the Engine Oil Level.....	9-14
Engine Specification.....	2-8
Engine Start/Stop Button.....	6-5
Remote Start.....	6-10
Explanation of Scheduled Maintenance Items.....	9-12
Exterior Lights.....	5-63
Battery Saver Function.....	5-66
Headlight Delay Function.....	5-66
High Beam Operation.....	5-65
Lighting Control.....	5-63
Turn Signals and Lane Change Signals.....	5-65
Exterior Overview (Front View).....	2-2
Exterior Overview (Rear View).....	2-3

F

Forward Collision–Avoidance Assist (FCA) (Front view camera only)	7-2
Forward Collision-Avoidance Assist Malfunction and Limitations.....	7-7
Forward Collision-Avoidance Assist Operation.....	7-4
Forward Collision-Avoidance Assist Settings	7-3
Forward/Reverse Parking Distance Warning (PDW).....	7-75
Forward/Reverse Parking Distance Warning Malfunction and Limitations	7-78
Forward/Reverse Parking Distance Warning Operation	7-76
Forward/Reverse Parking Distance Warning Settings	7-75
Fuel filler door.....	5-61
Fuel Requirements.....	1-5
Fuses.....	9-44
Engine Compartment Panel Fuse Replacement	9-46
Fuse/Relay Panel Description	9-47
Instrument Panel Fuse Replacement.....	9-45

G

Guide to Hyundai Genuine Parts.....	1-3
-------------------------------------	-----

H

Hazard Warning Flasher	8-2
High Beam Assist (HBA)	5-67
High Beam Assist Malfunction and Limitations	5-68
High Beam Assist Operation	5-68
High Beam Assist Settings	5-67
Hood	5-54
How to Use This Manual	1-4
HYUNDAI AUTO CANADA	1-2
Hyundai Digital Key	5-12
Digital Key (Card Key)	5-17
Digital Key (Smartphone)	5-12
Limitations of the System	5-21
Used Vehicle/Digital Key Maintenance	5-21

I

If the Engine Overheats	8-7
If the Engine Will not Start	8-3
If the Engine Doesn't Turn Over or Turns Over Slowly	8-3
If the Engine Turns Over Normally but Doesn't Start	8-3
If You Have a Flat Tire (With Tire Mobility Kit)	8-15
Components Of The Tire Mobility Kit	8-16
Emergency Towing	8-24
Emergency Towing	8-23
How to Adjust Tire Pressure	8-20
Introduction	8-15
Notes on the Safe Use of the Tire Mobility Kit	8-21
Removable Towing Hook	8-24
Towing Service	8-22
Using the Tire Mobility Kit when a Tire is Flat	8-17
Important Safety Precautions	3-2
Air Bag Hazards	3-2
Always Wear Your Seat Belt	3-2
Control Your Speed	3-2
Driver Distraction	3-2
Keep Your Vehicle in Safe Condition	3-2
Restrain All Children	3-2

In Case of an Emergency While Driving.....	8-2
If the Engine Stalls at a Crossroad or Crossing.....	8-2
If the Engine Stalls While Driving.....	8-2
If You Have a Flat Tire While Driving.....	8-3
Infotainment System.....	5-111
Antenna	5-111
Bluetooth® Wireless Technology Hands-Free	5-114
How Vehicle Radio Works	5-114
Infotainment System	5-113
Steering Wheel Audio Control	5-112
USB Port	5-111
Voice Recognition	5-113
Instrument Cluster	4-4
Cluster Display Messages	4-20
Gauges and Meters	4-5
Instrument Cluster Control.....	4-5
Transmission Shift Indicator	4-10
Warning and Indicator Lights.....	4-11
Instrument Panel Overview	2-6
Intelligent Speed Limit Assist (ISLA)	7-40
Intelligent Speed Limit Assist Malfunction and Limitations	7-44
Intelligent Speed Limit Assist Operation	7-42
Intelligent Speed Limit Assist Settings	7-41
Interior Features.....	5-105
Clock	5-110
Coat Hook	5-110
Cup Holder	5-105
Power Outlet.....	5-106
Sunvisor.....	5-106
USB Charger	5-107
Wireless Smart Phone Charging System.....	5-108
Interior Lamps	5-70
Front Lamps	5-70
Interior Lamp Auto Cut.....	5-70
Luggage Compartment Lamp.....	5-71
Mood Lamp.....	5-71
Rear Lamp.....	5-71
Vanity Mirror Lamp	5-71
Welcome System	5-72

Interior Overview.....	2-4
Introduction	1-2

J

Jump Starting.....	8-4
--------------------	-----

L

Lane Following Assist (LFA)	7-56
Lane Following Assist Malfunction and Limitations.....	7-59
Lane Following Assist Operation.....	7-57
Lane Following Assist Settings.....	7-56
Lane Keeping Assist (LKA)	7-14
Lane Keeping Assist Malfunction and Limitations.....	7-17
Lane Keeping Assist Operation.....	7-15
Lane Keeping Assist Settings.....	7-14
Light Bulbs	9-55
Headlight, Position Light, Turn Signal Light and Daytime Running Light Bulb Replacement	9-56
High Mounted Stop Light Replacement.....	9-59
Interior Light Bulb Replacement.....	9-60
License Plate Light Bulb Replacement	9-59
Rear Combination Light Bulb Replacement	9-57
Side Repeater Light Replacement.....	9-56

M

Maintenance Services	9-4
Owner Maintenance Precautions.....	9-4
Owner's Responsibility	9-4
Manual Climate Control System	5-75
Heating and Air Conditioning	5-76
System Maintenance	5-83
System Operation	5-81
Manual Speed Limit Assist (MSLA).....	7-37
Manual Speed Limit Assist Operation	7-38
Manual Speed Limit Assist Settings.....	7-37
Manual transmission (MT)	6-12
Good Driving Practices	6-14
Manual Transmission Operation	6-12
Rev Matching	6-15

Mirrors	5-33
Inside Rearview Mirror	5-33
Side View Mirrors	5-43

N

N button	6-44
N1/N2 Button Settings	6-44

O

Open Source Software Notice	2-15
Owner Maintenance.....	9-5
Normal Maintenance Schedule	9-8
Owner Maintenance Schedule.....	9-5

P

Performance Option	6-53
Launch Control.....	6-54
Maximum Performance Driving (How to drive with Octane Number Learning)	6-62
N Power Shift (For Dual Clutch Transmission).....	6-60
N Sound Equalizer	6-60
N Track Sense Shift (For Dual Clutch Transmission).....	6-58
Performance Option Settings	6-53
Shift Light	6-57

R

Rear Cross-Traffic Collision-Avoidance Assist (RCCA)	7-64
Rear Cross-Traffic Collision Avoidance Assist Malfunction and Limitations	7-69
Rear Cross-Traffic Collision Avoidance Assist Operation	7-66
Rear Cross-Traffic Collision Avoidance Assist Settings	7-65
Rear Occupant Alert (ROA)	5-27
Rear Occupant Alert Operation	5-27
Rear View Monitor (RVM).....	7-60
Rear View Monitor Malfunction and Limitations	7-63
Rear View Monitor Operation.....	7-62
Rear View Monitor Settings	7-60
Recommended Lubricants and Capacities.....	2-12
Recommended SAE Viscosity Number	2-13
Reporting Safety Defects.....	2-16

S

Safe Exit Warning (SEW).....	7-32
Safe Exit Warning Malfunction and Limitations.....	7-34
Safe Exit Warning Operation.....	7-33
Safe Exit Warning Settings.....	7-32
Safety Messages.....	1-4
Seat Belts	3-13
Additional Seat Belt Safety Precautions	3-19
Care of Seat Belts	3-21
Seat Belt Restraint System	3-14
Seat Belt Safety Precautions	3-13
Seat Belt Warning Light	3-14
Seats.....	3-3
Front Seats.....	3-5
Head Restraints	3-9
Rear seats.....	3-7
Safety Precautions	3-4
Seat Warmers	3-11
Smart key	5-4
Battery Replacement	5-10
Immobilizer System	5-11
Locking.....	5-4
Loss of a Smart Key	5-8
Mechanical Key.....	5-8
Panic Button	5-7
Remotely Starting Vehicle.....	5-7
Smart Key Precautions	5-9
Start-up	5-8
Trunk unlocking	5-7
Unlocking Your Vehicle (When the Two Press Unlock feature is off).....	5-5
Unlocking Your Vehicle (When the Two Press Unlock feature is on)	5-6
Special Driving Conditions	6-63
Driving at Night	6-64
Driving in Flooded Areas	6-65
Driving in the Rain.....	6-64
Hazardous Driving Conditions.....	6-63
Highway Driving.....	6-65
Rocking the Vehicle.....	6-63
Smooth Cornering	6-64

Steering Wheel.....	5-29
Heated Steering Wheel.....	5-31
Horn.....	5-32
Motor Driven Power Steering (MDPS).....	5-29
Tilt Steering / Telescope Steering.....	5-30
Storage Compartment.....	5-104
Center Console Storage.....	5-104
Glove Box	5-104
Sunroof	5-50
Automatic Reversal.....	5-52
Resetting the Sunroof.....	5-53
Slide Open/Close.....	5-51
Sunroof Open Warning.....	5-53
Sunshade.....	5-50
Tilt Open/Close	5-51

T

Theft-Alarm System	5-28
Tire Pressure Monitoring System (TPMS)	8-9
Changing a Tire with TPMS.....	8-13
Check Tire Pressure.....	8-9
Low Tire Pressure Position and Tire Pressure Telltale.....	8-11
Low Tire Pressure Telltale.....	8-11
Tire Pressure Monitoring System.....	8-10
TPMS (Tire Pressure Monitoring System) Malfunction Indicator	8-13
Tire Specification and Pressure Label	2-14
Tires and Wheels	2-10, 9-31
All Season Tires	9-41
Check Tire Inflation Pressure.....	9-33
Radial-Ply Tires.....	9-42
Recommended Cold Tire Inflation Pressures.....	9-32
Snow Tires.....	9-41
Summer Tires	9-41
Tire Care.....	9-32
Tire Maintenance.....	9-35
Tire Replacement	9-34
Tire Rotation.....	9-33
Tire Sidewall Labeling	9-35
Tire Terminology and Definitions	9-39

Tire Traction	9-35
Wheel Alignment and Tire Balance	9-34
Wheel Replacement.....	9-35
Trailer Towing	6-74
Trunk.....	5-56
Emergency Trunk Safety Release.....	5-57
Smart Trunk Release	5-58

V

Vehicle Auto-Shut Off	6-11
Deactivating Conditions	6-11
Operating Conditions	6-11
System Operation	6-11
Vehicle Break-In Process.....	1-7
Vehicle certification label	2-14
Vehicle Data Collection and Event Data Recorders	1-8
Vehicle Identification Number (VIN).....	2-14
Vehicle Load Limit	6-70
The Loading Information Label	6-70
Vehicle Modifications.....	1-7
Vehicle Settings (Infotainment System)	4-33
Setting Your Vehicle.....	4-33
Volume and Weight.....	2-11

W

Washer Fluid	9-22
Checking the Parking Brake.....	9-22
Checking the Washer Fluid Level	9-22
Parking Brake	9-22
Windows	5-45
Power Windows.....	5-46
Windshield defrosting and Defogging.....	5-98
Auto Defogging System (Only For Automatic Climate Control System)	5-101
Automatic Climate Control System	5-99
Defogging Logic	5-100
Defroster.....	5-102
Manual Climate Control System	5-98

Winter Driving.....	6-66
Snow or Icy Conditions.....	6-66
Winter Precautions	6-67
Wiper Blades.....	9-26
Blade Inspection.....	9-26
Blade Replacement.....	9-26
Wipers and Washers.....	5-73
Windshield Washers	5-74
Windshield Wipers	5-73