



- Ground to enable LNA and switch XFER_position to energized
- JP1 Solder Jumper defaulted to route EN Signal to connector....
- JP1 could be switched to ground by default, which enables sys

- Intended for system level safety and lockout control.
- When low disables system, and overrides EN functionality

Id: 1/1