

报错截图如下图所示：

- ▼ [Place 30-69] Instance u\_SOC\_TOP/Iobuf\_dakeup\_n/IBUFCTRL\_INST (IBUFCTRL) is unplaced after IO placer (99 more like this)
- ❗ [Place 30-69] Instance u\_SOC\_TOP/Iobuf\_dakeup\_n/INBUF\_INST (INBUF) is unplaced after IO placer
  - ❗ [Place 30-69] Instance u\_SOC\_TOP/Iobuf\_dakeup\_n/OBUFT (OBUFT) is unplaced after IO placer
  - ❗ [Place 30-69] Instance u\_SOC\_TOP/Iobuf\_gpio\_0/IBUFCTRL\_INST (IBUFCTRL) is unplaced after IO placer
  - ❗ [Place 30-69] Instance u\_SOC\_TOP/Iobuf\_gpio\_0/INBUF\_INST (INBUF) is unplaced after IO placer
  - ❗ [Place 30-69] Instance u\_SOC\_TOP/Iobuf\_gpio\_0/OBUFT (OBUFT) is unplaced after IO placer
  - ❗ [Place 30-69] Instance u\_SOC\_TOP/Iobuf\_gpio\_1/IBUFCTRL\_INST (IBUFCTRL) is unplaced after IO placer

内容文字是：在run implentation是报错

[Place 30-69] Instance u\_SOC\_TOP/Iobuf\_gpio\_0/IBUFCTRL\_INST (IBUFCTRL) is unplaced after IO placer

对应的报错代码是：

```
wire iobuf_gpio_0_o;
IOBUF
#(
    .DRIVE(12),
    .IBUF_LOW_PWR("TRUE"),
    .IOSTANDARD("DEFAULT"),
    .SLEW("SLOW")
)
IOBUF_gpio_0
(
    .O(iobuf_gpio_0_o),
    .IO(gpio_0),
    .I(dut_io_pads_gpio_0_o_oval),
    .T(~dut_io_pads_gpio_0_o_oe)
);
assign dut_io_pads_gpio_0_i_ival = iobuf_gpio_0_o & dut_io_pads_gpio_0_o_ie;
```