

H POWER SOURCE (Current Flow Chart)

Location			Page Nos. of Related Systems																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																					
Parts																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																								
Code or Location																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																								
CB or Fuse																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																								
			A/C Condenser Fan Motor	A/C Magnetic Clutch and Lock Sensor	A/C Triple Pressure SW (A/C Dual and Single Pressure SW)	ABS & TRC & VSC Actuator	ABS & TRC & VSC Actuator	Air Flow Meter	Alternator	A/C Control Assembly	A/T Shift Position Illumination	ABS & TRC & VSC ECU	ABS & TRC & VSC ECU	ABS & TRC & VSC ECU	ABS & TRC & VSC ECU	Ashtray Illumination Rear LH	Ashtray Illumination Rear RH	Auto Antenna Control Relay and Motor	Blower Motor Controller	Body ECU No.1																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																				
			A2	A3	A4	A6	A7	A11	A15	A16	A21	A22	A23	A24	A25	A36	A37	A38	B4	B5																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																				
①	5A	IGN			●									●																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																										</

* These are the page numbers of the first page on which the related system is shown.
The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ①: Driver Side J/B (See page 58)

② : Passenger Side J/B (See page 60)

④ : Engine Room No.2 R/B (See page 55) ⑤ : Engine Room No.3 R/B (See page 56)

[illegible]

③ : Engine Room No.1 R/B (See page 54)

⑥ : Passenger Side R/B (See page 57)

⑦: Driver Side R/B (See page 57)

H POWER SOURCE (Current Flow Chart)

Location			Page Nos. of Related Systems	Parts	Code or Location	CB or Fuse	238,262,288,298,308 312,316,326,336,348 362,374,386,400,416 424,432,438,450,462	478	138,148 160,478 490,610	148,160 172,478 490,598	610	208 214	188	188	200 204	200 204	552	546	238,262,288,298 316,326,336,348 362,374,386,400 416,424,450,462
							Driver Door ECU	Engine and ECT ECU	Engine and ECT ECU	Engine and ECT ECU	Exhaust Gas Sensor	ECT Pattern Select SW	Front Fog Light LH	Front Fog Light RH	Front Turn Signal and Clearance Light LH	Front Turn Signal and Clearance Light RH	Front Wiper Motor	Fuel Lid Opener SW	Front Passenger Door ECU
							D20	E3	E5	E6	E10	E11	F1	F2	F5	F6	F7	F8	F11
①	5A	IGN							●	●									
	5A	SRS-B							●										
	5A	STARTER							●										
	7.5A	OBD																	
	7.5A	PANEL										●							
	10A	FUEL OPN																●	
	10A	GAUGE						●	●	●									
	10A	HEATER							●		●								
	10A	TAIL													●	●			
	15A	CIG																	
	15A	ECU-IG					●												●
	15A	FR FOG											●	●					
	15A	RADIO NO.2																	
	15A	SRS-ACC																	
	15A	STOP							●										
	20A	D FR DOOR																	
	20A	D RR DOOR																	
	20A	WASHER																	
	25A	WIPER															●		
	30A	D P/SEAT																	
②	5A	ECU-B2																	
	10A	DOME																	
	10A	MIR HTR																	
	10A	RR FOG																	
	15A	TV																	
	20A	P FR DOOR																	●
	20A	P RR DOOR																	
	20A	SEAT HTR																	
	25A	S/ROOF																	
	30A	DEFOG																	
	30A	P P/SEAT																	
③	5A	ALT-S																	
	10A	H-LP L UPR																	
	10A	H-LP R UPR																	
	10A	HORN																	
	10A	MPX-B					●												●
	15A	ETCS								●									
	15A	H-LP L LWR																	
	15A	H-LP R LWR																	
	15A	TEL																	
	10A	TURN-HAZ																	
	20A	RADIO NO.1																	
	25A	EFI							●	●									
	30A	CDS FAN																	
	30A	DRL NO.1																	
	40A	H-LP CLN																	
	30A	RDI FAN																	
	40A	ABS NO.2																	
	50A	HEATER																	
	60A	ABS NO.1																	
⑤	15A	H-LP L UPR																	
	15A	H-LP R UPR																	

* These are the page numbers of the first page on which the related system is shown.
The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ① : Driver Side J/B (See page 58)

② : Passenger Side J/B (See page 60)

④ : Engine Room No.2 R/B (See page 55) ⑤ : Engine Room No.3 R/B (See page 56)

121

H POWER SOURCE (Current Flow Chart)

Location			Page Nos. of Related Systems	Parts	Code or Location	CB or Fuse																					
						H22	H23	H25	H26	I11	I13	I14	I15	L2	L3	L4	L5	L7	L8	L9	M2	M4	N1	N3	N5	P4	
①	5A	IGN																									
	5A	SRS-B																									
	5A	STARTER																									
	7.5A	OBD																									
	7.5A	PANEL	●															●									
	10A	FUEL OPN																									
	10A	GAUGE																									
	10A	HEATER																									
	10A	TAIL																									
	15A	CIG																									
	15A	ECU-IG																									
	15A	FR FOG																									
	15A	RADIO NO.2																									
	15A	SRS-ACC																									
	15A	STOP			●	●																					
	20A	D FR DOOR																									
	20A	D RR DOOR																									
	20A	WASHER	●																								
	25A	WIPER																									
	30A	D P/SEAT																									
②	5A	ECU-B2																									
	10A	DOME																									
	10A	MIR HTR																									
	10A	RR FOG																									
	15A	TV																									
	20A	P FR DOOR																									
	20A	P RR DOOR																									
	20A	SEAT HTR																									
	25A	S/ROOF																									
	30A	DEFOG																									
30A	P P/SEAT																										
③	5A	ALT-S																									
	10A	H-LP L UPR																									
	10A	H-LP R UPR																									
	10A	HORN																									
	10A	MPX-B																									
	15A	ETCS																									
	15A	H-LP L LWR																									
	15A	H-LP R LWR																									
	15A	TEL																									
	10A	TURN-HAZ																									
	20A	RADIO NO.1																									
	25A	EFI																									
	30A	CDS FAN																									
	30A	DRL NO.1																									
⑤	40A	H-LP CLN																									
	30A	RDI FAN																									
	40A	ABS NO.2																									
	50A	HEATER																									
	60A	ABS NO.1																									
	15A	H-LP L UPR																									
	15A	H-LP R UPR																									

* These are the page numbers of the first page on which the related system is shown.
The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ① : Driver Side J/B (See page 58) ② : Passenger Side J/B (See page 60)
④ : Engine Room No.2 R/B (See page 55) ⑤ : Engine Room No.3 R/B (See page 56)

123

H POWER SOURCE (Current Flow Chart)

Location	Page Nos. of Related Systems	Parts	Code or Location	CB or Fuse	Rear Door RH ECU	Remote Control Mirror LH	Remote Control Mirror RH	Seat Heater SW	Shift Lock Control ECU	Step Light LH	Step Light RH	Stereo Component Amplifier	Stop Light SW	Seat Heater (Driver's Seat Back)	Seat Heater (Driver's Seat Cushion)	Seat Heater (Front Passenger's Seat Back)	Seat Heater (Front Passenger's Seat Cushion)	Tilt and Telescopic ECU	Transponder Key Amplifier	Turn Signal Flasher	Telephone Transceiver and Speaker Relay	VSV (ACIS)	VSV (EVAP)
					R14	R17	R18	S4	S5	S6	S7	S10	S12	S16	S17	S18	S19	T5	T6	T7	T8	V2	V3
①	5A	IGN											●										
	5A	SRS-B											●										
	5A	STARTER																					
	7.5A	OBD																					
	7.5A	PANEL		●				●															
	10A	FUEL OPN							●											●			
	10A	GAUGE																					
	10A	HEATER																					
	10A	TAIL																					
	15A	CIG																					
	15A	ECU-IG		●														●			●		
	15A	FR FOG																					
	15A	RADIO NO.2						●															
	15A	SRS-ACC																					
	15A	STOP											●										
	20A	D FR DOOR																					
	20A	D RR DOOR		●																			
	20A	WASHER																					
	25A	WIPER																					
	30A	D P/SEAT																					
②	5A	ECU-B2																					
	10A	DOME							●	●													
	10A	MIR HTR				●	●																
	10A	RR FOG																					
	15A	TV																					
	20A	P FR DOOR																					
	20A	P RR DOOR		●																			
	20A	SEAT HTR						●						●	●	●	●						
	25A	S/ROOF																					
	30A	DEFOG																					
③	5A	ALT-S																					
	10A	H-LP L UPR																					
	10A	H-LP R UPR																					
	10A	HORN																					
	10A	MPX-B		●																			
	15A	ETCS																					
	15A	H-LP L LWR																					
	15A	H-LP R LWR																					
	15A	TEL																					
	10A	TURN-HAZ																					
	20A	RADIO NO.1																					
	25A	EFI										●											
	30A	CDS FAN																					
	30A	DRL NO.1																					
	40A	H-LP CLN																					
	30A	RDI FAN																					
④	40A	ABS NO.2																					
	50A	HEATER																					
	60A	ABS NO.1																					
	15A	H-LP L UPR																					
⑤	15A	H-LP R UPR																					

* These are the page numbers of the first page on which the related system is shown.
The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ① : Driver Side J/B (See page 58)

② : Passenger Side J/B (See page 60)

④ : Engine Room No.2 R/B (See page 55) ⑤ : Engine Room No.3 R/B (See page 56)

125

H POWER SOURCE (Current Flow Chart)

Location	*Page Nos. of Related Systems		Parts		Code or Location		CB or Fuse											
	498 508	238 262 336 348 528	238 262 336 348 528	498 508	610	610	606	606	606	606	450	574	574	610	238 262 610	262 474	262 474	
	ABS SOL Relay (Point Side)	HORN Relay (Coil Side)	HORN Relay (Point Side)	TRAC MOTOR Relay (Point Side)	A/C COMP Relay (Coil Side)	A/C COMP Relay (Point Side)	FAN NO.1 Relay (Coil Side)	FAN NO.1 Relay (Point Side)	FAN NO.2 Relay (Coil Side)	FAN NO.2 Relay (Point Side)	FAN NO.3 Relay (Point Side)	Defogger Relay (Coil Side)	Defogger Relay (Point Side)	Heater Relay (Coil Side)	Heater Relay (Point Side)	Rear Fog Light Relay (Coil Side)	Rear Fog Light Relay (Point Side)	
	④				⑤				⑥				⑦					
①	5A	IGN																
	5A	SRS-B																
	5A	STARTER																
	7.5A	OBD																
	7.5A	PANEL																
	10A	FUEL OPN																
	10A	GAUGE																
	10A	HEATER																
	10A	TAIL																
	15A	CIG																
	15A	ECU-IG																
	15A	FR FOG																
	15A	RADIO NO.2																
	15A	SRS-ACC																
	15A	STOP																
	20A	D FR DOOR																
	20A	D RR DOOR																
	20A	WASHER																
	25A	WIPER																
	30A	D P/SEAT																
②	5A	ECU-B2																
	10A	DOME																
	10A	MIR HTR																
	10A	RR FOG																
	15A	TV																
	20A	P FR DOOR																
	20A	P RR DOOR																
	20A	SEAT HTR																
	25A	S/ROOF																
	30A	DEFOG																
	30A	P P/SEAT																
③	5A	ALT-S																
	10A	H-LP L UPR																
	10A	H-LP R UPR																
	10A	HORN																
	10A	MPX-B																
	15A	ETCS																
	15A	H-LP L LWR																
	15A	H-LP R LWR																
	15A	TEL																
	10A	TURN-HAZ																
	20A	RADIO NO.1																
	25A	EFI																
	30A	CDS FAN																
	30A	DRL NO.1																
	40A	H-LP CLN																
	30A	RDI FAN																
40A	ABS NO.2																	
50A	HEATER																	
60A	ABS NO.1																	
⑤	15A	H-LP L UPR																
	15A	H-LP R UPR																

* These are the page numbers of the first page on which the related system is shown.
The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ① : Driver Side J/B (See page 58) ② : Passenger Side J/B (See page 60)
④ : Engine Room No.2 R/B (See page 55) ⑤ : Engine Room No.3 R/B (See page 56)