

LIST OF DISABLE A MONITOR

HINT:

This table indicates ECM monitoring status for the items in the upper columns if the DTCs in each line on the left are being set.

As for the "X" mark, when the DTC on the left is stored, detection of the DTC in the upper column is not performed.

DIAGNOSTICS – SFI SYSTEM (2AZ-FE(PZEV))

Monitor detected malfunction	Fault code		Monitor disablement (X – disabled)																			
	Fault code		Component/ system																			
	Fault code		Component/ system																			
P0010,P0020	P0010,P0020	VVT VSV 1, 2	VVT VSV 1, 2																			
P0011	P0011	VVT System 1 – Advance	VVT System 1 – Advance																			
P0012	P0012	VVT System 1 – Retard	VVT System 1 – Retard																			
P0016,P0018	P0016,P0018	VVT System – Misalignment	VVT System – Misalignment																			
P0021	P0021	VVT System 2 – Advance	VVT System 2 – Advance																			
P0022	P0022	VVT System 2 – Retard	VVT System 2 – Retard																			
P0030,50	P0031,32,51,52	O2 Sensor Heater–Sensor1	O2 Sensor Heater–Sensor1																			
P0135,P0155	P0031,32,51,52	A/F Sensor Heater–Sensor1	A/F Sensor Heater–Sensor1																			
P0036,56	P0037,38,57,58	O2 Sensor Heater–Sensor2	O2 Sensor Heater–Sensor2																			
P0043,44,63,64	P0043,44,63,64	O2 Sensor Heater–Sensor3	O2 Sensor Heater–Sensor3																			
P0100,P0101	P0100-P0103	MAF sensor	MAF sensor																			
P0105,P0106	P0105-P0108	MAP sensor	MAP sensor																			
P0110	P0110-P0113	IAT sensor	IAT sensor																			
P0115,P0116	P0115-P0118	ECT sensor	ECT sensor																			
P0120,P0121	P0120-P0223,P2135	TP sensor	TP sensor																			
P0125	P0125	Insufficient ECT for Closed Loop	Insufficient ECT for Closed Loop																			
P0128	P0128	Thermostat	Thermostat																			
P0130-P0153	P0130-P0153	O2 Sensor–Sensor1	O2 Sensor–Sensor1																			
P0134,P0154	P0134,P0154	O2 Sensor, A/F sensor (No Activity)–Sensor1	O2 Sensor, A/F sensor (No Activity)–Sensor1																			
P0136,P0156	P0136,P0156	O2 Sensor–Sensor2	O2 Sensor–Sensor2																			
P0142,P0162	P0142,P0162	O2 Sensor–Sensor3	O2 Sensor–Sensor3																			
P0171,P0172	P0171,P0172	Fuel system	Fuel system																			
P0300-P0308	P0300-P0308	Misfire	Misfire																			
P0325,P0330	P0325-P0333	Knock sensor	Knock sensor																			
P0335	P0335	CKP sensor	CKP sensor																			
P0340,P0341	P0340,P0341	CMP sensor	CMP sensor																			
P0340-P0346	P0340-P0346	VVT sensor 1, 2	VVT sensor 1, 2																			
P0351-P0358	P0351-P0358	Ignitor	Ignitor																			
P0385	P0385	CKP sensor 2	CKP sensor 2																			
P0401	P0401	EGR system (closed)	EGR system (closed)																			
P0402	P0402	EGR system (open)	EGR system (open)																			
P0405,P0409	P0405-P0409	Lift sensor	Lift sensor																			
P0420,P0430	P0420,P0430	Catalyst	Catalyst																			
P0442-P0456	P0442-P0456	EVAP system	EVAP system																			
P0450,P0451	P0450-P0453	EVAP press sensor	EVAP press sensor																			

Monitor detected malfunction	Fault code			Monitor disablement (X – disabled)																			
	Fault code			Monitor disablement (X – disabled)																			
	Fault code			Monitor disablement (X – disabled)																			
	Component/ system			Monitor disablement (X – disabled)																			
	P0500	P0500	VSS	VVT VSV 1, 2	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0030,50	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125
	P0511	P0511	IAC valve	VVT System 1 – Advance	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P0510	P0510	Idle switch	VVT System 1 – Retard	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P0560	P0560	System Voltage	VVT System – Misalignment	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P0617	P0617	Starter signal	VVT System 2 – Advance	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P0705	P0705	Shift lever position switch	VVT System 2 – Retard	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P0710	P0710-P0713	Trans fluid temp sensor	O2 Sensor Heater-Sensor1	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P0720-P0793	P0720-P0793	Output speed sensor	A/F Sensor Heater-Sensor1	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P0715-P0717	P0715-P0717	Input speed sensor	O2 Sensor Heater-Sensor2	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P0724	P0724	Stop lamp switch	O2 Sensor Heater-Sensor3	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P0741-P0796	P0741-P0796	Trans solenoid (function)	MAF sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P0748-P0798	P0748-P0798	Trans solenoid (range)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P0850	P0850	PNP switch	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P1010,P1020	P1010,P1020	VVTL	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P1011,12(,21,22)	P1011,12(,21,22)	VVTL system1(,2)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P1126	P1126	Electronic magnet clutch	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P1129	P1129	Electronic throttle system	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P1430	P1430	HC absorber ACT press sensor	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2004,6	P2004,6	Intake Manifold Runner Control	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2009,10	P2009,10	Intake Manifold Runner Control Circuit	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2014,16,17	P2014,16,17	Intake Manifold Runner Position Sensor	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2102,P2103	P2102,P2103	Throttle motor	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2120-P2138	P2120-P2138	Accel position sensor	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2196,P2198	P2196,P2198	A/F sensor (rationality)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2226	P2226	BARO sensor	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2237,2240	P2237,2240	A/F sensor (open)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2423,24	P2423,24	HC Absorption Catalyst	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2430,2,3	P2430,2,3	A/R Pressure Sensor (Low/High)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2431	P2431	A/R Pressure Sensor (Rationality)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2440	P2440	A/R control valve stuck open	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2441	P2441	A/R control valve stuck close	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2444	P2444	AIP stuck On	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2445	P2445	AIP stuck Off	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2714-P2759	P2714-P2759	Trans solenoid (SLU-SLD)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128
	P2A00,P2A03	P2A00,P2A03	A/F sensor (slow response)	MAP sensor	P0010,P0020	P0011	P0012	P0016,P0018	P0021	P0022	P0031,32,51,52	P0037,38,57,58	P0043,44,63,64	P0100	P0101	P0105	P0106	P0110	P0115	P0116	P0120,P0121	P0125	P0128

Monitor detected malfunction	Fault code		Monitor disablement (X – disabled)	
	Fault code		Monitor disablement (X – disabled)	
	Component/ system		Monitor disablement (X – disabled)	
P0010,P0020	P0010,P0020	VVT VSV 1, 2		X
P0011	P0011	VVT System 1 – Advance		
P0012	P0012	VVT System 1 – Retard		
P0016,P0018	P0016,P0018	VVT System – Misalignment		
P0021	P0021	VVT System 2 – Advance		
P0022	P0022	VVT System 2 – Retard		
P0030,50	P0031,32,51,52	O2 Sensor Heater–Sensor1		X
P0135,P0155	P0031,32,51,52	A/F Sensor Heater–Sensor1		
P0036,56	P0037,38,57,58	O2 Sensor Heater–Sensor2		
P0043,44,63,64	P0043,44,63,64	O2 Sensor Heater–Sensor3		
P0100,P0101	P0100-P0103	MAF sensor		X
P0105,P0106	P0105-P0108	MAP sensor		X
P0110	P0110-P0113	IAT sensor		X
P0115,P0116	P0115-P0118	ECT sensor		X
P0120,P0121	P0120-P0223,P2135	TP sensor		X
P0125	P0125	Insufficient ECT for Closed Loop		X
P0128	P0128	Thermostat		
P0130-P0153	P0130-P0153	O2 Sensor–Sensor1		X
P0134,P0154	P0134,P0154	O2 Sensor, A/F sensor (No Activity)–Sensor1		X
P0136,P0156	P0136,P0156	O2 Sensor–Sensor2		
P0142,P0162	P0142,P0162	O2 Sensor–Sensor3		
P0171,P0172	P0171,P0172	Fuel system		X
P0300-P0308	P0300-P0308	Misfire		X
P0325,P0330	P0325-P0333	Knock sensor		X
P0335	P0335	CKP sensor		X
P0340,P0341	P0340,P0341	CMP sensor		X
P0340-P0346	P0340-P0346	VVT sensor 1, 2		
P0351-P0358	P0351-P0358	Ignitor		X
P0385	P0385	CKP sensor 2		X
P0401	P0401	EGR system (closed)		X
P0402	P0402	EGR system (open)		X
P0405,P0409	P0405-P0409	Lift sensor		
P0420,P0430	P0420,P0430	Catalyst		
P0442-P0456	P0442-P0456	EVAP system		X
P0450,P0451	P0450-P0453	EVAP press sensor		
		Knock sensor	P0325-P0333	P0325,P0330
		CKP sensor	P0335	P0335
		CMP sensor	P0340,P0341	P0340,P0341
		VVT sensor 1, 2	P0340-P0346	P0340-P0346
		Ignitor	P0351-P0358	P0351-P0358
		CKP sensor 2	P0385	P0385
		EGR system (closed)	P0401	P0401
		EGR system (open)	P0402	P0402
		EGR Lift sensor	P0405,P0406	P0405
		EGR Lift sensor	P0409	P0409
		Catalyst	P0420,P0430	P0420,P0430
		EVAP system	P0440-P0446	P0440-P0446
		EVAP press sensor	P0450-P0453	P0450,P0451
		VSS (ECT2 sensor)	P0500	P0500
		VSS (ECT1 sensor, non-ECT)	P0500	P0500
		VSS (M/T)	P0500	P0500
		IAC valve	P0511	P0511
		Idle switch	P0510	P0510
		System Voltage	P0560	P0560
		Starter signal	P0617	P0617
		Shift lever position switch	P0705	P0705
		Trans fluid temp sensor	P0710-P0713	P0710
		Output speed sensor	P0720-P0793	P0720-P0793
		Input speed sensor	P0715-P0717	P0715-P0717
		Stop lamp switch	P0724	P0724
		Trans solenoid (function)*1	P0741-P0796	P0741-P0796

Fault code			Monitor disablement (X – disabled)															
			P0325-P0330	P0325-P0333	P0335	P0340-P0341	P0340-P0346	P0351-P0358	P0385	P0401	P0402	P0405	P0409	P0420-P0430	P0440-P0446	P0450-P0451	P0500	P0500
Fault code			Knock sensor	CKP sensor	CKP sensor	CMP sensor	VVT sensor 1, 2	Igniter	CKP sensor 2	EGR system (closed)	EGR system (open)	EGR Lift sensor	EGR Lift sensor	Catalyst	EVAP system	EVAP press sensor	VSS (ECT2 sensor)	VSS (ECT1 sensor, non-ECT)
Component/ system																		
P0500	P0500	VSS							X	X				X	X			
P0511	P0511	IAC valve															X	
P0510	P0510	Idle switch								X				X	X		X	
P0560	P0560	System Voltage																
P0617	P0617	Starter signal																
P0705	P0705	Shift lever position switch																
P0710	P0710-P0713	Trans fluid temp sensor																
P0720-P0793	P0720-P0793	Output speed sensor																
P0715-P0717	P0715-P0717	Input speed sensor																
P0724	P0724	Stop lamp switch																
P0741-P0796	P0741-P0796	Trans solenoid (function)																
P0748-P0798	P0748-P0798	Trans solenoid (range)																
P0850	P0850	PNP switch															X	
P1010,P1020	P1010,P1020	VVTL																
P1011,12(,21,22)	P1011,12(,21,22)	VVTL system1(,2)							X	X				X	X		X	
P1126	P1126	Electronic magnet clutch																
P1129	P1129	Electronic throttle system																
P1430	P1430	HC absorber ACT press sensor													X	X		
P2004,6	P2004,6	Intake Manifold Runner Control																
P2009,10	P2009,10	Intake Manifold Runner Control Circuit																
P2014,16,17	P2014,16,17	Intake Manifold Runner Position Sensor																
P2102,P2103	P2102,P2103	Throttle motor																
P2120-P2138	P2120-P2138	Accel position sensor																
P2196,P2198	P2196,P2198	A/F sensor (rationality)							X	X				X				
P2226	P2226	BARO sensor																
P2237,2240	P2237,2240	A/F sensor (open)							X	X				X				
P2423,24	P2423,24	HC Absorption Catalyst																
P2430,2,3	P2430,2,3	A/R Pressure Sensor (Low/High)																
P2431	P2431	A/R Pressure Sensor (Rationality)																
P2440	P2440	A/R control valve stuck open							X	X				X				
P2441	P2441	A/R control valve stuck close							X	X				X				
P2444	P2444	AIP stuck On							X	X				X				
P2445	P2445	AIP stuck Off							X	X				X				
P2714-P2759	P2714-P2759	Trans solenoid (SLU-SLD)																
P2A00,P2A03	P2A00,P2A03	A/F sensor (slow response)							X	X				X			X	

Monitor detected malfunction				Monitor disablement (X – disabled)																								
	Fault code	Fault code	Component/ system																									
				P0741-P0796	P0748-P0799	P0850	P1010,P1020	P1011,12,(21,22)	P1126	P1129	P1430	P2004,6	P2009,P2010	P2014,16,17	P2102,P2103	P2120-P2138	P2196,P2198	P2226	P2237,P2240	P2423,24	P2430,2,3	P2431	P2440	P2441	P2444	P2445	P2714-P2759	P2A00,P2A03
P0010,P0020	P0010,P0020	VVT VSV 1, 2																										
P0011	P0011	VVT System 1 – Advance																										
P0012	P0012	VVT System 1 – Retard																										
P0016,P0018	P0016,P0018	VVT System – Misalignment																										
P0021	P0021	VVT System 2 – Advance																										
P0022	P0022	VVT System 2 – Retard																										
P0030,50	P0031,32,51,52	O2 Sensor Heater–Sensor1																	X									
P0135,P0155	P0031,32,51,52	A/F Sensor Heater–Sensor1																X	X	X								
P0036,56	P0037,38,57,58	O2 Sensor Heater–Sensor2																X		X								
P0043,44,63,64	P0043,44,63,64	O2 Sensor Heater–Sensor3																		X								
P0100,P0101	P0100-P0103	MAF sensor						X	X									X		X	X			X	X	X	X	
P0105,P0106	P0105-P0108	MAP sensor						X	X									X		X	X			X	X	X	X	
P0110	P0110-P0113	IAT sensor											X					X		X				X	X	X	X	
P0115,P0116	P0115-P0118	ECT sensor	X				X	X					X					X		X	X			X	X	X	X	
P0120,P0121	P0120-P0223,P2135	TP sensor																X		X	X			X	X	X	X	
P0125	P0125	Insufficient ECT for Closed Loop	X				X											X		X	X			X	X	X	X	
P0128	P0128	Thermostat																										
P0130-P0153	P0130-P0153	O2 Sensor–Sensor1																		X				X	X	X	X	
P0134,P0154	P0134,P0154	O2 Sensor, A/F sensor (No Activity)–Sensor1																X		X	X			X	X	X	X	
P0136,P0156	P0136,P0156	O2 Sensor–Sensor2																X		X	X							
P0142,P0162	P0142,P0162	O2 Sensor–Sensor3																		X								
P0171,P0172	P0171,P0172	Fuel system																X		X	X			X	X	X	X	
P0300-P0308	P0300-P0308	Misfire																X		X	X			X	X	X	X	
P0325,P0330	P0325-P0333	Knock sensor																						X	X	X	X	
P0335	P0335	CKP sensor						X	X									X		X	X			X	X	X	X	
P0340,P0341	P0340,P0341	CMP sensor						X	X									X		X	X			X	X	X	X	
P0340-P0346	P0340-P0346	VVT sensor 1, 2																						X	X	X	X	
P0351-P0358	P0351-P0358	Igniter																			X			X	X	X	X	
P0385	P0385	CKP sensor 2						X	X									X		X	X			X	X	X	X	
P0401	P0401	EGR system (closed)																			X							
P0402	P0402	EGR system (open)																X		X	X			X	X	X	X	
P0405,P0409	P0405-P0409	Lift sensor																										
P0420,P0430	P0420,P0430	Catalyst																										
P0442-P0456	P0442-P0456	EVAP system																X		X				X	X	X	X	
P0450,P0451	P0450-P0453	EVAP press sensor																						X	X	X	X	

			Monitor disablement (X – disabled)																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																					
Monitor detected malfunction	Fault code		Component/ system																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																					
	Fault code	Fault code																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																						
				P0741-P0796	P0741-P0796	P0748-P0798	P0850	P1010,P1020	P1011,12,(21,22)	P1126	P1129	P1430	P2004,6	P2009,P2010	P2014,16,17	P2102,P2103	P2120-P2138	P2196,P2198	P2226	P2237,P2240	P2423,24	P2430,2,3	P2431	P2440	P2441	P2444	P2445	P2714-P2759	P2A00,P2A03																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																											
	P0500	P0500	VSS	X													X	X	X			X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X