## Backup, Restore and Event Log

Okan Okumuş okanokumuss@gmail.com


#### THE CONTENTS OF THE DOCUMENT

- 1. BACKUP of the current system
- 2. RESTORE the system form backup file
- 3. EVENT LOG of the system

Backup of the current system can be created in either in *Automatic* or *Manuel Mode*. And then insert your USB to the *USB port* of FlexPendant





From the window tab, to select *Backup and Restore* section.




From the opening menu select *Backup Current System...* on left side of the menu.

Select the *Backup path* as your USB.






Press to go back until your USB name is seen and then tab *OK* on the screen.




And as a last step to backup press *Backup*. The backup of the current system is created on the USB.



#### How to compare two backups?

- Using RobotStudio we can compare two backups to see what are the differences and the changes. More details about this comparison will be discussed below.
- Prerequest: You have to install your computer RobotStudio of any latest version.


#### How to compare two backups?



Red highlighted lines that are the differences of the two backups and the changes can be seen from here

## Restore

- Backup of the current system is to take a backup of the robot program which are program and system modules in addition to that system parameters of the robot.
- In besides that, restore from the backup file is basically to load the taken backup to the robot system.




## Restore

For restoring *Manuel Mode* must be selected from the controller of the robot. And then insert your USB to the *USB port* of FlexPendant.




Your USB must have the backup file that you want to load to the robot.
Again from the window select *Backup and Restore*. Choose *Restore*System...




## Restore

Select the USB path to load.



Press to go back until your USB name is seen and then tab **OK** on the screen.



A restart occurs when the system is resarted


## **Event Log**


- Robot systems are often operated without any personnel present. The logging function is a way to store information about past events for future reference in order to facilitate trouble shooting.
- There are two ways to see the *Event Log* of the system:
- 1. From the *status bar* of the Flex Pendant
- 2. From the Event Log menu

## **Event Log**

Press All Logs As...

Press to go back until your USB name is seen and then tab *OK* on the screen





# **END**