网名"鱼树"的学员聂龙浩,

学习"韦东山 Linux 视频第 2 期"时所写的笔记很详细,供大家参考。

也许有错漏,请自行分辨。

目录

网卡驱动程序框架		2
网卡驱动程序"收发功能":		2
编程步骤		2
>设置 net_device 结构:		2
> 硬件相关设置		2
接收到数据要做的事情:		3
发包函数:		3
写一个虚拟网卡驱动:		3
1,分配 net_device 结构:		3
测试:		5
网卡驱动程序框架:		5
怎么写网卡驱动程序?		6
测试 1th/2th:		6
网卡驱动程序编写	www.100ask.org	13
测试 DM9000C 驱动程序:		13
1. 把 dm9dev9000c.c 放到内核的 c	Irivers/net 目录下	13
2. 修改 drivers/net/Makefile		13
3. make ulmage		13
4 使用 NFS 启动		13

网卡驱动程序框架

网卡驱动程序"收发功能":

只要把上层的数据发给网卡,从网卡来的数据构造成包给上层即可。网卡只需要 "socket"编程,不需要打开某设备。 驱动程序都是以面向对象的思想写的,都有相关的结构体。

编程步骤

- 1,分配某结构体: net device
- 2,设置结构体。
 - ①, 提供一个发包函数: hard start xmit()
 - ②,提供收包的功能: net_interrupt(int irq, void *dev_id)-->netif_rx(skb); 收到数据后,网卡里面一般都有中断程序。在中断程序中有一个上报数据的函数。
- 3, 注册结构体:register netdev(dev) 真实驱动中使用的是此注册函数。
- 4,硬件相关操作。

看内核中的"cs89x.c"这个真实的网卡驱动程序:

nt __init init_module(void)

-->分配一个 net_device 结构体

struct net_device *dev = alloc_etherdev(sizeof(struct net_local));

--->alloc_netdev(sizeof_priv, "eth%d", ether_setup); 分配时用了eth%d这样的名字。

-->设置 net device 结构:

MAC 地址,硬件相关操作

 $dev->dev_addr[0] = 0x08;$

 $dev->dev_addr[1] = 0x89$

dev->dev addr[2] = 0x89

dev->dev addr[3] = 0x89

dev - > dev addr[4] = 0x89

dev->dev_addr[5] = 0x89; //以上为MAC地址。

--> 硬件相关设置

```
-->ret = cs89x0_probe1(dev, io, 1);
```

-->net_device结构中有open,read等函数。

dev->open = net_open;

dev->tx_timeout = net_timeout

dev->watchdog_timeo = HZ;

dev->hard_start_xmit = net_send_packet; //硬件启动传输。这是发包函数。

dev->get_stats = net_get_stats;

dev->set_multicast_list = set_multicast_list;

dev->set_mac_address = set_mac_address;

接收到数据要做的事情:

irgreturn_t net_interrupt(int irg, void *dev_id)

-->net_rx(dev);

-->从硬件芯片里读出来

status = readword(ioaddr, RX_FRAME_PORT);

length = readword(ioaddr, RX_FRAME_PORT);

- -->skb = dev_alloc_skb(length + 2); 分配一个skb缓冲。
- -->netif_rx(skb);
- -->netif_wake_queue(dev); 发送完数据后就唤醒队列

发包函数:

int net_send_packet(struct sk_buff *skb, struct net_device *dev)

接收到包后是上报了一个"sk_buff"缓冲(netif_rx(skb))

sk_buff 结构 是纽带,运用 "hard_start_xmit()"和 "netif_rx()": 应用层构造好一个包后,放到 "skb_buff"结构交给网卡驱动,调用 "hard start xmit()"来发送。

网卡在中断程序中收到数据后,从芯片里把数据读出来构造一个"skb_buff"结构数据,调用"netif_rx()"上报数据给应用层。

- -->netif stop queue(dev); 先停止队列
- -->将"skb_buff"中数据写到网卡芯片:

writeword(dev->base_addr, TX_CMD_PORT, lp->send_cmd);

writeword(dev->base addr, TX LEN PORT, skb->len);

writewords(dev->base_addr, TX_FRAME_PORT,skb->data,(skb->len+1) >>1);

-->dev_kfree_skb (skb); 然后释放skb_buff。

写一个虚拟网卡驱动:

1. 分配 net device 结构:

net_device *alloc_netdev(int sizeof_priv, const char *name,void (*setup)(struct net_device *))

//1,分配 net_device 结构体

vnet_dev = alloc_netdev(0, "vnet%d", ether_setup);

直接用 "alloc_netdev()" 自忆定义网卡的名字为 "vent%d". 其中 "ether_setup"是默认的设置函数。

sizeof priv 是私有数据,我们的这里定义私有数据为 0.

内核中经常会在只分配一个结构体的时候多分配一个内存。这块内存就是用来存放自已的"私有数据"。




这里不需要私有信息,所以直接分配"net_device"结构中没有分配"私有数据空间",上面指为了"0"。

```
//1.1, net_device 结构变量 vnet_dev.
 static net_device *vnet dev;
 static int virt_net_init(void)
    //1,分配 net_device 结构体
    vnet dev = alloc netdev(0, "vnet%d", ether setup); //alloc_etherdev()
    //2,设置
    //3,注册
    register netdevice (vnet dev);
    return 0;
 static void virt_net_exit(void)
    unregister_netdevice (vnet_dev);
     free netdev(vnet dev);
 module init (virt net init);
 module_exit (virt net exit);
 MODULE AUTHOR ("ian1900");
 MODULE LICENSE ("GPL");
这就是最简单的网卡驱动程序。
```

```
int register netdev(struct net device *dev)
     int err;
     rtnl lock();
      * If the name is a format string the caller wants us to do a
      * name allocation.
     if (strchr(dev->name, '%')) {
         err = dev alloc name(dev, dev->name);
         if (err < 0)
              goto √out;
     }
     err = register netdevice(dev);
out:
     rtnl unlock();
     return err;
} ? end register_netdev ?
要用上面的"register_netdev()"来注册,里面获得锁后用"register_netdevice()"
来注册。
测试:
book@book-desktop:/work/drivers_and_test/16th_virt_net/1th$ make
make -C /work/system/linux-2.6.22.6 M=`pwd` modules
make[1]: Entering directory \text{\work/system/linux-2.6.22.6}
  CC [M] /work/drivers_and_test/16th_virt_net/1th/virt_net.o
  Building modules, stage 2.
  MODPOST 1 modules
         /work/drivers_and_test/16th_virt_net/1th/virt_net.mod.o
 LD [M] /work/drivers_and_test/16th_virt_net/1th/virt_net.ko
make[1]: Leaving directory `/work/system/linux-2.6.22.6´
book@book-desktop:/work/drivers_and_test/16th_virt_net/1th$
```

网卡驱动程序框架.

app:	socke	et 编程
		若干层网络协议一纯软件(网络七层模型)
hard_s	start_	$\ \ \ \ \ \ \ \ \ \ \ \ \ $
	ī	 硬件相关的驱动程序(要提供 hard_start_xmit,有数据时要用 netif_rx 上报)



怎么写网卡驱动程序?

- 1. 分配一个 net device 结构体
- 2. 设置:
- 2.1 发包函数: hard start xmit
- 2.2 收到数据时(在中断处理函数里)用 netif_rx 上报数据
- 2.3 其他设置
- 3. 注册: register netdev

www.100ask.org

测试 1th/2th:

1. insmod virt_net.ko

3065 行错误:

```
#define ASSERT_RTNL() do { \
    if (unlikely(rtnl_trylock())) { \
        rtnl_unlock(); \
        printk(KERN_ERR "RTNL: assertion failed at %s (%d)\n", \
        ___FILE__, ___LINE__); \
        dump_stack(); \
    } \
} while(0)

想获得一把锁,但没有成功。而真实的注册函数 "register_netdev()" 中有获得锁和解锁的过程。
```

```
ASSERT_RTNL() 相当于下面的代码: 不停的获得锁。

do

{

    if (unlikely(rtnl_trylock())) //若

    {

        rtnl_unlock();

        printk(KERN_ERR "RTNL: assertion failed at %s (%d)\n", __FILE__, __LINE__);

        dump_stack();

    }

    while(0)
```

2. ifconfig vnet0 3.3.3.3

ifconfig // 查看

```
# ifconfig vnet0 3.3.3.3
# ifconfig
          Link encap:Ethernet HWaddr 00:60:6E:33:44:55
eth0
          inet addr:192.168.1.17 Bcast:192.168.1.255 Mask:255.255.255.0
          UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
          RX packets:1676 errors:0 dropped:0 overruns:0 frame:0
          TX packets:689 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:2139996 (2.0 MiB) TX bytes:109814 (107.2 KiB)
          Interrupt:51 Base address:0xa000
lo
          Link encap:Local Loopback
          inet addr:127.0.0.1 Mask:255.0.0.0
UP LOOPBACK RUNNING MTU:16436 Metric:1
          RX packets:0 errors:0 dropped:0 overruns:0 frame:0
          TX packets:0 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:0
          RX bytes:0 (0.0 B) TX bytes:0 (0.0 B)
          Link encap:Ethernet HWaddr 00:00:00:00:00:00
vnet0
          inet addr:3.3.3.3 Bcast:3.255.255.255 Mask:255.0.0.0
          UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
          RX packets:0 errors:0 dropped:0 overruns:0 frame:0
          TX packets:0 errors:0 dropped:0 over<mark>ru:s:</mark>0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:0 (0.0 B) TX bytes:0 (0.0 B)
```


```
3. ping 3.3.3.3 // 成功
# ping 3 3 3 3 7 28 26 7 6
PING 3.3.3.3 (3.3.3.3): 56 data bytes
64 bytes from 3.3.3.3: seq=0 ttl=64 time=0.783 ms
64 bytes from 3.3.3.3: seq=1 ttl=64 time=0.416 ms
64 bytes from 3.3.3.3: seq=2 ttl=64 time=0.405 ms
64 bytes from 3.3.3.3: seq=3 ttl=64 time=0.410 ms
64 bytes from 3.3.3.3: seq=4 ttl=64 time=0.418 ms
ping 应用程序可以 ping 通自己,说明 ping 从应用程序中进来,没有经过网卡驱动层直接
从应用程序返回了。
这说明"IP" 是纯软件的概念。
ping 3.3.3.4 // 死机
Backtrace:
[<c023ddb0>] (dev_hard_st<mark>art_xmit</mark>+0x0/0x240) from [<c024ae40>] (__qdisc_run+0xb0/0x198) r8:03030303 r7:c3d15c2c r6:c3cab980 r5:00000000 r4:c3d15c00
  ping 时会调用"dev hard start xmit"函数。但这个函数没有提供,故死机了。
加上发包函数后,会发现可以 ping 了:
//2,设置
static int virt net sendpacket (struct sk buff *skb,struct net device *dev)
{//里面什么也没做,只是打印出此函数被调用的次数。
   printk("virt_net_sendpacket = %d\n",++cnt);
重新编译驱动后再 ping:
# ping 3.3.3.4
PING 3.3.3.4 (3.3.3.4): 56 data bytes
virt_net_send_packet cnt = 1
virt_net_send_packet cnt = 2
virt_net_send_packet cnt = 3
virt_net_send_packet cnt = 4
virt_net_send_packet cnt = 5
virt_net_send_packet cnt = 6
上面发送了6个数据包,但统计信息里显示还是"0"个。
在"net_dev"结构体中有统计信息成员:
struct net_device_stats
```

```
unsigned long rx_packets;
                                     /* total packets received */
                                      /* total packets transmitted
/* total bytes received *
     unsigned long tx_packets;
     unsigned long rx_bytes;
                                      /* total bytes transmitted */
     unsigned long tx_bytes;
                                      /* bad packets received
     unsigned long rx_errors;
     unsigned long tx_errors;
                                     /* packet transmit problems */
                                      /* no space in linux buffers
     unsigned long rx_dropped;
                                      /* no space available in linux
     unsigned long tx_dropped;
     unsigned long multicast;
                                      /* multicast packets received
     unsigned long collisions;
     /* detailed rx_errors: */
unsigned long rx_length_errors;
     unsigned long rx_over_errors;
                                          /* receiver ring buff overflow */
                                         /* recved pkt with crc error */
/* recv'd frame alignment error */
/* recv'r fifo overrun */
     unsigned long rx_crc_errors;
     unsigned long rx_frame_errors;
     unsigned long rx_fifo_errors;
     unsigned long rx_missed_errors; /* receiver missed packet
     /* detailed tx_errors */
     unsigned long tx_aborted_errors;
     unsigned long tx_carrier_errors;
unsigned long tx_fifo_errors;
     unsigned long tx_heartbeat_errors;
     unsigned long tx_window_errors;
     /* for cslip etc */
     unsigned long rx_compressed; unsigned long tx_compressed;
} ? end net_device_stats ? ;
再编译后测试:
              Link encap:Ethernet HWaddr 08:89:89:89:89:11
```

struct net_device_stats

```
vnet0
             inet addr:3.3.3.3 Bcast:3.255.255.255 Mask:255.0.0.0
             UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
             RX packets:0 errors:0 dropped:0 overruns:0 frame:0
TX packets:9 errors:0 dropped:0 overruns:0 carrier:0
collisions:0 xqueuelen:1000
             RX bytes:0 (0.0 B) TX bytes:378 (378.0 B)
```

把数据写入网卡后,网卡并不是立即全部发送出去。网卡发送完数据后会产生一个中断。



```
struct ethhdr {
                        h dest[ETH ALEN]; /* destination eth addr */
      unsigned char
                         h source[ETH ALEN]; /* source ether addr */
      unsigned char
                                      /* packet type ID field */
       be16
                    h proto;
     attribute ((packed));
/ 从硬件读出/保存数据
/* 对调"源/目的"的 mac 地址 */
ethhdr = (struct ethhdr *)skb->data; //数据放在skb的data中。
memcpy(tmp_dev_addr, ethhdr->h_dest, ETH_ALEN); //将目的MAC拷贝到临时数组中.
memcpy(ethhdr->h_dest, ethhdr->h_source, ETH_ALEN);//将源、目的MAC对调。
memcpy(ethhdr->h_source, tmp_dev_addr, ETH_ALEN); //对调源、目的MAC。
```

接着 IP 头也要对调,将 ping 包的类型修改为回复:

```
struct iphdr {
 #if defined( LITTLE ENDIAN BITFIELD)
               ihl:4,
       u8
           version: 4;
 #elif defined (__BIG_ENDIAN_BITFIELD)
               version: 4,
           ih1:4;
 #else
 #error "Please fix <asm/byteorder.h>"
 #endif
       u8
               tos;
        be16 tot len;
        be16 id;
       be16 frag off;
               ttl;
        u8
      u8 protocol;
        sum16 check;
        be32 saddr;
       be32 daddr;
      /*The options start here. */
 } ? end iphdr ? ;
/* 对调"源/目的"的 ip 地址 */
ih = (struct iphdr *)(skb->data + sizeof(struct ethhdr));
saddr = &ih->saddr;
daddr = &ih->daddr:
              //源IP放到tmp
tmp = *saddr;
*saddr = *daddr; //指针所指内容交换
*daddr = tmp:
//((u8 *)saddr)[2] ^= 1; /* change the third octet (class C) */
type = skb->data + sizeof(struct ethhdr) + sizeof(struct iphdr);
//printk("tx package type = %02x\n", *type);
// 修改类型,原来0x8表示ping
*type = 0; /* 0表示reply */
重新计算校验码:
ih->check=0:
                             /* and rebuild the checksum (ip needs it) */
ih->check = ip_fast_csum((unsigned char *)ih,ih->ihl); //校验码要重新计算
```

重新编译并测试:

```
# ping 3.3.3.4
PING 3.3.3.4 (3.3.3.4): 56 data bytes
virt_net_send_packet cnt = 1
64 bytes from 3.3.3.4: seq=0 ttl=64 time=0.809 ms
virt_net_send_packet cnt = 2
64 bytes from 3.3.3.4: seq=1 ttl=64 time=0.454 ms
virt_net_send_packet cnt = 3
64 bytes from 3.3.3.4: seq=2 ttl=64 time=0.456 ms
virt_net_send_packet cnt = 4
64 bytes from 3.3.3.4: seq=3 ttl=64 time=0.450 ms
```



网卡驱动程序编写

测试 DM9000C 驱动程序:

- 1. 把 dm9dev9000c.c 放到内核的 drivers/net 目录下
- 2. 修改 drivers/net/Makefile

把

obj-\$(CONFIG_DM9000) += dm9000.o

改为

obj-\$(CONFIG_DM9000) += dm9dev9000c.o

3. make ulmage

使用新内核启动

4. 使用 NFS 启动

或

ifconfig eth0 192.168.1.17 ping 192.168.1.1

