# **Rockchip ROS Introduction**

ID: RK-SM-YF-377

Release Version: V1.0.2

Release Date: 2020-08-06

Security Level: □Top-Secret □Secret □Internal ■Public

#### DISCLAIMER

THIS DOCUMENT IS PROVIDED "AS IS". ROCKCHIP ELECTRONICS CO., LTD. ("ROCKCHIP") DOES NOT PROVIDE ANY WARRANTY OF ANY KIND, EXPRESSED, IMPLIED OR OTHERWISE, WITH RESPECT TO THE ACCURACY, RELIABILITY, COMPLETENESS, MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY REPRESENTATION, INFORMATION AND CONTENT IN THIS DOCUMENT. THIS DOCUMENT IS FOR REFERENCE ONLY. THIS DOCUMENT MAY BE UPDATED OR CHANGED WITHOUT ANY NOTICE AT ANY TIME DUE TO THE UPGRADES OF THE PRODUCT OR ANY OTHER REASONS.

#### **Trademark Statement**

"Rockchip", "瑞芯微", "瑞芯" shall be Rockchip's registered trademarks and owned by Rockchip. All the other trademarks or registered trademarks mentioned in this document shall be owned by their respective owners.

#### All rights reserved. ©2020. Rockchip Electronics Co., Ltd.

Beyond the scope of fair use, neither any entity nor individual shall extract, copy, or distribute this document in any form in whole or in part without the written approval of Rockchip.

Rockchip Electronics Co., Ltd.

No.18 Building, A District, No.89, software Boulevard Fuzhou, Fujian, PRC

Website: www.rock-chips.com

Customer service Tel: +86-4007-700-590

Customer service Fax: +86-591-83951833

Customer service e-Mail: fae@rock-chips.com

## Preface

### Overview

This document mainly introduces how to use ROS of Rockchip Linux SDK.

## **Product Version**

Chipset	Kernel Version
RK3XXX	4.4

## **Intended Audience**

This document (this guide) is mainly intended for:

Technical support engineers

Software development engineers

## **Revision History**

Version	Author	Date	Change Description
V1.0.0	WZZ	2018-12	ROS has been porting into buildroot, removing the original building method and switching to the new one.
V1.0.1	WZZ	2019-12	Fix beginner_tutorials building issue
V1.0.2	Ruby Zhang	2020-08-06	Update the company name and document format

## **Rockchip ROS Introduction**

- 1. Overview
- 2. Build
- 3. Add the New ROS Code
- 4. Flashing
- 5. Run

## 1. Overview

Rockchip Linux SDK integrated ROS which provides a range of libraries and tools to help software developers create robotic applications.

ROS version which Rockchip integrated are Indigo and kinetic.

## 2. Build

There are two default configurations of ros\_indigo.config and ros\_kinetic.config under buildroot/configs/rockchip directory. Before building rootfs, add ros\_xxx.config to the config corresponding to rootfs.

Take RK3308 Linux SDK as an example. Others are similar, modify buildroot/configs/rockchip rk3308 release defconfig:

```
diff --git a/configs/rockchip_rk3308_release_defconfig
b/configs/rockchip_rk3308_release_defconfig
index f905f16..a2afac1 100644

--- a/configs/rockchip_rk3308_release_defconfig
+++ b/configs/rockchip_rk3308_release_defconfig
@@ -135,3 +135,4 @@ BR2_TARGET_ROOTFS_SQUASHFS=y
# BR2_TARGET_ROOTFS_TAR is not set
BR2_PACKAGE_HOST_MKE2IMG=y
BR2_PACKAGE_HOST_VBOOT_UTILS=y
+#include "ros_indigo.config"
```

And then run ./build.sh.

Or first select the rockchip\_rk3308\_release corresponding to source envsetup.sh, then run make.

The compilation for the first time will take a few hours. After the compilation is complete, buildroot/output/rockchip rk3308 release/images/rootfs.squashfs which is the rootfs firmware will be generated.

## 3. Add the New ROS Code

There is a ros\_sample provided: <a href="https://github.com/DZain/ROS\_Sample.git">https://github.com/DZain/ROS\_Sample.git</a>

Put the project to external, and rename to beginner tutorials.

Then add the following files and modifications in buildroot:

 vi buildroot/package/rockchip/ros/beginner\_tutorials/Config.in, add the following contents:

```
config BR2_PACKAGE_BEGINNER_TUTORIALS
bool "beginner tutorials"
select BR2_PACKAGE_ROSCPP
select BR2_PACKAGE_ROSPY
select BR2_PACKAGE_STD_MSGS
select BR2_PACKAGE_GENMSG
help
beginner tutorials
```

The select option in the Config depends on the dependencies in the project.

2. vi buildroot/package/rockchip/ros/beginner\_tutorials/beginner\_tutorials.mk

```
BEGINNER_TUTORIALS_VERSION = 1.0.0
BEGINNER_TUTORIALS_SITE_METHOD = local
BEGINNER_TUTORIALS_SITE = $(TOPDIR)/../external/beginner_tutorials

BEGINNER_TUTORIALS_DEPENDENCIES = roscpp rospy std-msgs genmsg

${eval ${catkin-package}}$
```

#### 3. Add beginner tutorials to buildroot:

```
1 @@ -46,6 +46,7 @@ source diff --git a/package/rockchip/ros/Config.in
b/package/rockchip/ros/Config.in
2 index e26003aa9f..cb6f6c18e6 100644
3 --- a/package/rockchip/ros/Config.in
4 +++ b/package/rockchip/ros/Config.in
5 @@ -46,6 +46,7 @@ source "package/rockchip/ros/cmake_modules/Config.in"
6 source "package/rockchip/ros/rospack/Config.in"
7 source "package/rockchip/ros/orocos_kinematics_dynamics/Config.in"
8 source "package/rockchip/ros/image-common/Config.in"
9 +source "package/rockchip/ros/beginner_tutorials/Config.in"
10 source "package/rockchip/ros/bond-core/Config.in"
11 source "package/rockchip/ros/bond-core/Config.in"
```

#### 4. Build

Run the source envsetup.sh in the SDK root directory, select rockchip\_rk3308\_release (If you have already ran it, don't have to run again).

Configure make menuconfig, use '/' opening search menu, search BEGINNER\_TUTORIALS (in step 1, defined in Config.in), and select.

Save the configuration.

Build with make.

(Or use make beginner\_tutorials directly. Rebuild using make beginner\_tutorials-directly. Rebuild using make beginner\_tutorials.)

## 4. Flashing

Please refer to the release documentations of Rockchip Linux SDK for instructions on how to flash firmware. It won't go into details here. Just download the Rootfs.img generated by ROS building to the corresponding rootfs partition.

# 5. Run

The steps to run ROS are as follows:

1. Configure environment variables

```
1 | source /opt/ros/indigo/setup.sh
```

2. Run roscore

```
1 | roscore &
```

3. Run the code

Take the beginner\_tutorials as an example:

```
1 rosrun beginner_tutorials talker
```

#### Running result:

```
1  [ INFO] [1501923947.458788791]: hello world 0
2  [ INFO] [1501923947.558904332]: hello world 1
3  [ INFO] [1501923947.658774958]: hello world 2
4  [ INFO] [1501923947.758644458]: hello world 3
5  [ INFO] [1501923947.858779666]: hello world 4
6  [ INFO] [1501923947.958779291]: hello world 5
```

(The beginner\_tutorials code is a pair of programs, "talker" is used to send and "listener" is used to listen, open talker alone, number will accumulate continuously, and there is no phenomenon when opening listener alone, but when talker is opened at the same time, two programs number print simultaneously)