Port Mirroring Configuration Commands

Table of Contents

Chapter 1 Configuring Port Mirroring Commands....1
1.1 Port Mirroring Configuration Commands....1
1.1.1 mirror....1
1.1.2 show mirror....1

Chapter 1 Configuring Port Mirroring Commands

1.1 Port Mirroring Configuration Commands

The following are port mirroring configuration commands:

- mirror
- show mirror

1.1.1 mirror

Description

[**no**] **mirror session** *session_number* {**destination** {**interface** *interface-id* } | **source** {**interface** *interface-id* [, | -] [**both** | **rx** | **tx**] }

It is used to configure the command.

Parameters

Parameter	Description
session_number	Number of port mirroring, whose value is 1
destination	Information about the destination port mirroring
source	Information about the mirrored port
both | *rx* | *tx*	Data flow that will be mirrored **rx** means that the input data is mirrored. **tx** means that the output data is mirrored. **both** means that input and output data are mirrored.

Instruction

Configure the command at the global configuration mode.

Example

Port g0/2 functions as the output mirror of port g0/1.

```
Switch(config)# mirror session 1 destination interface g0/2
Switch(config)# mirror session 1 source interface g0/1 tx
```

1.1.2 show mirror

Description

show mirror [session *session_number]*

It is used to display the port mirroring information.

Parameter

Parameter	Description
session_number	Number of port mirroring, whose value is 1

Default

None

Instruction

It is used to display the port mirroring information.

Example

All port mirroring information are displayed.

```
Switch# show mirror
Session 1
---------
Source Ports:
RX Only: Fe0/3
TX Only: None
Both: None
Source VLANs:
RX Only: None
TX Only: None
Both: None
```