MAC Address List Characteristic Configuration Commands

Table of Contents

Chapter 1 MAC Access List Configuration Commands..... 1
1.1 MAC Access List Configuration Commands..... 1
1.1.1 mac access-list..... 1
1.1.2 permit..... 1
1.1.3 deny..... 2
1.1.4 mac access-group..... 3

Chapter 1 MAC Access List Configuration Commands

1.1 MAC Access List Configuration Commands

- mac access-list
- permit
- deny
- mac access-group

1.1.1 mac access-list

description

To add a MAC access list, use the mac access-list command. To delete a MAC access list, use the mac access-list command.

[**no**] **mac access-list** *name*

parameter

parameter	Description
name	MAC access list name.

default

none

command mode

Global configuration mode

example

The following example establishes MAC access list named mac-acl:

Switch-config_# mac access-list mac-acl
Switch-config-macl#

1.1.2 permit

description

To add a permit entry to the MAC access list, use the permit command. Use the no form of this command to delete a permit entry from the MAC access list.

[**no**] **permit** {**any** | **host** *src-mac-addr*} {**any** | **host** *dst-mac-addr*}[*ethertype*]

parameter

parameter	description	Value range
any	Any value	—
host	Host	—
src-mac-addr	Source MAC address	H.H.H
dst-mac-addr	Destination MAC address	H.H.H
ethertype	Types of the matching ethernet data packet.	0-0xFFFF

default

deny all

command mode

MAC access list configuration mode

example

The following example permits host whose source MAC address is 1234.5678.abcd:

Switch-config-macl#permit host 1234.5678.abcd any 0x806

1.1.3 deny

description

To add a deny entry to the MAC access list, use the deny command. Use the no form of this command to delete a deny entry from the MAC access list.

[**no**] **deny** {**any** | **host** *src-mac-addr*} {**any** | **host** *dst-mac-addr*}**[***ethertype***]**

parameter

parameter	Description	Value range
any	Any value	—
host	Host	—
src-mac-addr	Source MAC address	H.H.H
dst-mac-addr	Destination MAC address	H.H.H
ethertype	Types of the matching ethernet data packet.	0-0xFFFF

default

deny all

comamnd mode

MAC access list configuration mode

example

The following example denies host whose source MAC address is 1234.5678.abcd:

Switch-config-macl#deny host 1234.5678.abcd any 0x806

1.1.4 mac access-group

description

To apply the configured MAC access list in global configuration mode, use the mac access-group command. Use the no form of this comand to delete the mac access-list.

[**no**] **mac access-group** *name*

parameter

parameter	Description
name	Name of the MAC access list.

default

No MAC access list is applied.

Command mode

Global configuration mode

example

The following example configures MAC access list named macacl:

Switch_config#mac access-group macacl