Preset Template Commands

Table of Contents

Chapter 1 Preset Template Commands..... 1
1.1 Preset Template Configuration Commands..... 1
1.1.1 epon onu-config-template..... 1
1.1.2 cmd-sequence..... 2
1.1.3 epon pre-config-template..... 2
1.1.4 show onu-config-template..... 3

第 1 章 Preset Template Commands

1.1 Preset Template Configuration Commands

- epon onu-config-template
- cmd-sequence
- epon pre-config-template
- show onu-config-template

1.1.1 epon onu-config-template

To create a preset template and enter the template mode, run the following command:

epon onu-config-template *word*

Parameter

Parameter	Description
Word	Stands for the name of the to-be-set template.

Default value

No template

Command mode

Global configuration mode

Explanation

If the **word** template does not exist, a template need be created; otherwise, the system enters the template mode.

Example

switch_config**#epon onu-config-template** 123

switch_config_template_123#

1.1.2 cmd-sequence

To set the commands in the template, run the following first command:

cmd-sequence *number commad*

no cmd-sequence *number*

Parameter

Parameter	Description
number	Stands for the command sequence number in the template, which cannot be duplicated.
commad	Stands for a command in the template.

Default value

There is no default settings.

Command mode

Template configuration mode

Explanation

Different preset commands, which are for ONU settings, are identified by different sequence numbers. A sequence number cannot be doubly used only when the corresponding command is deleted. The ordering of delivering commands to ONU is the same as that of the commands in the preset template. The spelling of a command must be correct.

Example

```
cmd-sequence 1 epon onu port-protect
```

1.1.3 epon pre-config-template

To apply a preset template on an port, run the following first command:

epon pre-config-template *onu-templatet-name* **binded-onu-llid** *llid-range*

no epon pre-config-template *onu-templatet-name*

Parameter

Parameter	Description
onu-templatet-name	Stands for the name of the to-be-set template. This template will be used by ONU, which is in the range of LLID.

llid-range	Sets the LLID range.

Default value

There is no template being applied.

Command mode

Interface configuration mode

Explanation

Different preset templates with different LLIDs can be set according to customers' requirements. The template's name configured by users must exist, or the presetting is null.

Example

omitted

1.1.4 show onu-config-template

To show the preset template, run the following command:

show onu-config-template *word*

Parameter

Parameter	Description
Word	Stands for the name of the to-be-set template.

Default value

N/A

Command mode

EXEC

Explanation

This command is used to display the configured template's name and its presetting commands.

Example

```
Switch# show onu-config-template 123

ONU config template 123 ,total cmd 2

-------------------------------------------

Index     command content

1         epon onu port-protect

2         epon onu port 1 ctc vlan mode tag 10
```