Web Configuration Commands

Table of Contents

Chapter 1 HTTP Configuration Commands....2
1.1 ip http language....2
1.2 ip http port....2
1.3 ip http secure-port....3
1.4 ip http server....3
1.5 ip http http-access enable....3
1.6 ip http log-login enable....4
1.7 ip http web max-vlan....4
1.8 ip http web igmp-groups....4

Chapter 1 HTTP Configuration Commands

1.1 ip http language

Syntax

ip http language {chinese | english}

It is used to set the prompt language when a command is configured.

Parameter

Parameter	Remarks
chinese	Sets the language to Chinese.
english	Sets the language to English.

Default value

N/A

Remarks

This command is configured in global configuration mode.

Example

The following example shows how to set the language to English.

Switch_config#ip http language english

1.2 ip http port

Syntax

[no]ip http port { *portNumber* }

It is used to set the HTTP port.

Parameter

Parameter	Remarks
portNumber	Means the HTTP port's valid range is from 1 to 65535.

Default value

80

Remarks

This command is configured in global configuration mode.

Example

The following example shows how to set the HTTP port to 1234.

Switch_config#ip http port 1234

1.3 ip http secure-port

Syntax

[no] ip http secure-port {*portNumber*}

It is used to set the HTTPS port.

Parameter

Parameter	Remarks
portNumber	Means the HTTPS port's valid range is from 1 to 65535.

Default value

443

Remarks

This command is configured in global configuration mode.

Example

The following example shows how to set the HTTPS port to 1234.

```
Switch_config# ip http secure-port 1234
```

1.4 ip http server

Syntax

[no] ip http server

It is used to set the HTTP service.

Remarks

This command is configured in global configuration mode.

Example

It is used to set the HTTP service.

```
Switch_config# ip http server
```

1.5 ip http http-access enable

Syntax

[no] ip http http-access enable

It is used to set the HTTP access mode.

Remarks

This command is set in global configuration mode and used to access the website, which starts with http://.

Example

The following example shows how to set the HTTP access mode.

```
Switch_config# ip http http-access enable
```

1.6 ip http log-login enable

Syntax

[no] ip http log-login enable

It is used to enable HTTP login logs.

Remarks

This command should be set in global configuration mode and can be used to record user's switch logins.

Example

The following example shows how to enable HTTP login logs.

Switch_config# ip http log-login enable

1.7 ip http web max-vlan

Syntax

[no] ip http web max-vlan { *max-vlan* }

It is used to set the maximum number of VLAN entries displayed in a web page.

Parameter

Parameter	Remarks
max-vlan	Means the maximum number of vlan entries in the web page, which ranges from 1 to 4094.

Default value

100

Remarks

This command is configured in global configuration mode.

Example

The following example shows how to set the maximum number of VLAN entries displayed in a web page to 123.

Switch_config# ip http web max-vlan 123

1.8 ip http web igmp-groups

Syntax

[no] ip http web igmp-groups { *igmp-groups* }

It is used to set the maximum number of multicast entries displayed in a web page.

Parameter

Parameter	Remarks
igmp-groups	Means the maximum number of multicast entries in the web page, which ranges from 1

	to 100.

Default value

15

Remarks

This command is configured in global configuration mode.

Example

The following example shows how to set the maximum number of multicast entries displayed in a web page to 12.

```
Switch_config#ip http web igmp-groups 12
```