Practice

- 步驟一▶測試 sr04.py
- 步驟二
 - ▶修改sr04.py為 可以連續執行
- 步驟三 (倒車雷達) (檢查看code及輸出)
 - ▶加入LED執行距離 D cm以上, LED 沒反應
 - ▶小於 D cm, LED 開始閃爍
 - ▶ 小於 D/2 cm, LED 的閃爍變快
 - ▶D = 組別 % 4 +3
 - ▶組別 1-1 →11, 3-2 →32, 11-1 →11, 12-2 →22

