
# 18.SI-DRIVE (SUBARU Intelligent Drive) Selector

## A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove the console box. <Ref. to EI-67, RE-MOVAL, Console Box.>
- 3) Remove the multi-selector switch connector from the console box.
- 4) Remove the screws and tabs holding the multiselector switch to the console box and the multi-selector switch.



#### **B: INSTALLATION**


Install in the reverse order of removal.

#### Tightening torque:

1.5 N⋅m (0.2 kgf-m, 1.1 ft-lb)

### C: INSPECTION

- 1) Check that the multi select switch does not have deformation, cracks, or damage.
- 2) Check the resistance between the terminals at the SI-DRIVE selector.



Switch position	Terminal No.	Standard
Sport (When turning the SI- DRIVE selector to the left)	5 and 8	Less than 1 $\Omega$
Intelligent (When pressing the SI-DRIVE selector)		1±0.05 kΩ
Sport Sharp (When turning the SI-DRIVE selector to the right)		3.67±0.1835 kΩ