11.List of Diagnostic Trouble Code (DTC)

A: LIST

DTC	Item	Content of diagnosis	Reference
U0073	Control Module Com- munication Bus Off	Detected when CAN line abnormality is detected.	<ref. al(diag)-15,="" control="" dtc="" mod-<br="" to="" u0073="">ULE COMMUNICATION BUS OFF, Diagnostic Pro- cedure with Diagnostic Trouble Code (DTC).></ref.>
U0122	Lost Communication With Vehicle Dynamics Control Module	Detected when CAN data from VDC (vehicle speed signal) does not arrive.	<ref. (dtc).="" al(diag)-15,="" code="" communication="" control="" diagnostic="" dtc="" dynamics="" lost="" module,="" procedure="" to="" trouble="" u0122="" vehicle="" with=""></ref.>
U0140	Lost Communication With Body Control Module	Detected when CAN data from body integrated unit (headlight ON signal) does not arrive.	<ref. (dtc).="" al(diag)-15,="" body="" code="" communication="" control="" diagnostic="" dtc="" lost="" module,="" procedure="" to="" trouble="" u0140="" with=""></ref.>
U0416	Invalid Data Received From Vehicle Dynamics Control Module	Detected when data from VDC (vehicle speed signal) is abnormal.	<ref. al(diag)-15,="" data<br="" dtc="" invalid="" to="" u0416="">RECEIVED FROM VEHICLE DYNAMICS CON- TROL MODULE, Diagnostic Procedure with Diag- nostic Trouble Code (DTC).></ref.>
U0422	Invalid Data Received From Body Control Module	Detected when CAN data from body integrated unit (headlight ON signal) is abnormal.	<ref. al(diag)-15,="" data<br="" dtc="" invalid="" to="" u0422="">RECEIVED FROM BODY CONTROL MODULE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).></ref.>
B2900	AHLCU Error	Detected when an error occurred in auto headlight beam leveler CM.	<ref. ahlcu="" al(diag)-16,="" b2900="" dtc="" error,<br="" to="">Diagnostic Procedure with Diagnostic Trouble Code (DTC).></ref.>
B2902	Rear Height Sensor Error	Detected when an error occurred in rear vehicle height sensor.	<ref. al(diag)-17,="" b2902="" dtc="" height<br="" rear="" to="">SENSOR ERROR, Diagnostic Procedure with Diag- nostic Trouble Code (DTC).></ref.>
B2904	Led Headlamp(RH) Error	Detected when malfunction is found in LED headlight (right side) trouble signal line.	<ref. al(diag)-19,="" b2904="" dtc="" head-<br="" led="" to="">LAMP(RH) ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).></ref.>
B2905	Led Headlamp(LH) Error	Detected when malfunction is found in LED headlight (left side) trouble signal line.	<ref. al(diag)-21,="" b2905="" dtc="" head-<br="" led="" to="">LAMP(LH) ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).></ref.>