## 26.Crankshaft

## **A: SPECIFICATION**

Refer to "Cylinder Block" for removal and installation procedures of the crankshaft. <Ref. to ME(w/o STI)-260, REMOVAL, Cylinder Block.> <Ref. to ME(w/o STI)-272, INSTALLATION, Cylinder Block.>