## 11. System Operation Check Mode

### **A: OPERATION**

For detailed operation procedures, refer to "PC application help for Subaru Select Monitor".

#### NOTE:

If not equipped (based on area or condition), process will not go on.

#### **CAUTION:**

After executing the system operation check mode, execute the Clear Memory Mode. <Ref. to IDI(diag)-15, OPERATION, Clear Memory Mode.>

#### **B: LIST**

#### · Combination meter

| Check item        | Item 1                  | Item 2   | Note |
|-------------------|-------------------------|--|------|
|                   | Speedometer             | _  | _    |
| Pointer operation | Tachometer              | _  | _    |
| check             | Fuel Meter Operation    | _  | _    |
|                   | Water thermometer       | Identer Importation Importment Importation Importation Importation Importation Importation | _    |
|                   | All lamps lit           | — — — — — — — — — — — — — — — — — — —  | _    |
| Lamp check        |                         | High-beam indicator  | _    |
|                   |                         | Position light indicator   | _    |
|                   | Indicator drive         | Front fog light indicator  | _    |
|                   |                         | Rear fog light indicator   | _    |
|                   |                         | VDC OFF indicator  | _    |
|                   |                         | VDC operation/failure indicator  | _    |
|                   |                         | Hill start assist OFF/failure indicator  | _    |
|                   |                         | REV/RED ZONE indicator   | _    |
|                   |                         | Traction mode indicator  | _    |
|                   | mp check  Warning drive | Driver side seat belt warning  | _    |
|                   |                         | Airbag warning   | _    |
|                   |                         | TPMS warning   | _    |
| Lamp check        |                         | E/G remaining oil warning  | _    |
|                   |                         | AT (CVT) oil temperature warning   | _    |
|                   |                         | R.DIFF oil temperature warning   | _    |
|                   |                         | ABS warning  | _    |
|                   |                         | BRAKE warning  | _    |
|                   |                         | AWD warning  |      |
|                   |                         | Remaining fuel warning   |      |
|                   |                         | EPS warning  |      |
|                   |                         | Check E/G warning  |      |
|                   |                         | Charge warning   |      |
|                   |                         | Oil pressure warning   |      |
|                   |                         | Vacuum pump warning  |      |
|                   |                         | HID auto leveler warning   |      |
|                   |                         | LED LO beam warning  | _    |

# **System Operation Check Mode**

INSTRUMENTATION/DRIVER INFO (DIAGNOSTICS)

| Check item                      | Item 1   | Item 2 | Note |
|---------------------------------|--|--------|------|
| MFD output check                | Passenger side seat belt warning               | _      | _    |
|                                 | Rear seat (right) seat belt warning            | _      | _    |
|                                 | Rear seat (center) seat belt warning           | _      | _    |
|                                 | Rear seat (left) seat belt warning             | _      | _    |
|                                 | Momentary fuel efficiency display value        | _      | _    |
|                                 | Mean fuel efficiency A display value           | _      | _    |
|                                 | Mean fuel efficiency B display value           | _      | _    |
|                                 | Remaining fuel cruising distance display value | _      | _    |
|                                 | Ambient air temperature                        | _      | _    |
|                                 | Mean vehicle speed display value               | _      | _    |
| Illumination check              | Brightness check                               | _      | _    |
| Buzzer output                   | Sounding output ON/OFF                         | _      | _    |
| Display Operation<br>Check Mode | White indication                               | _      | _    |
|                                 | Black indication                               | _      | _    |
|                                 | Red indication                                 | _      | _    |
|                                 | Green indication                               | _      | _    |
|                                 | Blue indication                                | _      | _    |
|                                 | Gradation indication                           | _      | _    |
|                                 | Flicker indication                             | _      | _    |
|                                 | Cross talking indication                       |        | _    |