
# 30. Keyless Access Outdoor Antenna

## A: REMOVAL

## 1. FRONT ANTENNA

#### **CAUTION:**

Do not detach the antenna from the front door outer handle. If replacement is required, replace the front outer handle assembly as a whole.



1) Disconnect the ground cable from battery. <Ref. to NT-5, BATTERY, NOTE, Note.> NOTE:

For models other than STI model, disconnect the ground terminal from battery sensor.

2) Remove the handle - door outer. <Ref. to SL-33, REMOVAL, Front Outer Handle.>

#### 2. REAR ANTENNA


#### **CAUTION:**

- Do not detach the antenna except when replacing it. Detaching unnecessarily will lead to insecure attachment of the antenna.
- When replacing the antenna, do not reuse the tapping screw. Always replace with new tapping screws.
- 1) Disconnect the ground cable from battery. <Ref. to NT-5, BATTERY, NOTE, Note.>

#### NOTE:

For models other than STI model, disconnect the ground terminal from battery sensor.

- 2) Remove the bumper face rear. <Ref. to EI-41, REMOVAL, Rear Bumper.>
- 3) Remove the rear antenna assembly exterior.
  - (1) Disconnect the connector.
  - (2) Remove the screws, and remove the rear antenna assembly exterior.



### **B: INSTALLATION**

1) Install the rear antenna assembly - exterior.

### Tightening torque:

## 7.5 N·m (0.8 kgf-m, 5.5 ft-lb)

- 2) Install the bumper face rear.
- 3) Connect the battery ground terminal. <Ref. to NT-5, BATTERY, NOTE, Note.>

#### NOTE:

For models other than STI model, connect the ground terminal to battery sensor.

## C: INSPECTION

- 1) Check the setting by performing Keyless access system check using the Subaru Select Monitor. <Ref. to KPS(diag)-38, OPERATION, Keyless Access System Check.>
- 2) Disconnect the Subaru Select Monitor. Operate the touch sensor of the door outer handle to check if door lock operates.
- 3) If the system does not operate normally as the result of inspection, refer to "General Diagnostic Table" of the "KEYLESS ACCESS WITH PUSH BUTTON START SYSTEM (DIAGNOSTICS)" section. <Ref. to KPS(diag)-111, KEYLESS ACCESS SYSTEM, INSPECTION, General Diagnostic Table.>