74.Rear Wiring Harness and Trunk Lid Cord

A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
AB31	2	В	B-2		Curtain airbag module LH
AB32	4	Υ	C-1		Curtain airbag sensor LH
AB33	2	В	A-4		Curtain airbag module RH
AB34	4	Υ	B-4		Curtain airbag sensor RH
AB41	2	Υ	B-2		Satellite safing sensor
R11	2	В	C-3		Rear differential oil temperature sensor
R14	4	*	B-3		J/C
R16	3	*	B-4		Rear door switch RH
R17	1	В	B-4		Amplifier bracket ground
R19	2	*	B-4		High-mounted stop light
R20	2	В	B-4		Trunk room light
R22	3	*	C-2		Rear door switch LH
R24	12	*	B-4	R60	Trunk lid cord
R26	6	*	B-5		Rear combination light RH
R28	6	*	C-3		Rear combination light LH
R29	3	В	C-3		Rear vehicle height sensor
R58	6	GR	B-2		Fuel pump assembly (engine type EJ)
noo	4	*	B-2		Fuel pump assembly (engine type FA)
R59	2	*	B-2		Fuel sub level sensor
R60	12	*	B-5	R24	Rear wiring harness RH
R65	1	В	B-2		Rear defogger (–)
R72	2	GR	B-3		Rear ABS wheel speed sensor RH
R73	2	GR	C-2		Rear ABS wheel speed sensor LH
R76	2	*	C-4		License plate light LH
R77	2	*	B-4		License plate light RH
R80	8	*	B-3		Keyless entry CM (without push button start)
R97	1	*	B-2	AN8	Antenna cord
R117	4	*	B-3		Woofer
R122	6	*	B-4		Fuel pump CM (engine type FA)
11122	10	GR	B-4		Fuel pump CM (engine type EJ)
R174	1	В	A-4		Rear defogger (+)
R186	3	*	C-4		Trunk lid lock actuator & switch
R211	12	*	C-2		TPMS CM
R221	12	*	B-3		TPMS & keyless entry CM
R294	2	BR	B-4		Trunk opener button
R296	5	*	B-3		Receiver (with push button start)
R297	3	*	B-3		Keyless access interior antenna (rear)
R298	3	*	B-3		Keyless access interior antenna (center)
R299	6	*	C-4		Keyless access exterior antenna (rear)
R316	10	*	B-3		- Audio amplifier
R317	12	*	B-3		·
R330	4	*	B-5	R356	Trunk lid cord
R356	4	*	B-5	R330	Rear wiring harness RH
R357	4	*	C-4		Rearview camera
R386	24	*	B-3		Audio amplifier
R400	8	*	B-3		ELCM
★: White or natural color					

