

Scenes

Named lighting looks you recall with one tap. Open **Sidebar** → **Scenes**.

Two scene types

Standard

Applies stored **WLED presets** and **DMX scene cues** (static looks).

Party

Starts **party mode** on the WLED / DMX targets you pick for that scene.

Standard scenes and party mode are mutually exclusive: applying one stops the other.

Apply a scene

- 1 Open **Scenes** and tap a scene card.
- 2 Confirm **Switch scene** (or **Start party** for the party scene).
- 3 Look for the **Active** badge on the card.

Badges: **Active** = currently applied · **Default** = runs at startup · **Party** = party scene

Create or edit

- 1 Click **Manage** → **Create scene** (or select an existing scene).
- 2 Set a **Name** (e.g. “Lobby warm”).
- 3 **Standard:** move WLED / DMX into **Included**, then pick a **preset** or **scene cue** for each.
- 4 **Party:** enable **Party mode scene**, then choose **WLED targets** / **DMX targets**.
- 5 Click **Create scene** or **Save scene**.

Scene cues live on each fixture page under **Scene cues** — set the look on **Live**, then capture it. Scenes do **not** use party cues.

Tips

- Enable **Apply this scene when the app starts** for a startup look (not for party scenes).
- Use **Import** / **Export** to share a scene as JSON.
- **Blackout** stops party and zeros channels; DMX output keeps streaming.

USB DMX interface

Required for DMX fixtures in scenes. Output starts automatically when an interface is ready — there is no Start/Stop DMX button.

Attach & select

- 1 Plug in an **Enttec Pro-compatible** USB-DMX adapter.
- 2 Open **Settings** → **DMX**.
- 3 Turn on **Enable DMX component**.
- 4 Turn on **Enable USB transport**.
- 5 Click **Refresh USB devices**, then pick the adapter (not **No device selected**).

DMX badge · green

Connected — packets are being sent.

DMX badge · red

Disconnected — no active adapter.

Troubleshooting checklist

- ? **Enable DMX component** is on
- ? **Enable USB transport** is on
- ? Adapter listed after **Refresh USB devices**
- ? Real device selected (not **No device selected**)
- ? Toolbar **DMX** badge is green
- ? Adapter is Enttec Pro-compatible (or OpenDMX-style)
- ? Linux / Pi: user in dialout for /dev/ttyUSB* or /dev/ttyACM*
- ? After import or host change: re-select the USB device (paths change)

Selected device unavailable? Unplug → replug → **Refresh USB devices** → select again. There is no separate Reconnect button.

Dig deeper

- 1 **Settings** → **Console** → watch **USB DMX** lines for USB DMX adapter started... or USB write failed.
- 2 Optional: enable **Simulate USB-DMX512 interface** to test the UI without hardware.
- 3 Channel mapping issues: **Settings** → **DMX** → **DMX fixture channel sweep** (stop party first).

Scenes say “No DMX interface configured”?

Open **DMX settings**, enable USB (and/or Art-Net), select a device, then retry the scene.

Quick recovery

Refresh → re-select → confirm green **DMX** badge → apply scene again.