					T					1			
	序	31	ucosii	指令	指令说明	指令格式	OP	RS	RT	RD	SA	FUNCT	指令码 16
	号	条	V2.52				31-26	25-21	20-16	15-11	10-6	5-0	进制
3	1	٧	٧	addi	加立即数	addi rt, rs, immediate	001000				00000	100000	20000000
3	2	٧	٧	addiu	加立即数(无符 号)	addiu rd, rs, immediate	001001)					24000000
3	3	٧	٧	andi	立即数与	andi rt, rs, immediate	001100						30000000
3	4	٧	٧	ori	或立即数	ori rt, rs, immediate	001101						34000000
3	5	٧	٧	sltiu	小于立即数置 1 (无符号)	sltiu rt, rs, immediate (001011						2C000000
3	6	٧	٧	lui	立即数加载高位	lui rt, immediate	001111	00000					3C000000
3	7	٧		xori	异或 (立即数)	xori rt, rs, immediate	001110			00000	00000	000000	38000000
3	8	٧		slti	小于置1(立即	slti rt, rs, immediate	001010			00000	00000	000000	28000000
					数)								
3	9	٧	٧	addu	加 (无符号)	addu rd, rs, rt	_000000				00000	100001	00000021
3	10	٧	٧	and	与	and rd, rs, rt	000000				00000	100100	00000024
? 4	11	٧	٧	beq	相等时分支	beq rs, rt, offset	000100						10000000
7.4	12	٧	٧	bne	不等时分支	bne rs, rt, offset	000101						14000000
ک	13	٧	٧	j	跳转	j target	000010						08000000
3	14	٧	٧	jal	跳转并链接	jal target	000011						0C000000
2	15	٧	٧	jr	跳转至寄存器所指 地址	jr rs	000000					001000	00000009
q	16	٧	٧	lw	取字	lw rt, offset(base)	100011						8C000000
3	17	٧	٧	xor	异或	xor rd, rs, rt	000000				00000	100110	00000026
3	18	٧	٧	nor	或非	nor rd, rs, rt	000000				00000	100111	00000027

												~	
3	19	٧	٧	or	或	or rd, rs, rt	000000				00000	100101	00000025
3	20	٧	٧	sll	逻辑左移	sll rd, rt, sa	000000	00000				000000	00000000
3	21	٧	٧	sllv	逻辑左移(位数可	sllv rd, rt, rs	000000				00000	000108	00000004
′					变)								
3	22	٧	٧	sltu	小于置1(无符	sltu rd, rs, rt	000000				00000	101011	0000002B
/					号)								
3	23	٧	٧	sra	算数右移	sra rd, rt, sa	000000	00000				000011	00000003
3	24	٧	٧	srl	逻辑右移	srl rd, rt, sa	000000	00000				000010	00000002
ક	25	٧	٧	subu	减 (无符号)	sub rd, rs, rt	000000				00000	10001)	00000022
3	26	٧	٧	SW	存字	sw rt, offset(base)	101011						AC000000
3	27	٧		add	加	add rd, rs, rt	000000				00000	100000	00000020
3	28	٧		sub	减	sub rd, rs, rt	000000				00000	100010	00000022
3	29	٧		slt	小于置 1	slt rd, rs, rt	000000				00000	101010	0000002A
3	30	٧		srlv	逻辑右移(位数可	srlv rd, rt, rs	_000000				00000	000110	00000006
					变)								
3	31	٧		srav	算数右移(位数可	srav rd, rt, rs	000000				00000	000111	00000007
					变)								
04	32		٧	clz	前导零计数	clz rd, rs	011100				00000	100000	70000020
54	33		٧	divu	除 (无符号)	divu rs, rt	000000			00000	00000	011011	000001B
3	34		٧	eret	异常返回	eret	010000	10000	00000	00000	00000	011000	42000018
	35		٧	jalr	跳转至寄存器所指	jalr rs	000000		00000			001001	80000000
3					地址,返回地址保								
					存在								
4	36		٧	lb	取字节	lb rt, offset(base)	100000						80000000
¥	37		٧	lbu	取字节 (无符号)	Ibu rt, offset(base)	100100						90000000

4	38	٧	lhu	取半字 (无符号)	lhu rt, offset(base)	100101						94000000
Ψ	39	√	sb	存字节	sb rt, offset(base)	101000						A0000000
4	40	√	sh	存半字	sh rt, offset(base)	101001						A4000000
ç	41		lh	取半字	Ih rt, offset(base)	100001						84000000
3	42	V	mfc0	读 CPO 寄存器	mfc0 rt, rd	010000	00000			00000	000000	40000000
	43	٧	mfhi	读 Hi 寄存器	mfhi rd	000000	00000	00000		00000	010000	00000010
•	44	٧	mflo	读 Lo 寄存器	mflo rd	000000	00000	00000		00000	010010	00000012
	45	٧	mtc0	写 CPO 寄存器	mtc0 rt, rd	010000	00100			00000	000000	40800000
2	46	٧	mthi	写 Hi 寄存器	mthi rd	000000		00000	00000	00000	010001	00000011
_	47	٧	mtlo	写 Lo 寄存器	mtlo rd	000000		00000	00000	00000	010011	00000013
	48	٧	mul	乘	mul rd, rs, rt	011100				00000	000010	70000002
,	49	V	multu	乘 (无符号)	multu rs, rt	000000			00000	00000	011001	00000019
•	50	٧	syscall	系统调用	syscall	000000					001100	000000C
6	51	٧	teq	相等异常	teq rs, rt	000000				(110100	00000034
3	52	٧	bgez	大于等于0时分支	bgez rs, offset	000001		0001				04010000
/	53		break	断点	break	000000					001101	000000D
	54		div	除	div rs, rt	000000			00000	00000	011010	000001A