Headers

	_HEADER.USB.DEVICE.D-	10
	HEADER.USB.DEVICE.D+	SH1 10
	PA9/COM1.TX/PWM1	SH2 10
	PA10/COM1.RX/PWM2	SH3 10
	PA8/PWM0/MC01	SH4 10
	PC9/PWM10/SD.D1	SH5 10
	PC8/PWM9/SD.D0	SH6
	PC10/SD.D2	SHZ 10
	_PC11/SD.D3	SH8 10
	_PC12/SD.CLK	SH9 10
	_PD2/SD.CMD	SH10
	_PB3/SPI1.CLK	SH11 10
	_PB4/SPI1.MISO	SH12 10
	_PB5/SPI1.MOSI	SH13
	PB6/PWM11/I2C1.SCL	SH14
	_PBZ/PWM12/I2C1.SDA	SH15
	_PB13/SPI2.SCK	SH16
	_PB14/SPI2.MIS0	SH1Z
	_PB15/SPI2.MOSI	SH18
윘		SH19
ල්		SH2Ø

JP40	5V.USB	
JP39		
01		– o ≌
JP38		10
<u>01</u> J₽37		
(1)	RESET#	
<u>JP36</u>		
01	UBAT.HEADER	
JP35	PB10/MODE	
JP34	1000100	
01	PA15/LDR0	
JP33		
01	PC13/LDR1	
J₽32	PB8/PWM13	
JP31	FDOV ENITLS	
01	PB9/PWM14	
JP30		
01	PA5/ADC5	
JP29	PA4/ADC4	
JP28	FILIVITIO	
01	PA3/ADC3/COM2.RX/PWM6	
JP27		
O ¹	PA2/ADC2/COM2.TX/PWM5	
JP26	PA1/ADC1/COM2.RTS/PWM4	
JP25	FILLY HIDELY CONTART 37 FWILL	
01	PA0/ADC0/COM2.CTS/PWM3	
JP24		
01	PC3/ADC13	
JP23	PC2/ADC12	
<u>□1</u> JP22	1 027 110012	
0 ¹	PC1/ADC11	
JP21	PC0/ADC10	
ш		

