




Packing List





















A15	*1	A16 *1
A17	*1	A18 *1
A19	*1	



Components

Copper Standoff	Round head screw		
M2*6 x4	M1.6*10	x8	
M2.5*10+6 x4	M2*10	x10	
M2.5*14 x4	M2*14	x6	
M3*12 x4	M2.5*10(black)	x10	
M3*30 x8	M3*8(black)	x28	
Spring Washer	M3*12	x14	
Spring washer	M3*14	x4	
M4 x6	M3*18	x1	
	M4*6	x2	
	M4*40	x2	
Nylon isolation column	Flat head screw		
7*4*18 x2	M3*10 x2		




self-tapping screw (black)	Hex nuts			
M1.7*6*6 x4	9	M1.6	x8	
		M2	x23	
		M3	x13	
		M4	x1	
Mechanical parts bearings F624ZZ x6 F687ZZ x4		Nylon colum M3*30 x	an 3	


Transmission Parts

Bevel gear x2	M3*3 Locking Screw x2
S12D4 Coupling x2	M4*4 Locking Screw x4












Tools








Electronic Component










You need to purchase the following components



Raspberry Pi version compatible with the product: 3B, 3B+, 4B.

And the corresponding power cable of the Raspberry Pi version.

Choose an 18650 battery that supports a maximum output current of at least 4A or choose an



18650 battery with "high rate discharge".	
16GB and above SD card.	