NAME

mbset – Sets values in **mbprocess** parameter files.

VERSION

Version 5.0

SYNOPSIS

mbset –**I***infile* [–**E** –**L** –**P***PARAMETER*:*value* –**V** –**H**]

DESCRIPTION

mbset is a utility for creating and modifying **mbprocess** parameter files.

The program **mbprocess** can perform a variety of swath data processing functions in a single step (producing a single output swath data file), including:

- Merge edited navigation generated by **mbnavedit**.
- Apply bathymetry edit flags from **mbedit** and **mbclean**
- Recalculate bathymetry from raw travel time and angle data by raytracing through water sound speed models from **mbvelocitytool** or **mbsvplist**.
- Apply changes to roll bias, pitch bias, heading bias, and draft values.
- Recalculate sidescan from raw backscatter samples (Simrad multibeam data only).
- Apply tides to bathymetry.
- Insert metadata.

The actions of **mbprocess** are controlled by text parameter files. Each **mbprocess** parameter file contains single line commands that set processing modes and parameters. The **–P** option of **mbset** is used to modify a single **mbprocess** parameter command. This option can be invoked as many times as desired on the command line, allowing **mbset** to set multiple **mbprocess** processing parameters and modes. If the swath data file specified by the **–linfile** option of **mbset** has an existing **mbprocess** parameter file, then that parameter file will be read and the existing parameter values will be modified. If no **mbprocess** parameter file exists, then **mbset** starts with default processing parameters, modifies those, and then generates a new parameter file.

If the input file specified by the **–I** option is a single swath data file, **mbset** will act on that file and it's parameter file only. If the input file is a datalist, then **mbset** will act on all swath files extracted from the datalist (and any recursively parsed datalist files). This function allows users to easily set uniform processing parameters for large numbers of data files. The default input file is "datalist.mb-1".

The processing parameter file used by **mbprocess** has an ".par" suffix. In addition to **mbset**, these files are generated or modified by **mbedit**, **mbnavedit**, **mbvelocitytool**, **mbnavadjust**, and **mbclean**.

The processed output swath files produced by **mbprocess** are named using a convention based on the data format id. **MB-System** data formats are specified using two-digit or three-digit numbers (see the **MBIO** manual page). If an input swath data file is named "root.mbXX", where XX is the format id, then the default processed output file will be "rootp.mbXX" (e.g. mydata.mb71 -> mydatap.mb71). The "p" inserted before the ".mbXX" suffix indicates the output file has been created by **mbprocess**. If the input file does not follow the *.mbXX naming convention, then the output filename will just consist of the input name with "p.mbXX" added as a suffix (e.g. mydata -> mydatap.mb71)

MBPROCESS PARAMETER FILE COMMANDS

The **mbprocess** parameter file commands modified by **mbset** are:

GENERAL PARAMETERS:

EXPLICIT

causes mbprocess to set modes implicitely

– e.g. the SVPFILE command will also set
raytracing on even if the RAYTRACE command
is not given [explicit mode commands required]

FORMAT constant

sets format id [no default]

INFILE filename

sets input file path [no default]

OUTFILE filename

sets output file path [no default]

NAVIGATION MERGING:

NAVMODE boolean

sets navigation merging [0]

0: navigation merge off

1: navigation merge on

NAVFILE filename

sets navigation file path [no default]

NAVFORMAT constant

sets navigation file format [9]

see the **mbprocess** man page for documentation of the supported navigation formats.

NAVHEADING boolean

sets heading to be merged from navigation file

 note: heading merged from navigation before heading correction applied

0: heading not changed

1: heading merged from navigation file

NAVSPEED boolean

sets speed to be merged from navigation file

0: speed not changed

1: speed merged from navigation file

NAVDRAFT boolean

sets draft to be merged from navigation file

 note: draft merged from navigation before draft correction applied

0: draft not changed

1: draft merged from navigation file

NAVATTITUDE boolean

sets roll, pitch and heave to be merged from navigation file

 note: roll, pitch, and heave merged from navigation before roll bias and pitch bias corrections applied

0: roll, pitch, and heave not changed

1: roll, pitch, and heave merged from navigation file

NAVINTERP boolean

sets navigation interpolation algorithm [0]

0: linear interpolation (recommended)

1: spline interpolation

NAVTIMESHIFT constant

sets navigation time shift (seconds) [0.0]

 note: time shift added to timestamps of navigation fixes read in from NAVFILE prior to merging

NAVIGATION OFFSETS AND SHIFTS:

NAVSHIFT boolean

sets navigation offset [0]

 note: offsets and shifts are applied to navigation values from both survey and navigation records, and are applied to navigation read in from

NAVFILE prior to merging

 note: offsets and shifts are NOT applied to adjusted navigation values from NAVADJFILE

NAVOFFSETX constant

sets navigation athwartship offset (meters) [0.0]

 note: the effective navigation shift is (NAVOFFSETX – SONAROFFSETX), and the navigation is corrected by subtracting this effective shift.

 note: athwartship shift is positive to starboard.

NAVOFFSETY constant

sets navigation fore-aft offset (meters) [0.0]

 note: the effective navigation shift is (NAVOFFSETY – SONAROFFSETY), and the navigation is corrected by subtracting this effective shift.

- note: fore-aft shift is positive forward.

NAVOFFSETZ constant

sets navigation vertical offset (meters) [0.0]

- note: this value is not yet used for anything.
- note: vertical shift is positive down.

NAVSHIFTLON constant

sets navigation longitude shift (degrees) [0.0]

NAVSHIFTLAT constant

sets navigation latitude shift (degrees) [0.0]

NAVSHIFTX constant

sets navigation longitude shift (meters) [0.0]

NAVSHIFTY constant

sets navigation latitude shift (meters) [0.0]

ADJUSTED NAVIGATION MERGING:

NAVADJMODE mode

sets navigation merging from mbnavadjust [0]

can apply to longitude and latitude only or longitude, latitude, and depth offset
disadjusted navigation merge off

1: adjusted navigation merge on

2: adjusted navigation and depth offset merge on

NAVADJFILE filename

sets adjusted navigation file path

 this file supercedes navigation file for lon and lat only

uses mbnavadjust output

NAVADJINTERP boolean

sets adjusted navigation interpolation algorithm [0]

0: linear interpolation (recommended)

1: spline interpolation

ATTITUDE MERGING:

ATTITUDEMODE mode

sets attitude (roll, pitch, and heave) merging [0]

- roll, pitch, and heave merged before roll bias and pitch bias corrections applied
- attitude merging from a separate file supersedes attitude merging from a navigation file

0: attitude merging off

1: attitude merging on

ATTITUDEFILE filename

sets attitude file path

ATTITUDEFORMAT constant

sets attitude file format [1]

- attitude files can be in one of four ASCII

table formats

- 1: format is <time_d roll pitch heave>
- 2: format is <yr mon day hour min sec roll pitch heave>
- 3: format is <yr jday hour min sec roll pitch heave>
- 4: format is <yr jday daymin sec roll pitch heave>
- time_d = decimal seconds since 1/1/1970
- daymin = decimal minutes start of day
- roll = positive starboard up, degrees
- pitch = positive forward up, degrees
- heave = positive up, meters

SONARDEPTH MERGING:

SONARDEPTHMODE mode

sets sonardepth merging [0]

- sonardepth merged before draft corrections applied
- sonardepth merging from a separate file supersedes draft merging from a navigation file

0: sonardepth merging off

1: sonardepth merging on

SONARDEPTHFILE filename

sets sonardepth file path

SONARDEPTHFORMAT constant

sets sonardepth file format [1]

- sonardepth files can be in one of four ASCII table formats
- 1: format is <time_d sonardepth>
- 2: format is <yr mon day hour min sec sonardepth>
- 3: format is <yr jday hour min sec sonardepth>

- 4: format is <yr jday daymin sec sonardepth>
- time_d = decimal seconds since 1/1/1970
- daymin = decimal minutes start of day
- sonardepth = sonar depth positive down, meters

DATA CUTTING:

DATACUTCLEAR

removes all existing data cutting commands DATACUT kind mode min max

adds new data cutting command, where:

kind = 0 : cut applied to bathymetry data

kind = 1 : cut applied to amplitude data

kind = 2: cut applied to sidescan data

mode = 0: no data are flagged or zeroed

mode = 1 : min and max indicate start and end beam/pixel numbers between which data are flagged or zeroed

mode = 2 : min and max indicate start and end acrosstrack distance (m) between which data are flagged or zeroed

mode = 3: min and max indicate minimumn and platform speed (km/hr) between which data are flagged or zeroed

BATHCUTNUMBER min max

adds new bathymetry data cutting command where min and max are the start and end beam numbers between which data are flagged (note that flagging bathymetry also flags amplitude data)

BATHCUTDISTANCE min max

adds new bathymetry data cutting command where min and max are the start and end acrosstrack distance (m) between which data are flagged (note that flagging bathymetry also flags amplitude data)

BATHCUTSPEED min max

adds new bathymetry data cutting command where all beams are flagged for pings with a ship or vehicle speed less than min or greater than max (note that flagging bathymetry also flags amplitude data)

AMPCUTNUMBER min max

adds new amplitude data cutting command where min and max are the start and end beam numbers between which amplitude data are zeroed (note that zeroing amplitude data has no impact on bathymetry data)

AMPCUTDISTANCE min max

adds new amplitude data cutting command where min and max are the start and end acrosstrack distance (m) between which amplitude data are zeroed (note that zeroing amplitude data has no impact on bathymetry data)

AMPCUTSPEED min max

adds new amplitude data cutting command where

all amplitude values are zeroed for pings with a ship or vehicle speed less than min or greater than max (note that zeroing amplitude data has no impact on bathymetry data)

SSCUTNUMBER min max

adds new sidescan data cutting command where min and max are the start and end pixel numbers between which sidescan data are zeroed (note that zeroing sidescan data has no impact on bathymetry data)

SSCUTDISTANCE min max

adds new sidescan data cutting command where min and max are the start and end acrosstrack distance (m) between which sidescan data are zeroed (note that zeroing sidescan data has no impact on bathymetry data)

SSCUTSPEED min max

adds new sidescan data cutting command where all sidescan values are zeroed for pings with a ship or vehicle speed less than min or greater than max (note that zeroing sidescan data has no impact on bathymetry data)

BATHYMETRY EDITING:

EDITSAVEMODE boolean

turns on reading edit save file (from mbedit) [0]

EDITSAVEFILE filename

sets edit save file path (from mbedit) [none]

BATHYMETRY RECALCULATION:

SVPMODE mode

sets usage of a water sound speed model (sound velocity profile, or SVP) [0]

- 0: bathymetry recalculation by raytracing off
- 1: bathymetry recalculation by raytracing on
- 2: translate depths from corrected to uncorrected or vice versa depending on SOUNDSPEEDREF command

SVPFILE filename

sets SVP file path [no default]

SSVMODE boolean

sets surface sound velocity (SSV) mode [0]

0: use SSV from file

- 1: offset SSV from file (set by SSV command)
- 2: use constant SSV (set by SSV command)

SSV constant/offset

sets SSV value or offset (m/s) [1500.0]

ANGLEMODE mode

sets handling of beam angles during raytracing [1]

0: angles not changed before raytracing

1: angles adjusted using Snell's Law for the difference between the surface sound velocity (SSV) and the sound speed at the sonar depth in the SVP.

2: angles adjusted using Snell's Law and the sonar array geometry for the difference between the surface sound velocity (SSV) and the sound speed at the sonar depth in the SVP.

TTMULTIPLY multiplier

sets value multiplied by travel times [1.0]

SOUNDSPEEDREF boolean

determines the handling of the sound speed reference for bathymetry [1]

- note: if raytracing is turned off then this command implies correcting or uncorrecting using the SVP specified with the SVPFILE command
- 0: produce "uncorrected" bathymetry referenced to a uniform 1500 m/s water sound speed model.
- 1: produce "corrected" bathymetry referenced to a realistic water sound speed model.

STATIC BEAM BATHYMETRY OFFSETS:

STATICMODE mode

sets offsetting of bathymetry by per-beam statics [0]

0: static correction off

- 1: static correction by beam number
- 2: static correction by acrosstrack beam angle

STATICFILE filename

sets static per-beam file path [no default]

- static files are two-column ascii tables
- if correction is by beam number then
 the beam # is in column 1 and
 the depth offset is in m in column 2
- if correction is by beam angle then the beam angle (starboard positive) is in column 1 and the depth offset is in m in column 2

DRAFT CORRECTION:

DRAFTMODE mode

sets draft correction [0]

- note: draft merged from navigation before draft correction applied
- 0: no draft correction
- 1: draft correction by offset
- 2: draft correction by multiply
- 3: draft correction by offset and multiply
- 4: draft set to constant

DRAFT constant

sets draft value (m) [0.0]

DRAFTOFFSET offset

sets value added to draft (m) [0.0]

DRAFTMULTIPLY multiplier

sets value multiplied by draft [1.0]

HEAVE CORRECTION:

HEAVEMODE mode

sets heave correction [0]

 note: heave correction by offset and/or multiplication is added to any lever heave correction, and then either used in bathymetry recalculation or added to existing bathymetry

0: no heave correction

- 1: heave correction by offset
- 2: heave correction by multiply
- 3: heave correction by offset and multiply

HEAVEOFFSET offset

sets value added to heave (m)

HEAVEMULTIPLY multiplier

sets value multiplied by heave

LEVER CORRECTION:

LEVERMODE mode

sets heave correction by lever calculation [0]

 note: lever heave correction is added to any heave correction by offset and/or multiplication, and then either used in bathymetry recalculation or added to existing bathymetry

0: no lever calculation

1: heave correction by lever calculation

VRUOFFSETX constant

sets athwartships offset of attitude sensor (m)

note: positive to starboard

VRUOFFSETY constant

sets fore-aft offset of attitude sensor (m)

- note: positive forward

VRUOFFSETZ constant

sets vertical offset of attitude sensor (m)

- note: positive down

SONAROFFSETX constant

sets athwartships offset of sonar receive array (m)

- note: positive to starboard

SONAROFFSETY constant

sets fore-aft offset of sonar receive array (m)

- note: positive forward

SONAROFFSETZ constant

sets vertical offset of sonar receive array (m)

- note: positive down

ROLL CORRECTION:

ROLLBIASMODE mode

sets roll correction [0]

0: no roll correction

1: roll correction by single roll bias

2: roll correction by separate port and starboard roll bias

ROLLBIAS offset

sets roll bias (degrees)

ROLLBIASPORT offset

sets port roll bias (degrees)

ROLLBIASSTBD offset

sets starboard roll bias (degrees)

PITCH CORRECTION:

PITCHBIASMODE mode

sets pitch correction [0]

0: no pitch correction

1: pitch correction by pitch bias

PITCHBIAS offset

sets pitch bias (degrees)

HEADING CORRECTION:

HEADINGMODE mode

sets heading correction [no heading correction]

- note: heading merged from navigation before heading correction applied
- 0: no heading correction
- 1: heading correction using course made good
- 2: heading correction by offset
- 3: heading correction using course made good and offset

HEADINGOFFSET offset

sets value added to heading (degrees)

TIDE CORRECTION:

TIDEMODE mode

sets tide correction [0]

- note: tide added to bathymetry after all other calculations and corrections
- 0: tide correction off
- 1: tide correction on

TIDEFILE filename

sets tide file path

TIDEFORMAT constan

sets tide file format [1]

- tide files can be in one of four ASCII table formats
- 1: format is <time_d tide>
- 2: format is <yr mon day hour min sec tide>
- 3: format is <yr jday hour min sec tide>
- 4: format is <yr jday daymin sec tide>
- time d = decimal seconds since 1/1/1970
- daymin = decimal minutes start of day

AMPLITUDE CORRECTION:

AMPCORRMODE boolean

sets correction of amplitude for

amplitude vs grazing angle function

0: amplitude correction off

1: amplitude correction on

AMPCORRFILE filename

sets amplitude correction file path

[no default]

AMPCORRTYPE mode

sets sidescan correction type [0]

0: correction by subtraction (dB scale)

1: correction by division (linear scale)

AMPCORRSYMMETRY boolean

forces correction function to be symmetric [1]

AMPCORRANGLE constant

sets amplitude correction reference angle (deg) [30.0]

AMPCORRSLOPE mode

sets amplitude correction slope mode [0]

- 0: local slope ignored in calculating correction
- 1: local slope used in calculating correction
- 2: topography grid used in calculating correction but slope ignored
- 3: local slope from topography grid used in calculating correction

SIDESCAN CORRECTION:

SSCORRMODE boolean

sets correction of sidescan for

amplitude vs grazing angle function

0: sidescan correction off

1: sidescan correction on

SSCORRFILE filename

sets sidescan correction file path

[no default]

SSCORRTYPE mode

sets sidescan correction type [0]

0: correction by subtraction (dB scale)

1: correction by division (linear scale)

SSCORRSYMMETRY boolean

forces correction function to be symmetric [1]

SSCORRANGLE constant

sets sidescan correction reference angle (deg) [30.0]

SSCORRSLOPE mode

sets sidescan correction slope mode [0]

- 0: local slope ignored in calculating correction
- 1: local slope used in calculating correction
- 2: topography grid used in calculating correction but slope ignored
- 3: local slope from topography grid used in calculating correction

AMPSSCORRTOPOFILE

Sets topography grid used for correcting amplitude and sidescan

SIDESCAN RECALCULATION:

SSRECALCMODE boolean

sets recalculation of sidescan for

Simrad multibeam data

0: sidescan recalculation off

1: sidescan recalculation on

SSPIXELSIZE constant

sets recalculated sidescan pixel size (m) [0.0]

- a zero value causes the pixel size to

be recalculated for every data record

SSSWATHWIDTH constant

sets sidescan swath width (degrees) [0.0]

- a zero value causes the swath width

to be recalculated for every data record

SSINTERPOLATE constant

sets sidescan interpolation distance (number of pixels)

METADATA INSERTION:

METAVESSEL string

sets mbinfo metadata string for vessel

METAINSTITUTION string

sets mbinfo metadata string for vessel operator institution or company

METAPLATFORM string

sets mbinfo metadata string for sonar platform (ship or vehicle)

METASONAR string

sets mbinfo metadata string for sonar model name

METASONARVERSION string

sets mbinfo metadata string for sonar version (usually software version)

METACRUISEID string

sets mbinfo metadata string for institutional cruise id

METACRUISENAME string

sets mbinfo metadata string for descriptive cruise name

METAPI string

sets mbinfo metadata string for principal investigator

METAPIINSTITUTION string

sets mbinfo metadata string for principal investigator

METACLIENT string

sets mbinfo metadata string fo data owner (usually PI institution)

METASVCORRECTED boolean

sets mbinfo metadata boolean for sound velocity corrected depths

METATIDECORRECTED boolean

sets mbinfo metadata boolean for tide corrected bathymetry

METABATHEDITMANUAL boolean

sets mbinfo metadata boolean for manually edited bathymetry

METABATHEDITAUTO boolean

sets mbinfo metadata boolean for automatically edited bathymetry

METAROLLBIAS constant

sets mbinfo metadata constant for roll bias (degrees + to starboard)

METAPITCHBIAS constant

sets mbinfo metadata constant for pitch bias

(degrees + forward)

METAHEADINGBIAS constant

sets mbinfo metadata constant for heading bias

METADRAFT constant

sets mbinfo metadata constant for vessel draft (m)

PROCESSING KLUGES:

KLUGE001 boolean

enables correction of travel times in Hydrosweep DS2 data from the R/V Maurice Ewing in 2001 and 2002.

KLUGE002 boolean

enables correction of draft values in

Simrad data

- some Simrad multibeam data has had an error in which the heave has bee added to the sonar depth (draft for hull mounted sonars)
- this correction subtracts the heave value from the sonar depth

KLUGE003 boolean

enables correction of beam angles in

SeaBeam 2112 data

- a data sample from the SeaBeam 2112 on the USCG Icebreaker Healy (collected on 23 July 2003) was found to have an error in which the beam angles had 0.25 times the roll added
- this correction subtracts 0.25 * roll from the beam angles before the bathymetry is recalculated by raytracing through a water sound velocity profile
- the mbprocess parameter files must be set to enable bathymetry recalculation by raytracing in order to apply this correction

KLUGE004 boolean

deletes survey data associated with duplicate or reversed time tags

 if survey data records are encountered with time tags less than or equal to the last good time tag, an error is set and the data record is not output to the processed data file.

KLUGE005 boolean

replaces survey record timestamps with timestamps of corresponding merged navigation records

 this feature allows users to fix timestamp errors using MBnavedit and then insert the corrected timestamps into processed data

KLUGE006 boolean

changes sonar depth / draft values without changing bathymetry values

KLUGE007 boolean

processing kluge 007 (not yet defined)

- occasionaly odd processing problems will occur that are specific to a particular survey or sonar version
- mbprocess will allow one-time fixes to be defined as "kluges" that can be turned on through the parameter files.

ANCILLARY DATA FILES

MB-System also uses a number of ancillary data files, most of which relate to **mbprocess** in some way. By default, these ancillary data files are named by adding a short suffix to the primary data file name (e.g. ".par", ".svp", ".esf", ".nve")

The common ancillary files are listed below. The example names given here follow from an input swath data file name of mydata.mb71.

The processing parameter file used by **mbprocess** has an ".par" suffix. These files are generated or modified by **mbset**, **mbedit**, **mbnavedit**, **mbnavedit**, **mbnavedit**, and **mbclean**.

mydata.mb71.par

The most prominent ancillary files are metadata or "inf" files (created from the output of **mbinfo**). Programs such as **mbgrid** and **mbm_plot** try to check "inf" files to see if the corresponding data files include data within desired areas. The program **mbprocess** automatically generates an "inf" file for any processed output swath file. Also, the program **mbdatalist** is often used to create or update "inf" files for large groups of swath data files.

mydata.mb71.inf mydata.mb71.inf

The "fast bath" or "fbt" files are generated by copying the swath bathymetry to a sparse, quickly read format (format 71). Programs such as **mbgrid**, **mbswath**, and **mbcontour** will try to read "fbt" files instead of the full data files whenever only bathymetry information are required. The program **mbprocess** automatically generates an "fbt" file for any processed output swath file. Also, the program **mbdatalist** is often used to create or update "fbt" files for large groups of swath data files. These files are not generated or used when the original swath data is already in a compact bathymetry-only data format.

mydata.mb71.fbt

The "fast nav" or "fnv" files are just ASCII lists of navigation generated using **mblist** with a **–O***tMXYHSc* option. Programs such as **mbgrid**, **mbswath**, and **mbcontour** will try to read "fnv" files instead of the full data files whenever only navigation information are required. These files are not generated or used when the original data is already in a single-beam or navigation data format.

mydata.mb71.fnv

The bathymetry edit save file generated by **mbedit** and **mbclean** has an ".esf" suffix. mydata.mb71.esf

A water sound velocity profile (SVP) file generated by **mbvelocitytool** has an ".svp" suffix unless the user specifies otherwise.

```
mydata.mb71.svp
```

Water sound velocity profile (SVP) files generated by **mbsvplist** also use the ".svp" suffix. However, multiple SVP files may be extracted from each input swath file, so the files are numbered using a "_YYY.svp" suffix, where YYY increments from 001.

```
mydata.mb71_001.svp
mydata.mb71_002.svp
mydata.mb71_003.svp
```

Edited navigation files generated by mbnavedit have an ".nve" suffix:

```
mydata.mb71.nve
```

These navigation files can be read independently using format 166.

Adjusted navigation files generated by **mbnavadjust** have an ".naY" suffix, where "Y" is a number between 0-9. The**mbna vadjust** package may be used multiple times for a survey; the adjustments are numbered sequentially from "0":

```
mydata.mb71.na0
mydata.mb71.na1
mydata.mb71.na2
```

and so on. These navigation files can be read independently using format 166.

MB-SYSTEM AUTHORSHIP

David W. Caress
Monterey Bay Aquarium Research Institute
Dale N. Chayes
Center for Coastal and Ocean Mapping
University of New Hampshire
Christian do Santos Ferreira
MARUM - Center for Marine Environmental Sciences
University of Bremen

OPTIONS

 $-\mathbf{E}$

This option causes **mbset** to require all processing modes to be explicitly set by **-P** calls. Normally, **mbset** will implicitly set some modes based on the parameters applied. For example, if a user applies **-P**SVPFILE:best.svp, **mbset** would normally set the bathymetry recalculation mode on so that the SVP file specified actually gets used.

−**I** infile

Swath data file for which an **mbprocess** parameter file will be created or updated, or a datalist file containing a list of input swath data files and/or other datalist files. If *infile* is a datalist file, then **mbset** will attempt to update or create the parameter files for all swath data files identified by recursively reading *infile*. Default *infile*: datalist.mb-1

 $-\mathbf{L}$

If given once, this option causes **mbset** to look for any edit save files and navigation files with expected names and set the **mbprocess** parameters so that these files are used. If multiple navigation files are available (reflecting use of **mbnavedit** and one or more uses of **mbnavadjust**), then the latest (highest numbered) **mbnavadjust** solution is used. If **–L** is given twice, **mbset** will also look for any SVP files with expected names and set the **mbprocess** parameters so that these files

are used for recalculating bathymetry by raytracing. If multiple SVP files are available (reflecting use of **mbsvplist** and **mbvelocitytool**), then the file derived from **mbvelocitytool** is used. If **–L** is given three times or more, then **mbset** will not look for any ancillary files, but instead reset the paths to all output files to be "local", meaning located in the same directory as the input file. This special option allows users to fix parameter files containing full paths for output files (as generated by early versions of this program).

- **–H** This "help" flag causes the program to print out a description of its operation and then exit immediately.
- **PARAMETER:** value The **-P** option of **mbset** is used to modify a single **mbprocess** parameter command. Here *PARAMETER* may be any of the processing parameter names listed above, and *value* is the corresponding value to be set. This option can be invoked as many times as desired on the command line, allowing **mbset** to set multiple **mbprocess** processing parameters and modes. The separater between *PARAMETER* and *value* can be either ':' or '='. Only the first ':' or '=' acts as a separater; later instances of these characters are taken as part of *value*.
- -V Normally, mbset works "silently" without outputting anything to the stderr stream. If the −V flag is given, then mbset works in a "verbose" mode and outputs the program version being used and lists the processing parameters output to the mbprocess parameter file.

EXAMPLES

NAVSHIFT 0

Suppose the user has a Simrad EM120 data file called "0051_20010829_223755.mb57" that requires processing.

Editing the bathymetry data in this file with mbedit will generate an edit save file "0051_20010829_223755.mb57.esf" and an mbprocess parameter file "0051_20010829_223755.mb57.par". The contents of the parameter file are:

```
## MB-System processing parameter file
## Written by mb_pr_writepar version $Id$
## MB-system Version 5.0.beta22
## Generated by user <caress> on cpu <menard> at <Fri Sep 6 21:27:41 2002>
##
##
## Forces explicit reading of parameter modes.
EXPLICIT
##
## General Parameters:
FORMAT 57
INFILE /data/0051_20010829_223755.mb57
OUTFILE /data/0051_20010829_223755p.mb57
##
## Navigation Merging:
NAVMODE 0
NAVFILE /data/0051_20010829_223755.mb57.nve
NAVFORMAT 0
NAVHEADING 0
NAVSPEED 0
NAVDRAFT 0
NAVATTITUDE 0
NAVINTERP 0
NAVTIMESHIFT 0.000000
## Navigation Offsets and Shifts:
```

NAVOFFSETX 0.000000

NAVOFFSETY 0.000000

NAVOFFSETZ 0.000000

NAVSHIFTLON 0.000000

NAVSHIFTLAT 0.000000

##

Adjusted Navigation Merging:

NAVADJMODE 0

NAVADJFILE

NAVADJINTERP 0

##

Attitude Merging:

ATTITUDEMODE 0

ATTITUDEFILE

ATTITUDEFORMAT 1

##

Sonardepth Merging:

SONARDEPTHMODE 0

SONARDEPTHFILE

SONARDEPTHFORMAT 1

##

Data cutting:

DATACUTCLEAR

##

Bathymetry Flagging:

EDITSAVEMODE 1

EDITSAVEFILE /data/0051_20010829_223755.mb57.esf

##

Bathymetry Recalculation:

SVPMODE 0

SVPFILE

SSVMODE 0

SSV 0.000000

TTMODE 0

TTMULTIPLY 1.000000

ANGLEMODE 0

SOUNDSPEEDREF 1

##

Draft Correction:

DRAFTMODE 0

DRAFT 0.000000

DRAFTOFFSET 0.000000

DRAFTMULTIPLY 1.000000

##

Heave Correction:

HEAVEMODE 0

HEAVEOFFSET 0.000000

HEAVEMULTIPLY 1.000000

##

Lever Correction:

LEVERMODE 0

VRUOFFSETX 0.000000

VRUOFFSETY 0.000000

VRUOFFSETZ 0.000000

SONAROFFSETX 0.000000

SONAROFFSETY 0.000000

SONAROFFSETZ 0.000000

##

Roll Correction:

ROLLBIASMODE 0

ROLLBIAS 0.000000

ROLLBIASPORT 0.000000

ROLLBIASSTBD 0.000000

##

Pitch Correction:

PITCHBIASMODE 0

PITCHBIAS 0.000000

##

Heading Correction:

HEADINGMODE 0

HEADINGOFFSET 0.000000

##

Tide Correction:

TIDEMODE 0

TIDEFILE

TIDEFORMAT 1

##

Amplitude Correction:

AMPCORRMODE 0

AMPCORRFILE

AMPCORRTYPE 0

AMPCORRSYMMETRY 1

AMPCORRANGLE 30.000000

AMPCORRSLOPE 0

##

Sidescan Correction:

SSCORRMODE 0

SSCORRFILE

SSCORRTYPE 0

SSCORRSYMMETRY 1

SSCORRANGLE 30.000000

SSCORRSLOPE 0

##

Sidescan Recalculation:

SSRECALCMODE 0

SSPIXELSIZE 0.000000

SSSWATHWIDTH 0.000000

SSINTERPOLATE 0

##

Metadata Insertion:

METAVESSEL

METAINSTITUTION

METAPLATFORM

METASONAR

METASONARVERSION

METACRUISEID

METACRUISENAME

METAPI

METAPIINSTITUTION
METACLIENT
METASVCORRECTED -1
METATIDECORRECTED -1
METABATHEDITMANUAL -1
METABATHEDITAUTO -1
METAROLLBIAS 0.000000
METAPITCHBIAS 0.000000
METAHEADINGBIAS 0.000000
METADRAFT 0.000000
##
Processing Kluges:

Editing the navigation with mbnavedit will generate a navigation file named " $0051_20010829_223755.mb57.nve$ " and will modify the parameter file. The changed lines in " $0051_20010829_223755.mb57.par$ " are:

```
## Navigation Merging:
NAVMODE 1
NAVFILE /data/0051_20010829_223755.mb57.nve
NAVFORMAT 9
NAVHEADING 1
NAVSPEED 1
NAVDRAFT 1
NAVATTITUDE 1
```

At this point, running **mbprocess** on "0051_20010829_223755.mb57" will apply the bathymetry flags from **mbedit** and merge the navigation from **mbnavedit**, but will not modify the data in any other way.

If the user wants to recalculate the bathymetry using an SVP file " $0051_20010829_223755.mb57.svp$ " and a roll bias correction of +0.5 degrees, the following will suffice:

The affected lines in "0051_20010829_223755.mb57.par" are:

```
## ## Bathymetry Recalculation:
SVPMODE 1
SVPFILE 0051_20010829_223755.mb57.svp
SSVMODE 0
SSV 0.000000
TTMODE 0
TTMULTIPLY 1.000000
ANGLEMODE 0
SOUNDSPEEDREF 1
## ## Draft Correction:
DRAFTMODE 4
DRAFT 1.950000
DRAFTOFFSET 0.0000000
DRAFTMULTIPLY 1.0000000
##
```

Roll Correction:
ROLLBIASMODE 1
ROLLBIAS 0.500000
ROLLBIASPORT 0.000000
ROLLBIASSTBD 0.000000

To process the data, run mbprocess:

```
mbprocess -I0051_20010829_223755.mb57 -V
```

The output to the terminal is: Program mbprocess MB-System Version 5.0.beta07

Program <mbprocess> MB-system Version 5.0.beta07

Program Operation:

Input file: 0051_20010829_223755.mb57

Format: 57

Files processed only if out of date. Comments embedded in output.

Data processed – out of date:

Input: 0051_20010829_223755.mb57 Output: 0051_20010829_223755p.mb57

Input and Output Files:

Format: 57

Input file: 0051_20010829_223755.mb57 Output file: 0051_20010829_223755p.mb57

Comments in output: ON

Navigation Merging:

Navigation merged from navigation file. Heading merged from navigation file. Speed merged from navigation file. Draft merged from navigation file.

Navigation file: 0051_20010829_223755.mb57.nve

Navigation algorithm: linear interpolation

Navigation time shift: 0.000000

Navigation Offsets and Shifts:

Navigation positions not shifted.

Adjusted Navigation Merging:

Navigation not merged from adjusted navigation file.

Adjusted navigation file:

Adjusted navigation algorithm: linear interpolation

Data Cutting:

Data cutting disabled.

Bathymetry Editing:

Bathymetry edits applied from file.

Bathymetry edit file: 0051_20010829_223755.mb57.esf

Bathymetry Recalculation:

Bathymetry recalculated by raytracing.

SVP file: 0051_20010829_223755.mb57.svp

SSV not modified.

SSV offset/constant: 0.000000 m/s Travel time multiplier: 1.000000 m

Bathymetry Water Sound Speed Reference:

Output bathymetry reference: CORRECTED

Depths recalculated as corrected

Draft Correction:

Draft set to constant.

Draft constant: 1.950000 m
Draft offset: 0.000000 m
Draft multiplier: 1.000000 m

Heave Correction:

Heave not modified.

Heave offset: 0.000000 m Heave multiplier: 1.000000 m

Lever Correction:

Lever calculation off.

Tide Correction:

Tide calculation off.

Roll Correction:

Roll offset by bias.

Roll bias: 0.500000 deg
Port roll bias: 0.000000 deg
Starboard roll bias: 0.000000 deg

Pitch Correction:

Pitch not modified.

Pitch bias: 0.000000 deg

Heading Correction:

Heading not modified.

Heading offset: 0.000000 deg

Amplitude Corrections:

Amplitude correction off.

Sidescan Corrections:

Sidescan correction off.

Sidescan Recalculation:

Sidescan not recalculated.

Sidescan pixel size: 0.000000

Sidescan swath width: 0.000000

Sidescan interpolation: 0

Metadata Insertion:
Metadata vessel:
Metadata institution:
Metadata platform:
Metadata sonar:

Metadata sonarversion: Metadata cruiseid: Metadata cruisename:

Metadata pi:

Metadata piinstitution:

Metadata client:

-1Metadata svcorrected: -1Metadata tidecorrected Metadata batheditmanual -1Metadata batheditauto: -1Metadata rollbias: 0.000000 Metadata pitchbias: 0.000000 Metadata headingbias: 0.000000 0.000000Metadata draft:

236 navigation records read

Nav start time: 2001 08 29 22:38:02.082999 Nav end time: 2001 08 29 23:37:22.322000

47 bathymetry edits read

236 input data records 3587 input nav records 17 input comment records 6617 input other records 236 output data records 3587 output nav records 64 output comment records 6617 output other records

Generating inf file for 0051_20010829_223755p.mb57

SEE ALSO

```
\textbf{mbsystem}(1), \textbf{mbprocess}(1), \textbf{mbedit}(1), \textbf{mbnavedit}(1), \textbf{mbvelocitytool}(1)
```

BUGS

Oh yeah...