

Port Forwarding / 端口转发

This class provides an easy way to forward local ports to another host/port. This is useful to provide a way to access Ethernet-connected devices from a computer tethered to the roboRIO USB port. This class acts as a raw TCP port forwarder, this means you can forward connections such as SSH.

这个类提供了一种将本地端口转发到另一台主机 / 另一个端口的简便方法。它使连接到 roboRIO USB 端口的计算机能够访问通过以太网连接的设备。这个类充当原始 TCP 端口转发器，因此可以转发 SSH 等连接。

Forwarding a Remote Port / 转发远程端口

Often teams may wish to connect directly to the roboRIO for controlling their robot. The PortForwarding class ([Java](#)) can be used to forward the Raspberry Pi connection for usage during these times. The PortForwarding class establishes a bridge between the remote and the client. To forward a port in Java, simply do `PortForwarder.add(int port, String remoteName, int remotePort)`.

队伍经常希望直接连接到 roboRIO 来控制机器人。此时，可以使用 PortForwarding 类 ([Java](#)) 转发 Raspberry Pi 的连接。PortForwarding 类在远端与客户端之间建立桥接。要在 Java 中转发端口，只需调用 `PortForwarder.add(int port, String remoteName, int remotePort)`。

```
public Robot() {  
    PortForwarder.add(8888, "wpilibpi.local", 80);  
}
```

Important / 重要

You can not use a port less than 1024 as your local forwarded port. It is also important to note that you can not use full URLs (`http://wpilibpi.local`) and should only use IP Addresses or DNS names.

不能使用小于 1024 的端口作为本地转发端口。还需要注意，不能使用完整 URL (`http://wpilibpi.local`)，只能使用 IP 地址或 DNS 名称。

Removing a Forwarded Port / 移除转发端口

To stop forwarding on a specified port, simply call `remove(int port)` with port being the port number. If you call `remove()` on a port that is not being forwarded, nothing will happen.

要停止指定端口上的转发，只需调用 `remove(int port)`，其中 port 为端口号。如果对未进行转发的端口调用 `remove()`，则不会发生任何操作。

```
public Robot() {  
    PortForwarder.remove(8888);  
}
```