

Фазоры действующих напряжений ветвей приемника

$$U_{12} = \dot{U}_1 \dot{U}_2 = -2 \text{ 17 } \angle 137^\circ 4' = 8 \text{ 66 } \angle 54^\circ 7'$$

$$U_{23} = \dot{U}_2 \dot{U}_3 = 4 \text{ 084 } (\angle -2 \text{ 17 } \angle 137^\circ) = 5 \text{ 59 } \angle 8^\circ 84'$$

$$U_{34} = \dot{U}_3 \dot{U}_4 = 7 \text{ 0 } (\angle -2 \text{ 17 } \angle 137^\circ) = -0 \text{ 70}$$

$$U_{45} = \dot{U}_4 \dot{U}_5 = -2 \text{ 12 } \angle 0^\circ 05' \quad \angle -31^\circ 8' \angle 0^\circ 77'$$

$$U_{56} = \dot{U}_5 \dot{U}_6 = 2 \text{ 1991 } (\angle -2 \text{ 12 } \angle 0^\circ 05') = 1 \text{ 19 } \angle 46^\circ 62'$$

$$U_{67} = \dot{U}_6 \dot{U}_7 = 2 \text{ 12 } \angle 73^\circ 2' (\angle -2 \text{ 12 } \angle 0^\circ 05') = 0 \text{ 65 } \angle 26^\circ 99'$$

$$U_{78} = \dot{U}_7 \dot{U}_8 = -0 \text{ 05 } \angle 42^\circ 14' = -0 \text{ 64 } \angle 19^\circ 87'$$

$$U_{89} = \dot{U}_8 \dot{U}_9 = 8 \text{ 4558 } (\angle -0 \text{ 05 } \angle 42^\circ) = 4 \text{ 906 } \angle 1^\circ 58'$$

$$U_{97} = \dot{U}_9 \dot{U}_7 = 5 \text{ 6847 } (-0 \text{ 05 } \angle 42^\circ) = 8 \text{ 069 } \angle 2^\circ 6'$$