
LIGHTLY-MANAGED SWITCH

SKS3200-4E2X

Web Management Manual

Version V1.0

June 2024

Revision Record: 2024-06-01 · V1.0 · First edition

Table of Contents

1 Preface	4
1.1 Intended Readers	4
1.2 Conventions Used in This Manual	4
2 Logging In to the Web Page	5
2.1 Logging In to the Web Management Client	5
2.2 Client Interface Layout	5
2.3 Web Interface Navigation Tree	5
3 Home	7
4 Switch Monitoring	8
4.1 MAC Address Table	8
4.2 Port Statistics	8
5 Switch Settings	10
5.1 Port Settings	10
5.2 Port Mirroring	10
5.3 Port Isolation	10
5.4 Port Rate Limiting	11
5.5 Port Aggregation	11
5.6 Static MAC	12
6 VLAN Settings	13
6.1 VLAN Settings	13
6.2 Port VLAN	13
7 Loop Settings	15
7.1 Loop Protocol	15
7.2 STP Global	15
7.3 STP Port	16
8 QoS Settings	17
8.1 Port to Queue	18
8.2 Queue Weight	18
9 Advanced Settings	19
9.1 DHCP Snooping	19
9.2 Storm Control	19
9.3 IGMP Settings	20
9.4 Jumbo Frames	20
10 System Management	21
10.1 IP Settings	21
10.2 Login Settings	21
10.3 Device Reboot	21
10.4 Save Configuration	21
10.5 Backup & Restore Configuration	22

10.6 System Upgrade..... 22

10.7 Restore Factory Settings..... 22

1 Preface

1.1 Intended Readers

This manual is intended for installers and system administrators who are responsible for installing, configuring, or maintaining networks. It assumes that you understand all the transmission and management protocols used in your network.

This manual also assumes that you are familiar with the terminology, theoretical principles, practical skills, and specialized knowledge of networking devices, protocols, and interfaces. You must also have working experience with graphical user interfaces, command-line interfaces, the Simple Network Management Protocol (SNMP), and web browsers.

1.2 Conventions Used in This Manual

This manual uses the following conventions.

GUI Convention	Description
① Note	Describes the operation content and provides necessary supplements and explanations.
 Caution	Reminds you of items that require attention during operation. Improper operation may cause data loss or device damage.

2 Logging In to the Web Page

2.1 Logging In to the Web Management Client

Open a web browser, enter the switch's default address `http://192.168.10.12`, and press Enter.

Note: Supported browsers: IE 9.0 or later, Chrome 23.0 or later, Firefox 20.0 or later.

When logging in to the switch, make sure the PC's IP address is in the same network segment as the switch. For first-time login, set the PC's IP address to `192.168.10.x` (where x is 1–254, excluding 1 and 12) and the subnet mask to `255.255.255.0`. The PC's IP address must not be the same as the switch's, i.e. it cannot be `192.168.10.12`.

The login window then appears. Enter the default username `admin` and password `admin`, then click the <Login> button to view the switch system information.

Login Parameter	Value
Default address	<code>http://192.168.10.12</code>
Default username	<code>admin</code>
Default password	<code>admin</code>
PC IP address	<code>192.168.10.x</code> ($x = 1\text{--}254$, excluding 1 and 12)
Subnet mask	<code>255.255.255.0</code>

2.2 Client Interface Layout

The typical operating interface of the web management system consists of a navigation tree on the left and a main work area on the right showing device information and port status. (See the screenshot in the original manual.)

2.3 Web Interface Navigation Tree

The web management menu mainly provides menu items such as System, Configuration, Security, Diagnostics, and Tools. Each menu item contains submenus. The detailed navigation tree is as follows:

Menu Item	Submenu	Description
Home	—	Configure the device name and view device information and port status
Switch Monitoring	MAC Address Table	View MAC address information
	Port Statistics	View port status and data statistics
Switch Settings	Port Settings	Configure and view device port information
	Port Mirroring	Configure and view port mirroring

Menu Item	Submenu	Description
	Port Isolation	Configure and view port isolation
	Port Rate Limiting	Configure and view port rate limits
	Port Aggregation	Configure and view link aggregation
	Static MAC	Configure and view static MAC addresses on ports
VLAN Settings	VLAN Settings	Configure and view port VLANs
	Port VLAN	Configure and view port type, PVID, and allowed VLANs
Loop Settings	Loop Protocol	Configure and view loop detection
	STP Global	Configure and view global spanning tree information
	STP Port	Configure and view spanning tree port information
QoS Settings	Port to Queue	Configure and view port queues
	Queue Weight	Configure and view queue weights
Advanced Settings	DHCP Snooping	Configure and view DHCP snooping on ports
	Storm Control	Configure and view storm suppression information
	IGMP Settings	Configure and view IGMP snooping
	Jumbo Frames	Configure and view port jumbo frames
System Management	IP Settings	Configure and view the device's management IP address
	Login Settings	Configure the account and password
	Device Reboot	Reboot the system
	Save Configuration	Save the changed configuration
	Backup & Restore Configuration	Back up and update the device configuration file
	System Upgrade	Update and upgrade the device software version
	Restore Factory Settings	Reset the system and restore factory settings

3 Home

Based on the connected switch, the Home page intuitively displays the information of each port on the switch's front panel together with product information, including: product model, firmware version, IP address, MAC address, and so on.

Procedure:

1. Click "Home" in the navigation tree to enter the device information and port status view page.

4 Switch Monitoring

4.1 MAC Address Table

The main function of an Ethernet switch is to forward packets at the data link layer, that is, to output packets to the corresponding port according to the packet's destination MAC address. The MAC address forwarding table is a Layer 2 forwarding table containing the mapping between MAC addresses and forwarding ports; it is the basis on which an Ethernet switch achieves fast Layer 2 packet forwarding.

Each entry in the MAC address forwarding table contains the following information:

- Destination MAC address
- VLAN ID to which the port belongs
- Number of the outgoing forwarding port on this device

When forwarding packets, the Ethernet switch adopts one of the following two forwarding methods based on the MAC address table entries:

- Unicast: When the MAC address forwarding table contains an entry matching the packet's destination MAC address, the switch sends the packet directly out of the forwarding port specified in that entry.
- Broadcast: When the switch receives a packet whose destination address is all Fs, or the MAC address forwarding table contains no entry matching the packet's destination MAC address, the switch broadcasts the packet to all ports except the receiving port.

On this page, you can view MAC address table information. To adapt to network changes, the MAC address table needs to be updated constantly. Entries automatically generated in the MAC address table are not valid forever; each entry has a lifetime. Entries that are not refreshed by the end of their lifetime are deleted. This lifetime is called the aging time. If an entry is refreshed before its lifetime expires, its aging time is recalculated.

Procedure:

1. Click "Switch Monitoring > MAC Address Table" in the navigation tree to enter the page.

 **Caution:** During the waiting period of a MAC lookup, communication with the device will be interrupted.

4.2 Port Statistics

Query port statistics information.

Procedure:

1. Click "Switch Monitoring > Port Statistics" in the navigation tree to enter the port data statistics page.

The meanings of the page items are shown in the table below.

Query Item	Description
Port	Port list
Status	Port status
Link Status	Port link status
TX Packets	Number of correctly sent packets
RX Packets	Number of correctly received packets
TX Bytes	Statistics of normally sent packets
RX Bytes	Statistics of normally received packets

5 Switch Settings

5.1 Port Settings

Query and configure Ethernet ports.

Procedure:

1. Click "Switch Settings > Port Settings" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Status	Port on/off switch
Speed/Duplex	Port speed and duplex mode
Flow Control	Flow control on/off switch

5.2 Port Mirroring

Port mirroring copies the packets of the switch's source mirror port to the mirror destination port. The mirror destination port is usually connected to a data-monitoring device, which users employ to analyze the packets received on the source mirror port for network monitoring and troubleshooting.

Procedure:

1. Click "Switch Settings > Port Mirroring" in the navigation tree to enter the page.

Configuration Item	Description
Mirror Group	Only one mirror group is supported
Source Mirror Port	Only one ordinary physical port can be selected, excluding link aggregation ports and the source port
Mirror Direction	Enable or disable port mirroring; supports inbound, outbound, and both directions
Mirror Destination Port	Only one ordinary physical port can be selected, excluding link aggregation ports and the source port
Mirror Port List	List of mirror source ports

5.3 Port Isolation

Sometimes traffic between ports does not need to communicate with each other, but broadcast and multicast packets flood between all ports. In this case, the port isolation function can be used to isolate packets between ports.

Procedure:

1. Click "Switch Settings > Port Isolation" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Port	Port list
Port Isolation List	The ports to which packets from the corresponding port are allowed to be forwarded

5.4 Port Rate Limiting

Configuring port rate limiting means limiting the rate at which a physical interface sends data outward. Before traffic leaves a port, rate limiting is configured in the port's outbound direction to control all outgoing packet traffic.

Procedure:

1. Click "Switch Settings > Port Rate Limiting" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Port	Port list
Ingress Rate Limit	Ingress rate limit value, range: 1 to 2500M
Egress Rate Limit	Egress rate limit value, range: 1 to 10000M

5.5 Port Aggregation

Link aggregation is a method of bundling a group of physical interfaces together as one logical interface to increase bandwidth and reliability.

A Link Aggregation Group (LAG) refers to a logical link formed by bundling several Ethernet links together, abbreviated as Eth-Trunk.

As network scales continue to expand, users place ever higher requirements on link bandwidth and reliability. In traditional technology, bandwidth is commonly increased by replacing interface boards with higher-speed ones or replacing devices that support higher-speed interface boards, but this approach is expensive and inflexible.

Link aggregation technology can increase link bandwidth without hardware upgrades by bundling multiple physical interfaces into one logical interface. The backup mechanism of link aggregation can effectively improve reliability and, at the same time, achieve load sharing of traffic across different physical links.

For example, when SwitchA and SwitchB are connected by three Ethernet physical links and these three links are bundled together, they become one Eth-Trunk logical link whose bandwidth equals the total bandwidth of the original three Ethernet physical links, thereby increasing link bandwidth. At the same time, the three Ethernet physical links back each other up, effectively improving link reliability.

Procedure:

1. Click "Switch Settings > Port Aggregation" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Aggregation Group	A maximum of 2 groups are supported
Type	The aggregation type can be Static or LACP
Port	Member ports of the aggregation group; up to 4 members are supported

5.6 Static MAC

Static entries are manually configured by the user and delivered to each interface board; these entries do not age out. This settings page can also filter on source and destination MAC addresses; once configured, the filtering takes effect on all ports.

Procedure:

1. Click "Switch Settings > Static MAC" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
MAC	MAC address, e.g. FF:FF:FF:FF:FF:FF
VLAN ID	The specified VLAN
Port	List of ports bound to the static MAC

6 VLAN Settings

The composition of a VLAN is not restricted by physical location, so hosts in the same VLAN do not need to be placed in the same physical space. A VLAN divides one physical LAN into multiple logical LANs, and each VLAN is a broadcast domain. Hosts within a VLAN can exchange packets through traditional Ethernet communication, while hosts in different VLANs must communicate through network-layer devices such as routers or Layer 3 switches.

Compared with traditional Ethernet, VLANs have the following advantages:

- **Controlled broadcast domain scope:** Broadcast packets in the LAN are confined within a VLAN, saving bandwidth and improving network processing capacity.
- **Enhanced LAN security:** Because packets are isolated at the data link layer by the broadcast domains created by VLAN division, hosts in different VLANs cannot communicate directly; packets must be forwarded at Layer 3 by network-layer devices such as routers or Layer 3 switches.
- **Flexible creation of virtual workgroups:** VLANs can create virtual workgroups that span physical network boundaries. When users move physically within the scope of the virtual workgroup, they can access the network normally without changing the network configuration.

This managed switch supports port-based VLANs.

6.1 VLAN Settings

On this settings page, you can choose whether to enable VLANs and add new VLANs.

Procedure:

1. Click "VLAN Settings > VLAN Settings" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
VLAN ID	The port's default VLAN
VLAN Remark	VLAN name description

6.2 Port VLAN

On this page, you can configure the corresponding port type, VLAN ID, and the VLANs allowed to intercommunicate for each port.

Procedure:

1. Click "VLAN Settings > Port VLAN" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Port	The port to be configured
Port Type	Port type: Access or Trunk
Access VLAN	The VLAN ID when the port is of Access type
Native VLAN	The VLAN ID when the port is of Trunk type
Allowed VLAN	The VLAN IDs allowed to pass when the port is of Trunk type

7 Loop Settings

7.1 Loop Protocol

The device confirms whether a loop exists by sending loop detection packets and checking whether they return to the device (the receiving and sending ports are not required to be the same port). If a port receives a loop detection packet sent by this device, the link on that port is determined to have a loop. When a loop appears in the network, the corresponding port LED will blink as an alarm (when loop avoidance is enabled, the loop will be blocked), to inform the network administrator that a loop exists on that port.

Procedure:

1. Click "Loop Settings > Loop Protocol" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Loop Function	Off, Loop Detection, Spanning Tree

7.2 STP Global

The Rapid Spanning Tree Protocol (RSTP) is used to eliminate physical loops at the data link layer in a LAN; its core is the rapid spanning tree algorithm. RSTP is fully backward compatible with STP. In addition to having the same loop-avoidance and dynamic redundant-link management functions as the traditional STP protocol, RSTP greatly shortens topology convergence time. Under ideal network topology scales, when all switching devices support RSTP and are properly configured, the time to restore stability after a topology change (link UP/DOWN) can be controlled within seconds. The main functions of RSTP can be summarized as follows:

- Discover and generate an optimal tree topology for the LAN.
- Detect topology failures and recover from them, automatically updating the network topology and enabling backup links while maintaining the optimal tree structure.

Procedure:

1. Click "Loop Settings > STP Global" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Version	Configure and view the STP mode
Max Age	Configure and view the maximum aging time
Hello Time	Configure and view the hello time
Forward Delay	Configure and view the forwarding delay time

7.3 STP Port

Procedure:

1. Click "Loop Settings > STP Port" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Path Cost	Configure and view the port path cost
Priority	Configure and view the port priority
Point-to-Point	Configure and view P2P
Edge	Configure and view edge ports

8 QoS Settings

QoS (Quality of Service) is used to evaluate the ability of a service provider to meet customer service requirements. On the Internet, QoS evaluates the network's ability to deliver packets. Since the services provided by a network are diverse, evaluation can be based on different aspects. QoS as commonly referred to is the evaluation of the service capability that supports core requirements such as bandwidth, delay, delay jitter, and packet loss rate during packet delivery.

- Bandwidth, also called throughput, indicates the average rate of a traffic flow within a certain period, usually measured in Kbit/s.
- Delay indicates the average time required for a traffic flow to traverse the network. For a device in the network, the delay requirement is generally understood as several levels. For example, with two delay levels, a priority-queue scheduling method allows high-priority traffic to be served as quickly as possible, while low-priority traffic is served only when there is no high-priority traffic waiting.
- Delay jitter indicates the variation in the time it takes a traffic flow to traverse the network.
- Packet loss rate indicates the proportion of packets lost during transmission. Because modern transmission systems are highly reliable, information loss usually occurs when the network is congested; the most common case is packet loss caused by queue overflow.

In traditional IP networks, all packets are treated equally without distinction. Each network device processes all packets using a first-in, first-out policy and makes its best effort (Best-Effort) to deliver packets to their destination, but provides no guarantee for performance such as reliability or transmission delay.

Networks are developing rapidly. As new applications keep emerging on IP networks, new requirements are placed on IP network service quality. For example, delay-sensitive services such as VoIP and video impose higher requirements on packet transmission delay; if the delay is too long, it will be unacceptable to users. To support voice, video, and data services with different service requirements, the network needs to distinguish different service types and then provide corresponding services for them.

The best-effort service of traditional IP networks cannot identify and distinguish the various service types in the network, while the ability to distinguish service types is the prerequisite for providing differentiated services. Therefore, the best-effort service model of traditional networks can no longer meet application needs. QoS technology emerged to solve this problem. QoS can regulate network traffic, avoid and manage network congestion, and reduce the packet loss rate. It also supports providing dedicated bandwidth for users and different service quality for different services, improving the network's service capability.

Different packets use different QoS priorities. For example, VLAN packets use 802.1p, also called the CoS (Class of Service) field, while IP packets use DSCP. When packets traverse different networks, in order to preserve packet priority, the mapping relationships between these priority fields must be configured on the gateways connecting the networks.

802.1p priority in the VLAN frame header

Layer 2 devices usually exchange VLAN frames. According to the IEEE 802.1Q definition, the PRI field in the VLAN frame header (i.e. the 802.1p priority), also called the CoS (Class of Service) field,

identifies the quality-of-service requirement. The 802.1Q header contains a 3-bit PRI field, which defines 8 service priority classes (CoS), valued from high to low priority as 7, 6, ..., 1, and 0.

IP Precedence / DSCP field

As defined in RFC 791, the ToS (Type of Service) field of the IP packet header consists of 8 bits, of which the 3-bit Precedence field identifies the priority of the IP packet.

Bits 0–2 represent the Precedence field, representing 8 priority levels for packet transmission, valued from high to low priority as 7, 6, ..., 1, and 0. The highest priorities, 7 and 6, are often reserved for routing or network-control communication updates; user-level applications can only use levels 0–5. In addition to the Precedence field, the ToS field also includes the D, T, and R bits: the D bit indicates the delay requirement (Delay, 0 for normal delay, 1 for low delay); the T bit indicates throughput (Throughput, 0 for normal throughput, 1 for high throughput); the R bit indicates reliability (Reliability, 0 for normal reliability, 1 for high reliability). Bits 6 and 7 of the ToS field are reserved.

RFC 1349 redefined the ToS field of IP packets, adding the C bit to indicate transmission cost (Monetary Cost). Later, the IETF DiffServ working group redefined bits 0–5 of the IPv4 ToS field as the DSCP in RFC 2474 and renamed the ToS field to the DS (Differentiated Services) byte. The first 6 bits (bits 0–5) of the DS field serve as the Differentiated Services Code Point (DSCP), and the upper 2 bits (bits 6 and 7) are reserved. The lower 3 bits (bits 0–2) of the DS field are the Class Selector Code Point (CSCP); the same CSCP value represents one class of DSCP. The DS node selects the corresponding PHB (Per-Hop Behavior) according to the DSCP value.

8.1 Port to Queue

Set processing priorities for different markings of data frames.

Procedure:

1. Click "QoS Settings > Port to Queue" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Queue	Range 1–8

8.2 Queue Weight

When the weight is Strict Priority, it is equivalent to SP; when the weight is a value from 1 to 15, it is equivalent to WRR (Weighted Round Robin scheduling algorithm).

Procedure:

1. Click "QoS Settings > Queue Weight" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Weight	Strict Priority by default; weight range 1–15

9 Advanced Settings

9.1 DHCP Snooping

DHCP snooping is a security feature of DHCP (Dynamic Host Configuration Protocol) used to ensure that DHCP clients obtain IP addresses from legitimate DHCP servers and to record the mapping between DHCP client IP addresses and MAC addresses and other parameters, preventing DHCP attacks on the network.

Procedure:

1. Click "Advanced Settings > DHCP Snooping" in the navigation tree to enter the page.

Configuration Item	Description
DHCP Snooping Switch	Enable or disable DHCP snooping
Trusted Ports	Set the ports that do not need to be snooped

9.2 Storm Control

Storm control prevents broadcast storms caused by broadcast, unknown multicast, and unknown unicast packets in the following way. The device supports storm control by packet rate for each of these three packet types on an interface. Within a detection interval, the device monitors the average rate of the three packet types received on the interface and compares it with the configured maximum threshold. When the packet rate exceeds the configured maximum threshold, the device performs storm control on the interface and executes the configured storm control action.

When a Layer 2 Ethernet interface on the device receives broadcast, multicast, or unknown unicast packets, if the device cannot determine the outgoing interface based on the packet's destination MAC address, it forwards these packets to all other Layer 2 Ethernet interfaces in the same VLAN (Virtual Local Area Network), which may cause a broadcast storm and degrade the device's forwarding performance.

Introducing the storm suppression feature can control the traffic of these three packet types and prevent broadcast storms.

Procedure:

1. Click "Advanced Settings > Storm Control" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Port	Port list
Broadcast Rate	Configure the broadcast transmission rate
Known Multicast Rate	Configure the known multicast transmission rate
Unknown Unicast Rate	Configure the unknown unicast transmission rate

Configuration Item	Description
Unknown Multicast Rate	Configure the unknown multicast transmission rate
Restore Defaults	Restore the factory default settings

9.3 IGMP Settings

IGMP snooping (Internet Group Management Protocol Snooping) is a multicast constraint mechanism running on Layer 2 devices, used to manage and control multicast groups.

A Layer 2 device running IGMP snooping analyzes the received IGMP packets to establish mappings between ports and MAC multicast addresses, and forwards multicast data according to these mappings.

When the Layer 2 device is not running IGMP snooping, multicast data is broadcast at Layer 2. After the Layer 2 device runs IGMP snooping, multicast data of known multicast groups is no longer broadcast at Layer 2 but is multicast at Layer 2 to the designated receivers; however, unknown multicast data is still broadcast at Layer 2.

Procedure:

1. Click "Advanced Settings > IGMP Settings" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
IGMP Switch	Enable or disable IGMP snooping
IGMP Table	Query IGMP group information

9.4 Jumbo Frames

Jumbo frames, also known as large frames, are Ethernet frames whose payload exceeds the 1500-byte limit of the IEEE 802.3 standard. This page sets the port's maximum transmission unit (MTU).

Procedure:

1. Click "Advanced Settings > Jumbo Frames" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Jumbo Frame Fragmentation	Enable or disable jumbo frame fragmentation
Fragment Size	Set the port MTU

10 System Management

10.1 IP Settings

Configure and view the device's management IP address.

Procedure:

1. Click "System Management > IP Settings" in the navigation tree to enter the IP settings page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Access Method	Static IP: fixed IP address access. Dynamic IP: DHCP access / automatically obtain an IP address
IP Address	Management IP address
Subnet Mask	IP address mask
Default Gateway	Gateway of the IP address

10.2 Login Settings

Users can check and modify the switch's current username and password.

Procedure:

1. Click "System Management > Login Settings" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Username	Account name
New Password	Account password
Confirm New Password	Re-enter the account password

10.3 Device Reboot

Reboot the device.

Procedure:

1. Click "System Management > Device Reboot" in the navigation tree to enter the page.

10.4 Save Configuration

Save the configuration.

Procedure:

1. Click "System Management > Save Configuration" in the navigation tree to enter the page.

10.5 Backup & Restore Configuration

Upgrade and back up the system configuration file.

Procedure:

1. Click "System Management > Backup & Restore Configuration" in the navigation tree to enter the page.

The meanings of the page items are shown in the table below.

Configuration Item	Description
Backup Configuration	Back up the configuration file
Restore Configuration	Upload a configuration file

 **Caution:** After uploading a configuration, a reboot is required for it to take effect.

10.6 System Upgrade

Upgrade the system version. After clicking Upgrade, the device enters upgrade mode; after the page redirects to the upgrade page, select Confirm.

Procedure:

1. Click "System Management > System Upgrade" in the navigation tree to enter the page.

 **Caution:** After clicking Confirm, do not power off the device during the upgrade. Stay on the upgrade page and wait approximately 1 minute for the upgrade to complete.

10.7 Restore Factory Settings

The system will restore the factory configuration.

Procedure:

1. Click "System Management > Restore Factory Settings" in the navigation tree to enter the page.

Click Restore to restore the factory settings.