To enter the "PHONE" mode, press the off-hook switch.

■ **Making a phone call**

● Dialing by selecting a name

● Speed dialing

● Dialing by entering the number

● Dialing from call histories

■ **Receiving a phone call**

● Answering the phone

● Refusing the call

■ **Operations during a call**

● Transferring a call

● Muting your voice

● Inputting digits

● Setting call volume

■ **Adjusting the ringtone volume when receiving a call**

## Dialing by selecting a name

STEP 1 Select "Phonebook" using ^{ENTER-LIST
TUNE-SCROLL} ⊚ .

STEP 2 Select the desired name using ^{ENTER-LIST
TUNE-SCROLL} ⊚ and press the off-hook switch.

By pressing ⌷ (Add S. Dial) and one of the speed dial buttons (from ⌷ to ⌷) while the desired name is selected, it can be registered as a speed dial.

Speed dialing

STEP 1 Select "Speed dials" using ^{ENTER-LIST
TUNE-SCROLL} ⊚ .

STEP 2 Press the desired preset button (from ⌷ to ⌷) and press the off-hook switch.

By pressing ⌷ (Add S. Dial) and one of the speed dial buttons (from ⌷ to ⌷) while the desired name is selected, it can be registered as a speed dial.

Dialing by entering the number

STEP 1 Select "Dial by number" using ^{ENTER-LIST
TUNE-SCROLL} ⊚ .

STEP 2 Enter the phone number and press the off-hook switch.

3

Interior features

263

Dialing from call histories

STEP 1 Select "All calls", "Missed calls", "Incoming calls" or "Outgoing

calls" using ⟨ENTER·LIST / TUNE·SCROLL⟩ 🎛.

STEP 2 Select a desired number using ⟨ENTER·LIST / TUNE·SCROLL⟩ 🎛 and press the off-hook
switch.

The following operations can be performed:

● Registering a number as a speed dial

Press ⌷ (Add S. Dial) and then press and hold the desired

preset button (from ⌷ to ⌷).

● Deleting the selected number

Press ⌷ (DELETE) and press ⌷ (YES).

When receiving a phone call

■ Answering the phone
Press the off-hook switch.

■ Refusing the call
Press the on-hook switch.

■ Receiving a call when on another call
Press the off-hook switch.

Pressing the off-hook switch again returns you to the previous call.

Operations during a call

● Transferring a call

A call can be transferred between the cellular phone and system while dialing, receiving a call, or during a call. Use one of the following methods:

a. Operate the cellular phone.

   Refer to the manual that comes with the cellular phone for the operation of the phone.

b. Press the [◦] * (PHONE).

*: This operation can be performed only when transferring a call from the cellular phone to the system during a call.

● Muting your voice

Press [◦] (MUTE).

● Inputting digits

Press [◦] (0-9) and using the ⟲ ENTER·LIST TUNE·SCROLL to input the desired digits.

• To send the input digits press [◦] (SEND).

• When finished, press [◦] (EXIT) to return to the previous screen.

● Setting call volume

Change the call volume using ⟲ ENTER·LIST TUNE·SCROLL .

To decrease the volume: Turn ⟲ ENTER·LIST TUNE·SCROLL counterclockwise.

To increase the volume: Turn ⟲ ENTER·LIST TUNE·SCROLL clockwise.

3

Interior features

265

Adjusting the ringtone volume when receiving a call

Change the ringtone volume using ⊚ .

To decrease the volume: Turn ⊚ counterclockwise.

To increase the volume: Turn ⊚ clockwise.

■ **When talking on the phone**

● Do not talk simultaneously with the other party.

● Keep the volume of the received voice down. Otherwise, voice echo will increase.

■ **Automatic volume adjustment**

When vehicle speed is 50 mph (80 km/h) or more, the volume automatically increases. The volume returns to the previous volume setting when vehicle speed drops to 43 mph (70 km/h) or less.

■ **Phone call system functions**

Depending on the cellular phone, certain functions may not be available.

■ **Situations where the system may not recognize your voice**

● When driving on a rough road

● When driving at high speeds

● When air is blowing out of the vents onto the microphone

● When the air conditioning fan emits a loud noise

Registering a Bluetooth® device in the system allows the system to function. The following functions can be used for registered devices:

■ **Functions and operation procedures**

STEP 1 Press ⌈SETUP⌉ and select "Bluetooth" using ⊙.

STEP 2 Press ⊙ and select one of the following functions using ⊙.

● Registering a Bluetooth® device
"BT Pairing"

● Listing the registered cellular phones
"List Phone"

● Listing the registered portable players
"List Audio"

● Changing the passkey
"Passkey"

● Setting automatic connection of the device on or off
"BT Power"

● Displaying the device status
"Bluetooth info"

● Setting the automatic connection confirmation display to on or off
"Display Setting"

● Initialization
"Initialize"

3

Interior features

267

Registering a portable player

Select "Pairing" using ^{ENTER·LIST
TUNE·SCROLL} ◎ , and perform the procedure for registering a portable player. (→P. 256)

Listing the registered cellular phones

Select "List Phone" using ^{ENTER·LIST
TUNE·SCROLL} ◎ . The list of registered cellular phones will be displayed.

● Connecting the registered cellular phone to the audio system

STEP 1 Select the name of the cellular phone to be connected using ^{ENTER·LIST
TUNE·SCROLL} ◎ .

STEP 2 Select "Select" using ^{ENTER·LIST
TUNE·SCROLL} ◎ .

● Deleting a registered cellular phone

STEP 1 Select the name of the cellular phone to be deleted using ^{ENTER·LIST
TUNE·SCROLL} ◎ .

STEP 2 Select "Delete" using ^{ENTER·LIST
TUNE·SCROLL} ◎ .

STEP 3 Press ☐ (YES).

Listing the registered portable players

Select "List Audio" using ^{ENTER·LIST TUNE·SCROLL} ⓞ . The list of registered portable play-ers will be displayed.

● Connecting the registered portable player to the audio system

STEP 1 Select the name of the portable player to be connected

using ^{ENTER·LIST TUNE·SCROLL} ⓞ .

STEP 2 Select "Select" using ^{ENTER·LIST TUNE·SCROLL} ⓞ .

● Deleting the registered portable player

STEP 1 Select the name of the portable player to be deleted using

^{ENTER·LIST TUNE·SCROLL} ⓞ .

STEP 2 Select "Delete" using ^{ENTER·LIST TUNE·SCROLL} ⓞ .

STEP 3 Press ⬜ (YES).

3

Interior features

269

Changing the passkey

STEP 1 Select "Passkey" using ^{ENTER·LIST} ^{TUNE·SCROLL} ◎ .

STEP 2 Select a 4 to 8-digit passkey using ^{ENTER·LIST} ^{TUNE·SCROLL} ◎ .

Input the number 1 digit at a time.

STEP 3 When the entire number to be registered as a passkey has

been input, press ^{ENTER·LIST} ^{TUNE·SCROLL} ◎ again.

If the passkey to be registered has 8 digits, pressing ^{ENTER·LIST} ^{TUNE·SCROLL} ◎ again
is not necessary.

Setting automatic connection of the device on or off

If "BT Power" is set to on, the registered device will be connected
automatically when the engine switch is turned to the "ACC" position.

STEP 1 Select "BT Power" using ^{ENTER·LIST} ^{TUNE·SCROLL} ◎ .

STEP 2 Select "ON" or "OFF" using ^{ENTER·LIST} ^{TUNE·SCROLL} ◎ .

Displaying the device status

Select "Bluetooth info" using ^{ENTER•LIST}_{TUNE•SCROLL} ⊚ .

● Displaying the device name

Select "Device Name" using ^{ENTER•LIST}_{TUNE•SCROLL} ⊚ .

● Displaying the device address

Select "Device Address" using ^{ENTER•LIST}_{TUNE•SCROLL} ⊚ .

Setting the automatic connection confirmation display to on or off

If the "Display Setting" is set to on, the portable player connection status will be displayed when the engine switch is turned to the "ACC" or "ON" position.

STEP 1 Select "Display Setting" using ^{ENTER•LIST}_{TUNE•SCROLL} ⊚ .

STEP 2 Select "ON" or "OFF" using ^{ENTER•LIST}_{TUNE•SCROLL} ⊚ .

3

Interior features

271

Initialization

Select "Initialize" using _{ENTER·LIST TUNE·SCROLL} ⊙ .

● Initializing the sound settings

Select "Sound setting" using _{ENTER·LIST TUNE·SCROLL} ⊙ and press ⊡ (YES).

For details about sound settings (→P. 242)

● Initializing the device information

Select "Car Device Info" using _{ENTER·LIST TUNE·SCROLL} ⊙ and press ⊡ (YES).

Automatic connection of a portable device, automatic connection confirmation display and the passkey will be initialized.

● Initializing all the settings

Select "All Initialize" using _{ENTER·LIST TUNE·SCROLL} ⊙ and press ⊡ (YES).

■ **The number of Bluetooth® devices that can be registered**

Up to 5 Bluetooth® devices can be registered in the system.

272

Using the "SET UP" menu ("Phone" menu)

■ **Functions and operation procedures**

To enter the menu of each function, press $\boxed{\text{SETUP}}$ and follow

the steps below using $\underset{\text{TUNE-SCROLL}}{\overset{\text{ENTER-LIST}}{\bigcirc}}$:

● Adding a new phone number
1. "Phone" → 2. "Phonebook" → 3. "Add contacts"

● Setting speed dials
1. "Phone" → 2. "Phonebook" → 3. "Add SD"

● Deleting call histories
1. "Phone" → 2. "Phonebook" → 3. "Delete Call History"

● Deleting a registered phone number
1. "Phone" → 2. "Phonebook" → 3. "Delete contacts"

● Deleting another cellular phone's phonebook
1. "Phone" → 2. "Phonebook" → 3. "Delete other PB"

● Setting call volume
1. "Phone" → 2. "HF Sound Setting" → 3. "Call Volume"

● Setting ringtone volume
1. "Phone" → 2. "HF Sound Setting" → 3. "Ringtone Volume"

● Setting ringtone
1. "Phone" → 2. "HF Sound Setting" → 3. "Ringtone"

● Transferring call histories
1. "Phone" → 2. "Transfer Histories"

3

Interior features

Adding a new phone number

Select "Add contacts" using _{ENTER•LIST
TUNE•SCROLL} ⊚ .

● Transferring all contacts from the cellular phone

Select "Overwrite all contacts" using _{ENTER•LIST
TUNE•SCROLL} ⊚ and press ⬚ (YES).

● Transferring one contact from the cellular phone

Select "Add one contact" using _{ENTER•LIST
TUNE•SCROLL} ⊚ and press ⬚ (YES).

Setting speed dials

STEP 1 Select "Add SD" using _{ENTER•LIST
TUNE•SCROLL} ⊚ .

STEP 2 Select the desired data using _{ENTER•LIST
TUNE•SCROLL} ⊚ .

STEP 3 Press and hold the desired preset button (from ⬚ to ⬚).

For details about setting speed dials from the call history: →P. 264

For details about deleting speed dials: →P. 264

Deleting call histories

Select "Delete Call History" using $\underset{\text{TUNE·SCROLL}}{\overset{\text{ENTER·LIST}}{\bigcirc}}$.

● Deleting outgoing call history

STEP 1 Select "Outgoing Calls" using $\underset{\text{TUNE·SCROLL}}{\overset{\text{ENTER·LIST}}{\bigcirc}}$.

STEP 2 Select the desired phone number using $\underset{\text{TUNE·SCROLL}}{\overset{\text{ENTER·LIST}}{\bigcirc}}$ and press ⌐∘⌐ (YES).

To delete all outgoing call history data, press ⌐∘⌐ (ALL) and then press ⌐∘⌐ (YES).

● Deleting incoming call history

STEP 1 Select "Incoming calls" using $\underset{\text{TUNE·SCROLL}}{\overset{\text{ENTER·LIST}}{\bigcirc}}$.

STEP 2 Select the desired phone number using $\underset{\text{TUNE·SCROLL}}{\overset{\text{ENTER·LIST}}{\bigcirc}}$ and press ⌐∘⌐ (YES).

To delete all incoming call history data, press ⌐∘⌐ (ALL) and then press ⌐∘⌐ (YES).

3

Interior features

275

● Deleting missed call history

STEP 1 Select "Missed Calls" using ENTER-LIST TUNE-SCROLL ⃝ .

STEP 2 Select the desired phone number using ENTER-LIST TUNE-SCROLL ⃝ and press
⌷ (YES).

To delete all missed call history data, press ⌷ (ALL) and then

press ⌷ (YES).

● Deleting a number from all call histories (Outgoing calls, Incoming calls and Missed calls)

STEP 1 Select "All Calls" using ENTER-LIST TUNE-SCROLL ⃝ .

STEP 2 Select the desired phone number using ENTER-LIST TUNE-SCROLL ⃝ and press
⌷ (YES).

To delete all of the call histories data, press ⌷ (ALL) and then

press ⌷ (YES).

Deleting a registered phone number

STEP 1 Select "Delete contacts" using ⌗.

STEP 2 Select the desired phone number using ⌗ and press ⌂ (YES).

To delete all of the registered phone numbers, select "All delete" using ⌗ and press ⌂ (YES).

Deleting another cellular phone's phonebook

STEP 1 Select "Delete other PB" using ⌗.

STEP 2 Select the desired phonebook using ⌗ and press ⌂ (YES).

Setting call volume

STEP 1 Select "Call Volume" using ⌗.

STEP 2 Change the call volume.

To decrease the volume: Turn ⌗ counterclockwise.

To increase the volume: Turn ⌗ clockwise.

3

Interior features

277

Setting ringtone volume

STEP 1 Select "Ringtone Volume" using ^{ENTER•LIST TUNE•SCROLL} ⊚ .

STEP 2 Change the ringtone volume.

To decrease the volume: Turn ^{ENTER•LIST TUNE•SCROLL} ⊚ counterclockwise.

To increase the volume: Turn ^{ENTER•LIST TUNE•SCROLL} ⊚ clockwise.

Setting ringtone

STEP 1 Select "Ringtone" using ^{ENTER•LIST TUNE•SCROLL} ⊚ .

STEP 2 Using ^{ENTER•LIST TUNE•SCROLL} ⊚ , select a ringtone (1 - 3). To set the selected

ringtone, press ^{ENTER•LIST TUNE•SCROLL} ⊚ .

Transferring call histories

Select "Transfer Histories" using ^{ENTER•LIST TUNE•SCROLL} ⊚ and press ▭ (YES).

■**Phone number**

Up to 1000 names can be stored.

■**Call history**

Up to 10 numbers can be stored in each of the outgoing, incoming and missed call history memories.

■**Limitation of number of digits**

A phone number that exceeds 24 digits cannot be registered.