
# 2-3. Operating the lights and wipers Headlight switch


## The headlights can be operated manually.

► Type A




- The daytime running lights turn on.
- The side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on.
- The headlights and all lights listed above (except daytime running lights) turn on.

## ► Type B



- The daytime running lights turn on.
- The side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on.
- The headlights and all lights listed above (except daytime running lights) turn on.

## Turning on the high beam headlights



■ With the headlights on, push the lever forward to turn on the high beams.

Pull the lever back to the center position to turn the high beams off.

2 Pull the lever toward you to turn on the high beams.

Release the lever to turn them off. You can flash the high beams with the headlights on or off.

#### ■ Daytime running light system

- To make your vehicle more visible to other drivers, the headlights turn on automatically whenever the engine is started and the parking brake is released.
- Compared to turning on the headlights, the daytime running light system offers greater durability and consumes less electricity, so it can help improve fuel economy.

#### ■ Light reminder buzzer

A buzzer sounds when the engine switch is turned OFF and the driver's door is opened with the key removed from the engine switch while the lights are turned on.


## **⚠** NOTICE

## ■To prevent battery discharge


Do not leave the lights on longer than necessary when the engine is not running.

The fog lights improve visibility in difficult driving conditions, such as in rain or fog. They can be turned on only when the headlights are on low beam.

► Type A




- OFF Off
- Front fog lights on




## Wiper can be operated manually.


## ► Type A



- INT Intermittent windshield wiper operation
- Low speed windshield wiper operation
- High speed windshield wiper operation
- 4 MIST Temporary operation




- Increases the intermittent windshield wiper frequency\*
- Decreases the intermittent windshield wiper frequency\*
- \*: If equipped




## Wash/wipe operation

Wipers operate automatically.


## ▶ Type B



- Intermittent windshield wiper operation
- Low speed windshield wiper operation
- High speed windshield wiper operation
- Temporary operation



- Increases the intermittent windshield wiper frequency\*
- Decreases the intermittent windshield wiper frequency\*
- \*: If equipped



## Wash/wipe operation

Wipers operate automatically.

#### ■ The windshield wipers and washers can be operated when

The engine switch is in the "ON" position.

#### ■ If no windshield washer fluid sprays

Check that the washer nozzles are not blocked and if there is washer fluid in the windshield washer fluid reservoir.

## **↑** NOTICE

## When the windshield is dry

Do not use the wipers, as they may damage the windshield.

## ■ When there is no washer fluid spray from the nozzle


Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually.

#### When a nozzle becomes blocked

Do not try to clear it with a pin or other object. The nozzle will be damaged.

## 2-3. Operating the lights and wipers

## Rear window wiper and washer\*




- INT Intermittent window wiper operation
- Normal window wiper operation
- Washer/wiper dual operation

Wiper operates automatically.

Washer/wiper dual operation

Wiper operates automatically.

## ► Type B



- Intermittent window wiper operation
- Normal window wiper operation
- Washer/wiper dual operation

Wiper operates automatically.

Washer/wiper dual operation

Wiper operates automatically.

## ■ The rear window wiper and washer can be operated when

The engine switch is in "ON".

## ♠ NOTICE

## When the rear window is dry

Do not use the wipers, as they may damage the rear window.

## ■ When there is no washer fluid spray from the nozzle

Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually.

#### When a nozzle becomes blocked

Do not try to clear it with a pin or other object. The nozzle will be damaged.