
cooneo_mini仿真——01

一、原理简介

1、阿克曼转向结构

阿克曼转向是一种现代汽车的转向方式,在汽车转弯的时候,内外轮转过的角度不一样,内侧轮胎 转弯半径小于外侧轮胎,下图就是理想的阿克曼转向。



这种转向方式最初是由的德国马车工程师的Georg Lankensperger 1817年提出,他的代理商 Rudolph Ackerman于1818年在英国申请专利,所以从今往后这个转向原理就叫阿克曼转向几何了。


由上图所示的示意图可知,在保证车辆尽量稳定运行,不漂移、不侧移的前提下。在车辆转弯的时候,后边内侧的轮子的转速必然会小于外侧的轮子。传统汽车是在后轮中间使用了一种机械装置——差速桥,该桥是一个机械式差速装置,在汽车行进的过程中合理分配左右轮转速。

除此之外,前轮的转向角度和后轮的转速也有关系。比如:车辆以最大角度Max_angle转向时,此时后轮内侧的转速应该是**大于0**的。所以结论是:**想要满足车辆行进过程中不漂移,车速和转向角度是有关联关系的**。


2、Gazebo仿真插件

为了便于学习和拓展,需要将该种结构的小车模型置入在Gazebo中仿真。想要在Gazebo中仿真出车体的运动效果,需要如下部件:模型文件(URDF、XACRO)、对应的仿真插件、控制命令。模型文件将在下面一节讲述,这里主要讲使用的仿真插件——**steer_bot_handware_gazebo**。

该仿真插件的功能就是接收外部发布的基于base_link(基座点)的线速度和角速度,然后根据车的尺寸,输出为前轮的转向角度和后轮的转速,示意图如下:




为了能够实现上述的转换,需要在模型上增加两个虚拟的点,分别是后轮中间的:rear_wheel_link/joint和前轮中间的:front_steer_link/joint。(上述的两个虚拟点的名称少了actual,不影响)官方给的示意图如下:



如上图右边所示,两个后轮速度关节接口用作命令接口,用于控制模型在Gazebo中线性运动。其他两个前轮关节只是用作转向。

3、cooneo_mini URDF模型文件

模型示意图与其TF转换树如下:



值得注意的是,两个前轮的"parent_link"并不是base_link,而是另外加的" front_steer_left_link"和"front_steer_right_link"。添加这两个的目的是控制前轮转向,因为在使用 urdf expoter插件时,一个关节只能绕一个轴转动,前轮除了转向以外,还需要滚动,所以添加这两个。

二、模型和仿真插件之间的适配

1、本仿真使用到的ROS package

cooneo_mini: 由Solidworks 2018 软件和 URDF expoter 插件,在原始三维设计图上导出的。导出时需要注意不同Link之间所包含的实体,在solidworks中的命名应该不同,其次,导出模型的过程中应该让计算机有充足的动态内存容量。否则,导出的模型容易错位。


steer_mini_gazebo: 自己创建的用于存放仿真过程中所需的配置文件和启动文件,分别在"config"和"launch"文件夹下。

steer_drive_ros: 使用的阿克曼仿真插件

2、给关节添加动力标签

给cooneo_mini中的原始urdf文件添加关节驱动标签,这样,关节才能在gazebo中动起来。cooneo_mini的各个Link之间的连接关系示意图如下:

带三角符号标识的表示Link之间连接的关节名称



由上图可知,需要给原始最初的模型文件cooneo_mini_rviz.urdf中的部分关节添加动力标签,内容如下:

```
<hardwareInterface>hardware_interface/PositionJointInterface/hardwareInterface
   </actuator>
   <joint name="front_steer_joint">
<hardwareInterface>hardware_interface/PositionJointInterface/hardwareInterface
   </joint>
 </transmission>
 <!-- add trans plugins to steer_joint and steer wheel joint-->
 <transmission name="front_steer_right_joint_trans">
   <type>transmission_interface/SimpleTransmission</type>
   <actuator name="front_steer_right_joint_motor">
     <mechanicalReduction>1</mechanicalReduction>
<hardwareInterface>hardware_interface/PositionJointInterface/hardwareInterface
   </actuator>
   <joint name="front_steer_right_joint">
<hardwareInterface>hardware_interface/PositionJointInterface/hardwareInterface
   </joint>
 </transmission>
 <transmission name="front_right_wheel_joint_trans">
   <type>transmission_interface/SimpleTransmission</type>
   <actuator name="front_right_wheel_joint_motor">
     <mechanicalReduction>1</mechanicalReduction>
<hardwareInterface>hardware_interface/VelocityJointInterface/hardwareInterface
   </actuator>
   <joint name="front_right_wheel_joint">
<hardwareInterface>hardware_interface/VelocityJointInterface</hardwareInterface</pre>
   </joint>
 </transmission>
 <transmission name="front_steer_left_joint_trans">
   <type>transmission_interface/SimpleTransmission</type>
   <actuator name="front steer left joint motor">
     <mechanicalReduction>1</mechanicalReduction>
<hardwareInterface>hardware_interface/PositionJointInterface/hardwareInterface
   </actuator>
   <joint name="front_steer_left_joint">
<hardwareInterface>hardware_interface/PositionJointInterface/hardwareInterface
   </joint>
 </transmission>
```

```
<transmission name="front_left_wheel_joint_trans">
   <type>transmission_interface/SimpleTransmission</type>
   <actuator name="front_left_wheel_joint_motor">
     <mechanicalReduction>1</mechanicalReduction>
<hardwareInterface>hardware_interface/VelocityJointInterface/hardwareInterface
   </actuator>
   <joint name="front_left_wheel_joint">
<hardwareInterface>hardware_interface/VelocityJointInterface/hardwareInterface
   </joint>
 </transmission>
<!-- add trans plugin to rear wheel joint-->
<transmission name="left_rear_joint_trans">
  <type>transmission_interface/SimpleTransmission</type>
   <actuator name="left_rear_joint_motor">
     <mechanicalReduction>1</mechanicalReduction>
<hardwareInterface>hardware_interface/VelocityJointInterface/hardwareInterface
   </actuator>
   <joint name="left_rear_joint">
<hardwareInterface>hardware_interface/VelocityJointInterface/hardwareInterface
   </joint>
 </transmission>
<transmission name="right_rear_joint_trans">
  <type>transmission_interface/SimpleTransmission</type>
   <actuator name="right_rear_joint_motor">
     <mechanicalReduction>1</mechanicalReduction>
<hardwareInterface>hardware_interface/VelocityJointInterface/hardwareInterface
   </actuator>
   <joint name="right_rear_joint">
<hardwareInterface>hardware_interface/VelocityJointInterface/hardwareInterface
   </joint>
 </transmission>
 <!--********************************
 <!-- add gazebo_ros_control plugin -->
 <gazebo>
   <plugin name="gazebo_ros_control" filename="libgazebo_ros_control.so">
     <robotNamespace>/</robotNamespace>
<robotSimType>steer_bot_hardware_gazebo/SteerBotHardwareGazebo</robotSimType>
   </plugin>
 </gazebo>
```

</robot>

解释:

上面的动力标签有两种类型分别如下:


hardware_interface / VelocityJointInterface: 转速的物理仿真插件,四个轮子的类型。

hardware interface /PositionJointInterface: 转向的物理仿真插件,前轮转向节的类型。

如上所述,给相应的关节添加相应的转动标签,然后相应的关节就能在Gazebo中动起来了,这样才能在仿真插件的控制下,实现Gazebo中仿真运动。

细心的你会发现,最后还添加了一个标签,该标签是一个插件,主要的作用就是连通Gazebo和ROS,是它俩的中间件,缺少它,就不能接收ROS下的控制指令。他们之间的关系可如下图:

CIR-KIT-Unit03 Detailed Configuration



3、修改仿真插件的配置文件

经过前面的步骤,我们的模型已经具备在Gazebo中运动的前提条件,现在,我们将利用仿真插件 驱动模型在Gazebo中运动。先查看启动的launch文件

(/steer_mini_gazebo/launch/steer_cooneo_mini_sim.launch),知道需要加载那些配置文件:

```
<?xml version="1.0"?>
<launch>
    <!-- setting the start position of the model -->
```

```
<arg name="x" default="0.0"/>
    <arg name="y" default="0.0"/>
    <arg name="z" default="0.0" />
    <arg name="roll" default="0.0"/>
    <arg name="pitch" default="0.0"/>
    <arg name="yaw" default="0.0"/>
    <!-- load environment into Gazebo -->
    <include file="$(find gazebo_ros)/launch/empty_world.launch" >
        <arg name="world_name" value="$(find</pre>
cooneo_mini)/worlds/cooneo_office.world"/>
    </include>
    <!-- Load the robot description -->
    <param name="robot_description" command=" cat $(find</pre>
cooneo_mini)/urdf/cooneo_mini.urdf"/>
    <!-- Load ros_controllers configuration parameters -->
    <rosparam file="$(find</pre>
steer_mini_gazebo)/config/ctrl_ackermann_steering_controller_mini.yaml"
command="load" />
    <rosparam file="$(find steer_mini_gazebo)/config/ctrl_gains_mini.yaml"</pre>
command="load" />
    <rosparam file="$(find</pre>
steer_mini_gazebo)/config/ctrl_joint_state_publisher_mini.yaml" command="load"
    <rosparam file="$(find</pre>
steer_mini_gazebo)/config/ctrl_steer_bot_hardware_gazebo_mini.yaml"
command="load" />
    <!-- Spawn the controllers -->
    <node pkg="controller_manager" type="spawner" name="controller_spawner"</pre>
        args="joint_state_publisher ackermann_steering_controller"
        output="screen" respawn="false" >
    </node>
    <!-- Launch the robot state publisher -->
    <node name="robot_state_publisher" pkg="robot_state_publisher"</pre>
type="robot_state_publisher">
        <param name="publish_frequency" value="50.0"/>
    </node>
    <!-- Launch a rqt steering GUI for publishing to
steer_drive_controller/cmd_vel -->
    <node pkg="rqt_robot_steering" type="rqt_robot_steering"</pre>
name="rqt_robot_steering" >
        <param name="default_topic"</pre>
value="ackermann_steering_controller/cmd_vel"/>
    </node>
    <!-- Spawn robot in Gazebo -->
    <node name="spawn_vehicle" pkg="gazebo_ros" type="spawn_model" args="-urdf -</pre>
param robot_description -model cooneo_mini -gazebo_namespace /gazebo
              -x \$(arg x) -y \$(arg y) -z \$(arg z)
              -R $(arg roll) -P $(arg pitch) -Y $(arg yaw)"
          respawn="false" output="screen" />
```

由上可见,涉及到的配置文件如下几个:

```
ctrl_ackermann_steering_controller_mini.yaml # 001
ctrl_gains_mini.yaml # 002
ctrl_joint_state_publisher_mini.yaml # 003
ctrl_steer_bot_hardware_gazebo_mini.yaml # 004
```

下面将分别讲述:

(1)ctrl_ackermann_steering_controller_mini.yaml

```
# Configuration for the ackermann_steering_controller.
ackermann_steering_controller:
   type: 'ackermann_steering_controller/AckermannSteeringController'
   # Odometry related
                                   # 里程计发布频率 default: 1.0
   publish_rate: 50
   open_loop: false
   # Joints
   rear_wheel: 'rear_wheel_joint'
   front_steer: 'front_steer_joint'
   # Geometry
   wheel_separation_h: 0.3492 #后轮与前轮的距离
   wheel_radius: 0.0625
                               #车轮半径
   # Odometry calibration and tuning
   wheel_separation_h_multiplier: 1.0 # 乘数应用于车轮分离参数。这用于解决机器人模型与
实际机器人之间的差异(例如,里程计调整) default: 1.0
   wheel_radius_multiplier: 1.0 # 乘数应用于车轮半径参数。这用于解决机器人模型与
实际机器人之间的差异(例如,里程计调整)。 default: 1.0
                                   # 转向位置角度倍增器可进行微调。 default: 1.0
   steer_pos_multiplier: 1.0
   # Odometry covariances for the encoder output of the robot.
   pose_covariance_diagonal: [0.001, 0.001, 0.001, 0.001, 0.001, 0.003]
   twist_covariance_diagonal: [0.001, 0.001, 0.001, 0.001, 0.001, 0.03]
   # Top level frame (link) of the robot description
   base_frame_id: 'base_link'
   # Transform from odom -> base_link
   enable_odom_tf: true
                           #是否直接发布odom --> base_link的tf转换
   odom_frame_id: '/odom'
   # Set to false if the motor driver provides velocity data.
   estimate_velocity_from_position: true
   # Commands
   publish_cmd: true
   allow_multiple_cmd_vel_publishers: false
   # Velocity and acceleration limits for the robot
```

```
linear:
      x:
          has_velocity_limits : true
          max_velocity : 10.0 # m/s
          has_acceleration_limits: true
          max\_acceleration : 2.0 # m/s^2
   angular:
      7:
          has_velocity_limits : true
                       : 3.0 # rad/s
          max_velocity
          has_acceleration_limits: true
          max_acceleration : 3.0 # rad/s^2
   # Other (undocumented but in source code)
   # velocity_rolling_window_size: 10
   # cmd_vel_timeout: 0.5
                         #连续两条速度命令之间允许的时间间隔,超过间隔后
会立即停车
   # Deprecated...
   # publish_wheel_joint_controller_state: false
```

(2)ctrl_gains_mini.yaml

```
# PID gains for the steer_bot_hardware_gazebo plugin.
gains:
    right_rear_joint:
        p: 1000000.0
        d: 10.0
        i: 0.50
        i_clamp: 3.0
left_rear_joint:
        p: 100000.0
        d: 10.0
        i: 0.50
        i_clamp: 3.0
```

$(3) ctrl_joint_state_publisher_mini.yaml$

```
# Configuration for the ros_controllers joint_state_controller.
joint_state_publisher:
    type: "joint_state_controller/JointStateController"
    publish_rate: 50
```

(4)ctrl_steer_bot_hardware_gazebo_mini.yaml

```
# Configuration for the steer_bot_hardware_gazebo plugin.
steer_bot_hardware_gazebo:
 rear_wheel : 'rear_wheel_joint'
                                  #后轮关节名称,用于接收来自
steer_drive_controller的线性驱动命令。
 front_steer : 'front_steer_joint' #前转向接头名称,用于从
steer_drive_controller接收角驱动命令。
 virtual_rear_wheels: ['right_rear_joint', 'left_rear_joint']
                                                                 #虚
拟后轮接头名称,用于向Gazebo的对应的轮接头发送速度指令。
 virtual_front_wheels: ['front_right_wheel_joint','front_left_wheel_joint'] #虚
拟前轮接头名称以掌握Gazebo相应轮接头的当前角度。
 virtual_front_steers: ['front_steer_right_joint', 'front_steer_left_joint'] #虚
拟前转向关节名称,用于向Gazebo中的相应转向关节发送位置命令。
 enable_ackermann_link: true #如果为true,则启用虚拟ackerman链接机制。否
则,将启用paralell链接机制。
                                 #左右两侧的车轮间隔长度,用于计算阿克曼连杆机构
 wheel_separation_h : 0.4035
的转向角。
 wheel_separation_w : 0.3492
                                  #前后轮距,用于计算阿克曼连杆机构的转向角。
```


三、实际运行效果展示

1、将pkg中的功能放入自己的工作空间中编译,source。

```
# 复制 cooneo_mini steer_drive_ros steer_mini_gazebo 进入自己的工作空间/src下,再退
出到根目录下
catkin_make
source devel/setup.bash
```

2、运行

roslaunch steer_mini_gazebo steer_cooneo_mini_sim.launch



3、rostopic list 运行结果是:

```
/ackermann_steering_controller/cmd_vel
/ackermann_steering_controller/odom
/clock
/gains/left_rear_joint/parameter_descriptions
/gains/left_rear_joint/parameter_updates
/gains/right_rear_joint/parameter_descriptions
/gains/right_rear_joint/parameter_updates
/gazebo/link_states
/gazebo/model_states
/gazebo/parameter_descriptions
/gazebo/parameter_updates
/gazebo/set_link_state
/gazebo/set_model_state
/gazebo_gui/parameter_descriptions
/gazebo_gui/parameter_updates
/joint_states
/rosout
/rosout_agg
/tf
/tf_static
```

由此可知,即可接收: "/ackermann_steering_controller/cmd_vel" 话题数据,也可以发布里程计信息:


"/ackermann_steering_controller/odom".

四、拓展

详情见cooneo_mini仿真——02章节

1、添加传感器标签,可以仿真传感器:

```
cd <catkin_workspace>
source devel/setup.bash
roslaunch steer_mini_gazebo steer_cooneo_mini_sensors_sim.launch
```



2、在1的基础上使用算法,建立栅格地图:

cd <catkin_workspace>
source devel/setup.bash
roslaunch steer_mini_gazebo gmapping_steer_cooneo_mini_sensors_sim.launch

