
Document No. 540-1022 October 26, 2016

# **TEC Dual Duct – Two Air Velocity Sensors Controller**



Generic Controller I/O Layout. See Wiring Diagram for application specific details.

## **Control Applications**

2237 and 2238

2267 through 2269

## **Product Description**

These instructions explain how to field install or replace a TEC Dual Duct Controller - Two Air Velocity Sensors.

## **Product Numbers**

TEC Dual Duct Controller - 540-506N Two Air Velocity Sensors

TEC Dual Duct Controller -Two Air Velocity Sensors with Autozero Module 540-507N

that enables space control if the permanent room or duct sensor is not installed (pack of 25).

Duct Temperature Sensor, NTC 100K  $\Omega$  Type 2, 3" Probe for Commissioning Only

Low cost temporary temperature

sensor, 10K thermistor with RJ11,

Shipping carton includes a controller assembly, a mounting rail, and two self-tapping/drilling screws.



#### CAUTION

Keep the unit in its static-proof bag until installation.

Otherwise you run the risk of damage to the printed circuit board from electrostatic discharge.

## **Accessories**

540-658P25

QAM1035.008P50

Item No. 540-1022. Rev. EA Page 1 of 6

Document No. 540-1022 Installation Instructions October 26, 2016

Large Equipment Controllers Enclosure (Long board and ATEC controllers.)

550-002

RJ11 (6 wire) RTS cable in 25 ft, 50 ft, or 100 ft (7.6 m, 15.2 m, 30.48 m)

588-100 series

Autozero Module (included with 540-380 540-507N)

## Warning/Caution Notation



### WARNING

Personal injury/loss of life may occur if you do not follow the procedures as specified.



#### CAUTION

Equipment damage or loss of data may occur if you do not follow the procedures as specified.

## **Expected Installation Time**

New controller installation

10 Minutes

Replacement (old controller has removable terminal blocks)

6 Minutes

Replacement (old controller does not 16 Minutes have removable terminal blocks)



#### NOTE:

You may require additional time for database work at the field panel.

## Required Tools and Materials

- Small flat-blade screwdriver (1/8-inch blade width)
- Cabling and connectors
- Cordless drill/driver set

## **Prerequisites**

- Wiring conforms to NEC and local codes and regulations. For further information see the Wiring Guidelines Manual.
- Room temperature sensor installed (optional).

- 24 Vac Class 2 power available.
- Supply power to the unit is OFF.
- Any application specific hardware or devices installed.
- Air velocity sensors installed in ducts.



If the controller is being installed on a box with 1 or more stages of electric heat, the 550-809 MOV with preterminated spade connectors must be installed across the manufacturersupplied airflow switch. MOVs can be installed at the time the controller is factory mounted; coordinate with the box manufacturer prior to order placement. For field installation, see Metal Oxide Varistor Kit Installation Instructions (540-986).


### Installation Instructions



#### NOTE:

All wiring must conform to national and local codes and regulations (NEC, CE, etc.).

- 1. Secure the mounting rail in the controller's desired location.
- 2. Place the ESD wrist strap on your wrist and attach it to a good earth ground.
- 3. Remove the controller from the static proof bag and snap it into place on the mounting rail.
- Connect the FLN. **3-WIRE FLN TRUNK**




Connect the point wiring (see *Wiring Diagrams*).

Page 2 of 6 Siemens Industry, Inc.

- **6.** Plug the room temperature sensor cable into the RTS port.
- Connect the power trunk. DO NOT apply power to the controller without first consulting the specialist.

#### **POWER TRUNK**







#### NOTE:

As a standard grounding procedure, ensure that a ground wire is connected directly from neutral of the 24Vac secondary (the side that connects to the "C" terminal of the TEC) to earth.

The installation is complete.





## Wiring Diagrams




### ⚠ CAUTION

The controller's DOs control 24 Vac loads only. The maximum rating is 12 VA for each DO. An external interposing relay is required for any of the following:

- VA requirements higher than the maximum
- 110 or 220 Vac requirements
- DC power requirements
- Separate transformers used to power the load.

(for example part number 540-147, Terminal Equipment Controller Relay Module)



Wiring for AI with a 4 to 20 mA Sensor.



#### NOTE:


If the voltage/current switch is set to current and a 4 to 20mA sensor is connected to an AI, then special wiring requirements must be followed.

Siemens Industry, Inc.




#### NOTE:

When wiring any actuator that uses a 0 to 10V control signal and ties AC neutral to DC common, an additional wire **must** connect the actuator AC neutral to the DC common of the PTEC/TEC AO being used to control the actuator.




24 Vac Modulating Control.


Actuator Symbol	TEC Connection	Function	Terminal Connection	Standard Color
1	Н	Supply (SP)	G	Red
2	С	Neutral (SN)	G0	Black
8	AO3 – 15 (+)	0 to 10V	Y	Gray
		input signal		
	C to AO3 16 (-)	Common		
		jumper		



Applications 2237, 2238, 2267, and 2268 with Hot Water Reheat.



Siemens Industry, Inc. Page 5 of 6



Application 2269 – Variable Air Volume with Changeover with Hot Water Reheat.

## Cyber security disclaimer

Products, solutions and services from Siemens include security functions to ensure the secure operation of building automation and control, fire safety, security management, and physical security systems. The security functions on these products, solutions and services are important components of a comprehensive security concept.

Drafting, implementing and managing a comprehensive and up-to-date security concept, customized to individual needs, is nevertheless necessary, and may result in additional plant- or site-specific preventive measures to ensure secure operation of your site regarding building automation and control, fire safety, security management, and physical security. These measures may include, for example, separating networks, physically protecting system components, user training, multi-level defensive measures, etc. For additional information on security as part of building technology and our product, solution and service offerings, please contact your Siemens sales representative or project department. We strongly recommend to always comply with our security advisories on the latest security threats, patches and other related measures. http://www.siemens.com/cert/en/certsecurity-advisories.htm

Information in this document is based on specifications believed correct at the time of publication. The right is reserved to make changes as design improvements are introduced. Product or company names mentioned herein may be the trademarks of their respective owners. © 2016 Siemens Industry, Inc.

Building Technologies Division 1000 Deerfield Parkway Buffalo Grove, IL 60089-4513 USA