D-ATIS 127.45(ARR) 128.65(DEP) TWR(N) 124.3(118.15) TWR(S) 130.45(118.15) GND(N) 121.8(124.3) (Delivery 121.6 (DCL AVBL) GND(S) 121.65(130.45)

## ZLXY XI'AN/Xianyang

Bearing strength (PCN)		
Stands Nr.305-307,316-318,324-330,405-409	86/R/B/W/T	NR.
Stands Nr. 501-509,503L,503R,505L,505R,506L	78/R/B/W/T	Stands
Stands Nr. 201–225, 301–304, 308–315, 319–322, 401–404	71/R/B/W/T	NR.
Stands Nr.331-348,342L,342R,344L,344R,345L, 347L,350,410,415-423,425,601-604,601L,603L,701-711	70/R/B/W/T	Stands
Stands Nr.101-145,126A, 128A	60/R/B/W/T	NR.
		C 1 1

	Usage of pushed-back holding position.						
NR.	PB1	PB2	PB3	PB4	PB5	PB6	PB7
Stands	301	302	303	304	312		310,313
NR.	PB8	PB9	PB10	PB11	PB12	PB13	PB14
Stands	309,314	308,315	322	321	320	319	145
NR.	PB15						
Stands	144,145		_				

PBs in column 1 and 2 are fo	orbidden to use simultaneously
Column 1	Column 2
PB7, PB9	PB8
PB8	PB5, PB6, PB7, PB9
PB1, PB3	PB2, PB4
PB10, PB12	PB11, PB13

- Note: 1. All the stands with PBs shall push to the corresponding push-back points.
  - 2. Aircraft parking on stand Nr.311 shall push to PB6, then tow to PB7
  - to start up; aircraft parking on stand Nr.312 shall push to PB5, then tow
  - to PB7 to start up;
  - 3. Aircraft shall taxi to TWY T8 with idle power from PB

