ZSQD AD 2.1 机场地名代码和名称 Aerodrome location indicator and name

ZSQD-青岛/流亭 QINGDAO/Liuting

ZSQD AD 2.2 机场地理位置和管理资料 Aerodrome geographical and administrative data

1	机场基准点坐标及其在机场的位置 ARP coordinates and site at AD	N36° 15.9' E120° 22.4' Center of RWY		
2	方向、距离 Direction and distance from city	012° GEO, 23km from city center		
3	标高 / 参考气温 Elevation/Reference temperature	10m/30.5° C (JUL)		
4	机场标高位置 / 高程异常 AD ELEV PSN/ geoid undulation	THR35/6.0m		
5	磁差 / 年变率 MAG VAR/Annual change	6° W/-		
6	机场管理部门、地址、电话、传真、 AFS、电子邮箱、网址 AD administration, address, telephone, telefax, AFS, E-mail, website	Qingdao Liuting Airport Authority of CAAC Qingdao Liuting International Airport, Qingdao 266108, Shandong province, China TEL: 86-532-83787050 FAX: 86-532-84715390 E-mail: www.qdairport.com		
7	允许飞行种类 Types of traffic permitted(IFR/VFR)	IFR/VFR		
8	机场性质 / 飞行区指标 Military or civil airport & Reference code	Civil/4E		
9	备注 Remarks	Nil		

ZSQD AD 2.3 工作时间 Operational hours

	1-10-10-10-10-10-10-10-10-10-10-10-10-10		
	机场当局(机场开放时间)		
1	AD Administration (AD operational	H24	
	hours)		
2	海关和移民	H24	
2	Customs and immigration	1124	
3	卫生健康部门	H24	
3	Health and sanitation	1124	
4	航行情报服务讲解室	H24	
+	AIS Briefing Office	1124	
5	空中交通服务报告室	H24	
3	ATS Reporting Office (ARO)	1124	
6	气象讲解室	H24	
0	MET Briefing Office	1124	
7	空中交通服务	H24	
,	ATS	1124	
8	加油	H24	
6	Fuelling		
9	地勤服务	H24	
7	Handling	1124	
10	保安	H24	
10	Security	1124	
11	除冰	H24	
11	De-icing	1124	
12	备注	Nil	
12	Remarks	IVII	

ZSQD AD 2.4 地勤服务和设施 Handling services and facilities

1	货物装卸设施 Cargo-handling facilities	Platform lift (6.8 tones to 27 tones), conveyer belt vehicle, luggage tracto, fork-lift, luggage tray, container pallet, pallet tray, large container pallet		
2	燃油 / 滑油牌号 Fuel/oil types	Nr.3 jet fuel		
3	加油设施 / 能力 Fuelling facilities/capacity	Refueling trucks and pipeline tanker(13 liters-20liters /sec)		
4	除冰设施 De-icing facilities	De-icer, de-icing fluid		
5	过站航空器机库 Hangar space for visiting aircraft	Shandong Airlines Hangar available for two B737-800, no heating facilities; China Eastern Airlines Hangar available for one A300 or two A320, heating facilities available.		
6	过站航空器的维修设施 Repair facilities for visiting aircraft	Line maintenance available for various types of aircraft on request. For shandong airlines: (1) line maintenance: B737-300/700/800, CRJ-200/700, B737-700/800, main undercarriage change available; (2) periodic maintenance: B737-700/800, B737-300, CRJ-200, CRJ-700; (3) equipment for medium periodic maintenance: CRJ-200 and B737-700/800, equipment for engine change: CRJ-700, 737NG; For China Eastern airlines: (1) line maintenance: A330, A320, B737-300 and B737-NG; (2) periodic maintenance: A320; (3) equipment for engine change: A320.		
7	备注 Remarks	Ground power unit, air starting unit, air conditioning unit		

ZSQD AD 2.5 旅客设施 Passenger facilities

1	宾馆 Hotels	At AD
2	餐馆 Restaurants	At AD
3	交通工具 Transportation	Passenger's coaches, taxis, buses
4	医疗设施 Medical facilities	First-aid and 3 ambulances at AD
5	银行和邮局 Bank and Post Office	At AD
6	旅行社 Tourist Office	In the city TEL: 86-532-85720322
7	备注 Remarks	Nil

ZSQD AD 2.6 援救与消防服务 Rescue and fire fighting services

1	1 7	机场消防等级 AD category for fire fighting	CAT 9	
2	2 1	援救设备 Rescue equipment	Fire fighting facilities: rapid intervention vehicle, primary foam tender, heavy-duty foam tender, heavy-duty water tank truck, dry-chemical tender, chemical supply tender, illumination truck, command car. Rescue equipment: hydraulic pressure scissor, air pump, mobile surface operation devices, disassembly rescue truck, logistics truck.	
3	3 (搬移受损航空器的能力 Capability for removal of disabled aircraft	Capability: A320,B737-800 and equivalent Device: mobile pavement, uplift air cushion, sling cart, pulling equipment, tethered equipment, three axle trailer, increased sleepers	
4		备注 Remarks	Nil	

ZSQD AD 2.7 可用季节 - 扫雪 Seasonal availability-clearing

1	扫雪设备类型 Types of clearing equipment	All seasons Snow blowers, snow ploughs, friction coefficient measuring vehicle, spreading car, loading and unloading machine, dumper
2	扫雪顺序 Clearance priorities	RWY, TWY, apron
3	备注 Remarks	Nil

ZSQD AD 2.8 停机坪、滑行道及校正位置数据 Aprons, taxiways and check locations data

	停机坪道面和强度 Apron surface and strength	Surface:	Cement concrete	
1		Strength:	PCN 82/R/B/W/T (Stands Nr.C1, C2, C3, F1, F2) PCN 70/R/B/W/T (Stands Nr. 5-10, 21-23, 25-30, 41-49, C4-C7, G1) PCN 66/R/B/W/T (Stands Nr.50, 51, 53, D1-D7) PCN 56/R/B/W/T (Stands Nr.11-20, 31-38, 52, 60-66,B1-B3) PCN 44/R/B/W/T (Stands Nr.54、54L、54R、55、55L、55R)	
	滑行道宽度、道面和强度 Taxiway width, surface and strength	Width:	69m: A6; 60m:A2; 36m: B(east of main A); 34m: A3,A5,A7, B(west of main A), D(east of main A); 28.5m:A(north and south), C, E, F, G; 25m: A1; 23m: Main A, A8, D(west of main A);	
2		Surface:	Asphalt (A, B(west of main A), C, D(west of main A), E, F, G) Cement concrete (A1-A3, A5-A8, B(east of main A), D(east of main A))	
2		Strength:	PCN 82/R/B/W/T (A2) PCN 77/R/B/W/T (A(north and south), B(west of main A), D(west of main A), G) PCN 71/R/B/W/T (Main A) PCN 70/F/B/W/T (C, E, F) PCN 70/R/B/W/T (A3, A7, B(east of main A), D(east of main A)) PCN 56/R/B/W/T (A5, A6, A8) PCN 52/R/B/W/T (A1)	
3	高度表校正点的位置及其标高 ACL location and elevation	Nil		
4	VOR/INS 校正点 VOR/INS checkpoints	Nil		
5	备注 Remarks	Nil		

ZSQD AD 2.9 地面活动引导和管制系统与标识

Surface movement guidance and control system and markings

1	航空器机位号码标记牌、滑行道引导线、航空器目视停靠/停放位置引导系统的使用 Use of aircraft stand ID signs, TWY guide lines and visual docking/parking guidance system of aircraft stands	Aircraft stand identification sign board at apron. Taxiing guidance signs at all intersections of TWY and RWY and at all holding positions.
---	--	--

		RWY markings	THR, RWY designation, TDZ, center line, center circle, edge line, aiming point	
2	跑道和滑行道标志及灯光	RWY lights	Center line, edge line, THR, RWY end	
	RWY and TWY marking and LGT	TWY markings	Center line, edge line, taxi holding positions	
		TWY lights	Edge line, center line	
3	停止排灯 Stop bars	Nil		
4	备注 Remarks	Blue edge light for apron		

ZSQD AD 2.10 机场障碍物 Aerodrome obstacles

序号	障碍物类型 (*	磁方位	距离	海拔高度	影响的飞行程序及起飞航径区
Serial Nr.	代表有灯光)	BRG	DIST(m)	Elevation(m)	Flight procedure/take-off flight
	Obstacle type	(MAG)(degree)			path area affected
	(*Lighted)				
1	*BLDG	008	4473	59.3	
2	*BLDG	013	4502	60.9	
3	*BLDG	014	5531	62.3	
4	Chimney	017	14536	164.9	
5	BLDG	021	4649	71.7	
6	BLDG	021	4605	71.7	
7	*BLDG	022	4478	67.6	
8	*BLDG	023	4505	66.9	
9	BLDG	026	3767	64.6	
10	BLDG	026	3720	64.6	
11	*BLDG	029	4621	67.8	
12	*BLDG	033	4717	86.8	
13	BLDG	034	3631	69.1	
14	*BLDG	036	4494	67.1	
15	*BLDG	038	4176	72.4	
16	*BLDG	048	4598	59.2	
17	*BLDG	049	4511	56.7	
18	*BLDG	053	3926	63.6	
19	*BLDG	056	4217	65.7	
20	*BLDG	062	4661	81.3	
21	*BLDG	062	3438	60.6	
22	*BLDG	069	2317	61.8	
23	*Light Pole	073	2440	57.2	

序号 Serial Nr.	障碍物类型 (* 代表有灯光) Obstacle type (*Lighted)	磁方位 BRG (MAG)(degree)	距离 DIST(m)	海拔高度 Elevation(m)	影响的飞行程序及起飞航径区 Flight procedure/take-off fligh path area affected
24	*Light Pole	073	2621	58.5	
25	*Light Pole	076	2736	60.0	
26	*Light Pole	076	2557	58.9	
27	*BLDG	076	3270	71.8	
28	*BLDG	078	2283	59.4	
29	*BLDG	078	2347	64.8	
30	BLDG	078	2391	54.9	
31	*BLDG	078	3106	65.6	
32	*BLDG	079	2454	59.8	
33	BLDG	080	2514	54.3	
34	*Control TWR	089	596	69.7	RWY17 ILS/DME missed approach; RWY17 VOR/DME missed approach; RWY35 VOR/DME missed approach;
35	MT	091	14958	564	
36	MT	093	11785	427.6	
37	*BLDG	108	4773	91.7	
38	*TWR	112	4813	80.7	
39	*TWR	112	5056	89.5	
40	*TWR	114	4541	65.8	
41	BLDG	115	9687	438.8	
42	*TWR	115	4595	69.4	
43	MT	119	11538	452.0	
44	*BLDG	120	3157	62.2	
45	MT	123	13802	402.0	
46	*TWR	123	4689	63.1	
47	*BLDG	125	4966	67.8	
48	*BLDG	126	4810	68.0	
49	*TWR	126	4620	64.5	
50	MT	127	13682	277.0	
51	*BLDG	128	4925	66.8	
52	*TWR	129	4570	60.9	
53	*BLDG	130	4705	56.9	
54	*TWR	133	4524	68.3	
55	MT	135	10782	362.0	
56	MT	136	14208	180.0	

序号	障碍物类型 (*	磁方位	距离	海拔高度	影响的飞行程序及起飞航径区
Serial Nr.	代表有灯光)	BRG	DIST(m)	Elevation(m)	Flight procedure/take-off flight
	Obstacle type	(MAG)(degree)			path area affected
	(*Lighted)				
57	*TWR	138	4495	62.2	
58	*BLDG	138	5488	87.5	
59	*BLDG	139	5539	92.7	
60	*BLDG	140	4466	73.4	
61	*TWR	142	6697	251.3	
62	*TWR	142	4501	60.8	
63	MT	144	9737	434.0	
64	*BLDG	145	5005	84.0	
65	*TWR	146	4521	60.9	
66	*BLDG	146	5270	77.5	
67	*BLDG	147	5288	83.0	
68	*BLDG	147	6767	122.8	
69	*TWR	147	4680	69.5	
70	*BLDG	147	6732	122.8	
71	Chimney	147	12321	168.1	
72	*BLDG	148	3596	61.2	
73	*TWR	149	5031	76.2	
74	*TWR	151	5313	76.7	RWY35 VOR/DME final approach
75	MT	160	8400	209.0	RWY17 departure; CAT C/D Circling; RWY35 VOR/DME final approach
76	MT	165	8129	200.0	RWY17 Take-off path; RWY35 GP INOP final approach
77	BLDG	167	9175	118.5	
78	BLDG	168	7096	107.7	RWY17 Take-off path; RWY35 GP INOP final approach
79	Pole	170	2658	24.2	RWY17 Take-off path
80	BLDG	170	9508	114.8	
81	BLDG	172	4752	54.5	RWY35 GP INOP final approach
82	*Antenna	175	1404	25.0	RWY35 ILS/DME final approach
83	Chimney	176	4298	50.5	RWY17 Take-off path
84	*Pole	177	2078	16.8	RWY17 Take-off path
85	Chimney	177	1941	15.1	
86	*Chimney	181	6496	104.8	

序号 Serial Nr.	障碍物类型 (* 代表有灯光) Obstacle type (*Lighted)	磁方位 BRG (MAG)(degree)	距离 DIST(m)	海拔高度 Elevation(m)	影响的飞行程序及起飞航径区 Flight procedure/take-off flight path area affected
87	*Chimney	181	6470	108.5	CAT A/B Circling; RWY35 VOR/DME final approach
88	*Chimney	182	6444	105.1	
89	*Chimney	193	6080	84.1	
90	*Chimney	197	5937	83.4	
91	*BLDG	199	4949	61.4	
92	*BLDG	218	2407	65.4	
93	MT	224	4658	67.1	
94	MT	225	4718	59.2	
95	*BLDG	234	4011	66.2	
96	*BLDG	234	4042	61.7	
97	*Chimney	320	6774	132.5	
98	MT	342	14930	62	
99	*BLDG	345	4989	57.7	RWY17 VOR/DME final approach; RWY17 GP INOP final approach; RWY35 departure; RWY35 Take-off path;
100	*Antenna	345	1394	25.0	RWY17 ILS/DME final approach
101	BLDG	351	2791	29.3	RWY35 Take-off path
102	BLDG	353	4508	52.8	RWY35 Take-off path
103	TWR	353	2987	31.9	RWY35 Take-off path

序号 Serial Nr.	障碍物类型 (* 代表有灯光) Obstacle type (*Lighted)	磁方位 BRG (MAG)(degree)	距离 DIST(m)	海拔高度 Elevation(m)	影响的飞行程序及起飞航径区 Flight procedure/take-off flight path area affected
1	MT	006	15477	211	RWY17 initial approach; RWY17 intermediate approach
2	MT	062	28878	327	
3	MT	072	23665	311	
4	MT	074	15558	329	
5	MT	079	15141	364	
6	MT	084	18164	683	
7	MT	100	15890	514	

序号	障碍物类型 (*	磁方位	距离	海拔高度	影响的飞行程序及起飞航径区
Serial Nr.	代表有灯光)	BRG	DIST(m)	Elevation(m)	Flight procedure/take-off flight
	Obstacle type	(MAG)(degree)			path area affected
	(*Lighted)				
8	MT	101	20783	759	
9	MT	110	18304	601	
10	MT	110	23519	1020	
11	MT	112	19246	691	
12	MT	116	18886	732	
13	MT	119	21930	902	
14	MT	120	24783	1133	
15	MT	127	20099	633	
16	MT	148	15164	224	
17	MT	152	19922	398	
18	MT	171	20282	368	RWY 35 intermediate approach
19	MT	178	19526	207	
20	BLDG	183	22304	255.4	
21	BLDG	185	22375	228.1	
22	BLDG	186	19664	181.0	
23	BLDG	186	22468	249.5	
24	BLDG	187	19401	183.7	
25	BLDG	187	22736	240.0	
26	TWR	192	21989	346.7	
27	Chimney	200	17442	229.0	
28	Chimney	200	17600	229.0	
29	MT	223	42502	725	
30	MT	231	34958	351	
31	MT	235	41578	308	
32	MT	245	48397	208	
33	MT	254	42640	229	
34	MT	265	37700	113	
35	MT	271	40363	113	

ZSQD AD 2.11 提供的气象信息、机场观测与报告

$\label{lem:meteorological} \textbf{Meteorological information provided \& aerodrome observations and reports}$

1	相关气象室的名称 Associated MET Office	Qingdao ATMB MET Observatory
2	气象服务时间、服务时间以外的责任 气象室 Hours of service, MET Office outside hours	H24
3	负责编发 TAF 的办公室,有效期 Office responsible for TAF preparation,Periods of validity	Qingdao ATMB MET Observatory 9 HR, 24 HR
4	着陆预报类型、发布间隔 Type of landing forecast, Interval of issuance	Trend 1 HR
5	所提供的讲解 / 咨询服务 Briefing/consultation provided	P, T, video explain
6	飞行文件及其使用语言 Flight documentation, Languages used	Chart, International MET Codes, Abbreviated Plain Language Text Ch, En
7	讲解 / 咨询服务时可利用的图表和其 它信息 Charts and other information available for briefing or consultation	Synoptic charts, significant weather charts, upper W/T charts, satellite and radar material, AWOS real-time data, numerical forecast product
8	提供信息的辅助设备 Supplementary equipment available for providing information	Fax, web terminal
9	接收气象信息的空中交通服务单位 ATS units provided with information	ACC, APP, TWR
10	观测类型与频率 / 自动观测设备 Type & frequency of observation/ Automatic observation equipment	Hourly plus special observation/Yes
11	气象报告类型及所包含的补充资料 Type of MET Report & supplementary information included	METAR, SPECI, TEND
12	观测系统及位置 Observation System & Site(s)	SFC wind sensors: 17: 110m W of RCL, 326m inward THR17; MID: 110m W of RCL, 1700m inward THR35; 35: 110m W of RCL, 322m inward THR35; RVR EQPT: A: 100m W of RCL, 316m inward THR17; B: 100m W of RCL, 1700m inward THR35; C: 100m W of RCL, 312m inward THR35; C: 100m W of RCL, 312m inward THR35; Ceilometer: 17:106m W of RCL, 334m inward THR17; 35:106m W of RCL, 330m inward THR35;
13	气象观测系统的工作时间 Hours of operation for meteorological observation system	H24
14	气候资料 Climatological information	Climatological tables AVBL
15	其他信息 Additional information	Nil

ZSQD AD 2.12 跑道物理特征 Runway physical characteristics

跑道号码 Designation s RWY NR	真方位和磁方 位 TRUE & MAG BRG	跑道长宽 Dimensions of RWY (m)	跑道强度 (PCN), 跑道 道面 / 停止道道面 RWY strength (PCN), RWY surface/SWY surface	着陆入口坐标及 高程异常 THR coordinates and geoid undulation	跑道着陆入口标高 ,精密进近跑道接 地地带最高标高 THR elevation and highest elevation of TDZ of precision APP RWY
1	2	3	4	5	6
17	165° GEO 171° MAG	3400 × 45	81/R/B/W/T Asphalt	Nil	THR 9.7m
35	345° GEO 351° MAG	3400 × 45	81/R/B/W/T Asphalt	Nil	THR 10.0m
跑道 - 停止 道坡度 Slope of RWY-SWY	停止道长宽 SWY dimensions (m)	净空道长宽 CWY dimensions (m)	升降带长宽 Strip dimensions (m)	无障碍物地带 OFZ	跑道端安全区长宽 RWY end safety area dimensions (m)
7	8	9	10	11	12
See AOC	Nil	Nil	3520 × 300	5320 × 390	230 × 150m
See AOC	Nil	Nil	3520 × 300	5320 × 390	235 × 150m

Remarks: 1. 7.5m RWY shoulder on both sides.

2. Anti-blast pad 60 × 60m.

ZSQD AD 2.13 公布距离 Declared distances

跑道代号 RWY Designator	可用起飞滑跑 距离 TORA (m)	可用起飞距离 TODA (m)	可用加速停止距离 ASDA (m)	可用着陆距离 LDA (m)	备注 Remarks
17	3400	3400	3400	3400	Nil
35	3400	3400	3400	3400	Nil
Remarks:					

ZSQD AD 2.14 进近和跑道灯光 Approach and runway lighting

跑道 代号 RWY Desig nator	进类发展 长强 是 APCH LGT type LEN INTST	入口灯 颜色、 翼排灯 THR LGT colour WBAR	目 想 完 知 所 所 所 的 服 进 指 道 服 进 指 道 服 近 示 元 高 近 所 近 新 近 后 近 后 近 后 近 后 近 后 后 后 后 后 后 后 (MEH 后 (MEH 后 (MEH 后 (MEH 后 (MEH 后 (MEH 后 (MEH 后 (MEH 后 (MEH 后 (MEH 后 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 (MEH 任 () () () () () () () () () (接地地带 灯长度 TDZ LGT LEN	跑道中心线灯 长度、间隔、 颜色、强度 RWY Center line LGT LEN, spacing, colour, INTST	跑道边灯长 度、间隔、颜 色、强度 RWY edge LGT LEN, spacing, colour, INTST	跑道末端 灯颜色 RWY end LGT colour	停止道灯 长度、颜 色 SWY LGT LEN, colour
1	2	3	4	5	6	7	8	9
17	CAT I 900m* LIH	Green Green	PAPI Left/3°	Nil	3400m** spacing 30m	3400m*** spacing 60m	Red	Nil
35	CAT I 720m* LIH	Green Green	PAPI Left/3°	Nil	3400m** spacing 30m	3400m*** spacing 60m	Red	Nil

Remarks: * SFL

ZSQD AD 2.15 其它灯光, 备份电源 Other lighting, secondary power supply

1	机场灯标 / 识别灯标位置、特性和工作时间 ABN/IBN location, characteristics and hours of operation	Nil
2	着陆方向指示器位置和灯光; 风速表位置和灯光 LDI location and LGT, Anemometer location and LGT	Nil
3	滑行道边灯和中心线灯光 TWY edge and center line lighting	Blue edgelines and green centerlines for all TWYs
4	备份电源 / 转换时间 Secondary power supply/switch-over time	Electric supply and diesel generator/10-12 sec UPS standby power for RWY centerline, edge line, THR and end lights
5	备注 Remarks	Nil

ZSQD AD 2.16 直升机着陆区域 Helicopter landing area

1	TLOF 坐标或 FATO 入口坐标及高程异常 Coordinates TLOF or THR of FATO Geoid undulation	Nil
2	TLOF 和 / 或 FATO 标高 (m) TLOF and/or FATO elevation (m)	Nil

^{**} Up to 2500 White LIH, 2500-3100 White/Red LIH, 3100-3400 Red LIH *** Up to 2800 White LIH, 2800-3400 Yellow LIH

3	TLOF 和 FATO 区域范围、道面、强度 和标志 TLOF and FATO area	Nil
4	dimensions,surface, strength, marking FATO 的真方位和磁方位	Nil
4	True and MAG BRG of FATO	IVII
5	公布距离 Declared distance available	Nil
6	进近灯光和 FATO 灯光 APP and FATO lighting	Nil
7	备注 Remarks	Nil

ZSQD AD 2.17 空中交通服务空域 ATS airspace

名称 Designation	横向界限 Lateral limits	垂直界限 Vertical limits	备注 Remarks
Qingdao tower control area	A circuit, 2 arcs with radius 13km&17km centered at THR17&THR35 and 2 parallel lines of 10km FM RWY centerline.	SFC-900m(QNH)	
Fuel Dumping Area	N360000E1211000- N360000E1224500- N351000E1214500- N351000E1211000- N360000E1211000	Above 4000m	
Altimeter setting region and TL/TA	A circle with a radius of 55km centered on Qingdao VOR/DME.	TL 3600m TA 3000m 3300m(QNH ≥ 1031hPa) 2700m(QNH ≤ 979hPa)	

ZSQD AD 2.18 空中交通服务通信设施 ATS communication facilities

服务名称 Service Designation	呼号 Call sign	频率 Frequency (MHz)	工作时间 Hours of operation	备注 Remarks
1	2	3	4	5
ATIS		127.2	H24	D-ATIS available
APP	Qingdao Approach	119.4 (124.6) AP01	H24	Nil
APP	Qingdao Approach	121.15 (124.6) AP02	BY ATC	Nil
APP	Qingdao Approach	119.775 (124.6) AP03	BY ATC	Nil
TWR	Qingdao Tower	118.7(124.3)	H24	Nil
GND	Qingdao	121.65	H24	Nil
GND	Qingdao delivery	121.95	H24	DCL available

ZSQD AD 2.19 无线电导航和着陆设施 Radio navigation and landing aids

设施名称和类型 Name and type of aid	识别 ID	频率 Frequency	发射天线位置、 坐标 Antenna site coordinates	DME 发射天线 标高 Elevation of DME transmitting antenna	备注 Remarks
1	2	3	4	5	6
Xuejiadao VOR/DME	XDX	110.4MHz CH 41X	N35° 58.7′ E120° 17.4′	110m	BTN 43-44NM on R164° at 4200m(enroute) U/S
Qingdao VOR/DME	ТАО	117.5MHz CH 122X	N36° 17.3′ E120° 22.2′ 50m E of RCL,736m FM THR17	18m	
LOC 17 ILS CAT I	INX	110.7MHz	171° MAG/ 295m FM end RWY 17		
GP 17		330.2MHz	120m W of RCL,311m inward FM THR17		Angle 3° RDH 15m
DME 17	INX	CH 44X (110.7MHz)		15m	Co-located with GP17
LOC 35 ILS CAT I	IPP	111.7MHz	351° MAG/ 290m FM end RWY35		Beyond 20° rightside of front course U/S.
GP 35		333.5MHz	120m W of RCL,307m inward FM THR35		Angle 3° RDH 16m
DME 35	IPP	CH 54X (111.7MHz)		15m	Co-located with GP35
Remark:			'	<u>'</u>	<u>'</u>

ZSQD AD 2.20 本场飞行规定

ZSQD AD 2.20 Local traffic regulations

1. 机场使用规定

禁止活塞式发动机的航空器和未安装二次雷达应答机的航空器起降;

- 1.2. 所有技术试飞需事先申请,并在得到空中交通管制部门批准后方可进行;
- 1.3. 可使用最大机型: B747-8及其同类机型。

1. Airport operations regulations

- 1.1. Takeoff/landing of piston-engine aircraft and aircraft without SSR transponder are forbidden;
 - 1.2. Each and every technical test flight shall be filed in advance and shall be made only after clearance has been obtained from ATC;
 - 1.3. Maximum aircraft to be available: B747-8 and equivalent.

2. 跑道和滑行道的使用

2. Use of runways and taxiways

- 2.1. 可以通过地面管制申请引导车和拖车服务;
- 2.2. A2,A3,A5,B,D (A 滑行道以东) 滑行道供翼 展65m以

下航空器使用。每天23:00-15:59 (UTC), D滑行道不提供落地航班脱离跑道使用;

- 2.3. D (A滑行道以西)滑行道供翼展 52 米以下 航空器使用;
- 2.4. A6, A7 滑行道供翼展36米以下航空器使用。
- 2.5. A7滑行道仅供停放于41-51, B1-B3 号机位的 航空器滑出使用;
- 2.6 A8滑行道仅供翼展小于等于29米, 停放在B1-B3 停机位的航空器滑入时使用;
- 2.7 机场冲突多发地带运行要求
- 2.7.1 机动区冲突多发地带位置见AD2.24-1,2;
- 2.7.2 为减少运行差错,降低地面冲突和跑道入侵事件的发生概率,在机场活动区内运行的航空器需严格按照下述的要求运行:

HS1&HS2: 17/35 跑道ILS保护区

使用 17/35 跑道起降时,管制员将指令滑出的航空器在 ILS 保护区等待线外等待,航空器需穿越此区域进入使用跑到前,必须得到塔台管制员的许可:

HS3: 滑行道A2, B, C及交叉区域

从停机坪经滑行道A、B和A2滑出的航空器进入该区域前,注意管制员的等待或者滑行指令;

HS4: 滑行道D及交叉区域

经滑行道A滑行的航空器进入该区域前,注意管制员的等待或者滑行指令;

HS5: 滑行道A6, A7, A8, E及交叉区域

从停机坪经滑行道 A6、 A7滑出的航空器进入该区域前,注意管制员的等待或者滑行指令。沿 A滑行道进入 B1, B2 和 B3 停机位的航空器只能从 A8 进入,滑行时注意观察,避免从 A7 滑行道误入机坪。经滑行道 A 滑行的航空器进入该区域前,注意管制员的等待或者滑行指令;

HS6: 5-7, D2号停机位区域

- 2.1. Follow-me vehicle service and towing service are available via Ground Control;
- 2.2. TWYs A2, A3, A5, B and D (east of TWY A) available for aircraft with wing span less than 65m.Landing aircraft vacate the

RWY from TWY D is forbidden in 23:00-15:59(UTC);

- 2.3. TWY D (west of TWY A) is available for aircraft with wing span less than 52m;
- 2.4. TWY A6 and TWY A7 are available for aircraft with wing span less than 36m.
- 2.5. TWY A7 is only available for aircraft to exit stands Nr. 41-51 and B1-B3:
- 2.6 TWY A8 is only available for aircraft with wing span no more than 29m taxiing in stands Nr. B1-B3 for parking.
- 2.7 Hot spot procedure
- 2.7.1 Refer to AD2.24-1,2;
- 2.7.2 For the purpose of reducing errors that lead to ground conflicts and runway incursions, aircraft operating within the maneuvering area must follow the requirements below:

HS1 & HS2: Runway 17/35 ILS protected area.

Aircraft taxiing from apron will be instructed to hold short of ILS protected area outside RWY holding positions when runway 17/35 is in use. In that case, aircraft shall not proceed beyond RWY holding positions without ATC

clearance;

HS3:Intersections of TWYs A2, B, C

Aircraft exiting out of apron via TWY A, B and A2 shall pay attention to ATC holding or taxiing instructions before entering this area;

HS4: Intersections of TWYs A and D

Aircraft taxiing on main TWY A shall pay attention to ATC holding or taxiing instructions before entering this area;

HS5: Intersections of TWYs A6, A7, A8 and E

Aircraft taxiing out from apron via TWY A6, A7 shall pay attention to ATC instructions for holding or taxiing before entering this area. Aircraft taxiing into stands Nr. B1-B3 via main TWY A shall use TWY A8 only, crew shall pay attention to avoid taxiing into apron from TWY A7 by mistake. Aircraft taxiing via main TWY A shall pay attention to ATC instructions for holding or taxiing before entering this area;

HS6: Area of Stands Nr.5-7, D2

5号和7号停机位主要停放重型机,机场服务车道设置在5号与D2停机位中间。航空器进入该区域前,应注意管制员的等待或者滑行指令,并加强地面观察;

HS7: 16-20号停机位区域

16-20 号机位处于塔台盲区, 所有在该区域运行的航空器应注意管制员的等待或者滑行指令, 并加强地面观察。

Stands Nr.5 and 7 are mainly used for heavy type aircraft. Airport service lane are between stand Nr.5 and 7. Aircraft shall pay attention to ATC holding or taxiing instructions before entering this area and keep observing;

HS7: Area of Stands Nr.16-20

Stands Nr. 16-20 located at Control TWR blind area,. Aircraft shall pay attention to ATC holding or taxiing instructions before entering this area and keep observing.

3. 机坪和机位的使用

- 3.1 航空器地面滑行时,若对人员、设备/设施可能造成损坏或构成威胁时,使用牵引车牵引;
- 3.2 航空器禁止在牵引过程中开车;
- 3.3 无地面人员指挥,禁止航空器自行滑入机位;进入5-23,25-38,41-53,60-66,C1-C7,D1-D7,F1,F2号机位需使用引导车;
- 3.4 发动机试车,需经地面管制许可,并在指定的地点进行。严禁在廊桥附近、客机坪上和滑行道上试大车;
- 3.5 在C1-C7, D1-D7, F1, F2, G1, 5-20, 21, 25, 28-33, 36-38, 52 及53 号机位停放的航空器滑进推出; B1-B3, 22, 23, 26, 27, 34, 35, 41-51,60-66号机位的航空器滑进滑出;
- 3.643号机位不得用于滑行通道;
- 3.7 17-20 号停机位由 A6 道口滑入时沿 L6 线进入 机位; 17-20 号停机位推出时, 禁止头朝东南推出; 使用 52 号和 53 号停机位的航空器, 推出时只能机头朝东推出。

3. Use of aprons and parking stands

- 3.1 If an aircraft may possibly cause injury or constitute a hazard to personnel or equipment around while taxiing on ground surface, a tow tractor shall be used;
- 3.2 Engine start-up is forbidden while towing is in progress;
- 3.3 Aircraft shall not taxi into a parking stand on its own power without guidance of a marshaller; Entering stands Nr.5-23, 25-38, 41-53,60-66,C1-C7,D1-D7,F1,F2 shall be guided by follow-me vehicle;
- 3.4 Engine run-ups are subject to Ground Control clearance, and may only be carried out at a designated location. Fast engine run-ups near boarding bridges, on apron or taxiways are strictly forbidden;
- 3.5 Aircraft parking/docking at stands Nr.C1-C7, D1-D7,
- F1, F2, G1,5-20, 21, 25, 28-33, 36-38, 52 and 53 shall taxi in and be pushed back; Aircraft parking/docking at stands Nr. B1-B3, 22, 23, 26, 27, 34, 35, 41-51, 60-66 shall taxi in and out by itself;
- 3.6 Stand Nr.43 is forbidden to be used as taxi line;
- 3.7 Aircraft shall taxi in stands Nr.17-20 from A6 via L6, aircraft pushed back nose to southeast from 17-20 is forbidden; aircraft only permitted to push back nose to east from 52, 53.
- 3.8 航空器不能同时使用的机位 / Pair of stands forbidden to use simultaneously:

The stand in use	The stands forbidden to be used
Nr.5	Nr.6
Nr.20B	Nr.19 and 20

3.9 机位限制 /Limits for aircraft parking on the following stands:

停机位 /Stands	航空器翼展限制/	机身长度限制 /
デアレログ / Stands	Wing span limits for aircraft	fuselage

Nr.5,7,13,15,C4-C7,F1,F2,G1	65m	75.4m for stands Nr.5,C4,C6,C7,F1,G1; 70.7m for stands Nr.7,13,15,F2; 64m for stand Nr.C5;
Nr.6,8-10,14,16	52m	61.7m for stands Nr.6; 55m for stands Nr.8,10,14,16; 53.7m for stands Nr.9
Nr.12	48m	55m
Nr.11,17-23,25-38,41-55,60-66,C1-C3,D1-D7	36m	55m for stands Nr.17 46m for stands Nr.54,55,C1-C3; 44.6m for stands Nr.11,18-21,25,28-33,36,41- 53,60-63,65-66,D3-D7; 39.5m for stands Nr.22,23,26,27,34,35,37,38,64,D1,D2
Nr. B1, B3	29m	31m
Nr.54L、54R、55L、55R	24m	36.5m
Nr. B2	20m	31m

3.10 相邻机位禁止两架飞机同时运行。

3.11 当 38 机位停靠翼展大于 36m 的航空器时, 38A机位不可使用。当38A机位停放飞机时, 38 机位飞机应使用牵引车向前拖行50m才能启动滑 出。当39B机位停放飞机时, 39A机位飞机应使 用牵引车向前拖行50m才能启动滑出。

3.12 G1 号机位为隔离机位。

3.10 On adjancent parking stands, two aircrafts are forbidden to move.

3.11 Aircraft parking on stand Nr. 38 that wing span limits > 36m, stand Nr.38A U/S. When stand Nr. 38A in use, the aircraft parking at stands Nr. 38 shall move 50m forward by tow-truck before taxi out. When stand Nr. 39B in use, the aircraft parking at stands Nr. 39A shall move 50m forward by tow-truck before taxi out.

3.12 Stand Nr.G1 is isolated stand.

4. 进、离场管制规定

5. 机场的 II/III 类运行

无

无

无

4. Air traffic control regulations

5. CAT II/III operations at AD

Nil

Nil

Nil

6. 除冰规则

6. Rules for deicing

7. 平行跑道同时仪表运行

无

7. Simultaneous operations on parallel runways

Nil

8. 警告

无

8. Warning

Nil

9. 直升机飞行限制, 直升机停靠区

无

9. Helicopter operation restrictions and helicopter parking/docking area

Nil

ZSQD AD 2.21 噪音限制规定及减噪程序

ZSQD AD 2.21 Noise restrictions and Noise abatement procedures

无

Nil

ZSOD AD 2.22 飞行程序

ZSQD AD 2.22 Flight procedures

1. 总则

除经塔台特殊许可外, 在塔台管制区内的飞行, 必须按照仪表飞行规则进行。

1. General

Flights within Tower Control Area shall operate under IFR unless special clearance has been obtained from Tower Control.

2. 起落航线

起落航线在跑道西侧进行, A、B类航空器高度300米, C、D类航空器高度500米。

2. Traffic circuits

Traffic circuits shall be made to the west of RWY, at the altitude of 300m for aircraft CAT A/B, and 500m for aircraft CAT C/D.

3. 仪表飞行程序

- 3.1 严格按照航图中公布的进、离场程序飞行。如果需要,航空器可在空中交通管制部门指定的航路、导航台或定位点上空等待或做机动飞行;
- 3.2 进离场管制规定:

3. IFR flight procedures

- 3.1 Strict adherence is required to the relevant arrival/departure provisions published in the aeronautical charts. Aircraft may, if necessary, hold or maneuver on an airway, over an NDB or over a fix designated by ATC;
- 3.2 Air traffic control regulations:

3.2.1 当空域有限制时, 青岛机场进出港航空器按照以下要求运行:

进、离港航空器不得进入 NDB'FD'-AVBIK-ABVER-LATUX 连线以东空域。如果机组无法满足上述要求,应在申请放行许可时告知管制员;

使用17号跑道时,离港航空器保持一边飞至距青岛VOR/DME 'TAO'台8海里时,高度不得低于900米。如果机组无法满足上述要求,应在申请放行许可时告知管制员;

使用 35 号跑道时,进港航空器在五边飞至距 DME35 'IPP'台6海里或青岛 VOR/DME 'TAO'台8 海里时,高度不得低于820米;

- 3.2.2 具体听从管制指挥。
- 3.3 优先着陆
- 3.3.1 实施优先着陆的航空器, 经管制员允许后, 按ATC指令实施优先着陆。

4. 雷达程序和 / 或 ADS-B 程序

青岛进近管制区域内实施雷达管制。航空器最小水平间隔为6千米。

5. 无线电通信失效程序

- 5.1 航空器通信失效
- 5.1.1 航空器如果具有信号接收能力,根据接收到的管制指令继续飞行。
- 5.1.2 航空器如果不具备信号接收能力, 航空器应按照下列特定的进近程序继续进近并尽快落地; 如果本场不具备落地条件, 飞行员可自行决定返航或备降。
- a. 使用35号跑道

航空器按照最后接收到的管制员指令高度(如果指令高度低于1800米则立即上升至1800米,如果指令高度高于 1800米则保持指令高度)飞向XDX,过台后按仪表程序加入等待程序,下降至900米,按35号跑道仪表进近图着陆;如果过XDX高度为1800米,则可直接按35号跑道仪表进近图着陆。

3.2.1 Aircraft for arrival/departure shall follow the following requirements if the airspace is limited:

Aircraft for arrival/departure may not enter the East airspace of NDB 'FD'-AVBIK-ABVER-LATUX. If aircrew consider that they cannot fulfill the requirements, pilot shall inform ATC before apply for delivery clearance;

RWY17 in use: Departure aircraft shall keep the upwind to 8NM from VOR/DME 'TAO' at 900m or above. If aircrew consider that they cannot fulfill the requirements, pilot shall inform ATC before apply for delivery clearance;

RWY35 in use: Arrival aircraft shall keep the final to 6NM from DME35 'IPP' or 8nm from VOR/DME 'TAO' at 820m or above:

- 3.2.2 The details follow the ATC instructions.
- 3.3 Priority in landing
- 3.3.1 Aircraft shall take prior landing after ATC clearance and follow the ATC instructions.

4. Radar procedures and/or ADS-B procedures

Radar control within Qingdao APP has been implemented. The minimum horizontal radar separation is 6km.

5. Radio communication failure procedures

- 5.1 Aircraft communication failure
- 5.1.1 If able to receive signal, continue flying in accordance with ATC instructions.
- 5.1.2 If unable to receive signal, continue approach and land as soon as possible according to the specific approach procedure listed below. If the airport not suitable for landing, the pilot may return to the original airport or fly to the alternate at their own discretion.

a. RWY35 in use

Fly to XDX in accordance with the last designated altitude(if designated altitude is lower than 1800m, then climb to 1800m immediately; if designated altitude is higher than 1800m, maintain the designated altitude), after passing XDX, join holding procedure, descend to 900m, land in accordance with RWY35 instrument approach chart; if passing XDX at 1800m, land directly in accordance with RWY35 instrument approach chart.

b. 使用17号跑道

航空器按照最后接收到的管制员指令高度(如果指令高度低于1800米则立即上升至1800米,如果指令高度高于 1800 米则保持指令高度)飞向TAO,过台后按仪表程序加入等待程序,下降至550米,然后按17号跑道仪表进近图着陆;如果过TAO高度为1800米,则可直接按17号跑道仪表进近图着陆。

5.2 本场通信失效

本场无线电收发功能失效, 航空器无法与管制单位建立有效的通信联系时, 航空器应联系上一个管制单位, 并按照接收管制单位的管制指令继续飞行。

5.3 无线电通信恢复

失去通信联络的航空器已经着陆,或者已经恢复 联络的,可恢复正常的管制运行,并立即通知相 关管制单位。

6. 目视飞行程序

无

7. 目视飞行航线

无

8. 目视参考点

无

9. 其它规定

无

10. 区域导航飞行程序相关数据

10.1 RNAV程序实施范围

b. RWY17 in use

Fly to TAO in accordance with the last designated altitude(if designated altitude is lower than 1800m, then climb to 1800m immediately; if designated altitude is higher than 1800m, maintain the designated altitude), after passing TAO, join holding procedure, descend to 550m, land in accordance with RWY17 instrument approach chart; if passing TAO at 1800m, land directly in accordance with RWY17 instrument approach chart.

5.2 Local control unit communication failure

If local control unit communication failure, when unable to establish effective contact with the control unit, the aircraft should contact the last control unit, and continue flying in accordance with instructions from the accepting control unit.

5.3 Regaining radio communication

Once the aircraft experiencing communication failure landed, or regained contact, the control unit should resume normal operation and inform the concerned immediately.

6. Procedures for VFR flights

Nil

7. VFR route

Nil

8. Visual reference point

Nil

9. Other regulations

Nil

10. Data for RNAV flight procedures

10.1 Scope of implementation for RNAV procedure

在青岛进近管制范围内,对进出青岛流亭机场的 航班实施RNAV进离场飞行程序,包括离场、进 场以及起始进近阶段,中间进近、最后进近和复 飞阶段仍然采用传统程序。

10.2 RNAV程序的实施要求

要求当离场航班首次联系塔台或进场航班首次 联系进近前应首先检查自己具有的RNAV能力与 FPL中标示的RNAV能力是否相符,如果不符时, 首次联系时应主动向管制员报告,否则管制员认 为该航班实际RNAV能力与FPL报文RNAV能力 相符;

管制员指挥航空器按RNAV程序飞行是指航空器 须按RNAV程序的水平引导飞行,垂直方向的引导(高度)须以管制员发布的高度指令为准。

10.3 区域导航飞行程序相关数据

Within approach controlled airspace, RNAV procedures is implemented to flights inbound and outbound Qingdao airport in departure, arrival and initial approach phases. However, conventional procedures shall be used in intermediate approach, final approach and missed approach.

10.2 Procedure implementation requirements

When departing flight contacting Tower or arriving flight contacting Approach initially, check aircraft RNAV ability whether is compliant with labeled RNAV ability in FPL, if not, inform the controller on initial contact, otherwise controller will believe that the flight practical RNAV ability agree with the RNAV ability in FPL.

Conducting RNAV procedure instructed by controller refers to flying in accordance with the lateral guidance of RNAV procedure, however, vertical guidance shall be based on altitude or level issued by controller.

10.3 Data for RNAV flight procedures

	ID	COORDINATES	ID	COORDINATES
	QD001	N362401 E1201954	QD201	N361030 E1203330
	QD002	N362551 E1201919	AA3	N3616.6 E12028.5
I	QD003	N362653 E1202418	AA10	N3618.4 E12008.4
	QD004	N362332 E1202522	Fix H	N3617.7 E12016.0
	QD005	N362442 E1201352	ABVER	N3542.7 E12033.4
	QD006	N362943 E1201215	LATUX	N3529.0 E12047.0
	QD007	N363051 E1201742	IDVEL	N3522.9 E12034.9
	QD008	N364139 E1202408	URBAD	N3607.0 E12028.8
	QD009	N364120 E1203519	ATLED	N3631.9 E12022.7
	QD100	N360344 E1202621	AVBIK	N3631.2 E12033.6
	QD101	N360123 E1202706	VEPGI	N3622.8 E12029.7
	QD102	N360014 E1202135	GODOP	N3659.0 E12026.7
I	QD103	N355809 E1202807	OLPUG	N3619.0 E12001.0
	QD104	N355701 E1202242	TAO	N3617.3 E12022.2
	QD105	N355137 E1202425	XDX	N3558.7 E12017.4
	QD106	N355610 E1201841	FD	N3655.8 E12037.9
	QD108	N361004 E1201827	YO	N3626.3 E11941.3
	QD109	N361650 E1203332		

	Path Terminator	Waypoint ID	Fly over	Magnetic Course (°)	Turn Direction	Altitude (m)	IAS (km/h)	VPA/ TCH	Navigation Specification
l	RWY17 Departure YO-61X								

I

CA		171		300	MAX350	RNAV1
DF	Н		R	1200		RNAV1
TF	AA10			1800		RNAV1
TF	OLPUG			2400		RNAV1
TF	YO					RNAV1
RWY17	Departure YO-63X(b	y ATC)				
CA		171		300	MAX350	RNAV1
DF	OLPUG		R	2400		RNAV1
TF	YO					RNAV1
RWY17	Departure IDV-61X	'	•			
CA		171		1500		RNAV1
DF	XDX		R	1800		RNAV1
TF	IDVEL					RNAV1
RWY17	Departure IDV-63X(b	by ATC)		·		
CA		171		300	MAX350	RNAV1
DF	XDX		R	1800		RNAV1
TF	IDVEL					RNAV1
RWY17	Departure LAT-61X	·				·
CA		171		1500		RNAV1
CF	ABVER	171		3600 or by ATC		RNAV1
TF	LATUX					RNAV1
RWY17	Departure FD-61X	•	•	<u>.</u>		
CA		171		300	MAX350	RNAV1
DF	Н		R	1200		RNAV1
TF	VEPGI			1800		RNAV1
TF	AVBIK			2100		RNAV1
TF	QD009			2400 or by ATC		RNAV1
TF	FD			3900 or by ATC		RNAV1
RWY17	Departure FD-63X(by	y ATC)				·
CA		171		800	MAX350	RNAV1
CF	AVBIK	015	L	2100		RNAV1
TF	QD009			2400 or by ATC		RNAV1
TF	FD			3900 or by ATC		RNAV1
RWY35	Departure FD-62X					
CA		351		600	MAX380	RNAV1

DF	AVBIK		R	1800		RNAV1
TF	QD009			2400		RNAV1
TF	FD			3900 or by ATC		RNAV1
RWY3:	5 Departure YO-62X			·		·
CA		351		150	MAX380	RNAV1
DF	AA10		L	↑ 1500		RNAV1
TF	OLPUG			2400 or by ATC		RNAV1
TF	YO					RNAV1
RWY3	5 Departure YO-64X			·		·
CA		351		600	MAX380	RNAV1
DF	TAO		R			RNAV1
TF	Н			1200		RNAV1
TF	AA10			1500		RNAV1
TF	OLPUG			2400 or by ATC		RNAV1
TF	YO					RNAV1
RWY3:	5 Departure IDV-62X	•	•			
CA		351		600	MAX380	RNAV1
DF	AA3		R	1000		RNAV1
TF	URBAD			1800		RNAV1
TF	XDX			2100		RNAV1
TF	IDVEL					RNAV1
RWY3	5 Departure IDV-64X(b	y ATC)				
CA		351		600	MAX380	RNAV1
DF	QD109		R	1500		RNAV1
TF	QD201			1800		RNAV1
TF	URBAD			1800		RNAV1
TF	XDX			2100		RNAV1
TF	IDVEL					RNAV1
RWY3:	5 Departure LAT-62X	1		·	·	<u>'</u>
CA		351		600	MAX380	RNAV1
DF	AA3		R	1000		RNAV1
TF	URBAD			1800		RNAV1
TF	ABVER			3600 or by ATC		RNAV1
TF	LATUX					RNAV1
RWY3:	5 Departure LAT-64X(b	y ATC)	<u> </u>	1	1	I
CA		351		600	MAX380	RNAV1

D.E.	05100	1			<u> </u>	Darres
DF	QD109		R	↑ 1500		RNAV1
TF	QD201			1800		RNAV1
TF	URBAD			↑ 1800		RNAV1
TF	ABVER			3600 or by ATC		RNAV1
TF	LATUX					RNAV1
RWY35	Departure LAT-66X(b	y ATC)				
CA		351		600	MAX380	RNAV1
DF	QD109		R	↑ 1500		RNAV1
TF	QD201			1800		RNAV1
TF	ABVER			3600 or by ATC		RNAV1
TF	LATUX					RNAV1
RWY17	Arrival FD-51F	'	1	•		-
IF	FD			3900 or by ATC		RNAV1
TF	QD008			2400 or by ATC	MAX380	RNAV1
TF	ATLED			↑ 1200		RNAV1
TF	QD002			↑ 550		RNAV1
TF	QD001			550		RNAV1
RWY17	Arrival FD-53F(by A7	TC)	Į.			
IF	FD			3900 or by ATC		RNAV1
TF	QD008			2400 or by ATC	MAX380	RNAV1
TF	QD007			↑ 900		RNAV1
TF	QD002			↑ 550		RNAV1
TF	QD001			550		RNAV1
RWY17	Arrival GOD-51F	l		.		1
IF	GODOP			↓ 4500 ↑ 3900		RNAV1
TF	QD008			2400 or by ATC	MAX380	RNAV1
TF	ATLED			↑ 1200		RNAV1
TF	QD002			↑ 550		RNAV1
TF	QD001			550		RNAV1
RWY17	Arrival GOD-53F(by	ATC)			<u> </u>	
IF	GODOP			↓ 4500 ↑ 3900		RNAV1
TF	QD008			2400 or by ATC	MAX380	RNAV1

TF	QD007	1 900	RNAV1
TF	QD002	1 550	RNAV1
TF	QD001	550	RNAV1
RWY17	Arrival IDV-51F		
IF	IDVEL		RNAV1
TF	XDX	2100	RNAV1
TF	TAO	1500 MAX380	RNAV1
TF	QD004	↑ 900	RNAV1
TF	QD003	↑ 550	RNAV1
TF	QD002	↑ 550	RNAV1
TF	QD001	550	RNAV1
RWY17	Arrival IDV-53F(by ATC)		
IF	IDVEL		RNAV1
TF	XDX	2100	RNAV1
TF	TAO	1500 MAX380	RNAV1
TF	QD004		RNAV1
TF	ATLED	↑ 1200	RNAV1
TF	QD007	↑ 900	RNAV1
TF	QD002	↑ 550	RNAV1
TF	QD001	550	RNAV1
RWY17	Arrival IDV-55F(by ATC)		1
IF	IDVEL		RNAV1
TF	XDX	2100	RNAV1
TF	Н	1500 MAX380	RNAV1
TF	QD005	↑ 900	RNAV1
TF	QD002	† 550	RNAV1
TF	QD001	550	RNAV1
RWY17	Arrival IDV-57F(by ATC)		
IF	IDVEL		RNAV1
TF	XDX	2100	RNAV1
TF	Н	1500 MAX380	RNAV1
TF	QD006	1 900	RNAV1
TF	QD007	1 900	RNAV1
TF	QD002	† 550	RNAV1
TF	QD001	550	RNAV1
RWY17	Arrival LAT-51F		
IF	LATUX		RNAV1
TF	ABVER		RNAV1

TF	XDX				2100		RNAV1
TF	TAO				1500	MAX380	RNAV1
TF	QD004				1 900		RNAV1
TF	QD003				↑ 550		RNAV1
TF	QD002				1 550		RNAV1
TF	QD001				550		RNAV1
RWY17	Arrival LAT-53	F(by ATC)			·		
IF	LATUX						RNAV1
TF	ABVER						RNAV1
TF	XDX				2100		RNAV1
TF	TAO				1500	MAX380	RNAV1
TF	QD004						RNAV1
TF	ATLED				1 1200		RNAV1
TF	QD007				1 900		RNAV1
TF	QD002				1 550		RNAV1
TF	QD001				550		RNAV1
RWY17	Arrival LAT-55	F(by ATC)	-	.			
IF	LATUX						RNAV1
TF	ABVER						RNAV1
TF	XDX				2100		RNAV1
TF	Н				1500	MAX380	RNAV1
TF	QD005				↑ 900		RNAV1
TF	QD002				1 550		RNAV1
TF	QD001				550		RNAV1
RWY17	Arrival LAT-57	F(by ATC)	•	•			
IF	LATUX						RNAV1
TF	ABVER						RNAV1
TF	XDX				2100		RNAV1
TF	Н				1500	MAX380	RNAV1
TF	QD006				1 900		RNAV1
TF	QD007				1 900		RNAV1
TF	QD002				1 550		RNAV1
TF	QD001				550		RNAV1
RWY17	Holding (outbo	und time: 1	minute)			<u>. </u>	
НМ	QD008	Y	193	L	2400 or by ATC	MAX400	RNAV1
RWY35	Arrival IDV-52	F	•		•		
IF	IDVEL						RNAV1

TF	QD106		RNAV1
TF	QD104	1800 or by ATC	RNAV1
TF	QD103	† 1200 or by ATC MAX380	RNAV1
TF	QD101	1 900	RNAV1
TF	QD100	900	RNAV1
RWY35	Arrival IDV-54F		<u>'</u>
IF	IDVEL		RNAV1
TF	QD106		RNAV1
TF	XDX	1800 or by ATC MAX380	RNAV1
TF	QD102	↑ 1500	RNAV1
TF	QD101	1 900	RNAV1
TF	QD100	900	RNAV1
RWY35	Arrival LAT-52F		<u> </u>
IF	LATUX		RNAV1
TF	ABVER		RNAV1
TF	QD105		RNAV1
TF	QD104	1800 or by ATC	RNAV1
TF	QD103	† 1200 or by ATC MAX380	RNAV1
TF	QD101	↑ 900	RNAV1
TF	QD100	900	RNAV1
RWY35	Arrival LAT-54F(by ATC)		·
IF	LATUX		RNAV1
TF	ABVER		RNAV1
TF	QD103	† 1200 or by ATC MAX380	RNAV1
TF	QD101	1 900	RNAV1
TF	QD100	900	RNAV1
RWY35	Arrival FD-52F		
IF	FD	3900 or by ATC	RNAV1
TF	QD008	2400 or by ATC	RNAV1
TF	ATLED	1800	RNAV1
TF	QD108	† 1500 MAX380	RNAV1
TF	QD102	↑ 1500	RNAV1
TF	QD101	↑ 900	RNAV1

TF	QD100				900		RNAV1
RWY35	Arrival FD-54F	(by ATC)	•	•	•	•	
IF	FD				3900 or by ATC		RNAV1
TF	QD008				2400 or by ATC		RNAV1
TF	ATLED				1800		RNAV1
TF	Н				1800		RNAV1
TF	QD108				↑ 1500	MAX380	RNAV1
TF	QD102				↑ 1500		RNAV1
TF	QD101				↑ 900		RNAV1
TF	QD100				900		RNAV1
RWY35	Arrival GOD-52	2F		I	-	<u> </u>	1
IF	GODOP				↓ 4500 ↑ 3900		RNAV1
TF	QD008				2400 or by ATC		RNAV1
TF	ATLED				1800		RNAV1
TF	QD108				↑ 1500	MAX380	RNAV1
TF	QD102				↑ 1500		RNAV1
TF	QD101				↑ 900		RNAV1
TF	QD100				900		RNAV1
RWY35	Arrival GOD-54	4F(by AT	C)	1			
IF	GODOP				↓ 4500 ↑ 3900		RNAV1
TF	QD008				2400 or by ATC		RNAV1
TF	ATLED				1800		RNAV1
TF	Н				1800		RNAV1
TF	QD108				1500	MAX380	RNAV1
TF	QD102				1500		RNAV1
TF	QD101				↑ 900		RNAV1
TF	QD100				900		RNAV1
RWY35	Holding (outbo	und time:	1 minute)	<u> </u>	I	I I	l
НМ	QD104	Y	081	R	1800 or by ATC	MAX400	RNAV1
НМ	QD008	Y	193	L	2400 or by ATC	MAX400	RNAV1

ZSQD AD 2.23 其它资料

ZSQD AD 2.23 Other information

行区内采取了驱赶措施, 以减少鸟群活动。

1. 每年4-10月份为鸟情多发时段,机场当局在飞 1. Activities of bird flocks are found from april to october. Aerodrome Authority resorts to dispersal methods to reduce bird activities.