Supermodel Edition

Model:Cycles | Supermodel 2.38 - Features and shortcut guide

Main 2.38. Hold the first button while pressing the next button or turning the named knob. TRIG means a step key; pad means a track key; DATA means LEVEL/DATA. All listed features are included.

Machines and sound Six stock engines plus Sample Wizard, SD Vintage, Clap Vintage, SY Toy, SY Bits, Swarm LITE, MACRO, ACID, WAVE, Feral by Glycinate, Elder, TINY, Shadow, SPEAK, LEGACY, RETROSYN and MIDI Out. Elder is an original synth inspired by Junior by Fors. Machine browsing retains synth values; Wizard's four dials stay separate while MACHINES stays open.	**Performance and sequencing** Arpeggiator, held-note octave 0, ChordKeys and harmony locks, Sequence Genie, SCRAMBLE, slides, trig preview, Step Recorder, latching mute and solo.
Filters and effects Polivoks-style track/Wizard filters, second LFO, MACRO Fine/Lo-Fi; GATED, HALL, Ring Mod, ROOM, PS1, Vinyl, Reverb and Chorus 1/2; Phaser, DUCK, DUB, Ping Pong, Delay and Crush 1/2. Opaque FX menus apply on TRACK release. Cumulative PS1/filter optimizations. Both Shimmers and all combined modes are removed.	**Routing and workflow** MIDI Out with nine CC knobs, locks and two MIDI LFOs; MIDI OUT/THRU toggle; USB stereo or six tracks; permanent quick save, saved Mod Setup and optional DX diagnostics.

New in 2.38 - Pattern FX and louder WAVE

Feature	Controls	Behavior
Pattern FX	TRACK + REVERB SIZE / DELAY TIME	Each pattern remembers its selected FX types and all added FX controls, including extra sends. Save the project to keep these settings after reloading. Native send and reverb/delay parameters keep their normal pattern behavior.
Blank and queued patterns	Select or queue a pattern	A blank pattern starts with standard Delay, standard Reverb and default added FX settings. Edits stay with that pattern. A queued pattern changes the FX only when it begins playing.
Louder WAVE	Select WAVE and play	Output is boosted by 6 dB for the starter and imported tables. Track LEVEL/DIST still controls the listening level.

New in 2.37 - WAVE ready to play

Feature	Controls	Behavior
WAVE starter	Select WAVE and play	AV-WAVE-Morph is already loaded: 16 morphable frames, no first import required. COLOR selects position; SHAPE adds envelope movement. Custom tables replace the starter on their track.
WAVE folder navigation	BACK in the WAVE browser	Go up one folder. At /Wavetables, BACK closes the selector. Holding or releasing BACK after moving up leaves it open. Imported tables still load with the existing YES/pad controls.

New in 2.36 - Acid, SY BITS and Elder

Feature	Controls	Behavior
ACID filter Decay	DECAY	Filter envelope decay only. Volume holds until note-off, then a short fixed release; the Gate switch no longer turns Decay into an amplitude envelope. Slides and existing controls remain.
ACID Accent	Velocity 97-127	Progressive filter transient and level accent. Velocity 0-96 keeps the normal unaccented response; native velocity volume response is retained.
SY BITS fine detune	FUNC + COLOR	0.01-semitone steps across -24.00 to +24.00. Small signed decimal popup updates live. Plain COLOR changes whole semitones and preserves the fractional part. Fine values survive native sound save/load and remain available to parameter locks.
Louder Elder	VOL + DIST	Output raised 6 dB (2x), with bounded peaks. Wave, Warp, Noise, Motion, envelopes and Punch keep their existing behavior.

New in 2.35 - banks and RETROSYN

Feature	Controls	Behavior
Import a DX7 bank	Flasher > WAV / DX7 bank importers	Stop playback. Choose a Yamaha 32-voice .syx bank, connect Model:Cycles USB MIDI, choose slot 1-16 and send. Wait for LEGACY BANK SAVED. Reusing a slot replaces it. Importing does not change the active sound.
Load a stored bank	LEGACY: FUNC + MACHINES; DATA; BACK	Hold FUNC while pressing MACHINES to open the bank library. Turn DATA to choose; press DATA to load; BACK cancels. Factory restores the included voices. One active 32-voice bank is shared by every LEGACY track. Banks persist after reboot and are separate from Elektron project backups.
Quiet LEGACY voices	Automatic, fixed per note	Quiet carrier levels receive bounded output gain compensation. Velocity and envelope response are preserved; this cannot make a silent or disabled operator sound. Lower CPU cost is retained.
RETROSYN	MACHINES, immediately before MIDI Out	Color, Shape (six models), Sweep and Contour. Pitch, Decay, Gate and Punch remain available. Existing engine IDs are preserved; Elder remains in the list. MIDI Out stays last.
HALL and SPEAK updates	HALL: SIZE; SPEAK: SHAPE	HALL wet return raised about 6 dB; maximum SIZE gives a longer damped tail. SPEAK is slightly brighter, with CAREFUL (123) followed by CREATURE (124). Regular vocabulary only.
FX menu overlay	Hold TRACK + turn REVERB SIZE / DELAY TIME	The full opaque menu appears above Machine Selection and other windows. Turn to preview choices without changing the sound; release TRACK to apply. The previous window stays behind it. Control All track selection releases when TRACK is released.

Track, step and performance controls

Feature	Controls	Behavior
Step Recorder	Playback stopped: press REC twice; PLAY advances; STOP goes back; press REC again to exit	Enter step recording and play notes to write successive steps. PLAY advances one step; STOP moves back one step; press REC again to leave Step Recorder.
Latching mute	TRACK + tap FUNC	First choose Mute: LTC in Mod Setup. Then latch mute mode with this gesture; tap FUNC again to leave. Mute: Stk keeps stock behavior (default).
Solo in mute mode	In latching mute mode, hold FUNC + press T1-T6	Solo that track. Press the soloed track again to restore the previous mute state; tracks already muted remain muted.
Silent track selection	Choose Silent in Mod Setup ; tap T1-T6	Select a track without triggering its sound. TRACK + pad selects and plays. Stock pad behavior (Stk) is the default; select Silent to enable silent selection.
Trig preview	Hold TRIG + PAGE	Audition the selected step with its note and locks while stopped or paused.
Slide trig	SETTINGS + TRIG	Toggle a parameter slide on the step.
Sequence Genie	SETTINGS + PAGE	Open the generator for the selected track. Select with DATA; choose Generate or Queue and set Loop/Page timing.
SCRAMBLE	Quick tap SETTINGS + TRACK	On release, randomize the checked Pitch, Decay, Color, Shape, Sweep and Contour parameters for this track. Choose them in Mod Setup > SCRM. Decay now works; Punch stays unchanged. The original four default On. Marked steps use the same checklist without changing the base sound.
SCRAMBLE step / delete	Hold a step + quick SETTINGS + TRACK; delete normally	Toggle SCRAMBLE on that step. Deleting its trig clears the mark and locks; a replacement trig starts clean. Neighboring steps and tracks keep their settings.
Control All setup	TRACK + TRIG 1-6	Include or exclude audio tracks from Control All changes.
Audio beat repeat	Hold TRACK + RETRIG , then hold a TRIG 1-16	The held step selects a repeat division for included audio tracks. Release a modifier or division pad to stop.
Repeat mode latch	Hold TRACK + double-tap RETRIG	Release both; hold a TRIG to repeat, release it to stop. BACK exits. Copy/paste/clear blocked; plain PLAY/STOP available. Temporary, not saved. Stock FUNC + SETTINGS/PATTERN temp save/reload stay available; diagnostics never appear from latching.
Control All filter	Hold TRACK + MACHINES ; turn SWEEP / CONTOUR	Adjust cutoff/resonance across included audio tracks. Without TRACK, adjust the selected track.
Synth Attack	MACHINES + DECAY	Adjust the added attack control on supported machines.
Arpeggiator / ChordKeys settings	FUNC + RETRIG	Open the settings for the active Arpeggiator or ChordKeys feature. Arpeggiator octave 0 cycles only through held notes.
ChordKeys	Select the Chord machine, then play TRIG 1-16	Play scale-based chord voicings from the step keys. To leave a ChordKeys track you must use TRACK + Track Pad.
ChordKeys harmony locks	Grid record: hold a step TRIG and press T1-T6 . Live record: play a chord and use the harmony pads.	Record the chosen harmony on the step. Press the same harmony pad again on a held grid step to restore its base harmony. Harmony locks save with the pattern independently of LFO 2.

Effects

Supermodel 2.38 - Feature and shortcut reference

Feature	Controls	Behavior
Reverb-slot menu	Hold TRACK + REVERB SIZE	Top to bottom: GATED, HALL, ROOM, PS1, REVERB, VINYL, CHORUS 1, CHORUS 2, RING MOD. Turn left to move up, right to move down. Browse without changing sound; release TRACK to apply, BACK to cancel.
Delay-slot menu	Hold TRACK + DELAY TIME	Top to bottom: PHASER, DUCK, DUB, PING PONG, DELAY, CRUSH 1, CRUSH 2. From DELAY, left/up selects Ping Pong; right/down selects Crush 1 then Crush 2. Release TRACK to apply; BACK cancels.
Standard Reverb	REVERB SEND / SIZE / FUNC + SIZE	Per-track Send / native Size, including INF at maximum / Tone -64 through 0 to +63. Stock formatting returns immediately after leaving Chorus, even during playback.
GATED reverb	REVERB SEND / SIZE; FUNC + SIZE; SETTINGS + SIZE	Gated Send / Gate Time; Pre-delay; Tone. Gate Time 0-127: about 40 ms-6.7 s after input falls quiet. Pre-delay 0-568 ms, 1 ms steps through 64 then 8 ms. No added echoes; dry hit stays immediate and the gate follows the delayed sound. Try Gate Time 16-32, Pre-delay 25-40 ms on a snare. Gate Time and Pre-delay belong to each pattern; save the project to preserve them after reloading.
HALL reverb	REVERB SEND / SIZE / FUNC + SIZE or SETTINGS + SIZE	Hall Send per track / Decay / Tone. Wide stereo tail with longer reflections than ROOM. Four damped paths and two diffusers per channel at 12 kHz reuse existing reverb memory.
Ring Mod	REVERB SEND / SIZE / FUNC + SIZE or SETTINGS + SIZE	Ring Send per track / Frequency / Depth. Metallic sine ring modulation replaces the reverb return. Select RING MOD below Chorus 1/2. Frequency and Depth shared by tracks in this pattern; use the native track Send for locks.
Phaser	DELAY SEND / TIME / FUNC + TIME; FUNC first, then TRACK + TIME	Phaser Send per track / Rate / Depth; FUNC then TRACK + TIME is Feedback (also SETTINGS + TIME). Two-stage stereo phaser replaces the delay return. Select PHASER above DUCK. Hold FUNC before TRACK to avoid the mute latch.
DUCK delay	DELAY SEND / TIME / FUNC + TIME or SETTINGS + TIME; FUNC then TRACK + TIME or DELAY SEND	Native Delay Send / Time / Feedback. Hold FUNC first, then TRACK: TIME adjusts Amount; DELAY SEND adjusts Release. Strong wet ducking while the send input plays, then a swelling return; feedback remains intact. Try Amount 127, Release 32-64 on sparse notes. Amount 0 is standard Delay.
ROOM reverb	REVERB SEND / SIZE / FUNC + SIZE or SETTINGS + SIZE	Room Send per track / Decay / Tone. Compact stereo room tail at 12 kHz. Select ROOM above PS1; release TRACK to apply. Wet return raised by 6 dB at normal levels, with a gentle peak knee; dry level is unchanged.
PS1 reverb	REVERB SEND / SIZE / FUNC + SIZE or SETTINGS + SIZE	PS1 Send per track / Decay / Tone. PlayStation-inspired stereo tail, darker and grainier; cumulative processing optimizations retained. Wet return raised by 6 dB at normal levels, with a gentle peak knee; dry level is unchanged.
Chorus 1 / 2	REVERB SEND / SIZE / FUNC + SIZE	Chorus Send per track / Speed / Depth. Speed and Depth 0-127. Replaces reverb in this slot.
Vinyl	REVERB SEND; SIZE / FUNC + SIZE / FUNC first, then TRACK + SIZE	Vinyl Send; Crackle / Warble Amount / Warble Speed. Hold FUNC first, then TRACK for Speed. Send 0 is dry; Crackle 0 switches dust off. Bright independent pops/clicks continue through gaps. Track level, pan and mute apply.
Standard Delay	DELAY SEND / TIME / FUNC + TIME	Per-track Delay Send / native Time / native Feedback.
DUB delay	DELAY SEND / TIME / FUNC + TIME or SETTINGS + TIME	Per-track Delay Send / native Time / Feedback. Strongly filtered echoes alternate left and right, progressively narrowing in the feedback loop. Reuses the native delay and stereo bounce routing. Headphones or both outputs reveal the movement.
Ping Pong	DELAY SEND / TIME / FUNC + TIME or SETTINGS + TIME	Per-track send / Time / Feedback. Stereo echoes alternate left and right; listen through headphones or both outputs.
Crusher Rate / Bits	CRUSH 1 or 2: TIME / FUNC + TIME	Rate 0-127, about 750 Hz-48 kHz / Bits 2-16. Lower Rate or Bits is rougher. CRUSH 1 keeps the direct signal clean; CRUSH 2 blends direct clean/crushed. DELAY SEND is labeled Crush Send; no delay echoes in Crush modes.
Effect settings and save	Save Project	FX types and added controls belong to each pattern; save the project to preserve them after reloading. Blank patterns use standard Delay/Reverb and default added controls. Added FX controls have no p-lock/LFO destinations; native track sends retain their locks. Both Shimmers and all combined modes are removed.

Machines and sound controls

Supermodel 2.38 - Feature and shortcut reference

Feature	Controls	Behavior
Machine browsing	MACHINES + turn DATA	Fast turns move at most one machine per accepted event, spaced by 40 ms, to avoid skipping Sample Wizard. Saved machine IDs and TINY/Shadow/SPEAK/MIDI order stay unchanged.
Elder controls	Select Elder in MACHINES	COLOR = Wave; SHAPE = Warp; SWEEP = Noise; CONTOUR = Motion. PITCH, DECAY, PUNCH, Gate and Fine remain available. Original synth inspired by Junior by Fors.
Saved Retrosyn sounds	Elder replaces ChpHzrd / Retrosyn	The same machine slot now plays Elder, so previous Retrosyn sounds change timbre. The other engines and previous CPU fixes are retained. Feral is by Glycinate.
TINY controls	Select TINY in MACHINES	COLOR: Tone; SHAPE: Model0-51; SWEEP: Mod; CONTOUR: Excite. All52 original models; Feral and every other engine remain.
Shadow controls	Select Shadow after TINY in MACHINES	COLOR: Grain; SHAPE: Density; SWEEP: Spread; CONTOUR: Chaos. PUNCH: ratcheting attack. Pitch, Fine, Decay and Gate remain. Original pulsar/noise engine inspired by Opal Dust by Fors.

LEGACY machine

Feature	Controls	Behavior
LEGACY / selection	MACHINES: before RETROSYN and MIDI Out	Dexed MSFA six-operator FM with all 32 algorithms; one voice per track. MIDI Out remains last. COLOR = Velocity, SHAPE = Voice, SWEEP = Brightness, CONTOUR = EG Time. Native locks/CC/LFO mappings; Voice and Velocity are captured on the next trigger.
Voice library	SHAPE: slots 0-31	Starts with Tooropulse, Delicho and EinstofPia. Eight quieter slots now contain PIANO 1, E.PIANO 1, BASS 1, BRASS 1, STRINGS 1, CLAV 1, E.ORGAN 1 and MARIMBA from the supplied ROM1A cartridge.
Velocity / brightness	COLOR / SWEEP	Velocity 0-127 controls the cartridge operators response at each trigger; default 100. Brightness 64 preserves the patch. Lower softens modulation; higher adds bite.
Envelope time	CONTOUR / DECAY	EG Time 64 preserves the patch envelope timing; lower is faster, higher slower. DECAY and gate still set the native amplitude envelope. PITCH and FINETUNE transpose the voice; fixed-frequency operators follow their cartridge settings.
Import a DX7 bank	Flasher > WAV / DX7 bank importers	Stop playback. Choose a Yamaha 32-voice .syx bank, connect Model:Cycles USB MIDI, choose slot 1-16 and send. Wait for LEGACY BANK SAVED. Reusing a slot replaces it. Importing does not change the active sound.
Credits and load	Dexed / Google MSFA	Based on Dexed s Apache-licensed MSFA component by Google, Pascal Gauthier and contributors; original Cycles integration. Added cartridge voices supplied by the user. Six-operator patches can be more demanding than other machines.

LEGACY voice library

Supermodel 2.38 - Feature and shortcut reference

Slot	Voice	Source
0	Tooropulse	Legowelt Magic cart
1	Delicho	Legowelt Magic cart
2	EinstofPia	Legowelt Magic cart
3	Overcast P	Legowelt Magic cart
4	STRINGS 1	ROM1A
5	PWMfuzzy	Legowelt Magic cart
6	Sharpieblo	Legowelt Magic cart
7	RoboticSeq	Legowelt Magic cart
8	SplitStran	Legowelt Magic cart
9	PIANO 1	ROM1A
10	Heimwave	Legowelt Magic cart
11	CLAV 1	ROM1A
12	Synthotape	Legowelt Magic cart
13	Wavesply	Legowelt Magic cart
14	Poldermood	Legowelt Magic cart
15	FelineSaw	Legowelt Magic cart
16	Aguirio	Legowelt Magic cart
17	E.PIANO 1	ROM1A
18	E.ORGAN 1	ROM1A
19	Pinkcookie	Legowelt Magic cart
20	ObieSplash	Legowelt Magic cart
21	MARIMBA	ROM1A
22	Garudaydre	Legowelt Magic cart
23	VillageOrg	Legowelt Magic cart
24	BASS 1	ROM1A
25	Litehouze	Legowelt Magic cart
26	NostroSpli	Legowelt Magic cart
27	Velobleepb	Legowelt Magic cart
28	DimPacific	Legowelt Magic cart
29	SequenceMe	Legowelt Magic cart
30	BRASS 1	ROM1A
31	Swissynth	Legowelt Magic cart

SPEAK voice machine

Supermodel 2.38 - Feature and shortcut reference

Feature	Controls	Behavior
Select SPEAK	MACHINES: after Shadow, before LEGACY	Original 128-word formant speech engine. Microphone; CLASS VOICE / STYLE TALK / STR 1, DEX 5, MAG 5. v90 balances phoneme levels, smooths transitions and brightens voiced harmonics while keeping hiss reduced. Start around Vol+Dist 60, Punch off.
Voice / Word / Speed / Articulation	COLOR / SHAPE / SWEEP / CONTOUR	Voice/formant character / Word 0-127 / Speed (64 normal, lower slower) / Articulation. SHAPE popup shows the word and index. Word changes latch at the next trig; the other three controls remain live. Slow words now continue through quiet phoneme gaps; the idle detector no longer suspends unfinished speech.
Pitch and envelope	PITCH / notes; DECAY, Fine, Punch, Gate, Attack	Pitch changes independently of word speed. Begin with Decay 127 to hear complete words. Existing filters and FX sends apply. Each track has its own speech state.
Word sequences and modulation	Hold a trig + SHAPE, then lock Pitch and other knobs normally	Word and other native parameters support p-locks and LFO destinations. COLOR/SHAPE/SWEEP/CONTOUR use MIDI CC 16/17/18/19. Leave space for the word or increase Speed.
Example sentence	SHAPE words and note locks on successive trigs	HELLO 31, I 0, AM 62, A 17, ROBOT 113, I 0, LOVE 35, MUSIC 106. Full indexed word library follows at the end of this guide.
SPEAK tuning	PITCH / FINETUNE	Reference tuning corrected by about 1.17 semitones downward. The existing vocal octave register, formants and word timings remain.

LFO and MACRO controls

Feature	Controls	Behavior
Second audio LFO	Press LFO twice	Open LFO 2 and edit its speed, shape, destination and depth.
LFO quick assignment	On an LFO page, hold LFO and turn a destination knob	Assign the corresponding ordinary knob destination. To select the added Attack, Filter or Resonance targets, also hold MACHINES .
Attack / Filter / Resonance LFO targets	On an LFO page, hold LFO + MACHINES while turning DECAY , SWEEP or CONTOUR	Select Attack, Filter or Resonance as supported by the machine. Release MACHINES for ordinary knob control. Sample Wizard labels its native filter controls Filter and Resonance.
MACRO fine tune	SETTINGS + turn PITCH	Adjust fine pitch. Plain PITCH retains its regular control; FUNC + PITCH is MACRO Lo-Fi. Lo-Fi lowers sample rate to the left, bit depth to the right, with OFF at center. Model names and numbers 0-46 are shown.

Sample Wizard and saving

Feature	Controls	Behavior
Sample Preview	FUNC + MACHINES ; highlight a sample, then press its track pad or keyboard trig	Audition the highlighted sample. Scrolling through the list remains silent.
Sample lock	Open the sample selection menu and highlight a sample; then hold a step TRIG + MACHINES	Lock the highlighted sample to that step on a Sample Wizard track. The sample browser must be open with the desired sample selected.
Playback modes	SETTINGS + MACHINES	All seven modes: One-Shot, Loop, Slice, Granular, Stretch, Pluck and Wavetable. SETTINGS + PUNCH opens options for the current mode. Wizard dial values stay separate from synth values during the current MACHINES session; leaving and returning restores them.
Slice editor	FUNC + step key; FUNC + click DATA	Play upper slices; remove a slice marker with the DATA click. Marker knobs can snap to zero crossings.
Permanent quick save	Hold FUNC + SETTINGS	Save the project permanently using the stock quick-save action.
Temporary save / reload	Short FUNC + SETTINGS / FUNC + PATTERN	Stock temporary copy save / reload, including while retrig mode is latched.

MIDI Out machine

Supermodel 2.38 - Feature and shortcut reference

Feature	Controls	Behavior
Select and set up	MACHINES : MIDI Out; FUNC + TRACK	Silent MIDI track. Track Setup: Channel, Output, KbT (keyboard transpose), Pad Note. Turn DATA to select; click DATA before editing; BACK exits. Channel: 1-16 / Global. Output: Global / Off / USB / DIN / Both.
CC assignment and locks **MIDI Out machine only**	SETTINGS + gray knob; hold steps + assigned knob for locks	Assign OFF or CC0-127 to nine knobs. Turn a knob alone to send its value. Each lock keeps the CC number and value. Live recording captures knob changes. Chance and Swing retain their stock controls.
Two MIDI LFOs	LFO : LFO 1, LFO 2, track screen; BACK exits	DATA selects; click to edit. Order: Wav, Mul, Dst, Dep, Speed, Fade, Phase, Mode. LFO Speed adjusts the open LFO. Hold LFO + an assigned CC knob: assign destination, then turn further for depth.
Notes and save	Normal note/grid controls; FUNC + PAGE ; FUNC + SETTINGS	Incoming MIDI notes use the track receive channel or auto channel; live and step recording keep notes, velocity and length. FUNC + PAGE edits pattern length. Project/quick save keeps MIDI settings and locks.
MIDI OUT + THRU	CONFIG > MIDI > PORTS > OUT/THRU: THR; then FUNC + click DATA	Toggle the Cycles' own outgoing MIDI while retaining incoming MIDI Thru.

Mod Setup

Hold SETTINGS + TRACK until Mod Setup opens, then release both buttons. A short tap runs SCRAMBLE on release. DATA selects a row; click to edit, turn, click again to return. Stk = Stock; SIL = Silent; LTC = Latch.

Feature	Controls	Behavior
Pad	Stk / SIL Default: Stk	Stk keeps the original track-pad behavior: a pad selects and plays its track. Silent selects the track without sounding it; hold TRACK and press a track pad to select and play. ChordKeys tracks still require TRACK + track pad to leave the track.
USB	2ch / 6ch Default: 2ch	2ch sends the stereo mix to the computer. 6ch sends six separate mono tracks, before pan and without the mix delay/crusher/reverb/chorus returns. Stereo audio from the computer to Cycles works in both modes. Stop playback before changing this toggle. Changing modes reconnects the USB audio device; select its new channel layout in your DAW if needed.
Num	Off / On Default: Off	Off keeps the original volume and pan display. On shows numeric volume and pan values when you adjust those controls.
Mute	Stk / LTC Default: Stk	Stk keeps the original momentary mute controls. With LTC selected, hold TRACK and tap FUNC to stay in mute mode, then tap track pads to mute or unmute. Tap FUNC again to leave. In latched mute mode, hold FUNC and press a track pad to solo it; press the soloed pad again, or leave mute mode, to restore the previous mutes.
Delay	Stk / Div Default: Stk	Stk preserves the original Delay Time display and timing. Div displays musical divisions, including dotted and triplet values, and corrects the matching timing positions to exact divisions of the tempo. Other Delay Time positions retain their original timing; this does not quantize every knob position. Applies while using Delay mode.
DX	Off / On Default: Off	With DX On: tap FUNC, press FUNC again within 350 ms, hold at least 0.5 seconds, then release. Other controls cancel the gesture. Shows/resets A/P/O/N: average/peak CPU load, overruns, governor voice drops. Replaces the old shortcut; retrig latching never triggers it. Off by default.
SCRM	DATA opens; turn and press DATA; BACK returns	Six checkboxes per track: Pitch, Decay, Color, Shape, Sweep, Contour. Pitch/Decay default Off; the original four default On. Choices persist across projects and power cycles; saving waits until playback stops. Wizard allows Pitch/Decay; its sample/mode controls stay excluded.

These are global preferences. BACK closes Mod Setup and saves its global preferences; each track's Scramble checklist saves when you return from its submenu. If playback is running, the save waits until it stops. Stop playback and allow saving to finish before powering off. Saved choices return after reboot. FX types and added settings are separate: each pattern remembers them, and Save Project preserves them after reloading.

SPEAK word library

Supermodel 2.38 - Feature and shortcut reference

Index	Word	Index	Word	Index	Word	Index	Word
0	I	32	GOODBYE	64	IS	96	ONE
1	YOU	33	GOOD	65	WAS	97	TWO
2	WE	34	BAD	66	WERE	98	THREE
3	THEY	35	LOVE	67	WILL	99	FOUR
4	HE	36	LIKE	68	CAN	100	FIVE
5	SHE	37	WANT	69	COULD	101	SIX
6	IT	38	NEED	70	HAVE	102	SEVEN
7	ME	39	KNOW	71	HAS	103	EIGHT
8	US	40	THINK	72	HAD	104	NINE
9	THEM	41	FEEL	73	BEEN	105	ZERO
10	MY	42	SEE	74	IN	106	MUSIC
11	YOUR	43	HEAR	75	ON	107	SOUND
12	OUR	44	SAY	76	AT	108	BEAT
13	THIS	45	SPEAK	77	TO	109	RHYTHM
14	THAT	46	TELL	78	FOR	110	BASS
15	THESE	47	ASK	79	FROM	111	DRUM
16	THOSE	48	DO	80	WITH	112	MACHINE
17	A	49	MAKE	81	WITHOUT	113	ROBOT
18	AN	50	PLAY	82	OF	114	HUMAN
19	THE	51	STOP	83	UP	115	TIME
20	AND	52	START	84	DOWN	116	NIGHT
21	OR	53	GO	85	HERE	117	DAY
22	BUT	54	COME	86	THERE	118	WORLD
23	IF	55	STAY	87	NOW	119	FRIEND
24	SO	56	MOVE	88	THEN	120	HAPPY
25	BECAUSE	57	TURN	89	AGAIN	121	SAD
26	YES	58	TAKE	90	ALWAYS	122	NEW
27	NO	59	GIVE	91	NEVER	123	CAREFUL
28	NOT	60	GET	92	ALL	124	CREATURE
29	PLEASE	61	BE	93	SOME	125	LOUD
30	THANK	62	AM	94	MORE	126	DREAM
31	HELLO	63	ARE	95	LESS	127	FUTURE

Startup defaults: stock pads and mute behavior; USB 2ch; Num Off; DX Off. Blank patterns use standard Reverb and Delay with default added FX settings. Six-channel USB excludes the stereo effect returns.